






Drive Based – SB6 Manual

en-US
10/2025
ID 443498.00



STÖBER

Table of contents

Table of contents	2
1 Foreword	5
2 User information	6
2.1 Storage and transfer	6
2.2 Described product	6
2.3 Directives and standards	6
2.4 Timeliness	6
2.5 Original language	6
2.6 Limitation of liability	6
2.7 Formatting conventions	7
2.7.1 Display of warning messages and information	7
2.7.2 Markup of text elements	8
2.7.3 Mathematics and formulas	8
2.8 Trademarks	9
3 Safety notes	10
4 What you should know before commissioning	11
4.1 DS6 program interface	11
4.1.1 Configuring the view	13
4.1.2 Navigation using sensitive circuit diagrams	14
4.2 Meaning of parameters	15
4.2.1 Parameter groups	15
4.2.2 Parameter types and data types	16
4.2.3 Parameter types	17
4.2.4 Parameter structure	17
4.2.5 Parameter visibility	18
4.3 Signal sources	19
4.4 Non-volatile memory	19
5 Commissioning	20
5.1 Initiating the project	21
5.1.1 Projecting the drive controller and axis	21
5.1.2 Configuring safety technology	22
5.1.3 Creating other drive controllers and modules	22
5.1.4 Projecting the module	23
5.1.5 Projecting the project	23
5.2 Mapping the mechanical axis model	24
5.2.1 Parameterizing the motor	24
5.2.2 Parameterizing the axis model	25

5.3	Referencing absolute position.....	30
5.3.1	Defining the referencing method	30
5.3.2	Parameterizing the reference switch.....	30
5.3.3	Setting the reference.....	30
5.4	Parameterizing Drive Based device control	31
5.4.1	Parameterizing transition conditions	31
5.5	Transmitting and saving the configuration.....	32
5.6	Testing the configuration	33
5.6.1	Testing jog mode	34
5.6.2	Testing the motion commands	35
5.7	Parameterizing the Drive Based application	36
5.7.1	General motion variables and signal sources	36
5.7.2	Parameterizing velocity, torque/force operating mode	44
5.7.3	Parameterizing motion block operating mode	52
5.7.4	Parameterizing command operating mode.....	69
6	More on Drive Based?	74
6.1	Drive Based – Concept.....	74
6.1.1	Operating modes	75
6.1.2	Jog mode.....	76
6.1.3	Control panels.....	77
6.1.4	Motion core	77
6.1.5	Data sources	77
6.1.6	Additional functions	80
6.2	Axis model	95
6.3	Limit switches	98
6.3.1	Hardware limit switches	99
6.3.2	Software limit switches.....	101
6.4	Referencing.....	102
6.4.1	Referencing methods.....	102
6.4.2	Reference position.....	124
6.4.3	Reference retaining	125
6.4.4	Reference loss.....	125
6.5	Drive Based device control	129
6.5.1	Drive Based device state machine	129
6.5.2	States, transitions and conditions	130
6.6	Motion commands	136
6.7	Continue function.....	137
6.8	Electronic nameplate.....	139
6.9	Lag monitoring.....	139

7 Appendix..... 140

7.1 Standard mapping of Drive Based 140

7.1.1 SB6: Drive Based receive process data 140

7.1.2 SB6: Drive Based transmit process data 141

7.2 Further information 142

7.3 Abbreviations 143

8 Contact 144

8.1 Consultation, service and address 144

8.2 Your opinion is important to us 144

8.3 Close to customers around the world 145

List of figures..... 146

List of tables..... 147

Glossary 148

1 Foreword

The DriveControlSuite commissioning software for 6th generation drive controllers offers convenient functions for efficient project configuration and commissioning of drive controllers in multi-axis and single-axis applications.

The Drive Based application contained in the software provides universal solutions for drive-based motion control using position, velocity and torque/force control types. The motion commands associated with these control types are categorized into the following operating modes:

- Command
- Motion block
- Velocity, torque/force

The Drive Based application enables you to implement a wide range of applications in the various operating modes, e.g. the simple operation of pumps, fans or presses, or complex movements coordinated by a control system.

Additional functions for monitoring process variables such as positions or velocities offer added convenience in monitoring.

This documentation describes the general functions of the Drive Based application and guides you step by step through the setup and project configuration of your drive project in the individual operating modes.

2 User information

This documentation supports you in the setup and project configuration of your drive system with the Drive Based application in conjunction with Drive Based device control.

Technical knowledge

To be able to commission one or more drive controllers using the Drive Based application, possibly in combination with a controller, you should have basic knowledge of handling 6th generation STÖBER drive controllers and of the DriveControlSuite commissioning software.

Technical requirements

Before you begin operating your drive system, you need to have wired the drive controllers involved and initially check that they are functioning correctly. To do this, follow the instructions in the manual for the relevant drive controller.

2.1 Storage and transfer

As this documentation contains important information for handling the product safely and efficiently, it must be stored in the immediate vicinity of the product until product disposal and be accessible to qualified personnel at all times.

Also pass on this documentation if the product is transferred or sold to a third party.

2.2 Described product

This documentation is mandatory for SB6 series drive controllers in conjunction with the DriveControlSuite software (DS6) in V 6.7-A or later and associated firmware in V 6.7-A or later.

2.3 Directives and standards

Refer to the drive controller documentation for the European directives and standards relevant to the drive controller and accessories.

2.4 Timeliness

Check whether this document is the latest version of the documentation. We make the latest document versions for our products available for download on our website:

<http://www.stoeber.de/en/downloads/>.

2.5 Original language

The original language of this documentation is German; all other language versions are derived from the original language.

2.6 Limitation of liability

This documentation was created taking into account the applicable standards and regulations as well as the current state of technology.

No warranty or liability claims for damage shall result from failure to comply with the documentation or from use that deviates from the intended use of the product. This is especially true for damage caused by individual technical modifications to the product or the project configuration and operation of the product by unqualified personnel.

2.7 Formatting conventions

Orientation guides in the form of signal words, symbols and special text markups are used to emphasize specific information so that you are able identify it in this documentation quickly.

2.7.1 Display of warning messages and information

Warning messages are identified with symbols. They indicate special risks when handling the product and are accompanied by relevant signal words that express the extent of the risk. Furthermore, useful tips and recommendations for efficient, error-free operation are specially highlighted.

ATTENTION!

Attention

This indicates that damage to property may occur

- if the stated precautionary measures are not taken.

⚠ CAUTION!

Caution

This word with a warning triangle indicates that minor personal injury may occur

- if the stated precautionary measures are not taken.

⚠ WARNING!

Warning

This word with a warning triangle means there may be a considerable risk of fatal injury

- if the stated precautionary measures are not taken.

⚠ DANGER!

Danger

This word with a warning triangle indicates that there is a considerable risk of fatal injury

- if the stated precautionary measures are not taken.

Information

Information indicates important information about the product or serves to emphasize a section in the documentation that deserves special attention from the reader.

2.7.2 Markup of text elements

Certain elements of the continuous text are distinguished as follows.

Important information	Words or expressions with a special meaning
Interpolated position mode	Optional: File or product name or other name
<u>Detailed information</u>	Internal cross-reference
http://www.samplelink.com	External cross-reference

Software and other displays

The following formatting is used to identify the various information content of elements referenced by the software interface or a drive controller display, as well as any user entries.

Main menu Settings	Window names, dialog box names, page names or buttons, combined proper nouns, functions referenced by the interface
Select Referencing method A	Predefined entry
Save your <own IP address>	User-defined entry
EVENT 52: COMMUNICATION	Displays (status, messages, warnings, faults)

Keyboard shortcuts and command sequences or paths are represented as follows.

[Ctrl], [Ctrl] + [S]	Key, key combination
Table > Insert table	Navigation to menus/submenus (path specification)

Operating buttons

The buttons of the drive controller are depicted as follows in the continuous text.

[OK]	Button on the operating unit of the drive controller
------	--

2.7.3 Mathematics and formulas

The following signs are used to represent mathematical relationships and formulas.

–	Subtraction
+	Addition
×	Multiplication
÷	Division
	Absolute value

2.8 Trademarks

The following names used in connection with the device, its optional equipment and its accessories are trademarks or registered trademarks of other companies:

CANopen [®] , CiA [®]	CANopen [®] and CiA [®] are registered trademarks of CAN in AUTOMATION e.V., Germany, the international user and manufacturer association.
EnDat [®]	EnDat [®] and the EnDat [®] logo are registered trademarks of Dr. Johannes Heidenhain GmbH, Germany.
EtherCAT [®] , Safety over EtherCAT [®]	EtherCAT [®] and TwinCAT [®] are registered trademarks and patented technologies, licensed by Beckhoff Automation GmbH, Germany.
PLCopen [®]	PLCopen [®] is a registered trademark of the PLCopen Organisation, Netherlands.
PROFIBUS [®] , PROFINET [®]	PROFIBUS [®] and PROFINET [®] are registered trademarks of PROFIBUS Nutzerorganisation e.V., Germany.

All other trademarks not listed here are the property of their respective owners.

Products that are registered as trademarks are not specially indicated in this documentation. Existing property rights (patents, trademarks, protection of utility models) are to be observed.

3 Safety notes

WARNING!

Risk of fatal injury if safety notes and residual risks are not observed!

Failure to observe the safety notes and residual risks in the drive controller documentation may result in accidents causing serious injury or death.

- Observe the safety notes in the drive controller documentation.
- Consider the residual risks in the risk assessment for the machine or system.

WARNING!

Malfunction of the machine due to incorrect or modified parameterization!

In the event of incorrect or modified parameterization, malfunctions can occur on machines or systems which can lead to serious injuries or death.

- Observe the security notes in the drive controller documentation.
- Protect the parameterization, e.g. from unauthorized access.
- Take appropriate measures for possible malfunctions (e.g. emergency off or emergency stop).

4 What you should know before commissioning

The following chapters provide a quick introduction to the structure of the program interface and accompanying window designations as well as relevant information about parameters and generally saving your project configuration.

4.1 DS6 program interface

Using the graphical interface of the DriveControlSuite commissioning software (DS6), you can project, parameterize and commission your drive project quickly and efficiently. In case of service, you can evaluate diagnostic information such as operating states, fault memories and fault counters of your drive project using DriveControlSuite.

Information

The program interface of DriveControlSuite is available in German, English and French. To change the language of the program interface, select **Settings > Language**.

Information

The DriveControlSuite help in the menu bar can be reached via **Help > Help for DS6** or via the [F1] key on your keyboard. When you press [F1] in an area of the program, the corresponding help topic opens.




Fig. 1: DS6: Program interface

No.	Area	Description
1	Menu bar	Using the File, View, Settings and Window menus, you can open and save projects, display and hide program windows, select the interface language and access level and change between different windows in the workspace.
2	Toolbar	The toolbar enables quick access to frequently needed functions, like opening and saving projects and hiding and displaying windows in the program interface.
3	Project tree	The project tree forms the structure of your drive project in the form of modules and drive controllers. Select an element using the project tree first in order to edit it using the project menu.
4	Project menu	The project menu offers you various functions for editing the project, module and drive controller. The project menu adapts to the element that you selected in the project tree.
5	Workspace	The different windows which can be used to edit your drive project, such as the configuration dialog, wizards, the parameter list or the scope analysis tool, open in the workspace.
6	Parameter check	The parameter check points out irregularities and inconsistencies that were detected in the plausibility check of calculable parameters.
7	Messages	The entries in the messages log the connection and communication status of the drive controllers, incorrect inputs caught by the system, errors when opening a project or rule violations in the graphical programming.
8	Variable parameter lists	You can use variable parameter lists to compile any parameters in individual parameter lists for a quick overview.
9	Status bar	In the status bar, you can find the specifications of the software version and get additional information about the project file, the devices and the progress of the process during processes such as loading projects.

4.1.1 Configuring the view

In DriveControlSuite, you can change the visibility and arrangement of areas and windows, such as to optimize the available space in the workspace when working with smaller screens.

Showing/hiding areas

Use the icons in the toolbar or the items in the **View** menu to show or hide specific areas in DriveControlSuite as needed.

Icon	Item	Description
—	Reset	Resets the view to factory settings.
	Project	Shows/hides the Project window (project tree, project menu).
	Messages	Shows/hides the Messages window.
	Parameter check	Shows/hides the Parameter check window.
	Variable parameter lists	Shows/hides the Variable parameter lists window.

Arrange and group areas

You can undock and rearrange the individual areas via drag and drop. If you drag an undocked window to the edge of DriveControlSuite, you can release it there in a color-highlighted area either next to or on top of another window to redock it.

When you release the window onto another window, the two areas are merged into one window where you can use tabs to switch between the areas.

4.1.2 Navigation using sensitive circuit diagrams




Fig. 2: DriveControlSuite: Navigation using text links and symbols

In order to graphically illustrate the processing sequence of actual and set values, the use of signals or the arrangement of drive components and to make configuring the accompanying parameters easier, they are displayed on the respective wizard pages of the workspace in the form of circuit diagrams.


Blue text links or clickable icons indicate links within the program. These refer to the corresponding wizard pages and, as a result, allow you to reach additional helpful detail pages with a click.

4.2 Meaning of parameters

You can use parameters to adapt the function of the drive controller to your individual application. In addition, parameters visualize the current actual values (actual velocity, actual torque, etc.) and trigger actions such as Save values, Test phase, etc.

Interpretation of parameter identification

Parameter identification consists of the following elements, where short forms are also possible, i.e. only specifying a coordinate or the combination of coordinate and name.



4.2.1 Parameter groups

Parameters are assigned to individual groups by topic. The drive controllers differentiate between the following parameter groups.

Group	Topic
A	Drive controllers, communication, cycle times
B	Motor
C	Machine, velocity, torque/force, comparators
D	Set value
E	Display
F	Terminals, analog and digital inputs and outputs, brake
G	Technology – Part 1 (application-dependent)
H	Encoder
I	Motion (all motion settings)
J	Motion blocks
K	Control panel
L	Technology – Part 2 (application-dependent)
M	Profiles (application-dependent)
N	Additional functions (application-dependent; e.g. extended cam control unit)
P	Customer-specific parameters (programming)
Q	Customer-specific parameters, instance-dependent (programming)
R	Production data for the drive controller, motor, brakes, motor adapter, gearbox and geared motor
S	Safety (safety technology)
T	Scope
U	Protection functions
Z	Fault counter

Tab. 1: Parameter groups

4.2.2 Parameter types and data types

In addition to topic-based sorting in individual groups, all parameters belong to a certain data type and parameter type. The data type of a parameter is displayed in the parameter list, properties table. The connections between parameter types, data types and their value range can be found in the following table.

Data type	Parameter type	Length	Value range (decimal)
INT8	Integer or selection	1 byte (signed)	-128 – 127
INT16	Integer	2 bytes (1 word, signed)	-32768 – 32767
INT32	Integer or position	4 bytes (1 double word, signed)	-2 147 483 648 – 2 147 483 647
BOOL	Binary number	1 bit (internal: LSB in 1 byte)	0, 1
BYTE	Binary number	1 byte (unsigned)	0 – 255
WORD	Binary number	2 bytes (1 word, unsigned)	0 – 65535
DWORD	Binary number or parameter address	4 bytes (1 double word, unsigned)	0 – 4 294 967 295
REAL32 (single type according to IEE754)	Floating-point number	4 bytes (1 double word, signed)	$-3.40282 \times 10^{38} - 3.40282 \times 10^{38}$
STR8	Text	8 characters	—
STR16	Text	16 characters	—
STR80	Text	80 characters	—

Tab. 2: Parameters: Data types, parameter types, possible values

Parameter types: Use

- Integer, floating-point number
For general computing processes
Example: Set and actual values
- Selection
Numeric value to which a direct meaning is assigned
Example: Sources for signals or set values
- Binary number
Bit-oriented parameter information that is collected in binary
Example: Control and status words
- Position
Integer combined with associated units and decimal places
Example: Actual and set values of positions
- Velocity, acceleration, deceleration, jerk
Floating-point number combined with associated units
Example: Actual and set values for velocity, acceleration, deceleration, jerk
- Parameter address
Referencing of a parameter
Example: In F40 AO1 source, for example, E08 n-motor filtered can be parameterized
- Text
Outputs or messages

4.2.3 Parameter types


The following types of parameters are differentiated.

Parameter type	Description	Example
Simple parameters	Consist of one group and one line with a defined value.	A21 Brake resistor R: Value = 100 ohms
Array parameters	Consist of a group, a line and multiple sequential (listed) elements, which have the same properties but different values.	A10 Access level - A10[0] access level: Value = Access level via operating unit - A10[2] access level: Value = Access level via CANopen and EtherCAT - A10[4] access level: Value = Access level via PROFINET
Record parameters	Consist of a group, a line and multiple sequential (listed) elements, which can have different properties and different values.	A00 Save values - A00[0] Start: Value = Start action - A00[1] Progress: Value = Display action progress - A00[2] Result: Value = Display action result

Tab. 3: Parameter types

4.2.4 Parameter structure

Every parameter has specific coordinates with the following structure.



- Axis (optional)
In case of multiple axes, the one to which a parameter is assigned; not applicable for global parameters (value range: 1 – 4).
- Group
The thematic group to which a parameter belongs (value range: A – Z).
- Line
Distinguishes the parameters within a parameter group (value range: 0 – 999).
- Element (optional)
Elements of an array or record parameter (value range: 0 – 16000).
- Bit (optional)
Selection of a single bit for complete data addressing; depends on the data type (value range: 0 – 31).

4.2.5 Parameter visibility

The visibility of a parameter is controlled by the access level you set in DriveControlSuite and by the properties you project for the respective drive controller (e.g. hardware, firmware and application). A parameter can also be shown or hidden depending on other parameters or settings. For example, the parameters of an additional function are only shown as soon as you activate the relevant additional function.

Access level

The access options for the individual software parameters are ranked hierarchically and divided into individual levels. This means that parameters can be hidden for a specific purpose and, relatedly, their configuration options can be locked starting from a specific level.

Each parameter has one access level for read access (visibility) and one access level for write access (editability). The following levels are present:

- Level 0
Elementary parameters
- Level 1
Important parameters of an application
- Level 2
Important parameters for service with extensive diagnostic options
- Level 3
All parameters needed for commissioning and optimizing an application

The parameter A10 Access level controls general access to parameters:

- Over the drive controller display (A10[0])
- Over CANopen or EtherCAT (A10[2])
- Over PROFINET (A10[3])

Hardware

Which parameters are available to you in DriveControlSuite is determined by which series you select in the configuration dialog for the drive controller, for example, or whether you project an option module. Basically, the only parameters that are displayed are the ones you need to parameterize the configured hardware.

For example, a drive controller can evaluate an encoder using terminal X120, provided that a corresponding terminal module has been installed. The accompanying evaluation is activated using parameter H120. However, this parameter is visible only if the terminal module was initially selected during the drive project configuration.

Firmware

Due to the further development and updating of functions for the drive controllers, new parameters and also new versions of existing parameters are continuously being implemented in DriveControlSuite and in the firmware. The parameters are displayed in the software according to the DriveControlSuite version used and the configured firmware version of the respective drive controller.

Applications

Applications generally differ in terms of functions and their control. For this reason, different parameters are available with each application.

Information

If a parameter exists in the configuration due to the projected properties of the drive controller (e.g. hardware, firmware, application), it is generally available for fieldbus communication. The visibility of a generally available parameter has no effect on its availability for fieldbus communication (e.g. through access level or parameter selection).

4.3 Signal sources

Drive controllers are controlled either by a fieldbus, by terminals or by mixed operation consisting of a fieldbus system and terminals. You can use the corresponding selection parameters, referred to as signal sources, to configure in DriveControlSuite whether the control signals and set values of the application are obtained over a fieldbus or using terminals.

In case of activation by using terminals, the respective analog or digital inputs are specified directly as the source. In case of activation by fieldbus, parameters are selected as sources for control signals and set values, which must be part of the process data mapping between the controller and drive controller so that the controller can write to them via fieldbus.

4.4 Non-volatile memory

All project configurations, parameterizations and related changes to parameter values are in effect after transmission to the drive controller, but are only stored in volatile memory.

Saving to a drive controller

To save the configuration in non-volatile memory on a drive controller, you have the following options:

- Saving the configuration using the *Save values wizard*:
Project menu > Wizards area > Projected axis > Save values wizard:
Select the Save values action
- Saving the configuration using the parameter list:
Project menu > Parameter list area > Projected axis > Group A: Drive controller > A00 Save values:
Set the parameter A00[0] to the value 1: Active
- Saving the configuration using the S1 operating button:
Press and hold the operating button for 3 s
- Saving the configuration using the operating unit:
Press the save button for 3 s

Saving to all drive controllers within a project

To save the configuration in non-volatile memory on several drive controllers, you have the following options:

- Saving the configuration using the toolbar:
Toolbar > Save values icon: Click the Save values icon
- Saving the configuration using the Online functions window:
Project menu > Online connection button > Online functions window: Click on Save values (A00)

Information

Do not shut off the drive controller while saving. If the supply voltage to the control unit is interrupted while saving, the drive controller will start with the last correct configuration that was saved and with fault 40: Invalid data the next time it is switched on. In order to acknowledge the fault and successfully complete the saving process, the configuration must be stored again in non-volatile memory and the action must be completed.

5 Commissioning

The following chapters describe how to commission your drive system using DriveControlSuite.

For the components of your axis model, we assume one of the following two combinations as an **example**:

Synchronous servo motor with EnDat 2.2 digital encoder or EnDat 3 (with optional brake)

Synchronous servo motors are saved along with all relevant data for the project configuration in the DriveControlSuite motor database and in the electronic nameplate. When the motor is selected from the database, as well as when the nameplate is read out, all data is transferred to the corresponding parameters. There is no need for complex parameterization of the motor, encoder and brake.

LM Lean motor without encoder (with optional brake)

Lean motors are stored in the motor database of the DriveControlSuite, along with all the data relevant for project configuration. Furthermore, the motor data and the release and engaging times of the brake are part of the firmware. When the motor is selected from the database, all data is transmitted to the corresponding parameters. There is no need for time-consuming parameterization of the motor and brake. For optimum operation of the Lean motor, it is only necessary to parameterize the cable length and the mass inertia ratio of the load to the motor and, if necessary, activate the brake.

For asynchronous motors, the motor data relevant for project configuration is also taken from the motor database. All other motor types need to have their parameters configured manually.

Before you begin commissioning, make sure that the system nodes are hooked up and supplied with control voltage.

Information

Always perform the steps described below in the specified order!

Some parameters are interdependent and do not become accessible to you until you have first configured certain settings. Follow the steps in the specified sequence so that you can finish the parameterization completely.

5.1 Initiating the project

In order to be able to configure all drive controllers and axes of your drive system using DriveControlSuite, you must record them as part of a project.

5.1.1 Projecting the drive controller and axis

Create a new project and project the first drive controller along with the accompanying axis.

Information

Make sure that you project the correct series in the **Drive controller** tab. The projected series cannot be changed afterwards.

Creating a new project

1. Start DriveControlSuite.
2. On the start screen, click **Create new project**.
 - ⇒ The new project is created and the configuration dialog for the first drive controller opens.
 - ⇒ The **Drive controller** button is active.

Projecting the drive controller

1. **Properties tab:**

Establish the relationship between your circuit diagram and the drive controller to be projected in DriveControlSuite.

 - 1.1. **Reference:**

Define the reference code (equipment code) of the drive controller.
 - 1.2. **Designation:**

Give the drive controller a unique name.
 - 1.3. **Version:**

Version your project configuration.
 - 1.4. **Description:**

If necessary, save additional supporting information (e.g., the change history).
2. **Drive controller tab:**

Select the series, device type and firmware version of the drive controller.
3. **Option modules tab:**

Project the option modules of the drive controller.

 - 3.1. **Terminal module:**

If you are controlling the drive controller via analog and digital inputs, select the corresponding terminal module.
 - 3.2. **Safety module:**

If the drive controller is part of a safety circuit, select the corresponding safety module.
4. **Device control tab:**

Project the basic control of the drive controller.

 - 4.1. **Device control:**

Select device control **Drive Based**.
 - 4.2. **Rx process data, Tx process data:**

If you use a fieldbus to control the drive controller, select the corresponding receive and transmit process data.

Projecting the axis

1. Click Axis A.
2. **Properties tab:**
Establish the relationship between your circuit diagram and the axis to be projected in DriveControlSuite.
 - 2.1. **Reference:**
Define the reference code (equipment code) of the axis.
 - 2.2. **Designation:**
Give the axis a unique name.
 - 2.3. **Version:**
Version your project configuration.
 - 2.4. **Description:**
If necessary, save additional supporting information (e.g., the change history).
3. **Application tab:**
Select the Drive Based application.
4. **Motor tab:**
Select the type of motor you operate with this axis. If you are working with motors from third-party suppliers, enter the accompanying motor data later.
5. Confirm with OK.

5.1.2 Configuring safety technology

If the drive controller is part of a safety circuit, you must configure the safety technology in accordance with the commissioning steps outlined in the corresponding manual in the next step (see [Further information](#) [► 142]).

5.1.3 Creating other drive controllers and modules

In DriveControlSuite, all drive controllers within a project are grouped using modules. If you add a new drive controller to your project, be sure to always assign it to an existing module. Group drive controllers in a module if, for example, they are located in the same control cabinet or work together to operate the same machine part.

Creating a drive controller

1. In the project tree, select your project P1 > module M1 > context menu **Create new drive controller**.
⇒ The drive controller is created in the project tree and the configuration dialog opens.
2. Project the drive controller as described in [Projecting the drive controller and axis](#) [► 21].
3. Repeat the steps for all other drive controllers that you want to project.

Creating a module

1. In the project tree, select your project P1 > context menu **Create new module**.
⇒ The module is created in the project tree.
2. Project the module as described in [Projecting the module](#) [► 23].
3. Repeat the steps for all other modules that you want to project.

5.1.4 Projecting the module

Give your module a unique name, enter the reference code and, as an option, store additional information like the version and change history of the module.

1. Select the module in the project tree and click on **Project configuration** in the project menu.
⇒ The configuration dialog for the module opens.
2. Establish the relationship between your circuit diagram and the module in DriveControlSuite.
 - 2.1. **Reference:**
Define the reference code (equipment code) of the module.
 - 2.2. **Designation:**
Give the module a unique name.
 - 2.3. **Version:**
Version the module.
 - 2.4. **Description:**
If necessary, save additional supporting information (e.g., the change history).
3. Confirm with OK.

5.1.5 Projecting the project

Give your project a unique name, enter the reference code and, as an option, store additional information like the version and change history of the project.

1. Select the project in the project tree and click on **Project configuration** in the project menu.
⇒ The configuration dialog for the project opens.
2. Establish the relationship between your circuit diagram and the project in DriveControlSuite.
 - 2.1. **Reference:**
Define the reference code (equipment code) of the project.
 - 2.2. **Designation:**
Give the project a unique name.
 - 2.3. **Version:**
Version the project.
 - 2.4. **Description:**
If necessary, save additional supporting information (e.g., the change history).
3. Confirm with OK.

5.2 Mapping the mechanical axis model

To be able to put your real drive train with one or more drive controllers into operation, you must map your complete mechanical environment in DriveControlSuite.

The 6th generation of STÖBER drive controllers are specially developed for communication between the drive controller and controller on the basis of the actual variables at the output (° or mm of real axis movement). The scaling of the axis model is calculated by the drive controller's firmware independently of the encoder model, without any rounding errors or drift.

5.2.1 Parameterizing the motor

You have projected one of the following motors:

Synchronous servo motor with EnDat 2.2 digital encoder or EnDat 3 (with optional brake)

When the project is configured for the corresponding motor, limiting values for currents and torques as well as associated temperature data are automatically transferred to the respective parameters of the individual wizards. All additional data on the brake and encoder is transferred at the same time.

Lean motor without encoder (with optional brake)

When the project is configured for the corresponding motor, limiting values for currents and torques as well as associated temperature data are automatically transferred to the respective parameters of the individual wizards. You only have to parameterize the cable length in use and the mass inertia ratio of the load to the motor. Even the brake purging and engaging times are already stored. You just have to activate the brake.

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the **Motor** wizard.
3. **B101 Cable length:**
Select the cable length of the power cable in use.
4. Select the **Control cascade wizard** > **Control mode**.
5. **C30 J-Last / J-Motor:**
Parameterize the mass inertia ratio of the load to the motor.

Then activate the brake.

1. Select the relevant drive controller in the project tree and click on the first projected axis in the Project menu > Wizard area.
2. Select the **Brake** wizard.
3. **F00 Brake:**
Select 1: Active.

5.2.2 Parameterizing the axis model

Parameterize the setup of your drive in this order:

- Define the axis model
- Scale the axis
- Parameterize the position and velocity window
- Limit the axis (optional)
 - Limit the position
 - Limit the velocity, acceleration and jerk
 - Limit the torque and force

5.2.2.1 Define the axis model

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the **Axis model** wizard.
3. **I05 Type of axis:**
Define whether the axis type is rotational or translational.
 - 3.1. If you would like to configure the units of measure and the number of decimal places individually for specifying and displaying positions, velocities, accelerations and jerk, select 0: User defined, rotational or 1: User defined, translational.
 - 3.2. If the units of measure and the number of decimal places for specifying and displaying positions, velocities, accelerations and jerk are to be fixed, select 2: Rotational or 3: Translational.
4. **B26 Motor encoder:**
Select the interface to which the motor encoder is connected.
5. **I02 Position encoder (optional):**
Select the interface to which the position encoder is connected.
6. **I00 Position range:**
Select whether the travel range of the axis is limited or endless (modulo).

Information

When you parameterize I05 Type of axis, you can either use selection 0: User defined, rotational or 1: User defined, translational to configure units of measure and the number of decimal places for the axis model individually or use selections 2: Rotational and 3: Translational to revert to preset values.

Selection 0: User defined, rotational and selection 1: User defined, translational let you configure the unit of measure (I09) and the decimal places (I06) individually. Velocity, acceleration and jerk are represented as the derivative of the unit of measure with respect to time.

Selection 2: Rotational sets the following units of measure for the axis model: position in °, velocity in rpm, acceleration in rad/s^2 , jerk in rad/s^3 .

Selection 3: Translational sets the following units of measure for the axis model: position in mm, velocity in m/s, acceleration in m/s^2 , jerk in m/s^3 .

Information

If you do not parameterize it differently for I02 Position encoder, B26 Motor encoder is used for position control as standard.

5.2.2.2 Scale the axis

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the Axis model wizard > Axis: Scaling.
3. Scale the axis by configuring the overall gear ratio between the motor and output.
To simplify this scaling for you, you are provided with the scaling calculator *Conversion of positions, velocities, accelerations, torque/force*, which calculates the effects of changed motion variables on the entire system.
4. I01 Circular length:
If you have selected 1: Endless = I00 Position range, define the revolution length.
5. I06 Decimal places position (optional):
If you have selected 0: User defined, rotational or 1: User defined, translational for I05 Type of axis, define the desired number of decimal places.
6. I09 Measure unit (optional):
If you have selected 0: User defined, rotational or 1: User defined, translational for I05 Type of axis, define the desired unit of measure.
7. I03 Axis polarity:
Use the polarity to define the direction of interpretation between the axis movement and motor movement.

Information

A change to parameter I06 moves the decimal separator for all axis-specific position values! Ideally, define I06 before parameterizing other position values and then check them.

If the axis receives set value specifications from a controller or follows the master values of a master, the resolution of position values directly impacts the smooth operation of the axis. Therefore, you should define a sufficient number of decimal places appropriate for your application.

Information

Parameter I297 Maximum speed position encoder must be parameterized according to your application case. If I297 is set too low, the permitted maximum speed is exceeded even at normal operating speeds. On the other hand, if I297 is set too high, measuring errors of the encoder can be overlooked.

I297 depends on the following parameters: I05 Type of axis, I06 Decimal places position, I09 Measure unit as well as I07 Distance factor numerator position and I08 Distance factor denominator position or A585 Feed constant for CiA 402. If you have made changes to one of the parameters listed, select I297 accordingly as well.

5.2.2.3 Parameterizing the position and velocity window

Enter position limits and velocity zones for set values. To do so, parameterize boundary values for reaching a position or velocity.

1. Select the **Axis model wizard** > Window position, velocity.
2. C40 Velocity window:
Parameterize a tolerance window for velocity tests.
3. I22 Target window:
Parameterize a tolerance window for position tests.
4. I87 Actual position in window time:
Parameterize how long a drive must stay in the specified position window before a corresponding status message is output.
5. I21 Maximal following error:
Parameterize a tolerance window for lag tests.

For more information on monitoring the lag, see [Lag monitoring](#) [► 139].

5.2.2.4 Limiting the axis

As an option, you can limit the maximum permitted motion variables of position, velocity, acceleration, jerk and torque/force according to your application.

Information

To simplify the scaling and limiting of the axis, the Axis model wizard > Axis: Scaling provides you with the **Conversion of position, velocities, accelerations, torque/force** scaling calculator, which calculates the effects of changed motion variables on the entire system. You can use the scaling calculator to enter values for motion variables of the motor, gearbox output and axis in order to convert the values to all other locations in the axis model.

Limiting the position

To secure the travel range of the axis, you have the option to limit the permitted positions using a software or hardware limit switch.

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the Axis model wizard > Limit: Position.
3. I101 Source positive /limit switch, I102 Source negative /limit switch:
To limit the travel range of the axis in the positive or negative direction of motion via hardware limit switches, select the source of the digital signal that is used to evaluate a limit switch at the positive or negative end of the travel range.
 - 3.1. If bit 1 or bit 2 of the control word I210 of the application is the source, select 2: Parameter.
 - 3.2. If a digital input (direct or inverted) acts as the source, select the corresponding input.
4. I50 Software stop positive, I51 Software stop negative:
If you selected 0: Limited for I00 and would like to limit the travel range of the axis via software limit switches, define the largest or smallest permitted position for software position limiting.

ATTENTION!

Material damage due to leaving the permitted travel range

When a limit switch is overshoot, the axis at the end of the permitted travel range will go into a fault condition, either with or without a quick stop depending on the parameterization of the device control, so it may come to a standstill past the limit switch and outside the permitted travel range.

- Allow sufficient space past the limit switch for your application to bring the axis to a standstill.

Limiting velocity, acceleration, jerk

As an option, you can limit the motion variables of velocity, acceleration and jerk and define the quick stop deceleration according to your application. The default values are designed for slow velocities without gearboxes.

1. Select the **Motor wizard**.
2. **B83 v-max motor:**
Determine the maximum permitted velocity of the motor.
3. Select the **Axis model wizard > Axis: Scaling**.
4. **Conversion of positions, velocities, accelerations, torque/force area:**
Use the scaling calculator to determine the maximum permitted velocity of the motor and the maximum permitted velocity of the output as a reference value.
5. Select the **Axis model wizard > Limit: Velocity, acceleration, jerk**.
6. **I10 Maximal speed:**
Define the maximum permitted velocity of the output according to your application (taking into account the previously determined reference value).
7. **I11 Maximal acceleration:**
Define the maximum permitted acceleration for the output.
8. **I16 Maximal jerk:**
Define the maximum permitted jerk for the output.
9. **I17 Quickstop deceleration:**
Define the desired quick stop deceleration for the output.

Limiting the torque/force

As an option, you can limit the torque/force according to your application. The default values take into account the rated operation together with the overload reserves.

1. Select the **Axis model wizard > Limit: Torque/force**.
2. **C03 Maximum positive torque/force, C05 Maximum negative torque/force:**
Define the maximum permitted set torque/maximum permitted set force.
3. **C08 Maximum torque/force for quick stop:**
Define the maximum permitted set torque/maximum permitted set force in case of a quick stop and in case of drive-controlled emergency stop SS1, SS1 and SS2.

5.3 Referencing absolute position

When commissioning a system with position measurement systems, the relation of a measured to an actual axis position must be determined to be able to work with absolute positions.

If you are working with absolute positions, reference the axis now. Otherwise, proceed by parameterizing application-specific conditions and responses of the Drive Based device control.

5.3.1 Defining the referencing method

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the Referencing wizard.
3. I30 Referencing type, I31 Referencing direction, I35 Referencing with zero pulse:
Define the characteristics for referencing.
For information on possible combinations of the named characteristics as well as detailed descriptions of the individual referencing methods, see [Referencing methods](#) [► 102].
4. I43 Move to reference position:
If the axis is to automatically move to the referenced position after referencing, set this parameter to 1: Active.

5.3.2 Parameterizing the reference switch

If you are working with absolute positions and would like to determine a reference position while referencing using the reference switch, proceed as follows.

1. Select the Drive Based application wizard > Data sources > Application digital signals: Data source.
2. I103 Source reference switch:
 - 2.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 2.2. If bit 3 of the control word I210 of the application is the source, select 2: Parameter.

5.3.3 Setting the reference

If you are working with absolute positions and would like to reference without using a referencing run, the value of the current actual position is applied directly as a parameter value from I34 using the Set reference signal.

1. Select the Drive Based application wizard > Data sources > Application digital signals: Data source.
2. I111 Source set reference:
 - 2.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 2.2. If bit 11 of the control word I210 of the Drive Based application is the signal source, select 2: Parameter.

5.4 Parameterizing Drive Based device control

The Drive Based device control describes the control sequence of a drive controller based on a state machine, i.e. a drive controller switches its state due to an event. Some of the conditions and responses coupled with the state transitions can be influenced depending on the application; for example, it is possible to define the end of a quick stop or enable signal delays tailored to the respective application case.

For more information on the device control and Drive Based device state machine, see [Drive Based device control](#) [► 129].

5.4.1 Parameterizing transition conditions

- ✓ You have projected a drive controller with the Drive Based device control.
- 1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
- 2. Select the Drive Based device control wizard.
- 3. A34 Auto start:
If the drive controller is to switch directly to the Operation enabled state after the Switch on disabled state, activate this parameter.
- 4. A43 Enable switch-on/off delay
If you need to hide possible fault or test pulses on the enable input, enter the maximum internal activation and deactivation delay.
- 5. A44 Quick stop at enable off:
If the axis is to be stopped with a quick stop in the event of an Enable-off, activate this parameter.
- 6. A60 Source additional enable:
If you are working with multiple enable signals, select the source of additional signals in this parameter.
- 7. A29 Quick stop in case of fault:
If the axis is to be stopped with a quick stop – if possible – in case of a fault, activate this parameter. If the parameter is deactivated, motion of the axis is no longer controlled by the drive controller.
- 8. A39 Maximum quick stop duration for enable off:
If you have selected 1: Active for parameter A44, define the maximum time after which the power unit is switched off in A39.
- 9. A45 Quick stop end:
In this parameter, define whether a quick stop is considered ended when the axis is at a standstill or when the quick stop request is canceled.
- 10. A62 Source /quick stop:
Select the source of the digital signal used to activate the quick stop.

5.5 Transmitting and saving the configuration

In order to transmit and save the configuration to one or more drive controllers, you must connect your PC and the drive controllers over the network.

WARNING!

Injury to persons and material damage due to axis movement!

If there is an online connection between DriveControlSuite and the drive controller, changes to the configuration can lead to unexpected axis movements.

- Only change the configuration if you have visual contact with the axis.
- Make sure that no people or objects are within the travel range.
- For access via remote maintenance, there must be a communication link between you and a person on site with eye contact to the axis.

Information

During the search, all drive controllers within the broadcast domain are found via IPv4 limited broadcast.

Requirements for finding a drive controller in the network:

- Network supports IPv4 limited broadcast
- All drive controllers and the PC are in the same subnet (broadcast domain)

✓ The drive controllers are switched on and can be found in the network.

1. In the project tree, select the module under which you have recorded your drive controller and click **Online connection** in the project menu.

⇒ The **Add connection** dialog box opens. All drive controllers found via IPv4 limited broadcast are displayed.

2. **Direct connection** tab, **IP address** column:

Activate the IP addresses in question and confirm your selection with **OK**.

⇒ The **Online functions** window opens. All drive controllers connected through the selected IP addresses are displayed.

3. Select the module and the drive controller to which you would like to transfer the configuration. Change the selection of transmission type from **Read** to **Send**.

4. Change the selection **Create new drive controller**:

Select the configuration that you would like to transfer to the drive controller.

5. Repeat steps 3 and 4 for all other drive controllers to which you would like to transfer your configuration.

6. **Online** tab:

Click **Establish online connections**.

⇒ The configurations are transferred to the drive controllers.

Saving a configuration

- ✓ You have successfully transferred the configuration.
- 1. Online functions **window**, Online **tab**, Actions for drive controller in online operation **area**:
Click Save values (A00).
 - ⇒ The Save values (A00) window opens.
- 2. Select on which drive controllers you want to save the configuration.
- 3. Click Start action.
 - ⇒ The configuration is stored on the drive controllers in non-volatile memory.
- 4. Close the Save values (A00) window.

Information

For the configuration to take effect on the drive controller, a restart may be required in certain cases, such as after the configuration is saved on the drive controller for the first time or when changes are made to the firmware or process data mapping.

Restarting a drive controller

- ✓ You have stored the configuration on the drive controller in non-volatile memory.
- 1. Online functions **window**, Online **tab**:
Click Restart (A09).
 - ⇒ The Restart (A09) window opens.
- 2. Select which of the connected drive controllers you want to restart.
- 3. Click Start action.
- 4. Confirm the safety note with OK.
 - ⇒ The Restart (A09) window closes.
- ⇒ The fieldbus communication and connection between DriveControlSuite and drive controllers are interrupted.
- ⇒ The selected drive controllers restart.

5.6 Testing the configuration

After you have transferred the configuration to the drive controller, first check your projected axis model and the parameterized electrical and mechanical data for plausibility before continuing with the parameterization.

You can test the configuration quickly and easily via DriveControlSuite or, as an alternative, directly via the operating unit of the drive controller.

5.6.1 Testing jog mode

Jog control panel provides various commands for jog mode which you can use to test the configuration of your projected axis model for plausibility.

Information

Make sure that the values of the control panel are compatible with your projected axis model in order to obtain useful test results that you can use to optimize your configuration for the respective axis.

The scaling calculator is available under the *Axis model wizard > Axis: Scaling* to recalculate the values for the control panel according to your projected axis model.

WARNING!

Injury to persons and material damage due to axis movement!

When you activate the control panel, DriveControlSuite gives you sole control of the motions of the axis. If you are using a controller, it no longer monitors the axis movements after the control panel is activated. The controller cannot intervene to prevent collisions. The controller takes over control again when the control panel is deactivated, which can cause unexpected axis movements.

- Do not switch to other windows when the control panel is active.
- Only use the control panel if you have visual contact with the axis.
- Make sure that no people or objects are within the travel range.
- For access via remote maintenance, there must be a communication link between you and a person on site with eye contact to the axis.

Testing the configuration using the jog control panel

- ✓ There is an online connection between DriveControlSuite and the drive controller.
 - ✓ You have successfully stored the configuration on the drive controller.
 - ✓ No safety function is active.
1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
 2. Select the Jog control panel wizard.
 3. Click Control panel on and then Enable.
 - ⇒ The axis is monitored via the active control panel.
 4. Check the default values of the control panel and adjust them to your projected axis model if necessary.
 5. To test the configuration of your projected axis for direction of motion, velocity, etc., move the axis gradually using the Jog+, Jog-, Jog step+ and Jog step- buttons.
 6. Use your test results to optimize your configuration as necessary.
 7. To deactivate the control panel, click on Control panel off.

Information

Jog+ and Jog- cause a continual manual movement in the positive or negative direction. Jog step+ and Jog step- move the axis relative to the current actual position by the increment specified in I14.

Jog+ and Jog- have a higher priority than Jog step+ and Jog step-.

5.6.2 Testing the motion commands

Control panel motion provides a standard set of motion commands which you can use to test the basic movements of your axis. The command set is based on the PLCopen standard and supplemented by manufacturer-specific motion commands.

If you are working with absolute position measuring systems and need the MC_MoveAbsolute motion command for testing, you must reference an absolute position in advance (see [Referencing absolute position](#) [► 30]).

Information

Make sure that the values of the control panel are compatible with your projected axis model in order to obtain useful test results that you can use to optimize your configuration for the respective axis.

The scaling calculator is available under the **Axis model wizard > Axis: Scaling** to recalculate the values for the control panel according to your projected axis model.

WARNING!

Injury to persons and material damage due to axis movement!

When you activate the control panel, DriveControlSuite gives you sole control of the motions of the axis. If you are using a controller, it no longer monitors the axis movements after the control panel is activated. The controller cannot intervene to prevent collisions. The controller takes over control again when the control panel is deactivated, which can cause unexpected axis movements.

- Do not switch to other windows when the control panel is active.
- Only use the control panel if you have visual contact with the axis.
- Make sure that no people or objects are within the travel range.
- For access via remote maintenance, there must be a communication link between you and a person on site with eye contact to the axis.

Testing the configuration using the motion control panel

- ✓ There is an online connection between DriveControlSuite and the drive controller.
 - ✓ You have successfully stored the configuration on the drive controller.
 - ✓ No safety function is active.
1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
 2. Select the Control panel motion wizard.
 3. Click Control panel on and then Enable.
 - ⇒ The axis is monitored via the active control panel.
 4. Check the default values of the control panel and adjust them to your projected axis model if necessary.
 5. K402 Command:
 - Select the desired command and define the position, velocity, acceleration, deceleration and jerk.
 6. Execute the command by clicking Start.
 7. To test the configuration of your projected axis for direction of motion, velocity, etc., move the axis precisely using the individual commands.
 8. Use your test results to optimize your configuration as necessary.
 9. To deactivate the control panel, click on Control panel off.

5.7 Parameterizing the Drive Based application

The Drive Based application provides three operating modes: command operating mode, motion block operating mode and velocity, torque/force operating mode.

The operating modes provide you with a standard set of motion commands based on PLCopen that are supplemented with unique motion commands. The operating mode that is best suited to your application depends on your application case. If you are coordinating motion sequences using a controller, use the command operating mode. If you are not using a controller and are instead storing the motion profiles on the respective drive controller, use the motion block operating mode. If you only want to execute simple movements in which only set values may be subject to possible changes, such as for pumps, fans or conveyor belts, use the velocity, torque/force operating mode.

The general motion variables are grouped in the mode-independent **Data sources** wizard. Depending on the operating mode, unique wizards are also available which you can use to parameterize operating mode-specific motion variables. The general or operating mode-specific motion variables you need to parameterize depend on your drive project.

If you would like to use set values from external sources for your project, parameterize them in the first step. Then, continue with the operating mode-specific motion variables in the respective wizards.

5.7.1 General motion variables and signal sources

First, parameterize the general motion variables and signal sources before you begin parameterization of the operating mode-specific motion variables. The motion variables that you need to parameterize depend on your drive project.

5.7.1.1 Parameterizing analog inputs

If the analog inputs serve as a source for the application in your drive project, parameterize the respective analog input as described below. The number of available analog inputs depends on the configured terminal module.

For more information and continuous function charts for the analog inputs, see [Analog inputs \[► 77\]](#).

5.7.1.1.1 Parameterizing analog input AI1

Parameterize the analog input as a voltage source by defining a time constant for the associated filter and calibrating using the maximum positive, maximum negative and 0 V voltage. After that, you can scale the analog input as needed.

If the analog input is the current source, calibrate using the maximum and minimum currents instead, and optionally enable wire break monitoring.

Parameterizing analog input AI1

1. Select the **Terminals wizard** > **Analog input 1**.
2. **F13 AI1 lowpass filter:**
If the quality of the signal requires it, adjust the time constant for the filter accordingly.
3. **F15 AI1 wire break monitoring:**
If you want to use analog input AI1 as a current source and enable wire break monitoring, select 1: Active.
4. **F116 AI1 operating mode:**
Select the operating mode of analog input AI1.
 - 4.1. If analog input AI1 is the voltage source, select 0: -10V to 10V.
 - 4.2. If analog input AI1 is the current source, select 1: 0 to 20mA or 2: 4 to 20mA.

Calibrating analog input AI1 (voltage source)

- ✓ Analog input AI1 is interpreted as a voltage source (F116 = 0: -10V to 10V).
1. Select the **Terminals wizard** > **Analog input 1** > **Analog input 1: Calibration**.
 2. Set the voltage source to the minimum voltage.
 - 2.1. **F112 AI1 maximum negative value:**
Apply the value from parameter E110[1] for parameter F112.
 - 2.2. **F114 AI1 maximum negative % value:**
Define the associated value for F112 in % in parameter F114.
 3. Set the voltage source to the maximum voltage.
 - 3.1. **F111 AI1 maximum positive value:**
Apply the value from parameter E110[1] for parameter F111.
 - 3.2. **F115 AI1 maximum positive % value:**
Define the associated value for F111 in % in parameter F115.
 4. Set the voltage source to 0 V voltage.
 - 4.1. **F110 AI1 zero point offset:**
Apply the value from parameter E110[1] for parameter F110.
 5. **F113 AI1 deadband:**
Optionally define a deadband to compensate for any noise of the 0 V voltage at the analog input.

Calibrating analog input AI1 (current source)

✓ Analog input AI1 is interpreted as a current source (F116 = 1: 0 to 20mA or 2: 4 to 20mA).

1. Select the **Terminals wizard** > **Analog input 1** > **Analog input 1: Calibration**.
2. Set the current source to the minimum current.
 - 2.1. F110 AI1 zero point offset:
Apply the value from parameter E110[1] for parameter F110.
 - 2.2. F114 AI1 maximum negative % value:
Define the associated value for F110 in % in parameter F114.
3. Set the current source to the maximum current.
 - 3.1. F111 AI1 maximum positive value:
Apply the value from parameter E110[1] for parameter F111.
 - 3.2. F115 AI1 maximum positive % value:
Define the associated value for F111 in % in parameter F115.

Scaling analog input AI1

1. Select the **Drive Based Center Winder application wizard** > **Analog inputs: Scaling** > **Analog input 1: Scaling**.
2. G260 AI1 scaling:
Select the scaling for the analog input.
 - 2.1. If you want to use the value unscaled, select 0: Without scaling.
 - 2.2. If you want to use the value unsigned, select 1: Absolute value.
 - 2.3. If you want to use the value inverted, select 2: Inverting.
 - 2.4. If you want to scale the value using a curve, select 3: X/Y characteristic.
⇒ Parameters G261 and G262 for scaling the analog input using a curve are displayed.
3. G261 AI1 X-value scaling, G262 AI1 Y-value scaling:
If you have selected 3: X/Y characteristic for G260, define the value pairs of the calibrated value and scaled value for the scaling of the analog input.
⇒ The scaling of the analog input is completed.
⇒ The scaled value of analog input AI1 is displayed in G270.

5.7.1.1.2 Parameterizing analog input AI2

Parameterize the analog input as a voltage source by defining a time constant for the associated filter and calibrating using the maximum positive, maximum negative and 0 V voltage. After that, you can scale the analog input as needed.

Parameterizing analog input AI2

1. Select the **Terminals wizard** > **Analog input 2**.
2. **F23 AI2 lowpass filter:**
If the quality of the signal requires it, adjust the time constant for the filter accordingly.

Calibrating analog input AI2

1. Select the **Terminals wizard** > **Analog input 2** > **Analog input 2: Calibration**.
2. Set the voltage source to the minimum voltage.
 - 2.1. **F122 AI2 maximum negative value:**
Apply the value from parameter E111[1] for parameter F122.
 - 2.2. **F124 AI2 maximum negative % value:**
Define the associated value for F122 in % in parameter F124.
3. Set the voltage source to the maximum voltage.
 - 3.1. **F121 AI2 maximum positive value:**
Apply the value from parameter E111[1] for parameter F121.
 - 3.2. **F125 AI2 maximum positive % value:**
Define the associated value for F121 in % in parameter F125.
4. Set the voltage source to 0 V voltage.
 - 4.1. **F120 AI2 zero point offset:**
Apply the value from parameter E111[1] for parameter F120.
5. **F123 AI2 deadband:**
Optionally define a deadband to compensate for any noise of the 0 V voltage at the analog input.

Scaling analog input AI2

1. Select the **Drive Based Center Winder application wizard** > **Analog inputs: Scaling** > **Analog input 2: Scaling**.
2. **G263 AI2 scaling:**
Select the scaling for the analog input.
 - 2.1. If you want to use the value unscaled, select 0: Without scaling.
 - 2.2. If you want to use the value unsigned, select 1: Absolute value.
 - 2.3. If you want to use the value inverted, select 2: Inverting.
 - 2.4. If you want to scale the value using a curve, select 3: X/Y characteristic.
⇒ Parameters G264 and G265 for scaling the analog input using a curve are displayed.
3. **G264 AI2 X scaling, G265 AI2 Y scaling:**
If you have selected 3: X/Y characteristic for G263, define the value pairs of the calibrated value and scaled value for the scaling of the analog input.
⇒ The scaling of the analog input is completed.
⇒ The scaled value of analog input AI2 is displayed in G271.

5.7.1.1.3 Parameterizing analog input AI3

Parameterize the analog input as a voltage source by defining a time constant for the associated filter and calibrating using the maximum positive, maximum negative and 0 V voltage. After that, you can scale the analog input as needed.

Parameterizing analog input AI3

1. Select the **Terminals wizard** > **Analog input 3**.
2. **F33 AI3 lowp. filter:**
If the quality of the signal requires it, adjust the time constant for the filter accordingly.

Calibrating analog input AI3

1. Select the **Terminals wizard** > **Analog input 3** > **Analog input 3: Calibration**.
2. Set the voltage source to the minimum voltage.
 - 2.1. **F132 AI3 maximum negative value:**
Apply the value from parameter E112[1] for parameter F132.
 - 2.2. **F134 AI3 maximum negative % value:**
Define the associated value for F132 in % in parameter F134.
3. Set the voltage source to the maximum voltage.
 - 3.1. **F131 AI3 maximum positive value:**
Apply the value from parameter E112[1] for parameter F131.
 - 3.2. **F135 AI3 maximum positive % value:**
Define the associated value for F131 in % in parameter F135.
4. Set the voltage source to 0 V voltage.
 - 4.1. **F130 AI3 zero point offset:**
Apply the value from parameter E112[1] for parameter F130.
5. **F133 AI3 deadband:**
Optionally define a deadband to compensate for any noise of the 0 V voltage at the analog input.

Scaling analog input AI3

1. Select the **Drive Based Center Winder application wizard** > **Analog inputs: Scaling** > **Analog input 3: Scaling**.
2. **G266 AI3 scaling:**
Select the scaling for the analog input.
 - 2.1. If you want to use the value unscaled, select 0: Without scaling.
 - 2.2. If you want to use the value unsigned, select 1: Absolute value.
 - 2.3. If you want to use the value inverted, select 2: Inverting.
 - 2.4. If you want to scale the value using a curve, select 3: X/Y characteristic.
⇒ Parameters G267 and G268 for scaling the analog input using a curve are displayed.
3. **G267 AI3 X-value scaling, G268 AI3 Y-value scaling:**
If you have selected 3: X/Y characteristic for G266, define the value pairs of the calibrated value and scaled value for the scaling of the analog input.
⇒ The scaling of the analog input is completed.
⇒ The scaled value of analog input AI3 is displayed in G272.

5.7.1.2 Velocity – Parameterizing sources

If you are obtaining the set value for velocity from external sources for applications of the Drive Based type, enter this as described below.

If you transmit data via fieldbus, the set value can either be obtained directly from an internal parameter or indirectly by reading out a parameter (such as with PID controllers).

Set velocity – Parameterizing the source

If you are obtaining the set value for velocity from an external source, enter the source for the main set value.

- ✓ Use the motion command MC_MoveSpeed or MC_MoveVelocity.
- 1. Select the Drive Based application wizard > Data sources > External velocity: Data source.
- 2. G461 Source external velocity:
 - 2.1. If an analog input acts as the source, select the corresponding input.
 - 2.2. If you are transmitting data via fieldbus and would like to configure the value as the general data source, select 4: Parameter G460.
 - 2.3. If the set value is read out indirectly via a parameter, select 5: Indirect read parameter G811.
- 3. G460 External velocity:
If you have selected 4: Parameter G460 for G461, enter the set velocity here.
- 4. G811 Indirect read external velocity:
If you have selected 5: Indirect read parameter G811 for G461, enter the associated parameter coordinate here.

Additional velocity – Parameterizing the source

If you also want to regulate the set velocity, enter the source for the additional set value.

- ✓ Use the motion command MC_MoveSpeed or MC_MoveVelocity.
- ✓ You obtain the set velocity from an external source.
- 1. Select the Drive Based application wizard > Data sources > External additional velocity: Data source.
- 2. G464 Source external additional velocity:
 - 2.1. If an analog input acts as the source, select the corresponding input.
 - 2.2. If you are transmitting data via fieldbus and would like to configure the value as the general data source, select 4: Parameter G463.
 - 2.3. If the set value is read out indirectly via a parameter, select 5: Indirect read parameter G812.
- 3. G463 External additional velocity:
If you have selected 4: Parameter G463 for G464, enter the set velocity here.
- 4. G812 Indirect read additional external velocity:
If you have selected 5: Indirect read parameter G812 for G463, enter the parameter coordinate here.

5.7.1.3 Velocity override – Parameterizing the source

If you would like to use a velocity override to scale the velocity profile of your motion commands, enter the source for the velocity override.

If you transmit data via fieldbus, the set value can either be obtained directly from an internal parameter or indirectly by reading out a parameter (such as with PID controllers).

1. Select the Drive Based application wizard > Data sources > Velocity override: Data source.
2. G467 Source velocity override:
 - 2.1. If an analog input acts as the source, select the corresponding input.
 - 2.2. If you are transmitting data via fieldbus and would like to configure the value as the general data source, select 4: Parameter G466.
 - 2.3. If the set value is read out indirectly via a parameter, select 5: Indirect read parameter G813.
3. G466 Velocity override:
If you have selected 4: Parameter G466 for G467, enter the set velocity here.
4. G813 Indirect read velocity override:
If you have selected 5: Indirect read parameter G813 for G467, enter the parameter coordinate here.

5.7.1.4 Torque/Force – Parameterizing sources

If you have selected the motion command MC_TorqueControl for Drive Based type applications and obtain set values from external sources, enter the sources for the set torque/force and velocity bracketing.

If you transmit data via fieldbus, the set value can either be obtained directly from an internal parameter or indirectly by reading out a parameter (such as with PID controllers).

Set torque/force – Parameterizing the source

If you obtain the set value for torque/force from an external source, enter the source for the set torque/force.

✓ You are using the 9: MC_TorqueControl motion command.

1. Select the Drive Based application wizard > Data sources > Set torque/force, velocity bracketing: Data source.
2. G470 Source torque/force reference:
 - 2.1. If an analog input acts as the source, select the corresponding input.
 - 2.2. If you are transmitting data via fieldbus and would like to configure the value as the general data source, select 4: Parameter G469.
 - 2.3. If the set value is read out indirectly via a parameter, select 5: Indirect read parameter G814.
3. G469 Torque/Force reference:
If you have selected 4: Parameter G469 for G470, define the value for set torque/force here. The value relates to C03 Maximum positive torque/force and C05 Maximum negative torque/force.
4. G814 Indirect read torque/force reference:
If you have selected 5: Indirect read parameter G814 for G470, define the associated parameter coordinate here.
5. G500 Torque/force ramp removal, G501 Torque/force ramp removal:
Define the ramps for the build-up or reduction of torque/force.

Velocity bracketing – Parameterizing the source

If you obtain values for limiting the velocity from an external source, enter the source for the velocity bracketing.

✓ You are using the 9: MC_TorqueControl motion command.

1. Select the Drive Based application wizard > Data sources > Set torque/force, velocity bracketing: Data source.
2. G473 Source velocity bracketing positiv:
 - 2.1. If an analog input acts as the source, select the corresponding input.
 - 2.2. If you are transmitting data via fieldbus, select 4: Parameter G472.
3. G472 Velocity bracketing positiv:

If you have selected 4: Parameter G472 for G473, define the maximum limit that you want to permit for your mechanical system.
4. G476 Source velocity bracketing negative:
 - 4.1. If an analog input acts as the source, select the corresponding input.
 - 4.2. If you are transmitting data via fieldbus, select 4: Parameter G475.
5. G475 Velocity bracketing negative:

If you have selected 4: Parameter G475 for G476, define the maximum limit that you want to permit for your mechanical system here.

Information

If you define the velocity bracketing using G472 or G475, you should allow the control enough room. Therefore, select a value for the velocity bracketing that is greater than 1%. Values less than 1% are internally set to 1% and values greater than 100% are internally set to 100%. G472 and G475 refer to I10 Maximal speed.

5.7.2 Parameterizing velocity, torque/force operating mode

The following graphic shows the signal flows of velocity, torque/force operating mode. The elements shown in a lighter shade are optional.




Fig. 3: Velocity, torque/force operating mode: Signal flows

In the velocity, torque/force operating mode, an individual motion command is permanently stored on the drive controller with the associated set values. This way, you can operate simple applications such as belt drives, pumps or fans with set velocity. You can use set torque or set force to operate simple applications such as screwing machines, winders or presses.

In velocity, torque/force operating mode, drive controllers are controlled through either a fieldbus or mixed operation of a fieldbus and terminals.

Information

The motion variables available for this operating mode that you configure in the software depend on your application case as well as on additional project-specific factors such as the use of a controller or the type of data transmission (fieldbus, terminals).

Information

If an analog input serves as the source for the application, parameterize, calibrate and scale the respective analog input as described in [Parameterizing analog inputs](#) [37].

Proceed as follows ...

- Activate velocity, torque/force operating mode.
- Velocity operating mode
 - Select either the motion command MC_MoveSpeed or MC_MoveVelocity and parameterize the start signal for MC_MoveVelocity if necessary.
 - If you obtain the set velocity from an external source, parameterize the main set value and, if applicable, an additional set value.
 - If you want to switch between fixed set velocities, add the fixed set values for the velocity.
 - Store fixed values for acceleration, deceleration and jerk.
 - You can optionally limit the maximum velocity.
- Torque/force operating mode
 - Select the motion command MC_TorqueControl.
 - Parameterize the associated set values and limits.

5.7.2.1 Activate velocity, torque/force operation mode

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
 2. Select the Drive Based application wizard.
 3. Operating modes area:
Activate the Velocity, torque/force operating mode option.
- ⇒ The corresponding wizards are displayed.

5.7.2.2 Parameterizing velocity operating mode

In the velocity operating mode, two motion commands are available for moving the axis with a set velocity: MC_MoveSpeed and MC_MoveVelocity. Depending on your drive project, you can either specify the set velocity using set values or fixed set values. For both approaches, you also store fixed values for acceleration, deceleration and jerk.

Work with set values if your drive project requires continuous value changes – e.g. for conveyor belts, which must assume varying velocities. The set values are either fed in here using a potentiometer, a fieldbus or the analog output group of a controller.

Work with fixed set values if your drive project requires switching between different fixed and unchanging set values – e.g. for a three-stage pump setting. The fixed set values are stored directly in the software and are selected by a controller either via fieldbus or using the controller's own binary output group. As an alternative, the fixed set values can be defined using a BCD coded switch.

5.7.2.1 Velocity – Defining the motion command

In the velocity operating mode, two motion commands are available for moving the axis with a set velocity: MC_MoveSpeed and MC_MoveVelocity. The parameterization of set and fixed set values is identical for both commands.

For MC_MoveSpeed, velocity control is active and the set and fixed set values are processed automatically with the enable signal of the power unit. For MC_MoveVelocity, position control is active and the set and fixed set values are processed by a start signal, which you must parameterize manually.

Selecting the motion command

1. Select the Drive Based application wizard > Velocity, torque/force operating mode.
2. D01 Command:
Select a motion command in order to move the axis with a set velocity.
 - 2.1. If you want to move the axis with velocity control, select 1: MC_MoveSpeed.
 - 2.2. If you want to move the axis with position control, select 2: MC_MoveVelocity.

MC_MoveVelocity – Parameterizing the start signal

Parameterize the signal source for the start signal used to start the motion command MC_MoveVelocity.

✓ You have selected MC_MoveVelocity for D01 Command.

1. Select the Drive Based application wizard > Data sources > Application digital signals: Data source.
2. I100 Source execute:
 - 2.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 2.2. If the control word I210 of the application acts as the signal source, select 2: Parameter.

5.7.2.2.2 Velocity – Parameterizing set values

If continuous value changes are necessary in your drive project, configure corresponding set values for the velocity.

Information

Before you start parameterizing the operating mode-specific motion variables, parameterize the general motion variables and signal sources. If you obtain set values for velocity, velocity override or torque/force for your drive project from external sources, proceed as described in the chapter [General motion variables and signal sources](#) [► 36].

Velocity – Parameterizing the main set value

If you obtain the set velocity from an external source, enter the source for the main set value.

1. Select the Drive Based application wizard > Velocity, torque/force operating mode > Main set value.
2. D30 Source main reference value:
If you want to obtain the set value from an external source, select 1: Parameter G462.
3. D33 Inverting main reference value:
If you want to change the direction of rotation of the drive and apply the previously configured main set value, select 1: Active.
4. D232 Maximum positive torque/force:
If you also want to limit the torque/force using the operating mode, enter the maximum permitted positive value for torque/force.
5. D233 Maximum negative torque/force:
If you also want to limit the torque/force using the operating mode, enter the maximum permitted negative value for torque/force.

Velocity – Parameterizing the additional set value

If you also want to regulate the main set value for the set velocity, enter the source for the additional set value.

1. Select the Drive Based application wizard > Velocity, torque/force operating mode > Additional reference value.
2. D31 Source additional reference value:
Select 1: Parameter G465.
3. D34 Inverting additional reference value:
If you want to change the direction of rotation of the drive and apply the previously configured additional set value, select 1: Active.

5.7.2.2.3 Velocity – Parameterizing fixed set values

If switching between different, fixed and unchanging set velocities is a necessary part of your drive project, add them directly to the software as fixed set values. A controller either accesses the values via fieldbus or selects them with binary coding using corresponding digital inputs. You can add a maximum of 15 fixed set values.

Velocity – Parameterizing fixed set values

If you obtain the set velocity from fixed set values, enter the fixed set values as the source for the main set value.

1. Select the Drive Based application wizard > Velocity, torque/force operating mode > Main set value.
2. D30 Source main reference value:
If you want to obtain the set value from an external source, select 2: Fixed reference value D20.
3. D232 Maximum positive torque/force:
If you also want to limit the torque/force using the operating mode, enter the maximum permitted positive value for torque/force.
4. D233 Maximum negative torque/force:
If you also want to limit the torque/force using the operating mode, enter the maximum permitted negative value for torque/force.

Velocity – Storing fixed set values

If you are working with fixed set values, store them in the software.

1. Select the Drive Based application wizard > Velocity, torque/force operating mode > Fixed reference values: Velocity.
2. D12 Fixed velocity reference value:
You can store a total of 15 fixed set values in the parameter elements D12[0] – D12[14].
Element D12[15] is pre-assigned with I10 Maximal speed by the system.
3. To parameterize the selection of fixed set values, click on the Selection link.
⇒ The Fixed set value for velocity: Selection wizard opens.

Velocity – Parameterizing the fixed set value selection

If you are working with fixed set values, define whether they are selected via fieldbus or using digital inputs.

✓ You are in the Fixed set value for velocity: Selection wizard.

1. D05 Source selection fixed velocity reference value:
Define whether the fixed set values are selected via fieldbus or using the digital inputs.
 - 1.1. If you are selecting fixed set values using a fieldbus, select 1: Parameter D13.
 - 1.2. If you are selecting fixed set values using the digital inputs, select 2: Digital inputs.
2. D13 Control byte fixed velocity reference value:
If you have selected 1: Parameter D13 for D05, this parameter is written by the controller. The displayed number corresponds to the respective D12 parameter element configured previously.
3. D04 Source binary selection fixed velocity reference value:
If you have selected 2: Digital inputs for D05, configure the signal sources for parameter elements D04[0] – D04[7].

5.7.2.2.4 Acceleration, deceleration, jerk – Parameterizing fixed values

Parameterize at least one fixed value each for acceleration, deceleration and jerk. You need the fixed values for your drive project regardless of whether you specify the set velocity using set values or fixed set values.

5.7.2.2.4.1 Acceleration – Parameterize fixed value

If you have stored one or more set or fixed set values for the velocity, you must parameterize a fixed value for the acceleration.

Acceleration – Storing fixed values

1. Select the Drive Based application wizard > Velocity, torque/force operating mode > Fixed values: Acceleration.
2. D14 Fixed acceleration value:
You can store a total of 15 fixed set values in the parameter elements D14[0] – D14[14].
Element D14[15] is pre-assigned with I11 Maximal acceleration by the system.
3. To parameterize the selection of fixed values, click on the Selection link.
⇒ The Fixed value for acceleration: Selection wizard opens.

Acceleration – Parameterizing the fixed value selection

Define whether the fixed values are selected via fieldbus or using the digital inputs.

- ✓ You are in the Fixed value for acceleration: Selection wizard.
1. D07 Source selection fixed acceleration value:
Define whether the fixed values are selected via fieldbus or using the digital inputs.
 - 1.1. If you are selecting fixed values using a fieldbus, select 1: Parameter D15.
 - 1.2. If you are selecting fixed values using the digital inputs, select 2: Digital inputs.
 2. D15 Control byte fixed acceleration value:
If you have selected 1: Parameter D15 for D07, this parameter is written by the controller. The displayed number corresponds to the respective D14 parameter element configured previously.
 3. D06 Source binary selection fixed acceleration value:
If you have selected 2: Digital inputs for D07, configure the signal sources for parameter elements D07[0] – D07[7].

5.7.2.2.4.2 Delay – Parameterize fixed value

If you have stored one or more set or fixed set values for the velocity, you must parameterize a fixed value for the deceleration.

Deceleration – Storing fixed values

1. Select the Drive Based application wizard > Velocity, torque/force operating mode > Fixed values: Deceleration.
2. D16 Fixed deceleration value:
You can store a total of 15 fixed set values in the parameter elements D16[0] – D16[14].
Element D16[15] is pre-assigned with I11 Maximal acceleration by the system.
3. To parameterize the selection of fixed values, click on the Selection link.
⇒ The Fixed value for deceleration: Selection wizard opens.

Deceleration – Parameterizing the fixed value selection

Define whether the fixed values are selected via fieldbus or using the digital inputs.

✓ You are in the **Fixed value for deceleration: Selection wizard**.

1. D09 Source selection fixed deceleration value:

Define whether the fixed values are selected via fieldbus or using the digital inputs.

1.1. If you are selecting fixed set values using a fieldbus, select 1: Parameter D17.

1.2. If you are selecting fixed set values using the digital inputs, select 2: Digital inputs.

2. D17 Control byte fixed deceleration value:

If you have selected 1: Parameter D17 for D09, this parameter is written by the controller. The displayed number corresponds to the respective D16 parameter element configured previously.

3. D08 Source binary selection fixed deceleration value:

If you have selected 2: Digital inputs for D09, configure the signal sources for parameter elements D08[0] – D08[7].

5.7.2.4.3 Jerk – Parameterize fixed value

If you have stored one or more set or fixed set values for the velocity, you must parameterize a fixed value for the jerk.

Jerk – Storing fixed values

1. Select the **Drive Based application wizard > Velocity, torque/force operating mode > Fixed values: Jerk**.

2. D18 Fixed jerk value:

You can store a total of 15 fixed set values in the parameter elements D18[0] – D18[14].

Element D18[15] is pre-assigned with I16 Maximal jerk by the system.

3. To parameterize the selection of fixed values, click on the **Selection** link.

⇒ The **Fixed value for jerk: Data source wizard** opens.

Jerk – Parameterizing the fixed value selection

✓ You are in the **Fixed value for jerk: Data source wizard**.

1. D19 Control byte fixed jerk value:

This parameter is written by the controller. The displayed number corresponds to the respective D18 parameter element configured previously.

5.7.2.2.5 Limit velocity

If you move the axis with a set velocity and use a fieldbus, you have the option of limiting the velocity in ongoing operation.

1. Select the **Drive Based application wizard > Velocity, torque/force operating mode > Limit: Velocity; operating mode: Velocity, torque/force**.

2. D244 Source activation positive v limitation:

If you are transmitting the maximum positive velocity via fieldbus, select 2: Parameter.

3. D242 Activation positive velocity limitation:

Activate the positive velocity limit by setting the parameter to 1: Active.

4. D245 Source activation negativ v limitation:

If you are transmitting the maximum negative velocity via fieldbus, select 2: Parameter.

5. D243 Activation limitation negativ velocity:

Activate the negative velocity limit by setting the parameter to 1: Active.

5.7.2.3 Parameterizing torque/force operating mode

In the torque/force operating mode, the motion command MC_TorqueControl is available for moving the axis with a set torque/force. Unlike in velocity operating mode, a distinction is not made between set values and fixed set values. You only define set values, limiting values and the associated sources.

The motion command MC_TorqueControl is activated with the enable signal of the power unit, thus eliminating the parameterization of a start signal.

Information

Before you start parameterizing the operating mode-specific motion variables, parameterize the general motion variables and signal sources. If you obtain set values for velocity, velocity override or torque/force for your drive project from external sources, proceed as described in the chapter [General motion variables and signal sources](#) [► 36].

5.7.2.3.1 Torque/force – Parameterize values

1. Select the Drive Based application wizard > Velocity, torque/force operating mode.
2. D01 Command:
Select 3: MC_TorqueControl.
3. D232 Maximum positive torque/force:
If you also want to limit the torque/force using the operating mode, enter the maximum permitted positive value for torque/force.
4. D233 Maximum negative torque/force:
If you also want to limit the torque/force using the operating mode, enter the maximum permitted negative value for torque/force.

Information

The mechanical torque/force limit is executed using the axis model (limit: C03 and C05). Additional limiting through the operating mode is optional and applies to the maximum permitted values for torque/force that you defined in the axis model (reference values: C03, C05).

5.7.3 Parameterizing motion block operating mode

The following graphic shows the signal flows of motion block operating mode. The elements shown in a lighter shade are optional.




Fig. 4: Motion block operating mode: Signal flows

In the motion block operating mode, motion profiles are permanently stored on the drive controller in the form of motion blocks. A motion block includes a PLCopen-compliant motion command which defines the basic motion method of the axis. The associated motion variables supply specifications on velocity, acceleration, deceleration and jerk, which the motion core of the drive controller uses to calculate the motion profile.

Motion blocks can be selected individually using motion block numbers and they can be linked with each other, i.e. they are automatically processed in succession. In motion block linking, a linear, defined sequence as well as branches based on conditions are both possible for the further motion block continuation. You can parameterize specifications on velocity override and brake for each motion block individually.

In motion block operating mode, drive controllers are either activated using a fieldbus or by a mixed operation of a fieldbus and terminals. The number of axes and motion blocks used determines the memory you need for your project.

Information

The motion variables available for this operating mode that you configure in the software depend on your application case as well as on additional project-specific factors such as the use of a controller or the type of data transmission (fieldbus, terminals).

Information

If an analog input serves as the source for the application, parameterize, calibrate and scale the respective analog input as described in [Parameterizing analog inputs \[► 37\]](#).

Proceed as follows ...

- Activate motion block operating mode.
- Parameterize one or more motion blocks.
- Test the individual motion blocks using the motion block control panel.
- If you want to link motion blocks with each other, define subsequent motion blocks and triggers for continuation.
- Test the motion block links using the motion block control panel.
- Define how the motion blocks are started.
- Parameterize the source for the continue, reset and, if necessary, stop signals.

5.7.3.1 Activating motion block operating mode

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
 2. Select the Drive Based application wizard.
 3. Operating modes area:
Activate the Motion block operating mode option.
- ⇒ The corresponding wizards are displayed.

5.7.3.2 Limiting the torque/force using the operating mode

Basic torque/force limiting using the mechanical system takes place in the project configuration of the axis model. As an option, you can parameterize an additional torque/force limit via the operating mode, either for all motion blocks together or for each motion block individually.

1. Select the Drive Based application wizard > Motion block operating mode > Motion block > Torque/force limit: Data source.
2. J08 Source maximum T/F:
 - 2.1. If you would like to specify the maximum value from the axis model for all motion blocks centrally, select 3: 100%.
 - 2.2. If you would like to specify the maximum value using the operating mode for all motion blocks centrally, select 1: Parameter J09.
 - 2.3. If you would like to define an individual maximum value for each motion block, select 2: Parameter J25.
3. J09 Maximum torque/force:
If you have selected 1: Parameter J09 for J08, enter the maximum permitted value for torque/force.
4. If you have selected 2: Parameter J25 for J08, enter the maximum permitted value for torque/force during the parameterization of individual motion blocks in J25 Maximum torque/force.
To do so, proceed as described in the chapter [Parameterizing the motion block](#) [► 55].

Information

The mechanical torque/force limit is executed using the axis model (limit: C03 and C05). Additional limiting through the operating mode is optional and applies to the maximum permitted values for torque/force that you defined in the axis model (reference values: C03, C05).

5.7.3.3 Parameterizing motion blocks

Before you start parameterizing the individual motion blocks, determine whether you also want to limit torque/force using the operating mode. You have already defined the maximum value for torque/force in the axis model, but you have the option of specifying an additional limit for all motion blocks together or for each motion block individually.

For each motion block, select an appropriate motion command and parameterize the associated motion variables. You can copy parameterized motion blocks completely to create other motion blocks.

Then, test the parameterization of the individual motion blocks using [Motion block control panel](#).

Information

Before you start parameterizing the operating mode-specific motion variables, parameterize the general motion variables and signal sources. If you obtain set values for velocity, velocity override or torque/force for your drive project from external sources, proceed as described in the chapter [General motion variables and signal sources](#) [► 36].

5.7.3.3.1 Parameterizing the motion block

To parameterize a motion block, first select the desired motion command, then parameterize the associated motion variables according to your drive project.

✓ You have activated motion block operating mode.

1. Select the Drive Based application wizard > Motion block operating mode.
 - ⇒ By default, 16 motion blocks are available to you which you can parameterize individually.
2. To parameterize the first motion block, click its motion block number in the Number column.
 - ⇒ The details view for the first motion block is displayed.
3. J10 Name:
Define the name of the motion block.
4. J11 Command:
Select the desired motion command.
 - ⇒ The associated parameters are displayed.
5. J25 Maximum torque/force:
If you have also limited torque/force using the operating mode and have selected 2: Parameter J25 for J08, enter the maximum permitted value for torque/force for each motion block.
6. Parameterize the selected motion command based on its associated parameter.

Information

Using J28 Velocity override enable, you activate the scaling of the velocity profile of a motion block. For motion blocks with final velocity, the velocity override influences J14 Velocity and J18 End velocity equally, i.e. the relationship between J14 and J18 remains the same.

Information

Use J21 Command Mode to define how the motion block, as the subsequent motion block, is executed for motion block linking. If you select 0: Abort current command, the ongoing motion block is interrupted when the trigger is activated and the subsequent motion block is executed immediately. If you select 1: Start when current command has finished, the ongoing motion block is completed first before the subsequent motion block is started.

Moving the axis with a set velocity

✓ You have selected the motion command MC_MoveSpeed or MC_MoveVelocity.

1. J30 Source velocity:
Select the source from which you will obtain the set value for the velocity.
 - 1.1. If you obtain the set value via fieldbus, select 0: Parameter J14.
 - 1.2. If you obtain the set value from an external source, select 1: Parameter G462.
2. J14 Velocity:
If you have selected 0: Parameter J14 for J30, enter the set velocity.
3. J15 Acceleration, J16 Deceleration, J17 Jerk:
Enter the set values for acceleration, deceleration and jerk.
4. J28 Velocity override enable:
If you would like to apply a velocity override to the motion block, select 1: Active.
5. J21 Command Mode:
Select the mode in which the selected motion block, as the subsequent motion block, is to be executed.

Moving the axis with a set torque/force

- ✓ You have selected the motion command MC_TorqueControl.
- 1. J32 Source reference torque/force:
Select the source from which you will obtain the set value for torque/force.
 - 1.1. If you obtain the set value via fieldbus, select 0: Parameter J26.
 - 1.2. If you obtain the value from external sources, select 1: Parameter G471.
- 2. J26 Torque/Force reference:
If you have selected 0: Parameter J26 for J32, enter the set torque or set force.
- 3. J16 Deceleration, J17 Jerk:
Enter the set values for deceleration and jerk.
- 4. J28 Velocity override enable:
If you would like to apply a velocity override to the motion block, select 1: Active.
- 5. J21 Command Mode:
Select the mode for the motion block in which it, as the subsequent motion block, is to be executed.

Moving the axis to the set position

- ✓ You have selected the motion command MC_MoveAbsolute, MC_MoveAdditive or MC_MoveRelative.
- 1. J13 Position:
Enter the absolute or relative position to which the axis is to be moved.
- 2. J14 Velocity:
Enter the set value for the velocity.
- 3. J15 Acceleration, J16 Deceleration, J17 Jerk:
Enter the set values for acceleration, deceleration and jerk.
- 4. J18 End velocity:
Enter the final velocity with which you want to reach the set position J13.
- 5. J24 Waiting time at the end:
If a subsequent motion block is not to be started immediately, enter the wait time at the end of the motion block.
- 6. J27 Engage brake at the end:
If you have parameterized a brake and it is to engage at the end of the motion block, select 1: Active.
- 7. J28 Velocity override enable:
If you would like to apply a velocity override to the motion block, select 1: Active.
- 8. J21 Command Mode:
Select the mode for the motion block in which it, as the subsequent motion block, is to be executed.

Information

For motion blocks with a final velocity that is not 0, a change of travel direction by the subsequent motion block is not permitted.

Referencing the axis

- ✓ You have selected the motion command MC_Home.
- 1. J30 Referencing type:
Indicates what referencing type you have parameterized for the referencing process.
- 2. J16 Deceleration, J17 Jerk:
Enter the set values for deceleration and jerk with which the axis is stopped if referencing is interrupted by a control panel.
- 3. J24 Waiting time at the end:
If a subsequent motion block is not to be started immediately, enter the wait time at the end of the motion block.
- 4. J27 Engage brake at the end:
If you have parameterized a brake and it is to engage at the end of the motion block, activate J27.
- 5. J28 Velocity override enable:
If you have parameterized a velocity override and would like to apply it to the motion block, select 1: Active.

Information

To parameterize the referencing process, click the [Referencing](#) link and proceed as described in the chapter [Referencing absolute position](#) [► 30].

Stopping the axis

- ✓ You have selected the motion command MC_Halt or MC_Stop.
- 1. J16 Deceleration, J17 Jerk:
Enter the set values for deceleration and jerk with which the axis is stopped.
- 2. J24 Waiting time at the end:
If a subsequent motion block is not to be started immediately, enter the wait time at the end of the motion block.
- 3. J27 Engage brake at the end:
If you have parameterized a brake and it is to engage at the end of the motion block, activate J27.

5.7.3.3.2 Parameterizing the motion block duration

If you are using an endless motion command to move the axis with a set velocity or set torque/force, for example, you can switch to a subsequent motion block after a defined time using the additional motion block duration function and an indirect trigger.

- ✓ You are using an endless motion command.
- 1. Select the Drive Based application wizard > Motion block operating mode > Subsequent motion block > Indirect trigger: Data source.
- 2. Activate the Motion block duration option.
 - ⇒ The additional function is activated and the associated parameter J452 FSM block duration is shown in the Motion block wizard.
- 3. Click on the Motion block link.
 - ⇒ The Motion block wizard opens.
- 4. Number:

Use the arrow keys to select the number of the motion block for which you would like to define a motion block duration.
- 5. J452 FSM block duration:

Enter the duration for which the motion block is to be executed.

Information

As soon as the motion block duration is reached, the information is stored in bit 0 of parameter J453 FSM end of block duration. To continue on to a subsequent motion block once the motion block duration is reached, parameterize a subsequent motion block using the interrupt signal with an indirect trigger as described in [Parameterizing the subsequent motion block with a trigger](#) [► 60].

5.7.3.3.3 Copying a motion block

To make parameterization of similar motion blocks easier, you can apply the values from existing motion blocks.

- ✓ You are in the Motion block wizard.
- ✓ You have parameterized at least one motion block.
- 1. Number:

Select the number of the motion block to which you want to copy the values from an existing motion block.
- 2. Apply from:

Click on Apply from and select the existing motion block whose values you want to copy.
- 3. Confirm by clicking on OK.
 - ⇒ The values of the existing motion block are applied to the current motion block.
- 4. Adjust the copied values, such as J10 Name, if necessary.

5.7.3.3.4 Testing the motion block parameterization

Motion block control panel provides all functions you need to test the parameterization of individual motion blocks.

WARNING!

Injury to persons and material damage due to axis movement!

When you activate the control panel, DriveControlSuite gives you sole control of the motions of the axis. If you are using a controller, it no longer monitors the axis movements after the control panel is activated. The controller cannot intervene to prevent collisions. The controller takes over control again when the control panel is deactivated, which can cause unexpected axis movements.

- Do not switch to other windows when the control panel is active.
- Only use the control panel if you have visual contact with the axis.
- Make sure that no people or objects are within the travel range.
- For access via remote maintenance, there must be a communication link between you and a person on site with eye contact to the axis.

✓ The drive controller is switched on.

✓ You have established an online connection to the drive controller.

✓ You have parameterized at least one motion block.

1. Select the Drive Based application wizard > Motion block operating mode > Motion block control panel.
2. Click Control panel on and then Enable.
⇒ The drive is controlled using the active control panel.
3. J311 Motion block selection:
Select the motion block whose parameterization you would like to test.
4. Test the positions, velocities, accelerations and brakes and optimize your parameterization based on your test results if necessary.
5. If you want to link motion blocks with each other as subsequent motion blocks, first test the parameterization for each motion block individually to be able to rule out errors in motion block linking.
6. In order to deactivate the control panel, click Control panel off.

5.7.3.4 Parameterizing motion block linking

In order to configure rolling programs automatically, you can connect multiple motion blocks with each other in sequence. To do so, link the motion blocks in question with each other as subsequent motion blocks and enter the associated signal sources for continuation. The subsequent motion blocks that are assigned to a motion block are displayed in the motion block overview.

Then, test the linking of the individual motion blocks using [Motion block control panel](#).

5.7.3.4.1 Parameterizing subsequent motion blocks

You can define one or more possible subsequent motion blocks for each motion block. Continuation to the subsequent motion block either happens automatically at the end of the motion block or is caused by a trigger. The trigger can either be a direct trigger signal or a trigger condition that is configurable in the software (indirect trigger). Buffered subsequent motion blocks are parameterized without triggers and are intended for the case where the axis is moved to a set position in the previous motion block that is reached with the final velocity.

You can find more information on motion block linking and subsequent motion block under [Motion block](#) [► 76].

5.7.3.4.1.1 Parameterizing the subsequent motion block with a trigger

You can define up to five subsequent motion blocks that are each activated by a trigger signal or trigger condition (indirect trigger) for each motion block in the [Subsequent motion block wizard](#). Depending on the configuration, the subsequent motion block is only executed at the end of the previous motion block, or the ongoing motion block is interrupted when an interrupt signal is triggered or an interrupt condition occurs and the subsequent motion block is started.

For each subsequent motion block, define the signal sources for continuation by parameterizing either a direct trigger signal or an indirect trigger condition. You can configure multiple triggers for each motion block. Each trigger can either activate a subsequent motion block through interruption or a subsequent motion block at the end of the previous motion block. If multiple triggers are active simultaneously, the sequence continues with the subsequent motion block with the highest priority (A – E).

Information

Depending on the application case, you can either parameterize a regular subsequent motion block or a buffered subsequent motion block at the end of the previous motion block. The use of a regular subsequent motion block at the end rules out the simultaneous use of a buffered subsequent motion block for the same motion block, and vice versa. You can combine subsequent motion blocks through interruption with regular subsequent motion blocks at the end and with buffered subsequent motion blocks.

Information

J450 Source trigger and J439 Source indirect trigger are array parameters. The first element (J450[0], J439[0]) corresponds to trigger 1, the second element (J450[1], J439[1]) corresponds to trigger 2, etc.

Parameterizing the subsequent motion block at the end of motion block

Use subsequent motion blocks at the end of the motion block if you want to move the axis with a finite motion command and automatically switch to the subsequent motion block when the specified set value is reached.

The following section explains the process as an example, based on the parameterization of subsequent motion block A. For the parameterization of subsequent motion block B – E, proceed in the same manner.

- ✓ You have parameterized at least two motion blocks.
 - ✓ You are moving the axis with MC_MoveAbsolute, MC_MoveRelative or MC_MoveAdditive in the motion block to which you would like to add a subsequent motion block.
1. Select the Drive Based application wizard > Motion block operating mode > Subsequent motion block.
 2. Number:
Use the arrow keys to select the number of the motion block to which you would like to add a subsequent motion block.
 3. J281 Next motion block A at end:
If the subsequent motion block is to be executed once the motion block selected in Number has been completed, select the subsequent motion block here.
 4. J251 Source trigger next motion block A:
Select the trigger that activates continuation to the subsequent motion block.
 5. Click on the Trigger: Source link.
⇒ The Trigger: Data source wizard opens.
 6. J450[0] Source trigger:
Select the source of the trigger signal used to start the subsequent motion block.
 - 6.1. If you would like the subsequent motion block to be activated directly at the end of the previous motion block, select 1: High.
 - 6.2. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 6.3. If the subsequent motion block is to be executed when a configurable condition is fulfilled (indirect trigger), select 2: Parameter and proceed as described in the section **Parameterizing the indirect trigger**.

Information

For subsequent motion blocks at the end of the motion block, the trigger condition is only evaluated at the end of the ongoing motion block by using J281 – J285. Since the evaluation only takes place at the motion block end, J21 Command Mode does not influence when the subsequent motion block is started. The subsequent motion block always starts at the motion block end if the trigger condition is active.

Parameterizing the subsequent motion block due to interruption

Use subsequent motion blocks due to interruption if you would like to interrupt the ongoing motion block when the trigger is activated and continue to the subsequent motion block.

The following section explains the process as an example, based on the parameterization of subsequent motion block A. For the parameterization of subsequent motion block B – E, proceed in the same manner.

- ✓ You have parameterized at least two motion blocks.
 - ✓ You have selected 0: Abort current command for the subsequent motion block in J21 Command Mode.
1. Select the Drive Based application wizard > Motion block operating mode > Subsequent motion block.
 2. Number:
Use the arrow keys to select the number of the motion block to which you would like to add a subsequent motion block.
 3. J271 Next motion block A by interrupt:
If the subsequent motion block is to be executed as soon as the motion selected in Number is interrupted by an interrupt signal, select the subsequent motion block here.
 4. J251 Source trigger next motion block A:
Select the trigger that activates continuation to the subsequent motion block.
 5. Click on the Trigger: Source link.
⇒ The Trigger: Data source wizard opens.
 6. J450[0] Source trigger:
Select the source of the trigger signal that activates continuation to the subsequent motion block.
 - 6.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 6.2. If the subsequent motion block is to be executed when a configurable condition is fulfilled (indirect trigger), select 2: Parameter and proceed as described in **Parameterizing the indirect trigger**.

Information

For subsequent motion blocks due to interruption, the trigger condition is evaluated while the previous motion is still running by using J271 – J275. J21 Command Mode controls when the triggered subsequent motion block is started. When 0: Abort current command is selected, the subsequent motion block is executed immediately after the trigger condition is active. When 1: Start when current command has finished is selected, the subsequent motion block is buffered during activation of the trigger condition, but not executed until the motion block end.

Information

For motion blocks with a final velocity, you can parameterize a special case: a buffered subsequent motion block with trigger condition. To do so, use a subsequent motion block due to interruption (J271 – J275) with J21 Command Mode = 1: Start when current command has finished.

When 1: Start when current command has finished is selected, the subsequent motion block is buffered during activation of the trigger condition, but not executed until the motion block end. This enables a fluid transition to the subsequent motion block, depending on a trigger condition.

Parameterizing the indirect trigger

Parameterize the trigger condition for motion block continuation. If you parameterize a subsequent motion block that is to be triggered at the end of the previous motion block, the condition for continuation must be fulfilled before the set position is reached.

✓ You have selected 2: Parameter for J450[0] Source trigger.

1. Select the Drive Based application wizard > Motion block operating mode > Subsequent motion block > Indirect trigger: Data source.

2. J439[0] Source indirect trigger:

Activate the desired indirect trigger and enter the condition for continuation to subsequent motion block A.

2.1. If a simple parameter is used as the condition for continuation, select the BOOL notation: `Coordinate`.

2.2. If a certain bit of a simple parameter is used as the condition for continuation, select the bit notation: `Coordinate.Bit`.

2.3. If an array or record parameter is used as the condition for continuation, select the array notation: `Coordinate[Element]`.

2.4. If a certain bit of an array or record parameter is used as the condition for continuation, select the following notation: `Coordinate[Element].Bit`.

Information

Using J439, you can specify a parameter, a single bit or an element of an array parameter as the source for the indirect trigger. Possible sources for indirect triggers include individual bits of the status or control word for control via fieldbus or signals from additional functions such as motion block duration, comparator or cams.

Notation	Input format	Example
BOOL notation	<code>Coordinate</code>	J439[0] = I86 The subsequent motion block is only triggered if I86 In reference is fulfilled, i.e. if the axis is referenced.
Bit notation	<code>Coordinate.Bit</code>	J439[0] = J453.0 You use J452 FSM block duration and the triggering of the subsequent motion block is to be time-controlled. The information "Motion block duration is reached" is stored in bit 0 of J453 FSM end of block duration.
Array notation	<code>Coordinate[Element]</code>	J439[0] = I64[0] The subsequent motion block is to be triggered once the first cam position is reached. The information for the first cam is stored in array element 0 of I64 Cam result.
Combined notation	<code>Coordinate[Element].Bit</code>	—

Tab. 4: Indirect trigger: Notations

5.7.3.4.1.2 Parameterizing the buffered subsequent motion block

In the *Subsequent motion block* wizard, you can define a buffered subsequent motion block for each motion block. This means that the subsequent motion block is already loaded while the previous motion block is still being executed. Continuation therefore takes place automatically at the end of the previous motion block, without a delay and without a trigger signal.

Information

Depending on the application case, you can either parameterize a regular subsequent motion block or a buffered subsequent motion block at the end of the previous motion block. The use of a regular subsequent motion block at the end rules out the simultaneous use of a buffered subsequent motion block for the same motion block, and vice versa. You can combine subsequent motion blocks through interruption with regular subsequent motion blocks at the end and with buffered subsequent motion blocks.

Parameterizing the buffered subsequent motion block

Use a buffered subsequent motion block if you are moving the axis in the previous motion block with a set position (MC_MoveAbsolute, MC_MoveRelative, MC_MoveAdditive) and would like to transition fluidly into the next motion upon reaching the set position with the final velocity.

- ✓ You have parameterized at least two motion blocks.
 - ✓ You are moving the axis in the previous motion block with MC_MoveAbsolute, MC_MoveRelative or MC_MoveAdditive.
 - ✓ You have selected 1: Start when current command has finished for the motion block intended as the subsequent motion block in J21 Command Mode.
1. Select the Drive Based application wizard > Motion block operating mode > Subsequent motion block.
 2. Number:
Use the arrow keys to select the number of the motion block to which you would like to add a buffered subsequent motion block.
 3. J286 Buffered motion block:
Select the motion block that is to follow the motion block selected in Number without a delay or trigger signal.

Information

If you add a buffered subsequent motion block using J286 Buffered motion block, make sure that J281 Next motion block A at end up to J285 Next motion block E at end is set to -1: Inactive.

Information

For motion blocks with a final velocity, you can parameterize a special case: a buffered subsequent motion block with trigger condition. To do so, use a subsequent motion block due to interruption (J271 – J275) with J21 Command Mode = 1: Start when current command has finished.

When 1: Start when current command has finished is selected, the subsequent motion block is buffered during activation of the trigger condition, but not executed until the motion block end. This enables a fluid transition to the subsequent motion block, depending on a trigger condition.

5.7.3.4.2 Testing the motion block linking

Motion block control panel provides all functions that you need to test the motion block linking.

WARNING!

Injury to persons and material damage due to axis movement!

When you activate the control panel, DriveControlSuite gives you sole control of the motions of the axis. If you are using a controller, it no longer monitors the axis movements after the control panel is activated. The controller cannot intervene to prevent collisions. The controller takes over control again when the control panel is deactivated, which can cause unexpected axis movements.

- Do not switch to other windows when the control panel is active.
- Only use the control panel if you have visual contact with the axis.
- Make sure that no people or objects are within the travel range.
- For access via remote maintenance, there must be a communication link between you and a person on site with eye contact to the axis.

✓ The drive controller is switched on.

✓ You have established an online connection to the drive controller.

✓ You have parameterized at least one motion block.

1. Select the Drive Based application wizard > Motion block operating mode > Motion block control panel.
2. Click Control panel on and then Enable.
 - ⇒ The drive is controlled using the active control panel.
3. J311 Motion block selection:
Select the motion block whose linking with the subsequent motion block you would like to check.
4. Test the positions, velocities, accelerations and brakes and optimize your parameterization based on your test results if necessary.
5. Repeat the tests for each additional motion block for which you have defined subsequent motion blocks.
6. In order to deactivate the control panel, click Control panel off.

5.7.3.5 Parameterizing the type of motion block

Define how the motion blocks are to be started. Motion block operating mode offers the option to parameterize the direct start of up to three motion blocks without a controller. If you would like to use a controller, parameterize the start signal by defining the source for the execute signal and the source for the selection of the motion block to be started.

5.7.3.5.1 Parameterizing the direct motion block type

Motion block operating mode offers the option to parameterize the direct start of up to three motion blocks of your choice without a controller.

1. Select the Drive Based application wizard > Motion block operating mode > Motion block > Direct motion block start: Data source.
2. J80 Activation direct motion block start:
In order to activate the direct motion block start, select 1: Active.
3. J87 Selected direct motion block start 1:
Enter the number of the motion block that you would like to start directly.
4. J81 Source direct motion block start 1:
 - 4.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 4.2. If you would like to activate the motion block directly, select 2: Parameter J84.
5. J84 Direct motion block start 1:
If you have selected 2: Parameter J84 for J81 and want to start the motion block directly from DriveControlSuite, select 1: High.
6. Configure the direct start of a second and third motion block in the same way as the first motion block, if necessary.
 - 6.1. If you want to parameterize the direct start for a second motion block, repeat the steps in the same way for J88, J82 and J85.
 - 6.2. If you want to parameterize the direct start for a third motion block, repeat the steps in the same way for J89, J83 and J86.

Information

If you have configured the direct start of multiple motion blocks, they are activated with a simultaneous start signal according to your priority: J83 Source direct motion block start 3 > J82 Source direct motion block start 2 > J81 Source direct motion block start 1.

5.7.3.5.2 Parameterizing the execute signal

If you want to use a controller and start the motion block using an execute signal, define the source for the execute signal and the source for the selection of the motion block that is to be started by the execute signal.

Defining a source for the execute signal

1. Select the Drive Based application wizard > Data sources > Application digital signals: Data source.
2. I100 Source execute:

To start a motion block via a controller, select the source for the execute signal.

 - 2.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 2.2. If bit 0 of the control word I210 of the application is the source, select 2: Parameter.

Source for motion block selection

1. Select the Drive Based application wizard > Motion block operating mode > Motion block > Motion block selection: Data source.
2. J03 Source motion block selection:

To be able to select a motion block via a controller, select the source for the motion block selection signal.

 - 2.1. If the control word J02 of motion block operating mode acts as the data source, select 1: Parameter J02 and enter the number of the motion block to be started in the event of an execute signal in J02Reference motion block.
 - 2.2. If digital inputs act as the source, select 2: Digital inputs and enter the digital inputs (direct or inverted) that activate a controller or binary switch.

5.7.3.6 Parameterizing the motion block end control unit

The motion block end control unit allows you to monitor the status of up to 5 freely selectable motion blocks, making it easier for you to keep track of the motion block linking.

1. Select the Drive Based application wizard > Motion block operating mode > Motion block end control unit.
2. Activate the desired number of motion blocks to be monitored using the respective option.

⇒ Parameter J455[0] – [4] can be parameterized according to your selection.
3. J455 Move reference block:

Select the number of the motion block whose status you wish to monitor.

⇒ The state of the selected reference motion blocks can be observed in J457[0] – [4].

Information

The motion block end control unit indicates that the end of motion block has been reached (J457 = 1: High) as soon as the motion core has completed the motion command to be executed (I92 = 1: Active) and the actual motion block matches the reference motion block (J300 = J455).

If J455 is subsequently changed, the motion block chain must first be run through completely before J457 displays the correct state. If a motion block is executed several times, J457 is reset to 0: Low until the motion command is ended again.

5.7.3.7 Parameterizing the continue, reset and halt signal

To use the continue function to resume an interrupted motion block, configure the sources of the continue and reset signals. If you would like to use the motion command MC_Halt to stop a motion block during its run, also add the associated signal source here.

You can find more information on the continue function, continuable motion commands and reasons for canceling under [Continue function](#) [► 137].

1. **Select the Drive Based application wizard > Motion block operating mode > Motion block > Operating mode digital signals: Data source.**
2. **J917 Source continue:**
To use the continue function to resume interrupted motion commands, select the source for the continue signal.
 - 2.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 2.2. If the control byte J01 of the application acts as the source, select 2: Parameter J01.
⇒ Bit 2 of the control byte is set as the source.
3. **J07 Source reset motion block:**
To delete a canceled motion block from the continue memory and enable a different motion block start, enter the source for the reset signal.
 - 3.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 3.2. If the control word J01 is used as the source for the motion block operating mode, select 2: Parameter J01.
⇒ Bit 1 of the control word is set as the data source.
4. **J06 Source MC_Halt motion block:**
To be able to stop a motion block in general, select the source for the stop signal.
 - 4.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 4.2. If the control word J01 is used as the source for the motion block operating mode, select 2: Parameter J01.
⇒ Bit 0 of the control word is set as the data source.

5.7.4 Parameterizing command operating mode

The following graphic shows the signal flows of the command operating mode. The elements shown in a lighter shade are optional.




Fig. 5: Command operating mode: signal flows

In command operating mode, motion profiles are sent from a controller to the drive controller in the form of motion tasks. A motion task includes a PLCopen-compliant motion command which defines the basic motion method of the axis. The associated motion variables supply specifications on velocity, acceleration, deceleration and jerk, from which the motion core of the drive controller calculates the motion profile.

The controller coordinates the time progression and selects the motion tasks for the drive controller that the positioning, velocity and torque/force commands process and run. In the controller, you define the motion tasks. In the DS6, you parameterize the signal sources from which the drive controller receives the motion tasks from the controller.

In command operating mode, drive controllers are either activated using a fieldbus or by a mixed operation of a fieldbus and terminals.

Information

The motion variables available for this operating mode that you configure in the software depend on your application case as well as on additional project-specific factors such as the use of a controller or the type of data transmission (fieldbus, terminals).

Information

If an analog input serves as the source for the application, parameterize, calibrate and scale the respective analog input as described in [Parameterizing analog inputs](#) [► 37].

Proceed as follows ...

- Activate command operating mode.
- Optional: Limit torque/force using the operating mode.
- Parameterize the command-specific motion variables.
- Define the source for the start signal.
- Optional: Define the source for the continue signal.

5.7.4.1 Activating command operating mode

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
 2. Select the Drive Based application wizard.
 3. Operating modes area:
Activate the Command operating mode option.
- ⇒ The corresponding wizards are displayed.

5.7.4.2 Limiting the torque/force using the operating mode

Basic torque/force limiting using the mechanical system takes place in the project configuration of the axis model. As an option, you can parameterize an additional torque/force limit via the operating mode.

1. Select the Drive Based application wizard > Data sources > Torque/force limit: Data source.
2. C132 Source maximum positiv T/F, C133 Source maximum negative T/F:
Select the source for the torque/force limit.
 - 2.1. If an analog input acts as the source, select the corresponding input.
 - 2.2. If the limiting values are transmitted over a fieldbus, select 4: Parameter C232 or 4: Parameter C233.
3. If the limiting values are transmitted over a fieldbus, select Drive Based application > Command operating mode wizard.
4. J47 Maximum positive torque/force, J48 Maximum negative torque/force:
Enter the maximum permitted positive and negative values for torque/force.

Information

The mechanical torque/force limit is executed using the axis model (limit: C03 and C05). Additional limiting through the operating mode is optional and applies to the maximum permitted values for torque/force that you defined in the axis model (reference values: C03, C05).

5.7.4.3 Parameterizing command-specific motion variables

The parameters for the acceleration, deceleration and jerk motion variables are not included as standard in the process data mapping. You can either store the values for the motion variables permanently on the drive controller or add the corresponding parameters to the process data mapping in order to receive the values from the controller.

Information

Before you start parameterizing the operating mode-specific motion variables, parameterize the general motion variables and signal sources. If you obtain set values for velocity, velocity override or torque/force for your drive project from external sources, proceed as described in the chapter [General motion variables and signal sources](#) [► 36].

5.7.4.3.1 Storing motion variables: Drive controller

If you want to store the specifications for acceleration, deceleration and jerk permanently on the drive controller, check the default values in the **Command operating mode** wizard and, if necessary, adjust them to your drive project.

- ✓ You have activated command operating mode.
- ✓ Parameters J44, J45 and J46 are not part of the process data mapping.
- 1. Select the **Drive Based application wizard > Command operating mode**.
- 2. J44 Acceleration, J45 Deceleration, J46 Jerk:
Define the set values for acceleration, deceleration and jerk.
- ⇒ The specifications for acceleration, deceleration and jerk are permanently stored on the drive controller.

Information

The parameters in the **Command operating mode** wizard are written by the controller once there is an online connection between the drive controller and controller and provided that the parameters are part of the process data mapping. In this state, you can read off the values in the parameters that the drive controller receives from the controller. Using parameter J41 Motion-ID, you can identify the ongoing motion task in order to assign the status bit correctly.

5.7.4.3.2 Storing motion variables: Process data mapping

If you want to specify the settings for acceleration, deceleration and jerk via a controller, add the required parameters to both the receive process data of the drive controller and the transmit process data of the controller.

EtherCAT: Supplementing motion variables in PDO mapping

If you want to specify values for motion variables using a controller, supplement the desired parameters in the receive process data of the drive controller.

✓ You have activated command operating mode.

1. Select the **EtherCAT wizard** > Received process data RxPDO.

2. **Coordinate column:**

Enter the coordinate of the parameter that you want to apply to the process data mapping in the Coordinate column.

2.1. If you want to obtain the values for acceleration from the controller, enter J44.

2.2. If you want to obtain the values for deceleration from the controller, enter J45.

2.3. If you want to obtain the values for jerk from the controller, enter J46.

⇒ The parameter is applied to the receive process data of the drive controller.

In the **Name**, **Data type** and **Length** columns, your information about the parameters is displayed.

3. Add your changes to the process data mapping also to the transmit process data of the controller.

PROFINET: Supplementing motion variables in PZD mapping

If you want to specify values for motion variables using a controller, supplement the desired parameters in the receive process data of the drive controller.

✓ You have activated command operating mode.

1. Select the **PROFINET wizard** > Received process data RxPZD.

2. **Coordinate column:**

Enter the coordinate of the parameter that you want to apply to the process data mapping in the Coordinate column.

2.1. If you want to obtain the values for acceleration from the controller, enter J44.

2.2. If you want to obtain the values for deceleration from the controller, enter J45.

2.3. If you want to obtain the values for jerk from the controller, enter J46.

⇒ The parameter is applied to the receive process data of the drive controller.

In the **Name**, **Data type** and **Length** columns, your information about the parameters is displayed.

3. Add your changes to the process data mapping also to the transmit process data of the controller.

5.7.4.4 Parameterizing the start signal

Define the source for the execute signal in order to start a motion command selected in J40 in command operating mode.

1. Select the Drive Based application > Data sources > Application digital signals: Data source.
 2. I100 Source execute:
 - 2.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 2.2. If the control word I210 of the application acts as the source, select 2: Parameter.
- ⇒ Bit 0 of the control word is set as the data source.

5.7.4.5 Parameterizing the continue signal

To use the continue function to resume an interrupted movement command, configure the source of the continue signal. If you do not use the continue function, select a new command using J40 and start it using the start signal (execute).

You can find more information on the continue function, continuable motion commands and reasons for canceling under [Continue function \[► 137\]](#).

1. Select the Drive Based application > Command operating mode > Operating mode digital signals: Data source.
 2. J38 Source continue:

To use the continue function to resume interrupted motion commands, select the source for the continue signal.

 - 2.1. If a digital input (direct or inverted) acts as the source, select the corresponding input.
 - 2.2. If the control byte J37 for the command operating mode acts as the source, select 2: Parameter.
- ⇒ Bit 0 of the control byte is set as the source.

6 More on Drive Based?

The following chapters summarize the important terms, modules and relationships concerning Drive Based.

6.1 Drive Based – Concept

Applications such as Drive Based, which calculate and adjust the motions in the drive itself, are referred to as drive-based systems. They are either networked via a fieldbus or obtain signals and set values using analog and digital hardware inputs.

The Drive Based application provides you with a standard set of motion commands based on PLCopen, which is supplemented by your own motion commands and thus offers flexible drive-based motion control for the position, velocity and torque/force control types.

The motion commands are combined into corresponding operating modes for different applications. Depending on the selected operating mode, the motion variables required for parameterizing individual motion profiles, such as set or limit values, are recorded.

In addition, the Drive Based application provides you with various additional functions for different applications, such as jerk limitation, motion block linking, cam control unit or PID controller.

Based on all parameterized data, the motion core finally calculates an individual motion profile. Specified set values are transmitted to the control cascade, which in turn activates the motor.

Additional wizards such as control panels or jog mode help with commissioning and the configuration test or are designed for emergency operation.

The following graphic shows the components and configuration steps for the Drive Based application. The elements shown in a lighter shade are optional.




Fig. 6: Components and configuration steps

6.1.1 Operating modes

The operating modes of the Drive Based application involve command sets bundled by application for configuring individual motion profiles for production operation.

The drive functions of these operating modes include simple functions, like the position, velocity, and torque/force control types, as well as technology functions for single-axis applications.

Thanks to flexible, user-defined adjustment options for the operating modes, the Drive Based application offers a compact – yet extremely variable – scope of functions that is suitable for a wide range of application cases in drive technology. After selecting the suitable operating mode for the respective application case, users concentrate just on parameterizing the most important sequences for their application.

Note that a drive controller can only process one operating mode per axis.

6.1.1.1 Velocity, torque/force

Velocity, torque/force operating mode is suitable for simple movements in which only set values may subject to possible changes.

Typical application examples are pumps, fans, conveyor belts, or machines with higher-level position control, which output an analog set value for the axis for control and receive a corresponding position value of the axis as a response (CNC).

6.1.1.2 Motion block

In motion block operating mode, motion properties are predefined in the form of motion blocks. Special linking options allow for complete motion sequences to be set up that make it possible to execute sequences of motions quickly – regardless of whether an external controller is connected or the motion sequences are executed through digital signals.

Typical application examples are small machine automations or machine modules with predefined motion sequences.

Motion block linking

You can define one or more possible subsequent motion blocks for each motion block. Continuation to the subsequent motion block either happens automatically at the end of the motion block or is caused by a trigger. The trigger can either be a direct trigger signal or a trigger condition that is configurable in the software (indirect trigger).

For subsequent motion blocks with triggers, a distinction is made between subsequent motion blocks that are triggered at the end of the previous motion block and subsequent motion blocks that interrupt the previous motion block when an interrupt signal is triggered. The continuation can be executed by a direct or indirect trigger in either case.

Subsequent motion blocks at the end of a motion block are triggered as soon as the set value of a finite motion command is reached and the trigger is active. For subsequent motion blocks due to interruption, a finite or endless motion is interrupted and continued in the subsequent motion block as soon as the trigger is active. For example, the ongoing motion can be interrupted when a sensor or light barrier is triggered and the axis stopped.

Buffered subsequent motion blocks are parameterized without triggers and are intended for the case where the axis is moved to a set position in the previous motion block that is reached with the final velocity. In order to continue the motion fluidly and start the next motion command without a delay or standstill, the subsequent motion block is loaded in advance (buffered) while the previous motion block is still being executed. The continuation happens automatically at the end of the previous motions block.

6.1.1.3 Command

Command operating mode enables a drive controller to run parameterizable motions. In this process, a range of motion commands are processed that correspond to the behavior of the motion control blocks of the PLCopen standard.

A controller coordinates the time sequences by selecting motion commands based on PLCopen, such as MC_MoveAbsolute (move to absolute set position) or MC_MoveRelative (move relative to actual position).

Parameters such as set position, velocity or torque limit can be defined individually.

Typical application examples are individual axis movements that are communicated by a controller (PLC) to the drive controller.

6.1.2 Jog mode

For commissioning, emergency operation and maintenance or repair work, the manufacturer-specific jog mode (manual movement) is available. Using jog mode, you can move the drive independently of the controller, for example.

You can use jog mode through the operating unit of the drive controller, the jog control panel or a controller that applies the manual movement.

6.1.3 Control panels

The control panels are special wizards in DriveControlSuite, which you can use to take control of the axis. With the help of the control panels, you can manually release and move an axis even if the drive controller has no operating unit or is difficult to access.

Using control panels, you can check the connection wiring, the project configuration of your physical axis model or the parameterization of your application in the respective operating mode before you switch to normal operation.

The following control panels are available:

- Jog control panel is used to check the projected axis model in jog mode.
- Control panel motion provides you with a standard set of motion commands based on PLCopen. Via the control panel, independent of the application and fieldbus interface, you can parameterize a motion profile directly for the motion core of the axis in order to check the basic functions of the drive controller.
- Motion block control panel is used to check the parameterized motion block operating mode and provides you with all the functions you need to test the parameterization of individual motion blocks or motion block linking.
- Velocity, torque/force control panel is used to review the parameterized velocity, torque/force operating mode.

Because control panels override normal operation, they can be activated only with a deactivated enable signal and should be operated by experienced users only.

6.1.4 Motion core

Based on the projected and parameterized data, the motion core calculates a motion profile and associated detail movements as a basis for the drive controller as well as mandatory set values for the control cascade.

6.1.5 Data sources

The signals for controlling the drive controller, i.e. control signals for the start of motion, motion limits or set value specifications, can be obtained from various external sources.

A fieldbus is usually acts as the signal source, but analog or digital hardware inputs, or even mixed operation made up of the above-listed sources, can also be used to control the drive controller.

Values that are obtained from external data sources are usually adapted to the stored reference values automatically, i.e. calibrated and calculated with scaling.

6.1.5.1 Analog inputs

The analog inputs of the drive controller can serve as sources for set and actual values of the application in your drive project if, for example, you use sensors to measure motion variables such as velocities or torques/forces.

The available connections vary depending on the series and, if applicable, the terminal module of the drive controller.

For more information on the available connections, refer to the manual of the respective drive controller (see [Further information](#) [► 142]).

Information

If an analog input serves as the source for the application, parameterize, calibrate and scale the respective analog input as described in [Parameterizing analog inputs](#) [► 37].

Analog input AI1

Depending on whether analog input AI1 is used as a voltage source or current source, the following continuous function charts serve as examples (operating mode: F116).




Fig. 7: Continuous Function Chart: analog input AI1 (F116 = 0: -10V to 10V)




Fig. 8: Continuous Function Chart: analog input AI1 (F116 = 1: 0 to 20mA)




Fig. 9: Continuous Function Chart: analog input AI1 (F116 = 2: 4 to 20mA)

Analog input AI2

For analog input AI2 as a current source, the following continuous function chart serves as an example.




Fig. 10: Continuous Function Chart: analog input AI2

Analog input AI3

For analog input AI3 as a current source, the following continuous function chart serves as an example.




Fig. 11: Continuous Function Chart: analog input AI3

6.1.6 Additional functions

Each of the available operating modes can be expanded by drive-based additional functions. For example, these offer convenient monitoring of process variables such as position, velocity or torque/force (cams, comparators) or control of external process variables (PID controller).

6.1.6.1 Additional counter function

The additional counter function in Drive Based type applications provides you with up to 4 independent counters with which you can implement smaller automation tasks directly in the drive controller, such as direct or indirect control of the digital outputs.

Function

For each counter, you define a comparison value, a digital signal for increasing the counter reading and a digital signal for resetting the counter reading (comparison value: N41; increase source: N43; reset source: N46). With each rising edge of the counter signal, the counter reading is increased by 1 until the comparison value is reached (counter reading: N44). When the comparison value is reached, a status signal is issued and further counter signals are ignored until the counter reading is reset or the comparison value is increased (status: N42).




Fig. 12: Additional counter function: Example

The digital inputs of the drive controller (direct or inverted), parameters with the BOOL data type or individual bits of parameters with the BYTE, WORD or DWORD data type (example bit addressing: E49.4 for Switch on inhibit reason = STO) can serve as the source for the signals for increasing and resetting the counter status. The reset signal has priority and is executed immediately; as long as it is active, the counter reading remains at 0 and rising edges to increase the counter reading are ignored.

6.1.6.1.1 Parameterizing counters

To parameterize the additional counter function, proceed as described below.

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the Drive Based application wizard > Additional functions.
3. Activate the Counter option.
⇒ The additional function is activated and the associated wizards and parameters are displayed.
4. Select the Drive Based application wizard > Additional functions > Counters.
5. Number:
Select the desired counter and activate it using the corresponding option.
⇒ The associated parameters are displayed.
6. N41 Counter comparison value:
Define the comparison value.
7. N43 Source counter:
Select the source for the signal that increases the counter reading by 1 until the comparison value is reached.
 - 7.1. If a parameter is the source, select 2: Parameter.
 - 7.2. If a digital input (direct or inverted) acts as the source, select the corresponding input.
8. N45 Counter indirect reading:
If a parameter is used as the source for increasing the counter, define the desired coordinate, if necessary with bit addressing.
9. N46 Source reset counter reading:
Select the source for the signal that resets the counter reading to 0.
 - 9.1. If a parameter is the source, select 2: Parameter.
 - 9.2. If a digital input (direct or inverted) acts as the source, select the corresponding input.
10. N47 Reset counter reading via parameter:
If a parameter is used as the source for resetting the counter, define the desired coordinate, if necessary with bit addressing.

6.1.6.1.2 Parameterizing counters: Examples

For example, you can use the additional counter function to control the digital outputs directly or indirectly (using the additional INT32 comparator function) by reaching the comparison value.

In motion block operating mode, the additional counter function offers you options for automating motion block continuation, e.g. for repeating a motion block as often as required or interrupting a motion block after a certain number of events.

You can find more information on parameterizing motion blocks, subsequent motion blocks and triggers under [Parameterizing motion block operating mode \[► 52\]](#).

Controlling a digital output directly

To control a digital output directly via the counter, you can use the status of the counter as a source.

1. Activate the additional counter function.
 2. Select the **Counters wizard**.
 3. Parameterize the counter according to your application case.
 4. Select the status of the counter as the source for the desired digital output (e.g. DO1: F61 = N42).
- ⇒ The digital output is controlled directly via the status of the counter.

Controlling a digital output indirectly (INT32 comparator)

To indirectly control a digital output, you can use the additional counter and INT32 comparator functions in combination with each other. If you use the INT32 comparator to check whether the current counter reading fulfills a certain condition, you can control a digital output depending on the result of the comparator.

1. Activate the additional counter and comparator functions.
 2. Select the **Counters wizard**.
 3. Parameterize the counter according to your application case.
 4. Select the **INT32 comparators wizard**.
 5. Parameterize the INT32 comparator according to your application case.
 - 5.1. **C78 Source INT32 comparator:**
Select the counter reading N44 as the source for the INT32 comparator.
 6. Select the result of the INT32 comparator as the source for the desired digital output (e.g. DO1: F61 = C83).
- ⇒ The digital output is controlled indirectly via the counter reading.

Interrupting a motion block

To interrupt a motion block after a certain number of events, parameterize a motion block with an endless motion command, as well as a subsequent motion block using an interrupt with a motion command to stop an ongoing motion. The subsequent motion block is triggered by an indirect trigger, using the status of the counter as the source.

1. Activate the additional counter function.
 2. Select the **Counters** wizard.
 3. Parameterize the counter according to your application case.
 4. Select the **Motion block** wizard.
 5. Parameterize at least motion block 0 and motion block 1 according to your application.
 - 5.1. J11[0] Command:
Select for motion block 0 an endless motion command (e.g. 8: MC_MoveSpeed).
 - 5.2. J11[1] Command:
Select a motion command to stop for motion block 1 (e.g. 5: MC_Stop).
 6. For motion block 0, parameterize the motion block start (e.g. J80 = 1: Active; J81 = 3: DI1; J87 = 0).
 7. Select the **Subsequent motion block** wizard.
 8. J271[0] Next motion block A by interrupt:
Select motion block 1 as the subsequent motion block using interrupt for motion block 0.
 9. Select the **Trigger: Data source** wizard.
 10. J450[0] Source trigger:
To parameterize the status of the counter as an indirect trigger for the subsequent motion block, select 2: Parameter.
 11. Select the **Indirect trigger: Data source** wizard.
 12. J439[0] Source indirect trigger:
Activate the indirect trigger and define the status of the counter N42 as the source.
- ⇒ As soon as the counter has reached the comparison value, motion block 0 (8: MC_MoveSpeed) is interrupted by motion block 1 (5: MC_Stop) as a subsequent motion block by interrupt.

Repeating a motion block

To execute a motion block for a certain number of repetitions, parameterize a motion block with a finite motion command and a wait time at the end, as well as a subsequent motion block at the end with the 0: MC_DoNothing motion command. The subsequent motion block is triggered by an indirect trigger using the status of the counter as the source as soon as the desired number of repetitions has been reached.

Information

The status byte in the motion block operating mode indicates a motion block as ended if the motion core has successfully completed the motion command to be executed and if there is either no subsequent motion block (single motion block or end of the motion block chain) or if a wait time at the end has been parameterized for a motion block with a subsequent motion block and the subsequent motion block has not been started yet x(status byte: J302, bit 3; motion core: I92; wait time: J24).

If bit 3 of the status byte J302 is used as the source for the additional counter function in motion block operating mode, the wait time at the end should be at least twice the cycle time (cycle time: A150).

1. Activate the additional counter function.
2. Select the **Counters** wizard.
3. Parameterize the counter according to your application case.
 - 3.1. N41 Counter comparison value:
Define the desired number of motion block repetitions as the comparison value.
 - 3.2. N43 Source counter, N45 Counter indirect reading:
To count the number of times a motion block has been completed using the status byte of motion block operating mode, select N43 = 2: Parameter and N45 = J302.3.
4. Select the **Motion block** wizard.
5. Parameterize at least motion block 0 and motion block 1 according to your application.
 - 5.1. J11[0] Command:
Select a finite motion command for motion block 0 (e.g. 2: MC_MoveRelative).
 - 5.2. J24 Waiting time at the end:
Define the desired wait time at the end for motion block 0.
 - 5.3. J11[1] Command:
Select motion command 0: MC_DoNothing for motion block 1.
6. For motion block 0, parameterize the motion block start (e.g. J80 = 1: Active; J81 = 3: DI1; J87 = 0).
7. Select the **Subsequent motion block** wizard.
8. To be able to both repeat and interrupt motion block 0, parameterize two subsequent motion blocks for motion block 0.
 - 8.1. J281[0] Next motion block A at end:
Select motion block 1 as the subsequent motion block at the end of motion block 0 (0: MC_DoNothing).
 - 8.2. J282[0] Next motion block B at end:
Select motion block 0 as the subsequent motion block at the end of motion block 0 (2: MC_MoveRelative).

⇒ Subsequent motion block A is executed with higher priority than subsequent motion block B if both subsequent motion blocks are triggered simultaneously.
9. Select the **Trigger: Data source** wizard.

10. J450[0] Source trigger:
To parameterize the status of the counter as an indirect trigger for subsequent motion block A, select 2: Parameter.
11. J450[1] Source trigger:
To automatically repeat motion block 0, select 1: High as the trigger for subsequent motion block B.
⇒ Subsequent motion block B is executed until subsequent motion block A is triggered (priority: J281 > J282).
12. Select the Indirect trigger: Data source wizard.
13. J439[0] Source indirect trigger:
Activate the indirect trigger and parameterize the status of the counter N42 as the source.
⇒ As soon as the counter has reached the desired number of repetitions, motion block 1 (0: MC_DoNothing) is executed at the end of motion block 0 (2: MC_MoveRelative) due to its higher priority.

6.1.6.2 Additional motor potentiometer function

In Drive Based type applications, the additional motor potentiometer (MOP) function provides you with the option of adjusting an electromechanical potentiometer, for example for set value specification, for direct control of the analog outputs or for indirect control of the digital outputs.

Function

The motor potentiometer can be adjusted continuously via digital up and down signals, for example for specifying set values for axis movements via the output value (output value: G373). The output value can be limited by a maximum positive and a maximum negative value (limit: G362, G363; limit value reached: G374). Either the digital inputs of the drive controller or the graphical programming can serve as the source for the up and down signals (source: G364, G365). The initialization signal has priority over the up and down signals and is executed immediately; the initialization value is freely definable (source: G369; value: G366).




Fig. 13: Motor potentiometer: Linear and stepwise calculation

You can use the operating mode of the motor potentiometer to influence both the calculation of the output value and the storage behavior (operating mode: G368). The output value is calculated either linearly or in steps and can be saved either with an active enable signal, prior to the next restart of the drive controller or in non-volatile memory. The parameterized ramp (ramp: G361) applies to both the linear and stepwise calculations. With a linear calculation, the output value is changed for the duration of the incoming up or down signal. With a stepwise calculation, the output value is changed by the parameterized increment at signal input (increment: G367). If another up or down signal is received while the set value has not yet been reached, it is adjusted by the corresponding increment. If the up and down signals are active at the same time, the output value remains unchanged in both operating modes.

6.1.6.2.1 Parameterizing motor potentiometers

To parameterize the additional motor potentiometer function, proceed as described below.

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the Drive Based application wizard > Additional functions.
3. Activate the Motor potentiometer option.
⇒ The additional function is activated and the associated wizards and parameters are displayed.
4. Select the Drive Based application wizard > Additional functions > Motor potentiometer.
5. G361 Motor potentiometer ramp:
Define the ramp for calculating the output value.
6. G362 Motor potentiometer positive maximum value, G363 Motor potentiometer negative maximum value:
Define the maximum permissible positive and negative output values of the motor potentiometer.
7. G364 Source motor potentiometer up, G365 Source motor potentiometer down:
Select the sources for the up and down signals of the motor potentiometer.
 - 7.1. If the graphical programming is used as the source, select 2: Parameter.
 - 7.2. If a digital input (direct or inverted) acts as the source, select the corresponding input.
8. G368 Motor potentiometer operating mode:
Select the desired operating mode for the motor potentiometer.
 - 8.1. To calculate the output value of the motor potentiometer linearly, select 0: Linear, 2: Linear (remanent) or 4: Linear (enable-dependent), depending on the desired storage behavior.
 - 8.2. To calculate the output value of the motor potentiometer in steps, select 1: Step-by-step, 3: Step-by-step (remanent) or 5: Step-by-step (enable-dependent), depending on the desired storage behavior.
9. G367 Motor potentiometer increment:
If you calculate the output value of the motor potentiometer in steps, define the desired increment.
10. G366 Motor potentiometer initialization value:
Optionally define the desired initialization value.
11. G369 Source motor potentiometer initialization:
Select the source for the initialization signal of the motor potentiometer.

6.1.6.2.2 Parameterizing motor potentiometers: Examples

For example, you can use the additional motor potentiometer function to specify set values for the velocity, velocity override or torque/force and thus control the axis directly in local operation, e.g. during commissioning, if the controller fails or if the machine has no controller at all. Using the motor potentiometer, you can also control the analog outputs directly or the digital outputs indirectly (using the additional REAL32 comparator function).

Controlling an analog output directly

To control an analog output directly, you can use the output value of the motor potentiometer as the source.

1. Activate the additional motor potentiometer function.
 2. Select the **Motor potentiometer wizard**.
 3. Parameterize the motor potentiometer according to your application case.
 4. Select the **Analog output 1** or **Analog output 2 wizard**.
 5. F40 AO1 source, F50 AO2 source:
Select the output value of the motor potentiometer G373 as the source for the desired analog output AO1 or AO2.
 6. F41 AO1 reference value source, F51 AO2 reference value source:
If necessary, delete the reference value of the desired analog output.
- ⇒ The analog output is controlled directly via the motor potentiometer.

Controlling a digital output indirectly (REAL32 comparator)

To indirectly control a digital output, you can use the additional motor potentiometer and INT32 comparator functions in combination with each other. If you use the REAL32 comparator to check whether the output value of the motor potentiometer fulfills a certain condition, you can control a digital output depending on the result of the comparator.

1. Activate the additional motor potentiometer and REAL32 comparator functions.
 2. Select the **Motor potentiometer wizard**.
 3. Parameterize the motor potentiometer according to your application case.
 4. Select the **REAL32 comparators wizard**.
 5. Parameterize the REAL32 comparator according to your application case.
 - 5.1. C65 Source REAL32 comparator:
Select the output value of the motor potentiometer G373 as the source for the REAL32 comparator.
 6. Select the result of the REAL32 comparator as the source for the desired digital output (e.g. DO1: F61 = C75).
- ⇒ The digital output is controlled indirectly via the motor potentiometer.

Specifying a set velocity (external velocity)

To specify a set velocity via the motor potentiometer, select its output value as the source for the external velocity and use this as the set value source for the motion command.

1. Activate the additional motor potentiometer function.
 2. Select the Motor potentiometer wizard.
 3. Parameterize the motor potentiometer according to your application case.
 4. Select the External velocity: Data source wizard.
 5. G461 Source external velocity:
Select 5: Indirect read parameter G811.
 6. G811 Indirect read external velocity:
Select the output value of the motor potentiometer G373 as the source for the external velocity.
 - ⇒ The output value of the motor potentiometer serves as the source for the external velocity.
 - ⇒ The external velocity can be provided as a set value specification by accessing parameter G462.
 7. For the motion block operating mode, parameterize the motion command and set value source via parameters J11 and J30.
 - 7.1. J11 Command:
Select the motion command 4: MC_MoveVelocity or 8: MC_MoveSpeed.
 - 7.2. J30 Source velocity:
Select 1: Parameter G462 as the source for the external velocity.
 8. For the command operating mode, parameterize the motion command and set value source via parameters J40 and J52.
 - 8.1. J40 Command:
Select the motion command 4: MC_MoveVelocity or 8: MC_MoveSpeed.
 - 8.2. J52 Source velocity 1:
Select 1: Parameter G462 as the source for the external velocity.
 9. For the velocity, torque/force operating mode, parameterize the motion command and set value source via parameters D01 and D30.
 - 9.1. D01 Command:
Select the motion command 1: MC_MoveSpeed or 2: MC_MoveVelocity.
 - 9.2. D30 Source main reference value:
Select 1: Parameter G462 as the source for the external velocity.
- ⇒ The output value of the motor potentiometer serves as the set value specification; the conversion to a set velocity is carried out using maximum permissible speed l10.

Specifying a set velocity (external additional velocity)

To additionally regulate the set velocity via the motor potentiometer, select its output value as the source for the external additional velocity and use this as the set value source for the motion command.

- ✓ You are using command operating mode or velocity, torque/force operating mode.
- 1. Activate the additional motor potentiometer function.
- 2. Select the **Motor potentiometer wizard**.
- 3. Parameterize the motor potentiometer according to your application case.
- 4. Select the **External additional velocity: Data source wizard**.
- 5. **G464 Source external additional velocity:**
Select 5: Indirect read parameter G811.
- 6. **G812 Indirect read additional external velocity:**
Select the output value of the motor potentiometer G373 as the source for the external additional velocity.
 - ⇒ The output value of the motor potentiometer serves as the source for the external additional velocity.
 - ⇒ The external velocity can be provided as a set value specification by accessing parameter G465.
- 7. For the command operating mode, parameterize the motion command and set value source via parameters J40 and J54.
 - 7.1. **J40 Command:**
Select the motion command 4: MC_MoveVelocity or 8: MC_MoveSpeed.
 - 7.2. **J54 Source velocity 2:**
Select 1: Parameter G465 as the source for the external additional velocity.
- 8. For the velocity, torque/force operating mode, parameterize the motion command and set value source via parameters D01 and D31.
 - 8.1. **D01 Command:**
Select the motion command 1: MC_MoveSpeed or 2: MC_MoveVelocity.
 - 8.2. **D31 Source additional reference value:**
Select 1: Parameter G465 as the source for the external additional velocity.
- ⇒ The output value of the motor potentiometer serves as the set value specification; the conversion to a set velocity is carried out using maximum permissible speed l10.

Specifying the velocity override

To specify a velocity override via the motor potentiometer, select its output value as the set value source and apply the velocity override to the motion command.

1. Activate the additional motor potentiometer function.
2. Select the Motor potentiometer wizard.
3. Parameterize the motor potentiometer according to your application case.
4. Select the Velocity override: Data source wizard.
5. G467 Source velocity override:
Select 5: Indirect read parameter G813.
6. G813 Indirect read velocity override:
Select the output value of the motor potentiometer G373 as the source for the velocity override.
 - ⇒ The output value of the motor potentiometer serves as the source for the velocity override.
 - ⇒ The velocity override can be provided as a set value specification by accessing parameter G468.
7. For the motion block operating mode, parameterize the motion command and set value source via parameters J11 and J28.
 - 7.1. J11 Command:
Select the motion command 4: MC_MoveVelocity or 8: MC_MoveSpeed.
 - 7.2. J28 Velocity override enable:
To apply the velocity override to the desired motion block, select 1: Active.
8. For the command operating mode, parameterize the motion command and set value source via parameters J40 and J51.
 - 8.1. J40 Command:
Select the motion command 4: MC_MoveVelocity or 8: MC_MoveSpeed.
 - 8.2. J51 Source velocity override:
Select 1: Parameter G468 as the source for the velocity override.
9. For the velocity, torque/force operating mode, parameterize the motion command and set value source via parameter D01.
 - 9.1. D01 Command:
Select the motion command 1: MC_MoveSpeed or 2: MC_MoveVelocity.
 - ⇒ The parameterized velocity override is applied automatically; no further settings are necessary.
 - ⇒ The output value of the motor potentiometer is used as the set value specification for the velocity override.

Specifying the set torque/set force

To specify a set torque/force via the motor potentiometer, select its output value as the set value source for the motion command.

1. Activate the additional motor potentiometer function.
 2. Select the Motor potentiometer wizard.
 3. Parameterize the motor potentiometer according to your application case.
 4. Select the Set torque/force, velocity bracketing: Data source wizard.
 5. G470 Source torque/force reference:
Select 5: Indirect read parameter G814.
 6. G814 Indirect read torque/force reference:
Select the output value of the motor potentiometer G373 as the source for the set torque/force.
 - ⇒ The output value of the motor potentiometer serves as the source for the set torque/force.
 - ⇒ The set torque/force can be provided as a set value specification by accessing parameter G471.
 7. For the motion block operating mode, parameterize the motion command and set value source via parameters J11 and J32.
 - 7.1. J11 Command:
Select the 9: MC_TorqueControl motion command.
 - 7.2. J32 Source reference torque/force:
Select 1: Parameter G471 as the source for the set torque/force.
 8. For the command operating mode, parameterize the motion command and set value source via parameter J40.
 - 8.1. J40 Command:
Select the 9: MC_TorqueControl motion command.
 - ⇒ The parameterized set value source is applied automatically; no further settings are necessary.
 9. For the velocity, torque/force operating mode, parameterize the motion command and set value source via parameter D01.
 - 9.1. D01 Command:
Select the 3: MC_TorqueControl motion command.
 - ⇒ The parameterized set value source is applied automatically; no further settings are necessary.
- ⇒ The output value of the motor potentiometer serves as the set value specification for the set torque/force.

6.1.6.3 Additional fieldbus-controlled analog output function

In Drive Based type applications, the additional fieldbus-controlled analog output function allows you to control the respective analog output directly via a controller, e.g. for operating simple actuators such as pumps, fans, or valves. The additional function can be used to specify an individual set value for each analog output (enable: G303; set value: G306, G309). When fieldbus communication is active, the set value point is written by the controller via the process data mapping (G304, G307). In addition, a fallback value can be defined which supplies the set value at the respective analog output if fieldbus communication fails (G305, G308).

6.1.6.3.1 Parameterizing a fieldbus-controlled analogue output

To parameterize the additional function for controlling analog outputs via fieldbus, proceed as described below.

Information

To use the additional function for controlling the analog outputs via fieldbus, expand the process data mapping of the application, depending on the fieldbus used. Further information on process data mapping can be found in the relevant fieldbus manual.

Parameterizing fieldbus-controlled analogue output AO1

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the Drive Based application wizard > Additional functions.
3. Activate the Fieldbus-controlled analog output 1 option.
⇒ The additional function is activated and the associated wizard is displayed.
4. Select the Drive Based application wizard > Additional functions > Fieldbus-controlled analog output 1.
5. G305 Set value AO1 fallback:
Define the fallback value used to control the analog output if fieldbus communication fails.
6. Select the Terminals wizard > Analog output 1.
 - 6.1. F40 AO1 source:
For set value specification via fieldbus, select parameter G306 as the source for analog output AO1.
 - 6.2. F41 AO1 reference value source:
If necessary, delete the reference value of analog output AO1.
7. For fieldbus communication via CANopen, add parameter G304 to the receive process data RxPDO A225 – A228.
8. For fieldbus communication via EtherCAT, add parameter G304 to the receive process data RxPDO A225 – A228 and create a new ESI file for the controller if necessary.
9. For fieldbus communication via PROFINET, add parameter G304 to the receive process data RxPZD A90 – A91.

Parameterizing fieldbus-controlled analogue output AO2

1. Select the relevant drive controller in the project tree and click on the desired projected axis in the Project menu > Wizard area.
2. Select the Drive Based application wizard > Additional functions.
3. Activate the Fieldbus-controlled analog output 2 option.
⇒ The additional function is activated and the associated wizard is displayed.
4. Select the Drive Based application wizard > Additional functions > Fieldbus-controlled analog output 2.
5. G308 Set value AO2 fallback:
Define the fallback value used to control the analog output if fieldbus communication fails.
6. Select the Terminals wizard > Analog output 2.
 - 6.1. F50 AO2 source:
For set value specification via fieldbus, select parameter G309 as the source for analog output AO2.
 - 6.2. F51 AO2 reference value source:
If necessary, delete the reference value of analog output AO2.
7. For fieldbus communication via CANopen, add parameter G307 to the receive process data RxPDO A225 – A228.
8. For fieldbus communication via EtherCAT, add parameter G307 to the receive process data RxPDO A225 – A228 and create a new ESI file for the controller if necessary.
9. For fieldbus communication via PROFINET, add parameter G304 to the receive process data RxPZD A90 – A91.

6.2 Axis model

With the help of the axis model, you map the real mechanical environment of your drive project in DriveControlSuite by parameterizing the axis type and the arrangement of existing encoders. The parameterization of the axis model is required for the smooth operation and easy diagnosis of your drive train.

With I05 Type of axis, you select a rotational or a translational axis model and define whether the scaling of the axis is done using either predefined or individually configured units of measure. With I00 Position range, you parameterize either an endless (modulo) or a limited travel range. You parameterize the encoder arrangement by using B26 Motor encoder and I02 Position encoder.

The 6th generation of STÖBER drive controllers are specially developed for communication between the drive controller and controller on the basis of the actual variables at the output (° or mm of real axis movement). The scaling of the axis model is calculated by the drive controller's firmware independently of the encoder model, without any rounding errors or drift.

If your axis model is not followed by any other gear ratios, you can operate the axis with output-side motion variables where all nominal and actual values correspond to the real axis movement.

Information

The firmware processes values for the motion variables velocity, acceleration and jerk in the data type REAL32 (floating-point number, 32 bits). Position values are processed in the INT32 data type (integer, 32 bits) to eliminate rounding errors and enable precise movements.

Abbreviation	Meaning
LinM	Linear Motor
M	Motor
MEnc	Motor Encoder
PEnc	Position Encoder

Rotational axis models

The following figures each show a rotational axis model consisting of a motor, a gearbox and a rotary table (endless rotational) or a pointer (limited rotational). Rotational axis models support rotational motor encoders as well as rotational position encoders.




Fig. 14: Endless-rotational motion: Rotary table




Fig. 15: Limited-rotational motion: Pointer

Translational axis models

The following figures each show a translational axis model consisting of a motor, gearbox, feed and conveyor belt (endless translational) or tool slide (limited translational). Translational axis models support rotational motor encoders as well as rotational or translational position encoders.




Fig. 16: Endless translational motion: Conveyor belt




Fig. 17: Limited translational motion: Tool slide

Translational axis model: Linear motor

The following figure shows a limited translation axis model using the example of a linear motor. Linear motors only support translational motor encoders and translational position encoders.







Fig. 18: Limited translational motion: Linear motor

Encoder arrangement

You parameterize the encoder arrangement by using B26 Motor encoder and I02 Position encoder. The motor encoder for velocity control is located on the motor shaft. The position encoder for position control is located on the gearbox output. If you use only one of the two encoders, it will be used for both velocity and position control.

Encoder	Parameterization	Encoder arrangement
Motor encoder	B26 ≠ 0: Inactive I02 = 0: Motor encoder	
Position encoder	B26 ≠ 0: Inactive I02 = B26	
Motor encoder & position encoder	B26 ≠ 0: Inactive I02 ≠ B26	

6.3 Limit switches

With limit switches, you can secure the travel range by selecting the respective end of the travel range and thus limiting the permitted positions of the axis. Hardware limit switches and software limit switches are available to limit the travel range. Hardware and software limit switches can be used individually or in combination with each other.

Hardware limit switches are physical sensors (hardware) that are triggered when a certain position is reached, while software limit switches are purely software-implemented functions for position limiting that are only available when the travel range is limited (I00 = 0: Limited).

Function

When a limit switch is overshot, event 53: Limit switch is triggered and the axis goes into a fault condition with or without a quick stop, depending on the parameterization. As soon as a limit switch is triggered, the motion core interrupts the current motion command and refuses further commands in the same direction of motion. The direction lock ensures that the axis can only move away from the limit switch in the opposite direction and return to the permitted travel range. As soon as the direction lock is deactivated, event 53: Limit switch can be triggered again.

Further information on event 53: Limit switch, possible causes and actions can be found in the drive controller manual (see [Further information](#) [► 142]).

ATTENTION!

Material damage due to leaving the permitted travel range

When a limit switch is overshot, the axis at the end of the permitted travel range will go into a fault condition, either with or without a quick stop depending on the parameterization of the device control, so it may come to a standstill past the limit switch and outside the permitted travel range.

- Allow sufficient space past the limit switch for your application to bring the axis to a standstill.

Restriction of the direction of motion

With an endless travel range, a direction lock can also be triggered by a positioning command outside the revolution length or by restricting the direction of motion using I04 (travel range: I00 = 1: Endless; revolution length: I01; permitted direction: I04). A restriction of the direction of motion is also indicated in the operating state of the axis (operating state: E80).

Since restricting the direction of motion using I04 prevents the hardware limit switch from moving in the opposite direction of motion, it is generally not advisable to combine the two functions.

6.3.1 Hardware limit switches

Hardware limit switches can be used for both limited and endless travel ranges (travel range: I00). A digital input or a fieldbus can serve as the source for the digital signal for evaluating the respective hardware limit switch (source: I101, I102).

The digital signals for evaluating the hardware limit switches are low-active (normally closed contact), i.e. the limit switch is triggered when the digital signal is interrupted (signal: I441, I442 = 0: Inactive). Ensure that the hardware limit switches and, if necessary, the controller are connected correctly to prevent false triggering of event 53: Limit switch.

Relevant parameters

- I101 Source positive /limit switch
- I102 Source negative /limit switch
- I441 Signal /HW limit switch positive
- I442 Signal /HW limit switch negative
- I805 Actual value HW-Limit switch positive
- I806 Actual value HW-Limit switch negative
- I52 Delete limit switch memory
- I196 Direction blocking

Normal operation

When a hardware limit switch is overshoot, event 53: Limit switch is triggered with a fault reaction.

Causes

- 1: Hardware-Limit-Switch positive (prerequisite: I441 = 0: Inactive)
- 2: Hardware-Limit-Switch negative (prerequisite: I442 = 0: Inactive)

A hardware limit switch is triggered when the digital signal for evaluating the hardware limit switches is interrupted. The motion core interrupts the current motion command and refuses further commands in the same direction of motion; a direction lock becomes active (denial: I91 = 1: Active; cause: I90; direction lock: I196).

The direction lock is deactivated as soon as the limit switch memory is reset.

Jog mode

With hardware limit switches, the behavior of the axis is independent of the control type selected for jog mode (I26). When a hardware limit switch is overshoot, the axis behaves the same way in jog mode as in normal operation.

Referencing

During referencing, hardware limit switches can be evaluated like reference switches by using the corresponding referencing type (referencing type: I30 = 2: Limit switch; referencing methods: A, C, E, G).

With other referencing types, a triggered hardware limit switch reverses the direction of motion if the limit switch matches the direction of motion (e.g. positive limit switch and positive direction of motion). If a triggered hardware limit switch does not match the direction of motion, fault 53: Limit switch is triggered (e.g. positive limit switch with negative direction of motion).

Example

At the start of referencing, the axis is between the reference switch and positive limit switch. The referencing direction is positive. The axis moves in the positive direction and first encounters the positive limit switch, not the reference switch. The axis reverses and searches for the reference switch in the other direction.

Limit switch memory

When a hardware limit switch is overshoot, the position of the limit switch is saved internally and the triggered limit switch is recorded as active in the limit switch memory as long as the axis is at or past the limit switch (limit switch memory: I805, I806). Based on the stored position of the limit switch and the digital signals for evaluating the hardware limit switches, the limit switch memory is automatically reset in normal operation as soon as the axis has returned to the permitted travel range.




Fig. 19: Hardware limit switch: Limit switch memory

- 1 Negative HW limit switch triggered, limit switch memory set
- 2 Negative HW limit switch exited, limit switch memory reset
- 3 Positive HW limit switch triggered, limit switch memory set
- 4 Positive HW limit switch exited, limit switch memory reset

Example

A positive hardware limit switch ranges from position 100 to 120; when moving in the positive direction of motion, it is triggered at position 100 (signal: I441 = 1: Active → 0: Inactive). On the return journey, the tolerance may cause the real hardware limit switch to be left at position 101 (signal: I441 = 0: Inactive → 1: Active). However, in order for the effective limit switch or limit switch memory to be reset, position 100 must be reached or undershot.

The position of the limit switch is not stored in non-volatile memory, i.e. if the axis is outside the limit switches after switching on, it must first be moved back into the permitted travel range.

During commissioning or in case of defective hardware limit switch connections, problems can arise with the saved positions. These can be deleted with parameter I52. However, deletion only takes place if the corresponding limit switch signal is inactive. Stored positions can also be deleted by referencing, setting a reference can be deleted using I452 or by restarting the drive controller.

Controller start-up

If a controller is used as the source for the digital signals for evaluating the hardware limit switches and this is still in device start-up while the drive controller and fieldbus communication are already active, event 53: Limit switch is triggered (cause: 7: Both limit switches not connected) and the limit switch memory is set (I805, I806 = 1: Active).

If the power unit has not yet been enabled since the supply voltage was switched on, the limit switch memory is automatically reset as soon as the controller correctly transmits the signals for evaluating the hardware limit switches.

6.3.2 Software limit switches

Software limit switches are only available with a limited travel range (I00 = 0: Limited). To be able to check the actual position of the axis using software limit switches, the axis must be referenced.

The position of the negative software limit switch must be a smaller value than the position of the positive software limit switch. If the same value is defined for both software limit switches, the function is deactivated.

Relevant parameters

- I50 Software stop positive: Highest permitted position
- I51 Software stop negative: Lowest permissible position
- I22 Target window
- I80 Current position
- I196 Direction blocking

Normal operation

When a software limit switch is overshot, event 53: Limit switch is triggered with a fault reaction.

Causes

- 3: SW-limit switch positive (prerequisite: I80 > I50 + I22)
- 4: SW-limit switch negative (prerequisite: I80 < I51 – I22)

A software limit switch is triggered if the actual position of the axis is outside the permitted travel range, taking the position window into account. The motion core interrupts the current motion command and refuses further commands in the same direction of motion; a direction lock becomes active (denial: I91 = 1: Active; cause: I90; direction lock: I196).

The direction lock is deactivated as soon as the actual position of the axis is back within the permitted travel range, taking the position window into account.

Jog mode

With software limit switches, the behavior of the axis depends on the control type selected for jog mode (I26).

If I26 = 0: Velocity control, a quick stop is triggered instead of a fault reaction when a software limit switch is overshot in jog mode, so that the axis comes to a standstill outside the permitted travel range depending on the quick stop deceleration (deceleration: I17). The direction lock ensures that the axis can only move away from the limit switch in the opposite direction and return to the permitted travel range.

When I26 = 1: Position control and the set position is outside the permitted travel range, the axis is braked with jog deceleration and tip jerk so that the axis still comes to a standstill within the permitted travel range shortly before the software limit switch (deceleration: I45; jerk: I18).

Referencing

Software limit switches are not evaluated during referencing (motion command I401 = 6: MC_Home).

6.4 Referencing

To be able to work with a system with absolute positions, the relation of a measured axis position to an actual axis position must be determined.

During initial commissioning or after changes to the axis model, the actual position of the axis is unknown. A defined initial position is necessary. As a rule, this is either identified through a reference search or referencing setting. The associated process is referred to as referencing.








Absolute movements can be performed only in a referenced state. For relative movements, referencing is only required if the software limit switch function is used at the same time.

When replacing a drive controller, the reference can be transferred to the replacement drive controller via an SD card. The information is also saved on the SD card if the action A00 Save values is executed for the referenced axis. For more information on replacing a drive controller, refer to the manual for the respective drive controller.

6.4.1 Referencing methods

The following table shows an overview of the possible referencing methods.

Abbreviation	Meaning			
S	Switch			
M/F	Torque or force			

	Method	Initial movement	Zero pulse	Feature
	A	Negative	Yes	Negative limit switch
	B	Negative	Yes	Negatively positioned reference switch
	C	Negative	–	Negative limit switch
	D	Negative	–	Negatively positioned reference switch
	E	Positive	Yes	Positive limit switch
	F	Positive	Yes	Positively positioned reference switch
	G	Positive	–	Positive limit switch
	H	Positive	–	Positively positioned reference switch
	I	Positive	Yes	Centrally positioned reference switch
	J	Positive	–	Centrally positioned reference switch
	K	Negative	Yes	Centrally positioned reference switch
	L	Negative	–	Centrally positioned reference switch
	M	Negative	Yes	Zero pulse
	N	Positive	Yes	Zero pulse
	O	–	–	Setting the reference
	P	Positive	–	Torque/force stop
	Q	Positive	Yes	Torque/force stop
	R	Negative	–	Torque/force stop
	S	Negative	Yes	Torque/force stop

Tab. 5: Referencing methods

6.4.1.1 Referencing methods in detail

The following chapters show the individual referencing methods in detail.

The following abbreviations are used in the graphs on the referencing methods:

Abbreviation	Meaning
ALT	Alternative
LS	Limit Switch
RS	Reference Switch
ZP	Zero Pulse

Information


For graphically representing axes, the left is the smallest and the right is the largest position value. This means a positive movement goes to the right and a negative to the left.

The following parameters are used in the descriptions of the referencing methods:

Coordinate	Name
I28	Homing torque/force limit
I29	Time homing torque/force limit
I30	Referencing type
I31	Referencing direction
I32	Referencing speed fast
I33	Referencing speed slow
I34	Reference position
I35	Referencing with zero pulse
I39	Referencing acceleration
I43	Move to reference position
I44	Referencing jerk
I53	Index search offset
I101	Source positive /limit switch
I102	Source negative /limit switch
I103	Source reference switch

6.4.1.1.1 Referencing method A

Referencing method A determines a reference using a run to the negative limit switch and zero pulse.



Preparation

1. Activate referencing method A by setting the following parameters to the specified values:
 I30 to 2: Limit switch,
 I31 to 1: Negative,
 I35 to 1: Active.
2. I102:
 Enter the data source for the negative limit switch.
3. I32, I33, I39, I44, I34:
 Define the set values necessary for referencing.
4. I53:
 Define the start of the search for the zero pulse search


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the negative limit switch and continues its run with velocity I33 until it reaches the next zero pulse after leaving the limit switch.
3. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.2 Referencing method B

Referencing method B determines the reference using a run to the negatively positioned reference switch and zero pulse.



Preparation

1. Activate referencing method B by setting the following parameters to the specified values:
I30 to 1: Reference input,
I31 to 1: Negative,
I35 to 1: Active.
2. I103:
Enter the data source for the reference switch.
3. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.
4. I53:
Define the start of the search for the zero pulse search

Referencing

If the PLCopen command MC_Home is active, a distinction is made between two referencing variants.

✓ Alternative 1: Drive is positioned in front of the reference switch


1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I33 until it reaches the next zero pulse after leaving the reference switch.
3. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 2: Drive stopped at reference switch

1. The drive starts in the positive direction with acceleration I39 and velocity I33.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I32.
3. When the drive comes to a stop after the reference switch, it changes direction again and continues at velocity I33 until it reaches the zero pulse.
4. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.3 Referencing method C

Referencing method C determines the reference using a run to the negative limit switch.



Preparation

1. Activate referencing method C by setting the following parameters to the specified values:
 I30 to 2: Limit switch,
 I31 to 1: Negative,
 I35 to 0: Inactive.
2. I102:
 Enter the data source for the negative limit switch.
3. I32, I33, I39, I44, I34:
 Define the set values necessary for referencing.


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the negative limit switch and continues its run with velocity I33 until it leaves the limit switch again.
3. The current actual position is set to the value of the reference position I34 upon leaving the limit switch.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.4 Referencing method D

Referencing method D determines the reference using a run to the negatively positioned reference switch.



Preparation

1. Activate referencing method D by setting the following parameters to the specified values:
I30 to 1: Reference input,
I31 to 1: Negative,
I35 to 0: Inactive.
2. I103:
Enter the data source for the reference switch.
3. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.

Referencing

If the PLCopen command MC_Home is active, a distinction is made between two referencing variants.

✓ Alternative 1: Drive is positioned in front of the reference switch


1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I33 until it leaves the reference switch again.
3. The current actual position is set to the value of the reference position I34 upon leaving the reference switch.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 2: Drive stopped at reference switch

1. The drive starts with acceleration I39 and velocity I33 in the positive direction until it leaves the reference switch.
2. It changes its direction upon leaving the reference switch and continues its run with velocity I32.
3. When the drive comes to a stop after the reference switch, it changes direction and continues its run at velocity I33 until it reaches the reference switch again.
4. The current actual position is set to the value of the reference position I34 upon reaching the reference switch.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.5 Referencing method E

Referencing method E determines the reference using a run to the positive limit switch and zero pulse.



Preparation

1. Activate referencing method E by setting the following parameters to the specified values:
I30 to 2: Limit switch,
I31 to 0: Positive,
I35 to 1: Active.
2. I101:
Enter the data source for the positive limit switch.
3. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.
4. I53:
Define the start of the search for the zero pulse search


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the positive limit switch and continues its run with velocity I33 until it reaches the next zero pulse after leaving the limit switch.
3. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.6 Referencing method F

Referencing method F determines the reference using a run to the positively positioned reference switch and zero pulse.



Preparation

1. Activate referencing method F by setting the following parameters to the specified values:
I30 to 1: Reference input,
I31 to 0: Positive,
I35 to 1: Active.
2. I103:
Enter the data source for the reference switch.
3. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.
4. I53:
Define the start of the search for the zero pulse search

Referencing

If the PLCopen command MC_Home is active, a distinction is made between two referencing variants.

✓ Alternative 1: Drive is positioned in front of the reference switch


1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I33 until it reaches the next zero pulse after leaving the reference switch.
3. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 2: Drive stopped at reference switch

1. The drive starts in the negative direction with acceleration I39 and velocity I33.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I32.
3. When the drive comes to a stop after the reference switch, it changes direction again and continues at velocity I33 until it reaches the zero pulse.
4. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.7 Referencing method G

Referencing method G determines the reference using a run to the positive limit switch.



Preparation

1. Activate referencing method G by setting the following parameters to the specified values:
 I30 to 2: Limit switch,
 I31 to 0: Positive,
 I35 to 0: Inactive.
2. I101:
 Enter the data source for the positive limit switch.
3. I32, I33, I39, I44, I34:
 Define the set values necessary for referencing.


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the positive limit switch and continues its run with velocity I33 until it leaves the limit switch again.
3. The current actual position is set to the value of the reference position I34 upon leaving the limit switch.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.8 Referencing method H

Referencing method H determines the reference using a run to the positively positioned reference switch.



Preparation

1. Activate referencing method H by setting the following parameters to the specified values:
I30 to 1: Reference input,
I31 to 0: Positive,
I35 to 0: Inactive.
2. I103:
Enter the data source for the reference switch.
3. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.

Referencing

If the PLCopen command MC_Home is active, a distinction is made between two referencing variants.

✓ Alternative 1: Drive is positioned in front of the reference switch


1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I33 until it leaves the reference switch again.
3. The current actual position is set to the value of the reference position I34 upon leaving the reference switch.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 2: Drive stopped at reference switch

1. The drive starts with acceleration I39 and velocity I33 in the negative direction until it leaves the reference switch.
2. It changes its direction upon leaving the reference switch and continues its run with velocity I32.
3. When the drive comes to a stop after the reference switch, it changes direction and continues its run at velocity I33 until it reaches the reference switch again.
4. The current actual position is set to the value of the reference position I34 upon reaching the reference switch.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.9 Referencing method I

Referencing method I determines the reference using a run to the centered reference switch and zero pulse.



Preparation

1. Activate referencing method I by setting the following parameters to the specified values:
I30 to 1: Reference input,
I31 to 0: Positive,
I35 to 1: Active.
2. I103:
Enter the data source for the reference switch.
3. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.
4. I53:
Define the start of the search for the zero pulse search

Referencing

If the PLCopen command MC_Home is active, a distinction is made between three referencing sequences.

✓ Alternative 1: Drive is positioned between the negative limit and reference switches

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I33 until it reaches the next zero pulse after leaving the reference switch.
3. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 2: Drive stopped at reference switch


1. The drive starts in the negative direction with acceleration I39 and velocity I33.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I32.
3. When the drive comes to a stop after the reference switch, it changes direction again and continues at velocity I33 until it reaches the zero pulse.
4. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 3: Drive is positioned between the reference and positive limit switches

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the positive limit switch until the reference switch is reached.
3. Upon reaching the reference switch, the drive changes its velocity to I33 until it leaves the reference switch again.
4. The current actual position is set to the value of the reference position I34 after leaving the reference switch and upon reaching the next zero pulse.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.10 Referencing method J

Referencing method J determines the reference using a run to the centered reference switch.



Preparation

1. Activate referencing method J by setting the following parameters to the specified values:
 I30 to 1: Reference input,
 I31 to 0: Positive,
 I35 to 0: Inactive.
2. I103:
 Enter the data source for the reference switch.
3. I32, I33, I39, I44, I34:
 Define the set values necessary for referencing.

Referencing

If the PLCopen command MC_Home is active, a distinction is made between three referencing sequences.

✓ Alternative 1: Drive is positioned between the negative limit and reference switches

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I33 until it leaves the reference switch again.
3. The current actual position is set to the value of the reference position I34 upon leaving the reference switch.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 2: Drive stopped at reference switch


1. The drive starts in the negative direction with acceleration I39 and velocity I33.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I32 until it leaves the reference switch.
3. When the drive comes to a stop after the reference switch, it changes direction and continues its run at velocity I33 until it reaches the reference switch again.
4. The current actual position is set to the value of the reference position I34 upon reaching the reference switch.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 3: Drive is positioned between the reference and positive limit switches

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. Upon reaching the positive limit switch, the drive changes its direction and continues its run until it reaches the reference switch.
3. Upon reaching the reference switch, the drive changes its velocity to I33 until it leaves the reference switch again.
4. The current actual position is set to the value of the reference position I34 upon leaving the reference switch.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.11 Referencing method K

Referencing method K determines the reference using a run to the centered reference switch and zero pulse.



Preparation

1. Activate referencing method K by setting the following parameters to the specified values:
 I30 to 1: Reference input,
 I31 to 1: Negative,
 I35 to 1: Active.
2. I103:
 Enter the data source for the reference switch.
3. I32, I33, I39, I44, I34:
 Define the set values necessary for referencing.
4. I53:
 Define the start of the search for the zero pulse search

Referencing

If the PLCopen command MC_Home is active, a distinction is made between three referencing variants.

✓ Alternative 1: Drive is positioned between the reference and positive limit switches

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I33 until it reaches the next zero pulse after leaving the reference switch.
3. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 2: Drive stopped at reference switch


1. The drive starts in the positive direction with acceleration I39 and velocity I33.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I32.
3. When the drive comes to a stop after the reference switch, it changes direction again and continues at velocity I33 until it reaches the zero pulse.
4. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 3: Drive is positioned between the negative limit and reference switches

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the negative limit switch and continues its run until the reference switch is reached.
3. Upon reaching the reference switch, the drive changes its velocity to I33 and continues its run until it reaches the next zero pulse after leaving the reference switch.
4. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.12 Referencing method L

Referencing method L determines the reference using a run to the centered reference switch.



Preparation

1. Activate referencing method L by setting the following parameters to the specified values:
I30 to 1: Reference input,
I31 to 1: Negative,
I35 to 0: Inactive.
2. I103:
Enter the data source for the reference switch.
3. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.

Referencing

If the PLCopen command MC_Home is active, a distinction is made between three referencing variants.

✓ Alternative 1: Drive is positioned between the reference and positive limit switches

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the reference switch and continues its run with velocity I33 until it leaves the reference switch again.
3. The current actual position is set to the value of the reference position I34 upon leaving the reference switch.
4. The drive comes to a standstill with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 2: Drive stopped at reference switch


1. The drive starts with acceleration I39 and velocity I33 in the positive direction until it leaves the reference switch.
2. It changes its direction upon leaving the reference switch and continues its run with velocity I32.
3. When the drive comes to a stop after the reference switch, it changes direction and continues its run at velocity I33 until it reaches the reference switch again.
4. The current actual position is set to the value of the reference position I34 upon reaching the reference switch.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

✓ Alternative 3: Drive is positioned between the negative limit and reference switches

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the negative limit switch and continues its run until the reference switch is reached.
3. When the reference switch is reached, the drive changes its velocity to I33 and continues its run until it leaves the reference switch again.
4. The current actual position is set to the value of the reference position I34 upon leaving the reference switch.
5. The drive comes to a standstill with deceleration I39.
6. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.13 Referencing method M

This method determines the reference using a run to the zero pulse.



Preparation

1. Activate referencing method M by setting the following parameters to the specified values:
I30 to 3: Zero pulse,
I31 to 1: Negative,
2. I32, I39, I44, I34:
Define the set values necessary for the referencing.


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
3. The drive comes to a standstill with deceleration I39.
4. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.14 Referencing method N

Referencing method N determines the reference using a run to the zero pulse.



Preparation

1. Activate referencing method N by setting the following parameters to the specified values:
I30 to 3: Zero pulse,
I31 to 0: Positive,
2. I32, I39, I44, I34:
Define the set values necessary for the referencing.


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
3. The drive comes to a standstill with deceleration I39.
4. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.15 Referencing method O

Referencing method O determines the reference by setting the reference to any position.



Preparation

1. I30:
Activate referencing method O by setting this parameter to 5: Define home.
2. I34:
Define the reference position.


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

The current actual position is set to the value of the reference position I34.

6.4.1.1.16 Referencing method P

Referencing method P determines the reference using a run with a torque/force stop.



Preparation

1. Activate referencing method P by setting the following parameters to the specified values:
I30 to 4: Torque/force stopper,
I31 to 0: Positive,
I35 to 0: Inactive.
2. I32, I39, I44, I34:
Define the set values necessary for the referencing.
3. I28, I29:
Define the torque/force limit. If the actual torque for the time stored in I29 is above the limit defined in I28 for an ongoing period, the torque/force limit is reached.

Information

In case of a selected value for the torque/force variable that is too big, the machine can be damaged. In case of a selected value that is too small, an incorrect reference position may be applied.


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. The current actual position is set to the value of the reference position I34 when the torque/force limit is reached and the time stored in I29 has elapsed.
3. The set values are set to the value 0 with deceleration I39.
4. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.17 Referencing method Q

Referencing method Q determines the reference using a run with a torque/force stop and zero pulse.



Preparation

1. Activate referencing method Q by setting the following parameters to the specified values:
 I30 to 4: Torque/force stopper,
 I31 to 0: Positive,
 I35 to 1: Active.
2. I32, I33, I39, I44, I34:
 Define the set values necessary for referencing.
3. I28, I29:
 Define the torque/force limit. If the actual torque for the time stored in I29 is above the limit defined in I28 for an ongoing period, the torque/force limit is reached.
4. I53:
 Define the start of the search for the zero pulse search.

Information

In case of a selected value for the torque/force variable that is too big, the machine can be damaged. In case of a selected value that is too small, an incorrect reference position may be applied.


Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the positive direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the torque/force stop and when the time stored in I29 has passed, and continues its run with velocity I33 until it reaches the next zero pulse.
3. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
4. The set values are set to the value 0 with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.18 Referencing method R

Referencing method R determines the reference using a run with a torque/force stop.



Preparation

1. Activate referencing method R by setting the following parameters to the specified values:
I30 to 4: Torque/force stopper,
I31 to 1: Negative,
I35 to 0: Inactive.
2. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.
3. I28, I29:
Define the torque/force limit. If the actual torque for the time stored in I29 is above the limit defined in I28 for an ongoing period, the torque/force limit is reached.

Information


In case of a selected value for the torque/force variable that is too big, the machine can be damaged. In case of a selected value that is too small, an incorrect reference position may be applied.

Referencing

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. The current actual position is set to the value of the reference position I34 when the torque/force stop is reached and the time stored in I29 has elapsed.
3. The set values are set to the value 0 with deceleration I39.
4. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.1.1.19 Referencing method S

Referencing method S determines the reference using a run with torque/force stop and zero pulse.



Preparation

1. Activate referencing method S by setting the following parameters to the specified values:
I30 to 4: Torque/force stopper,
I31 to 1: Negative,
I35 to 1: Active.
2. I32, I33, I39, I44, I34:
Define the set values necessary for referencing.
3. I28, I29:
Define the torque/force limit. If the actual torque for the time stored in I29 is above the limit defined in I28 for an ongoing period, the torque/force limit is reached.
4. I53:
Define the start of the search for the zero pulse search

Information

In case of a selected value for the torque/force variable that is too big, the machine can be damaged. In case of a selected value that is too small, an incorrect reference position may be applied.

Referencing

If the PLCopen command MC_Home is active, referencing takes places as follows:

1. The drive starts in the negative direction with acceleration I39 and velocity I32.
2. It changes its direction upon reaching the torque/force stop and after the time stored in I29 has passed, and continues its run with velocity I33 until it reaches the next zero pulse.
3. The current actual position is set to the value of reference position I34 upon reaching the zero pulse.
4. The set values are set to the value 0 with deceleration I39.
5. If I43 is set to 1: Active, the drive is positioned at reference position I34.

6.4.2 Reference position

Depending on the referencing type I30, the actual position I80 is replaced by the reference position I34 during the referencing event.

6.4.3 Reference retaining

STOBER offers a convenient drive-based referencing system. Depending on the encoder model used and the reference management, different types of reference retaining (I46) are offered.

6.4.4 Reference loss

Axis

In certain cases, an axis loses its reference, and its state changes from I86 = 1: Active to I86 = 0: Inactive.

Normal operation (axis)

During normal operation, encoder faults or actions can lead to a loss of the reference. If the reference was deleted by an encoder event, it can subsequently be restored.

Information

Before restoring the reference, check the actual position displayed (I80). If in doubt, do the referencing again. If relative encoders are used or if the axis was still moving during the encoder fault, the actual position displayed may deviate from the real actual position of the axis.

Cause		Check and action
Event 76: Position encoder	Encoder fault	Actual position may still be correct, restoring the reference is possible: - Check the actual position (I80). - Confirm reference (I130) or re-reference axis
Event 37: Motor encoder	Encoder fault	When using the motor encoder as a position encoder (I02 = 0: Motor encoder), 2 faults are triggered (37: Motor encoder and 76: Position encoder); in display parameter E82 and in the fault memory it is possible that only one fault is displayed. Actual position may still be correct, restoring the reference is possible: - Check the actual position (I80). - Confirm reference (I130) or re-reference axis
Action I38	Deleted reference	Action I38 deletes the reference but does not change the actual position displayed. Actual position may still be correct, restoring the reference is not possible: - Check the actual position (I80). - Reference the axis again

Tab. 6: Loss of reference of the axis in normal operation

Parameter changes (axis)

Changing individual parameters or transferring a new configuration with changed settings can lead to a loss of the reference.

Cause		Check and action
Changing parameters	Changed axis model	Actual position is undefined if one of the following parameters was changed: ▪ B26 Motor encoder ▪ C15 Gear ratio n1 ▪ C16 Gear ratio n2 ▪ C17 Feed constant numerator ▪ C18 Feed constant denominator ▪ I00 Position range ▪ I01 Circular length ▪ I02 Position encoder ▪ I03 Axis polarity ▪ I05 Type of axis ▪ I07 Distance factor numerator position ▪ I08 Distance factor denominator position It is not possible to restore the reference: ▪ Reference the axis again
Changing parameters	Changed encoder interface	Actual position is undefined if a parameter of the H group was changed. It is not possible to restore the reference: ▪ Reference the axis again

Tab. 7: Reference loss of the axis due to parameter changes

Restarting the drive controller (axis)

Depending on the encoder type and method for reference retaining (I46), the reference of a previously referenced axis is restored or deleted after a restart.

By default (I46 = 0: Normal), the reference for a multi-turn absolute encoder is retained after a restart if the axis was referenced with this encoder. In all other cases, the reference is deleted as soon as the drive controller is switched off.

The method for reference retaining can be adapted in I46. In addition to the preset, the following further options are available:

- Reference is retained if the measuring range covers the entire travel range
- Reference is retained as long as the position change in the switched-off state is less than the reference retention window (I48)
- Reference is retained regardless of the presence of an encoder
- Reference is retained regardless of the encoder type
- Reference is deleted when the drive controller is switched off

Special case of incorrect motor connection (axis)

If a motor is inadvertently connected to the incorrect axis or the incorrect drive controller, such as after a case of service, the drive controller behaves as follows after it is switched on:

- The axis changes to the non-referenced state (I86 = 0: Inactive)
- The actual position displayed is undefined

However, the information from the original motor and the associated reference data are stored in the drive controller. After switching off the drive controller, connecting the correct motor and restarting the drive controller, the reference is restored and the actual position is displayed correctly (prerequisites: multi-turn absolute encoder, referenced axis and preset for reference retaining I46 = 0: Normal).

Master encoder

Actual positions of the master encoder are used in the Drive Based Synchronous application for synchronous operation.

In all applications except the Drive Based Center Winder application, the actual position of the master encoder can be used to pass on the position of another encoder attached to the machine to the control system. The drive controller transfers the position from the encoder interface to the respective fieldbus.

Master encoders behave in a similar way to position encoders. In certain cases, a master encoder loses its reference, and its state changes from G89 = 1: Active to G89 = 0: Inactive.

Normal operation (master encoder)

During normal operation, encoder faults can lead to a loss of the reference.

Cause		Check and action
Event 77: Master encoder	Encoder fault	Actual position of the master encoder is undefined, it is not possible to restore the reference: ▪ Reference the master encoder again

Tab. 8: Reference loss of the master encoder in normal operation

Parameter changes (master encoder)

Changing individual parameters or transferring a new configuration with changed settings can lead to a loss of the reference.

Cause		Check and action
Changing parameters	Changed axis model	Actual position of the master encoder is undefined if one of the following parameters was changed: ▪ G30 Position range master ▪ G40 Circular length master ▪ G47 Distance factor numerator master ▪ G48 Distance factor denominator master ▪ G104 Source master encoder It is not possible to restore the reference: ▪ Reference the master encoder again
Changing parameters	Changed encoder interface	Actual position of the master encoder is undefined if a parameter of the H group was changed. It is not possible to restore the reference: ▪ Reference the master encoder again

Tab. 9: Reference loss of the master encoder due to parameter changes

Restarting the drive controller (master encoder)

Depending on the encoder type and method for reference retaining (G35), the reference of a previously referenced master encoder is restored or deleted after a restart.

By default (G35 = 0: Normal), the reference for a multi-turn absolute encoder is retained after a restart if this encoder was used for referencing. In all other cases, the reference is deleted as soon as the drive controller is switched off.

The method for reference retaining can be adapted in G35. In addition to the preset, the following further options are available:

- Reference is retained if the measuring range covers the entire travel range
- Reference is retained as long as the position change in the switched-off state is less than the reference retention window (I48)
- Reference is retained regardless of the presence of an encoder
- Reference is retained regardless of the encoder type
- Reference is deleted when the drive controller is switched off

6.5 Drive Based device control

Drive Based device control is based on DRIVECOM profile drive technology 21; this profile describes the control sequence of a drive controller based on a device state machine. Each device state here represents a certain behavior that can be changed only through defined events. These events are assigned to individual state transitions.

Some of the conditions and responses coupled with the state transitions can be influenced specific to the user. For example, it is possible to define the end of a quick stop or enable delays in a way that is tailored to the respective application case (see wizard [Drive Based device control](#)).

The following chapters describe the device states and the possible state transitions associated with them. You will also learn whether certain actions are necessary on your part to reach the individual device states, what those actions are and which user-specific factors you can parameterize yourself.

6.5.1 Drive Based device state machine

The device state machine describes the different device states of the drive controller along with the possible state changes.




Fig. 20: Drive Based device state machine: device states and state changes

Priority levels are marked by dots. The more dots a state change has, the higher its priority. Accordingly, a state change without any dots has the lowest priority.

6.5.2 States, transitions and conditions

The states provided by Drive Based device control all have specific features. A state either transitions into another state automatically or requires certain actions from the user. There are also transition conditions that you can parameterize to be tailored to your application case using the Drive Based device control wizard.

Parameter E48 shows the current device state of a drive controller.

6.5.2.1 Key

The following terms are used in the descriptions of the states, transitions and conditions:

Term	Meaning
Enable active	Additional enable signal is active (A300 = 1: Active, source: A60)
Enable is inactive	Additional enable signal is inactive (A300 = 0: Inactive, source: A60)
Quick stop in case of Enable-off active	Quick stop in case of Enable-off is active (A44 = 1: Active)
Quick stop in case of Enable-off inactive	Quick stop in case of Enable-off is inactive (A44 = 0: Inactive)
Quick stop end	Standstill reached (I199 = 1: Active) OR maximum quick stop duration has expired (A39) OR A45 = 1: No stop and quick stop request ist inactive
Quick stop duration expired	Maximum quick stop duration has expired (A39)
Autostart active	Autostart is active (A34 = 1: Active)
Autostart inactive	Autostart is inactive (A34 = 0: Inactive)

Tab. 10: States, transitions and conditions: Terms

6.5.2.2 Not ready to switch on

Features

- Drive controller and safety module are initialized and tested
- The power unit as well as drive and activation functions are locked
- Brakes remain engaged

Transition to Switch on disabled (1)

The drive controller switches to the *Switch on disabled* state automatically after initialization and successfully completing the self-test (typically approx. 30 s).

Transition to Fault reaction active (14), priority: ● ● ●

Fault with or without fault reaction

6.5.2.3 Switch on disabled

Features

- Initialization has been completed
- Self-test was successfully completed
- The power unit as well as drive and activation functions are locked
- Brakes remain engaged, release override can be requested with a rising edge

Possible causes of a switch-on lockout include:

1. Enable is active (A300) and Autostart is inactive (A34); cause only in the Switch on disabled state)
2. Insufficient or no supply voltage/DC link feed-in
3. STO safety function is active
4. Release override is active (source: F06; cause only in the Switch on disabled, Ready to switch on and Switched on states)
5. Control panel or local operation is active (cause only in the Switch on disabled, Ready to switch on and Switched on states)

For the exact cause of a switch-on lockout, refer to parameter E49.

Application-specific parameterization

A34 Auto start:

If this parameter is enabled, the drive controller switches directly to the Ready to switch on state in case of a pending enable signal.

WARNING!

Injury to persons and material damage due to unexpected motor startup!

Only activate autostart if the standards and regulations applicable to the system or machine in question permit a direct switch to the Ready to switch on device state.

- In accordance with EN 61800-5-1, clearly mark an activated autostart on the system and in the associated system documentation.

Transition to Ready to switch on (2)

Enable inactive AND no cause for a switch-on lockout

OR

Enable active AND Autostart active AND no cause for a switch-on lockout

Transition to Fault reaction active (14), priority: ● ● ●

Fault with or without fault reaction

6.5.2.4 Ready to switch on

Features

- Power unit and drive function are disabled
- Drive controller is ready to switch on
- Brakes remain engaged, release override can be requested with a rising edge

Application-specific parameterization

In addition to the enable signal at terminal X1, the Drive Based device state machine also supports the use of an additional enable signal, for example over a fieldbus or using digital inputs. The enable signal and additional enable signals are coupled by an AND link. In this case, the drive controller is enabled only if the value of both signals is [HIGH](#).

A60 Source additional enable:

If you are working with an additional enable signal, define the data source of the additional signal in this parameter. In the case of a fieldbus connection, A180 bit 0 supplies the additional enable signal.

Transition to Switched on (3)

Enable active

Transition to Switch on disabled (6), priority: ●

Cause for a switch-on lockout

Transition to Fault reaction active (14), priority: ● ● ●

Fault with or without fault reaction

6.5.2.5 Switched on

Features

- Power unit is ready for operation
- Drive function is locked; set values are not processed
- Brakes remain engaged, release override can be requested with a rising edge

Transition to Operation enabled (4)

Enable active

Transition to Ready to switch on (5), priority: ●

Enable inactive

Transition to Switch on disabled (13), priority: ● ●

Cause for a switch-on lockout

Transition to Fault reaction active (14), priority: ● ● ●

Fault with or without fault reaction

6.5.2.6 Operation enabled

Features

- Power unit is switched on
- Drive function is enabled, set values are processed
- Brakes are released with the first active motion command

Application-specific parameterization

- **A43 Switch-off delay X1 enable:**
If the enable signal at terminal X1 of a safety relay is affected by OSSD test pulses, the drive controller cannot differentiate these signals from a functional enable-off. An incorrect interpretation of the test pulses can be avoided by defining a delay time in this parameter that is greater than the duration of the test pulses. This then eliminates unexpected switching of the drive controller to the states *Ready to switch on* or *Quick stop active* (see parameter A44).
- **A44 Quick stop at enable off:**
This parameter results in a drive being stopped with a quick stop in case of an inactive enable. In this case, the drive controller switches to the *Quick stop active* state. If parameter A44 is not activated, the drive switches to the *Ready to switch on* state in case of Enable-off. In this case, the drive is brought to an uncontrolled standstill, the power unit is disabled and axis movement is no longer controlled by the drive controller.
- **A29 Quick stop in case of fault**
This parameter results in a drive being stopped with a quick stop in case of a fault. In this case, the drive controller switches to the *Quick stop active* state. If parameter A29 is not activated, the drive switches to the *Fault reaction active* state in the event of a fault. In this case, the drive is brought to an uncontrolled standstill, the power unit is disabled and axis movement is no longer controlled by the drive controller.

Transition to Quick stop active (7)

Request for a quick stop

OR

Enable inactive AND quick stop in case of Enable-off active

OR

Request for drive-controlled SS1

OR

Request for drive-controlled SS2

Transition to Ready to switch on (11), priority: ●

Enable inactive AND quick stop in case of Enable-off inactive

Transition to Switch on disabled (12), priority: ● ●

Cause for a switch-on lockout

Transition to Fault reaction active (14), priority: ● ● ●

Fault with or without fault reaction

6.5.2.7 Quick stop active

Features

- Power unit is switched on; drive function is enabled
- A quick stop is executed
- Brakes remain released, brake engages at the end of the quick stop or at standstill
- Brake engaging ends the quick stop

Application-specific parameterization

- A39 Maximum quick stop duration for enable off:
If the drive is stopped with a quick stop in the case of an inactive enable signal (see A44), define the maximum time after which the power unit is switched off in this parameter.
- A45 Quick stop end:
Define whether a quick stop is ended with a standstill of the drive or by canceling the quick stop request in this parameter.
- A62 Source /quick stop:
Define how a requested quick stop is triggered in this parameter.

Transition to Operation enabled (8)

No quick stop request

AND

Enable active

AND

Quick stop end

AND

No SS1

AND

No SS2

Transition to Ready to switch on (9), priority: ●

Enable inactive AND quick stop in case of Enable-off inactive

OR

Enable inactive AND quick stop end

Transition to Switch on disabled (10), priority: ● ●

Cause for a switch-on lockout

OR

No SS1 AND no SS2 AND quick stop end

OR

SS1 AND standstill

Transition to Fault reaction active (14), priority: ● ● ●

Fault with or without fault reaction

6.5.2.8 Fault reaction active

Features

- A drive error has occurred
- Fault reaction is executed depending on the respective fault event
- Brakes are activated depending on the respective fault reaction

Application-specific parameterization

A29 Quick stop in case of fault:

If this parameter is activated, the drive is stopped with a quick stop, if possible, in case of fault; if the parameter is inactive, the movement of the axis is no longer controlled by the drive controller.

Transition to Fault (15)

Fault reaction finished

6.5.2.9 Fault

Features

- A drive error has occurred
- The fault reaction is finished
- The power unit as well as drive and activation functions are locked
- Brakes engage

Transition to Switch on disabled (16)

After remedying the fault cause and then acknowledging the fault message, the drive controller automatically switches to Switch on disabled.

6.6 Motion commands

The operating modes of the application feature special motion commands that are based on the PLCopen standard and are supplemented by two manufacturer-specific motion commands (MC_DoNothing and MC_MoveSpeed). Any motion command – except MC_Stop – can be interrupted during execution. To be able to execute a motion command, the following requirements must be met:

- Local and jog mode must not be activated
- A drive controller must not be in the Switch on disabled or Fault device state

Command	Description	Control type	Necessary motion variables
0: MC_DoNothing	—	—	—
8: MC_MoveSpeed	Axis moves without end with set velocity (without position control)	Velocity	▪ Velocity, override ▪ Acceleration ▪ Deceleration ▪ Jerk
4: MC_MoveVelocity	Axis moves without end with set velocity (with position control)	Position	▪ Velocity, override ▪ Acceleration ▪ Deceleration ▪ Jerk
9: MC_TorqueControl	Axis moves without end with set torque/force	Torque/force	▪ Torque/force
2: MC_MoveRelative	Axis moves a relative distance; set position is relative to the actual position at the start of the command	Position	▪ Position ▪ Velocity, override ▪ Acceleration ▪ Deceleration ▪ Jerk
3: MC_MoveAdditive	Axis moves a relative distance; set position is relative to the set position of the previous motion command	Position	▪ Position ▪ Velocity, override ▪ Acceleration ▪ Deceleration ▪ Jerk
1: MC_MoveAbsolute	Axis moves to an absolute set position (referencing necessary)	Position	▪ Position ▪ Velocity, override ▪ Acceleration ▪ Deceleration ▪ Jerk
6: MC_Home	Axis is referenced	Depending on the selected referencing type	▪ Velocity, override ▪ Acceleration ▪ Deceleration ▪ Jerk ▪ Torque/force

Command	Description	Control type	Necessary motion variables
11: MC_Halt	Axis is stopped; next command can be run before standstill	Velocity	▪ Deceleration ▪ Jerk
5: MC_Stop	Axis is brought to a standstill; next command can be executed after standstill	Velocity	▪ Deceleration ▪ Jerk

Tab. 11: Drive Based: Available motion commands

For detailed information on the motion commands, refer to the associated manual (see [Further information](#) [► 142]).

6.7 Continue function

In Drive Based type applications, the continue function allows you to resume interrupted motion commands, for example after a quick stop, the triggering of safety technology or after an event with a fault reaction. Using the continue function, you can also continue motion commands 2: MC_MoveRelative and 3: MC_MoveAdditive and end with the desired set position, which would not be possible when restarting using the execute signal.

Cancellation causes that can be continued

- Event with fault reaction
- Enable-off
- Motion command 5: MC_Stop, 11: MC_Halt
- Stop signal
- Quick stop signal
- SS1, SS2
- Jog

Motion commands

Motion command (I401)	Continue	Note
0: MC_DoNothing	–	–
1: MC_MoveAbsolute	✓	Motion continues until the set position is reached; set position is absolute
2: MC_MoveRelative	✓	Motion continues until the set position is reached; set position is relative to actual position at the start of the command
3: MC_MoveAdditive	✓	Motion continues until the set position is reached; set position is relative to the set position of the previous motion command
4: MC_MoveVelocity	✓	Motion continues without end at set velocity
5: MC_Stop	–	–
6: MC_Home	–	–
8: MC_MoveSpeed	✓	Motion continues without end at set velocity
9: MC_TorqueControl	✓	Motion continues without end with set torque/force
11: MC_Halt	–	–

Motion block operating mode

In motion block operating mode, the digital inputs, control byte of motion block operating mode or Motion block control panel can serve as the source for the continue signal (control byte: J01; continue source: J917). The continue signal not only continues the interrupted motion command, but also the entire motion block chain.

Cause of cancellation	Continue	Note
Event with fault reaction	✓	–
Enable-off	✓	–
Motion command 5: MC_Stop	–	Motion command 5: MC_Stop can be part of a motion block chain
Motion command 11: MC_Halt	✓	Motion command 11: MC_Halt can be part of a motion block chain; continue is only possible with stop signal via control byte (prerequisite: J06 = 2: Parameter J01)
Stop signal (I440 = 0: Inactive)	–	Stop signal is operated from the control panel in motion block operating mode and is used to stop and end the motion block chain
Quick stop signal (A302 = 0: Inactive)	✓	–
SS1	✓	–
SS2	✓	–
Jog (I443 = 1: Active)	–	–

Motion block reset

You can use the continue function to continue an interrupted motion block if both the motion command and the cause of cancellation can be continued. If it is not possible to resume the motion block or you do not want to continue the interrupted motion block, it always has to be deleted from the continue memory by means of a reset before a new motion block can be started using the execute signal.

6.8 Electronic nameplate

STÖBER synchronous servo motors are generally equipped with EnDat encoders that provide a special memory. This memory includes the electronic nameplate, i.e. all type-relevant master data as well as special mechanical and electronic values of a motor.

When you operate a drive controller with a STÖBER synchronous servo motor and an EnDat encoder, the electronic nameplate is read and all data transferred if the drive controller is connected online. This specifically includes job data, current controller values, motor parameters, data on motor temperature sensors, brakes, the commutation offset and the measured electromotive force. These can be manually optimized later and resaved in the drive controller.

Every time a drive controller is restarted, it checks whether the projected motor, the brake (if applicable), the motor temperature sensor or commutation have been changed. If so, the changed data is read out. The optimizations saved in the drive controller are maintained whenever possible.

The automatic read-out of the electronic nameplate is activated at the factory (B04 Electronic nameplate = 64: Active).

6.9 Lag monitoring

In Drive Based type applications, you can monitor the lag of the axis with active position control in order to detect increasing position deviations at an early stage. Monitoring the lag allows you to react quickly before material damage can occur, e.g. in the event of stiffness or a mechanical blockage of the output.

To monitor the lag, the difference between the actual position of the axis and the set position x_{2_set} of the control is determined and compared with the maximum permissible lag (actual position: I80; set position: I96; permissible lag: I21; result: I187). If the permitted lag is exceeded, event 54: Following error is triggered with the corresponding protection level (protection level: U22).

7 Appendix

7.1 Standard mapping of Drive Based

Information

For fieldbus communication via PROFINET, the processing of process data in some controllers is WORD-oriented (16 bits). In Drive Based applications, the standard mapping is pre-assigned appropriately. If changes are made to the standard mapping, take the parameter data type that you are adding to or removing from the mapping into account.

If you add or remove parameters of the BYTE or INT8 data type (8 bit), this can cause problems in the data structures of the controller. If necessary, use parameter A101 Dummy byte to fill the 8-bit gaps that result in the process data and implement the necessary data structure for the controller.

7.1.1 SB6: Drive Based receive process data

The following table shows the standard mapping for the receive process data in the Drive Based and Drive Based Synchronous applications. For fieldbus communication via PROFINET, the process data mapping is done via parameter A90 – A92. For fieldbus communication via EtherCAT, the process data mapping is done via parameter A225 – A228. If necessary, the standard mapping can be customized.

Byte	Data type	Name	Parameters
0	BYTE	Device control byte	A180
1	BYTE	Control byte command	1.J37
2 – 3	WORD	Control word application	I210
4	INT8	Command	1.J40
5	INT8	Motion-ID	1.J41
6 – 9	INT32	Position	1.J42
10 – 13	REAL32	Velocity 1	1.J43
14 – 17	REAL32	Velocity Override	1.J56
18 – 21	REAL32	Torque/Force reference	1.G469
22	BYTE	Control byte motion block	J01
23 – 24	INT16	Reference motion block	J02

Tab. 12: SB6: receive process data (standard mapping)

7.1.2 SB6: Drive Based transmit process data

The following table shows the standard mapping for the transmit process data in the Drive Based and Drive Based Synchronous applications. For fieldbus communication via PROFINET, the process data mapping is done via parameter A94 – A96. For fieldbus communication via EtherCAT, the process data mapping is done via parameter A233 – A236. If necessary, the standard mapping can be customized.

Byte	Data type	Name	Parameters
0	BYTE	Status byte device	E200[0]
1	BYTE	Status byte device	E200[1]
2 – 3	WORD	Status word 2	E201
4	BYTE	Status byte application	1.I212
5	BYTE	Status byte command	1.J39
6 – 7	WORD	Status word application	I200
8 – 11	INT32	Current position	1.I80
12 – 15	REAL32	Actual speed	1.I88
16 – 19	REAL32	Actual torque/force	E90
20 – 21	WORD	Status word user-defined	A67
22	INT8	Operating condition	E80
23	BYTE	Status byte motion block	J302
24 – 25	INT16	Actual motion block	J300
26	INT8	Device control state	E48

Tab. 13: SB6: transmit process data (standard mapping)

7.2 Further information

The documentation listed below provides you with further relevant information on the 6th STÖBER drive controller generation. The current status of the documentation can be found in our download center at:

<http://www.stoeber.de/en/downloads/>.

Enter the ID of the documentation in the search field.

Title	Documentation	Contents	ID
SB6 drive controller	Manual	System design, technical data, project configuration, storage, installation, connection, commissioning, operation, service, diagnostics	443340
EtherCAT communication – SB6	Manual	Electrical installation, data transfer, commissioning, diagnostics, detailed information	443516
PROFINET communication – SB6	Manual	Electrical installation, data transfer, commissioning, diagnostics, detailed information	443519
SR6 safety technology – STO via terminals	Manual	Technical data, installation, commissioning, diagnostics, detailed information	442741
SU6 safety technology – STO and SS1 via PROFIsafe	Manual	Technical data, installation, commissioning, diagnostics, detailed information	443258
SY6 safety technology – STO and SS1 via FSoE	Manual	Technical data, installation, commissioning, diagnostics, detailed information	442744
Motion commands	Manual	Control and status information, denials and limitations, motion	443349

7.3 Abbreviations

Abbreviation	Meaning
AI	Analog Input
ALT	Alternative
CAN	Controller Area Network
CB	Controller Based
CiA	CAN in Automation
CNC	Computerized Numerical Control
DI	Digital Input
EtherCAT	Ethernet for Control Automation Technology
IGB	Integrated Bus
LinM	Linear Motor
LS	Limit Switch
LSB	Least Significant Bit
M	Motor
M/F	Torque or force
MEnc	Motor Encoder
PEnc	Position Encoder
PROFINET	Process Field Network
RS	Reference Switch
S	Switch
PLC	Programmable Logic Controller
ZP	Zero Pulse

8 Contact

8.1 Consultation, service and address

We would be happy to help you!

We offer a wealth of information and services to go with our products on our website:

<http://www.stoeber.de/en/service>

For additional or personalized information, contact our consultation and support service:

<http://www.stoeber.de/en/support>

If you need our system support:

Phone: +49 7231 582-3060

systemsupport@stoeber.de

If you need a replacement device:

Phone: +49 7231 582-1128

replace@stoeber.de

Call our 24-hour service hotline:

Phone: +49 7231 582-3000

Our address is:

STÖBER Antriebstechnik GmbH + Co. KG

Kieselbronner Strasse 12

75177 Pforzheim, Germany

8.2 Your opinion is important to us

We created this documentation to the best of our knowledge with the goal of helping you build and expand your expertise productively and efficiently with our products.

Your suggestions, opinions, wishes and constructive criticism help us to ensure and further develop the quality of our documentation.

If you want to contact us for a specific reason, we would be happy to receive an e-mail from you at:

documentation@stoeber.de

Thank you for your interest.

Your STÖBER editorial team

8.3 Close to customers around the world

We offer you committed, expert advice and support in over 40 countries worldwide:

STOBER AUSTRIA

www.stoeber.at
+43 7613 7600-0
sales@stoeber.at

STOBER FRANCE

www.stober.fr
+33 478 98 91 80
sales@stober.fr

STOBER ITALY

www.stober.it
+39 02 93909570
sales@stober.it

STOBER KOREA

www.stober.kr
+82 10 5681 6298
sales@stober.kr

STOBER SWITZERLAND

www.stoeber.ch
+41 56 496 96 50
sales@stoeber.ch

STOBER TURKEY

www.stober.com
+90 216 510 2290
sales-turkey@stober.com

STOBER USA

www.stober.com
+1 606 759 5090
sales@stober.com

STOBER CHINA

www.stoeber.cn
+86 512 5320 8850
sales@stoeber.cn

STOBER Germany

www.stoeber.de
+49 7231 582-0
sales@stoeber.de

STOBER JAPAN

www.stober.co.jp
+81-3-5875-7583
sales@stober.co.jp

STOBER SWEDEN

www.stober.com
+46 702 394 675
neil.arstad@stoeber.de

STOBER TAIWAN

www.stober.tw
+886 4 2358 6089
sales@stober.tw

STOBER UK

www.stober.co.uk
+44 1543 458 858
sales@stober.co.uk

List of figures

Fig. 1	DS6: Program interface	12
Fig. 2	DriveControlSuite: Navigation using text links and symbols	14
Fig. 3	Velocity, torque/force operating mode: Signal flows	44
Fig. 4	Motion block operating mode: Signal flows.....	52
Fig. 5	Command operating mode: signal flows.....	69
Fig. 6	Components and configuration steps	75
Fig. 7	Continuous Function Chart: analog input AI1 (F116 = 0: -10V to 10V)	78
Fig. 8	Continuous Function Chart: analog input AI1 (F116 = 1: 0 to 20mA).....	78
Fig. 9	Continuous Function Chart: analog input AI1 (F116 = 2: 4 to 20mA).....	78
Fig. 10	Continuous Function Chart: analog input AI2	79
Fig. 11	Continuous Function Chart: analog input AI3	79
Fig. 12	Additional counter function: Example	80
Fig. 13	Motor potentiometer: Linear and stepwise calculation	86
Fig. 14	Endless-rotational motion: Rotary table	95
Fig. 15	Limited-rotational motion: Pointer	95
Fig. 16	Endless translational motion: Conveyor belt	96
Fig. 17	Limited translational motion: Tool slide.....	96
Fig. 18	Limited translational motion: Linear motor	96
Fig. 19	Hardware limit switch: Limit switch memory.....	100
Fig. 20	Drive Based device state machine: device states and state changes.....	129

List of tables

Tab. 1	Parameter groups.....	15
Tab. 2	Parameters: Data types, parameter types, possible values	16
Tab. 3	Parameter types.....	17
Tab. 4	Indirect trigger: Notations.....	63
Tab. 5	Referencing methods	102
Tab. 6	Loss of reference of the axis in normal operation.....	125
Tab. 7	Reference loss of the axis due to parameter changes	126
Tab. 8	Reference loss of the master encoder in normal operation	127
Tab. 9	Reference loss of the master encoder due to parameter changes	128
Tab. 10	States, transitions and conditions: Terms	130
Tab. 11	Drive Based: Available motion commands.....	136
Tab. 12	SB6: receive process data (standard mapping)	140
Tab. 13	SB6: transmit process data (standard mapping)	141

Glossary

Broadcast domain

Logical grouping of network devices within a local network that reaches all nodes via broadcast.

Control cascade

Complete model of the control structure with the position controller, velocity controller and current controller components.

Electronic nameplate

The synchronous servo motors are generally equipped with absolute encoders that provide special memory. This memory includes the electronic nameplate, i.e. all type-relevant master data as well as special mechanical and electronic values of a motor. When you operate a drive controller with a synchronous servo motor and an absolute encoder, the electronic nameplate is read and all motor data transferred if the drive controller is connected online. The drive controller automatically determines the associated limit values and control parameters from this data.

IPv4 limited broadcast

Type of broadcast in a network with IPv4 (Internet Protocol version 4). The IP address 255.255.255.255 is entered as the destination. The content of the broadcast is not forwarded by a router, which limits it to the local network.

PID controller

Universal controller type with a P-, I- and D-share. These three adjustment parameters make the controller flexible and ensure exact and highly dynamic control. However, by implication, it also necessitates a wide variety of variants. It is that much more important to ensure careful construction that is well-coordinated to the system. The application areas for this controller type are control circuits with systems of the second order and higher, which must be stabilized quickly and do not allow for any permanent control deviation.

PROFINET

Open Ethernet standard of PROFIBUS Nutzerorganisation e. V. (PNO) for automation.



4 4 3 4 9 8 - 0 0

10/2025

STÖBER Antriebstechnik GmbH + Co. KG
Kieselbronner Str. 12
75177 Pforzheim
Germany
Tel. +49 7231 582-0
mail@stoeber.de
www.stober.com

24 h Service Hotline
+49 7231 582-3000

www.stober.com