



SD6 drive controller

Commissioning instructions

en-US
01/2023
ID 442537.09



STÖBER

Table of contents

| | |
|---|-----------|
| Table of contents | 2 |
| 1 Foreword | 7 |
| 2 User information | 8 |
| 2.1 Scope of documentation | 8 |
| 2.2 Storage and transfer | 8 |
| 2.3 Described product | 8 |
| 2.4 UL file number | 9 |
| 2.5 Timeliness | 9 |
| 2.6 Original language | 9 |
| 2.7 Limitation of liability | 10 |
| 2.8 Formatting conventions | 10 |
| 2.8.1 Display of safety instructions | 10 |
| 2.8.2 Markup of text elements | 11 |
| 2.8.3 Mathematics and formulas | 11 |
| 2.9 Marks and test symbols | 12 |
| 2.10 Trademarks | 13 |
| 2.11 Licenses | 13 |
| 3 General safety instructions | 14 |
| 3.1 Directives and standards | 14 |
| 3.2 Qualified personnel | 14 |
| 3.3 Intended use | 14 |
| 3.4 Transport and storage | 15 |
| 3.5 Operational environment and operation | 15 |
| 3.6 Working on the machine | 16 |
| 3.7 Ensuring traceability | 16 |
| 3.8 Decommissioning | 16 |
| 3.9 Disposal | 17 |
| 3.10 Firefighting | 17 |
| 4 UL-compliant use | 18 |
| 5 Technical data | 20 |
| 5.1 Drive controllers | 20 |
| 5.1.1 General technical data | 20 |
| 5.1.2 Nameplate | 21 |
| 5.1.3 Type designation | 22 |
| 5.1.4 Material variant | 23 |

| | | |
|----------|--|-----------|
| 5.1.5 | Sizes | 23 |
| 5.1.6 | Electrical data | 24 |
| 5.1.7 | Dimensions | 29 |
| 5.1.8 | Weight | 31 |
| 5.1.9 | Cycle times..... | 31 |
| 5.2 | DC link connection..... | 31 |
| 5.2.1 | General technical data..... | 31 |
| 5.2.2 | DL6A – SD6 assignment | 32 |
| 5.2.3 | Dimensions | 33 |
| 5.2.4 | Weight | 34 |
| 5.3 | Safety technology | 34 |
| 5.3.1 | ST6 safety module | 34 |
| 5.3.2 | SE6 safety module | 34 |
| 5.4 | Controllable brakes | 35 |
| 5.4.1 | X5 | 35 |
| 5.4.2 | X8 (option SE6) | 35 |
| 6 | Storage..... | 36 |
| 6.1 | Drive controllers | 36 |
| 6.1.1 | Annual reforming..... | 36 |
| 6.1.2 | Reforming before commissioning..... | 37 |
| 7 | Installation | 38 |
| 7.1 | Safety instructions for installation..... | 38 |
| 7.2 | Basic assembly instructions | 38 |
| 7.2.1 | Drive controllers | 38 |
| 7.3 | Minimum clearances | 39 |
| 7.4 | Drilling diagrams and bore dimensions | 40 |
| 7.4.1 | Drive controllers | 40 |
| 7.5 | Length of copper rails..... | 42 |
| 7.6 | Installing the communication module..... | 42 |
| 7.7 | Installing the terminal module | 44 |
| 7.8 | Installing the drive controller without a rear section module..... | 47 |
| 7.9 | Installing the DC link connection | 48 |
| 7.10 | Installing a rear section braking resistor | 51 |
| 7.11 | Mounting the drive controller on the rear section module | 52 |
| 7.12 | Attaching the EMC shroud..... | 57 |
| 8 | Connection..... | 59 |
| 8.1 | Safety instructions for connection | 59 |
| 8.2 | Line routing..... | 60 |
| 8.3 | Protective measures..... | 60 |
| 8.3.1 | Line fuse..... | 60 |

| | | |
|-----------|---|------------|
| 8.3.2 | Residual current protective device | 64 |
| 8.3.3 | Protective grounding | 65 |
| 8.3.4 | EMC recommendations | 66 |
| 8.4 | Drive controllers | 67 |
| 8.4.1 | Overview with ST6 safety module | 67 |
| 8.4.2 | Overview with SE6 safety module | 72 |
| 8.4.3 | X1: Enable and relay 1 | 76 |
| 8.4.4 | X2: Motor temperature sensor | 76 |
| 8.4.5 | X3A, X3B: PC, IGB | 77 |
| 8.4.6 | X4: Encoder | 78 |
| 8.4.7 | X5: Brake – Actuation | 80 |
| 8.4.8 | X6: Brake – Feedback and supply (ST6 option) | 81 |
| 8.4.9 | X7: Brake 2 – Supply (SE6 option) | 81 |
| 8.4.10 | X8: Brake 2 – Safe brake control (SE6 option) | 82 |
| 8.4.11 | X10: 230/400 V supply | 82 |
| 8.4.12 | X11: 24 V supply | 84 |
| 8.4.13 | X12: Safety technology (option ST6) | 85 |
| 8.4.14 | X14: Safety technology – Safe inputs (SE6 option) | 86 |
| 8.4.15 | X15: Safety technology – Safe outputs, supply for X50 (SE6 option) | 87 |
| 8.4.16 | X20: Motor | 88 |
| 8.4.17 | X30: DC link connection, braking resistor | 90 |
| 8.4.18 | X50: Plausibility encoder (SE6 option) | 91 |
| 8.4.19 | Connecting a drive controller (ST6 option) | 92 |
| 8.4.20 | Connecting a drive controller (SE6 option) | 94 |
| 8.5 | Communication module | 96 |
| 8.5.1 | EC6: EtherCAT | 96 |
| 8.5.2 | CA6: CANopen | 97 |
| 8.5.3 | PN6: PROFINET | 98 |
| 8.6 | Terminal module | 100 |
| 8.6.1 | XI6 | 100 |
| 8.6.2 | RI6 | 106 |
| 8.6.3 | IO6 | 116 |
| 9 | Operation | 119 |
| 9.1 | Overview | 119 |
| 9.2 | Menu structure and navigation | 120 |
| 10 | What you should know before commissioning | 122 |
| 10.1 | DS6 program interface | 122 |
| 10.2 | Meaning of parameters | 123 |
| 10.2.1 | Parameter groups | 124 |
| 10.2.2 | Parameter types and data types | 125 |
| 10.2.3 | Parameter types | 126 |
| 10.2.4 | Parameter structure | 126 |
| 10.2.5 | Parameter visibility | 127 |

| | | |
|-----------|--|------------|
| 10.3 | Signal sources and process data mapping | 128 |
| 10.4 | Non-volatile memory | 128 |
| 11 | Commissioning | 129 |
| 11.1 | Initiating the project | 129 |
| 11.1.1 | Projecting the drive controller and axis | 129 |
| 11.1.2 | Configuring safety technology | 131 |
| 11.1.3 | Creating other modules and drive controllers | 131 |
| 11.1.4 | Projecting the module | 131 |
| 11.1.5 | Projecting the project | 131 |
| 11.2 | Mapping the mechanical axis model | 132 |
| 11.2.1 | Parameterizing the STOBER motor | 132 |
| 11.2.2 | Parameterizing the axis model | 132 |
| 11.3 | Transmitting and saving a configuration | 136 |
| 11.3.1 | Transmitting the configuration | 136 |
| 11.3.2 | Saving the configuration | 138 |
| 11.4 | Testing the configuration | 138 |
| 11.4.1 | Testing using DriveControlSuite | 139 |
| 11.4.2 | Testing using the operating unit | 139 |
| 12 | Replacement | 142 |
| 12.1 | Safety instructions for device replacement | 142 |
| 12.2 | Notes on the safety configuration | 142 |
| 12.3 | Notes on motor replacement | 143 |
| 12.4 | Replacing the drive controller | 143 |
| 12.5 | Replacing the Paramodul | 145 |
| 12.6 | Replacing or updating firmware using DS6 | 146 |
| 13 | Appendix | 147 |
| 13.1 | Terminal specifications | 147 |
| 13.1.1 | Overview | 147 |
| 13.1.2 | BCF 3,81 180 SN | 149 |
| 13.1.3 | BFL 5.08HC 180 SN | 149 |
| 13.1.4 | BLDF 5.08 180 SN | 150 |
| 13.1.5 | DFMC 1.5 -ST-3.5 | 150 |
| 13.1.6 | FK-MCP 1,5 -ST-3,5 | 151 |
| 13.1.7 | FMC 1,5 -ST-3,5 | 151 |
| 13.1.8 | G 10/2 | 152 |
| 13.1.9 | GFKC 2,5 -ST-7,62 | 152 |
| 13.1.10 | GFKIC 2.5 -ST-7.62 | 153 |
| 13.1.11 | ISPC 5 -STGCL-7,62 | 153 |
| 13.1.12 | ISPC 16 -ST-10,16 | 154 |
| 13.1.13 | MKDSP 25 -15,00 | 154 |
| 13.1.14 | SPC 5 -ST-7,62 | 155 |
| 13.1.15 | SPC 16 -ST-10,16 | 155 |

| | | |
|-----------|---|------------|
| 13.2 | Wiring examples | 156 |
| 13.2.1 | Stand-alone operation with direct brake control | 156 |
| 13.2.2 | Stand-alone operation with indirect brake control | 157 |
| 13.3 | Detailed information | 158 |
| 13.4 | Formula symbols | 160 |
| 13.5 | Abbreviations | 161 |
| 14 | Contact | 162 |
| 14.1 | Consultation, service and address | 162 |
| 14.2 | Your opinion is important to us | 162 |
| 14.3 | Close to customers around the world | 163 |

1 Foreword

STOBER drive controllers of the SD6 series offer maximum precision and productivity for automation technology and mechanical engineering despite ever more complex functions. Highly dynamic drives ensure the shortest recovery times from fast changes in set value and load jumps. There is also an option of connecting the drive controllers in a DC link for multi-axis applications, which improves the energy footprint of the entire system. The SD6 drive controller is available in four sizes with a nominal output current of up to 85 A.

Features

- Control of linear and rotary synchronous servo motors and asynchronous motors
- Multi-functional encoder interfaces
- Automatic motor parameterization from the electronic motor nameplate
- Isochronic system bus (IGB motion bus) for parameterization and multi-axis applications
- Communication over CANopen, EtherCAT or PROFINET
- Safe Torque Off (STO) in the standard version, expanded safety technology (SS1, SS2, SLS, etc.) as an option
- Digital and analog inputs and outputs as an option
- Brake chopper, brake control and line filter
- Energy supply through direct power supply
- Flexible DC link connection for multi-axis applications
- Convenient operating unit consisting of graphical display and keys
- Paramodul removable data storage for quick commissioning and service

2 User information

This documentation covers the SD6 drive controller. You will receive support for the assembly of the individual modules along with the associated components that you will need to operate the drive controllers in the control cabinet.

You will also find information on wiring the modules correctly and checking their functionality in the group with an initial test.

Combinations with other 6th generation STÖBER drive controllers are possible under certain boundary conditions.

2.1 Scope of documentation

This documentation contains important safety instructions as well as a selection of information about the SD6 drive controller that you need for commissioning.

Note that this documentation does not replace the detailed manual. Read the detailed documentation first before working with the devices.

You can find the manual and other documentation in PDF format on the enclosed CD/DVD or on our website.

An overview of the available documentation about the SD6 drive controller can be found in the appendix (see [Detailed information](#) [► 158]).

2.2 Storage and transfer

As this documentation contains important information for handling the product safely and efficiently, it must be stored in the immediate vicinity of the product until product disposal and be accessible to qualified personnel at all times.

Also pass on this documentation if the product is transferred or sold to a third party.

2.3 Described product

This documentation is binding for:

SD6 series drive controllers in conjunction with the
DriveControlSuite software (DS6) in V 6.5-H or higher, PASmotion in V 1.3.0 or higher and associated firmware in V 6.5-H or higher.

2.4 UL file number

cULus certified devices with the corresponding test symbol meet the requirements of standards UL 508C and UL 840.

Under the file number specified in the following table, you can find the product in the online database of Underwriter Laboratories (UL):

<https://iq2.ulprospector.com>

| Type | | File number | UL Category Control Number | | Certification |
|--------------------------|---|-------------|----------------------------|--------|---------------|
| | | | America | Canada | cULus/cURus |
| Drive controller | SD6A02 | E189114 | NMMS | NMMS7 | cULus |
| | SD6A04 | | | | |
| | SD6A06 | | | | |
| | SD6A14 | | | | |
| | SD6A16 | | | | |
| | SD6A24 | | | | |
| | SD6A26 | | | | |
| | SD6A34 | | | | |
| | SD6A36 | | | | |
| | SD6A38 | | | | |
| Braking resistors | FZMU, FZZMU | E212934 | NMTR2 | NMTR8 | cURus |
| | GVADU, GBADU | | | | |
| | FGFKU | | | | |
| | RB 5000 | | | | |
| Power chokes | TEP4010-2US00 | E103902 | XQNX2 | XQNX8 | cURus |
| Output chokes | TEP3720-0ES41 | E333628 | NMMS2 | NMMS8 | cURus |
| | TEP3820-0CS41 | | | | |
| | TEP4020-0RS41 | | | | |
| Motors | Synchronous servo motors of the EZ series | E488992 | PRHZ2 | PRHZ8 | cURus |
| | Asynchronous motors | E216143 | PRGY2 | PRGY8 | cURus |
| Encoder and power cables | All types | E172204 | AVLV2 | AVLV8 | cURus |

Tab. 1: File number-certified products

2.5 Timeliness

Check whether this document is the latest version of the documentation. We make the latest document versions for our products available for download on our website:

<http://www.stoeber.de/en/downloads/>.

2.6 Original language

The original language of this documentation is German; all other language versions are derived from the original language.

2.7 Limitation of liability

This documentation was created taking into account the applicable standards and regulations as well as the current state of technology.

No warranty or liability claims for damage shall result from failure to comply with the documentation or from use that deviates from the intended use of the product. This is especially true for damage caused by individual technical modifications to the product or the project configuration and operation of the product by unqualified personnel.

2.8 Formatting conventions

Orientation guides in the form of signal words, symbols and special text markups are used to emphasize specific information so that you are able identify it in this documentation quickly.

2.8.1 Display of safety instructions

Safety instructions are identified with the following symbols. They indicate special risks when handling the product and are accompanied by relevant signal words that express the extent of the risk. Furthermore, useful tips and recommendations for efficient, error-free operation are specially highlighted.

ATTENTION!

Attention

This indicates that damage to property may occur

- if the stated precautionary measures are not taken.

⚠ CAUTION!

Caution

This word with a warning triangle indicates that minor personal injury may occur

- if the stated precautionary measures are not taken.

⚠ WARNING!

Warning

This word with a warning triangle means there may be a considerable risk of fatal injury

- if the stated precautionary measures are not taken.

⚠ DANGER!

Danger

This word with a warning triangle indicates that there is a considerable risk of fatal injury

- if the stated precautionary measures are not taken.

Information

Information indicates important information about the product or serves to emphasize a section in the documentation that deserves special attention from the reader.

2.8.2 Markup of text elements

Certain elements of the continuous text are distinguished as follows.

| | |
|---|--|
| Important information | Words or expressions with a special meaning |
| Interpolated position mode | Optional: File or product name or other name |
| <u>Detailed information</u> | Internal cross-reference |
| http://www.samplelink.com | External cross-reference |

Software and other displays

The following formatting is used to identify the various information content of elements referenced by the software interface or a drive controller display, as well as any user entries.

| | |
|--------------------------------|---|
| Main menu Settings | Window names, dialog box names, page names or buttons, combined proper nouns, functions referenced by the interface |
| Select Referencing method A | Predefined entry |
| Save your <own IP address> | User-defined entry |
| EVENT 52: COMMUNICATION | Displays (status, messages, warnings, faults) |

Keyboard shortcuts and command sequences or paths are represented as follows.

| | |
|----------------------|---|
| [Ctrl], [Ctrl] + [S] | Key, shortcut |
| Table > Insert table | Navigation to menus/submenus (path specification) |

Buttons

The buttons of the drive controller are depicted as follows in .

| | |
|------|---|
| [OK] |  |
|------|---|

2.8.3 Mathematics and formulas

The following signs are used to represent mathematical relationships and formulas.

| | |
|---|----------------|
| – | Subtraction |
| + | Addition |
| × | Multiplication |
| ÷ | Division |
| | Absolute value |

2.9 Marks and test symbols

The following marks and test symbols are mentioned in the technical data.



RoHS lead-free mark

Marking in accordance with RoHS directive 2011-65-EU.



CE mark

Manufacturer's self declaration: The product meets the requirements of EU directives.



UKCA test symbol

Manufacturer's self declaration: The product meets the requirements of UK directives.



UL test symbol (cULus)

This product is listed by UL for the United States and Canada.

Representative samples of this product have been evaluated by UL and meet the requirements of applicable standards.



UL test symbol for recognized component mark (cURus)

This component or material is recognized by UL. Representative samples of this product have been evaluated by UL and meet applicable requirements.

2.10 Trademarks

The following names used in connection with the device, its optional equipment and its accessories are trademarks or registered trademarks of other companies:

| | |
|--|--|
| CANopen [®] , CiA [®] | CANopen [®] and CiA [®] are registered European Union trademarks of CAN in AUTOMATION e.V., Nuremberg, Germany. |
| EnDat [®] | EnDat [®] and the EnDat [®] logo are registered trademarks of Dr. Johannes Heidenhain GmbH, Traunreut, Germany. |
| EtherCAT [®] , Safety over EtherCAT [®] , TwinCAT [®] | EtherCAT [®] , Safety over EtherCAT [®] and TwinCAT [®] are registered trademarks of patented technologies licensed by Beckhoff Automation GmbH, Verl, Germany. |
| Hyper-V [®] | Hyper-V [®] is a registered trademark of the Microsoft Corporation in the United States and/or other countries. |
| PLCopen [®] | PLCopen [®] is a registered trademark of the PLCopen Organisation, Gorinchem, Netherlands. |
| PROFIBUS [®] , PROFINET [®] | PROFIBUS [®] and PROFINET [®] are registered trademarks of PROFIBUS Nutzerorganisation e.V., Karlsruhe, Germany. |
| speedtec [®] | speedtec [®] is a registered trademark of TE Connectivity Industrial GmbH, Niederwinkling, Germany. |
| VirtualBox [®] | VirtualBox [®] is a registered trademark of Oracle America, Inc., Redwood Shores, USA. |
| VMware [®] | VMware [®] is a registered trademark of VMware, Inc., Palo Alto, USA. |
| Windows [®] , Windows [®] 7, Windows [®] 10 | Windows [®] , das Windows [®] -Logo, Windows [®] XP, Windows [®] 7 und Windows [®] 10 are registered trademarks of Microsoft Corporation in the United States and/or other countries. |

All other trademarks not listed here are the property of their respective owners.

Products that are registered as trademarks are not specially indicated in this documentation. Existing property rights (patents, trademarks, protection of utility models) are to be observed.

2.11 Licenses

Software from the following licensor is used in the SD6 drive controller:

SEGGER Microcontroller GmbH & Co. KG
In den Weiden 11
40721 Hilden
Germany
Phone+49 2103-2878-0
Fax+49 2103-2878-28
Email: info@segger.com
Internet: <http://www.segger.com>

3 General safety instructions

There are risks associated with the product described in this documentation that can be prevented by complying with the described warning and safety instructions as well as the included technical rules and regulations.

3.1 Directives and standards

The following European directives and standards are relevant to the drive controllers:

- Machinery Directive 2006/42/EC
- Low Voltage Directive 2014/35/EU
- EMC Directive 2014/30/EU
- EN ISO 13849-1:2015
- EN ISO 13849-2:2012
- EN 61800-3:2004 and A1:2012
- EN 61800-5-1:2007
- EN 61800-5-2:2007

Subsequent references to the standards do not specify the respective year in order to improve readability.

3.2 Qualified personnel

In order to be able to perform the tasks described in this documentation, the persons instructed to perform them must have the appropriate professional qualification and be able to assess the risks and residual hazards when handling the products. For this reason, all work on the products as well as their operation and disposal may be performed only by professionally qualified personnel.

Qualified personnel are persons who have acquired the authorization to perform these activities either through training to become a specialist and/or instruction by specialists.

Furthermore, valid regulations, legal requirements, applicable basic rules, this documentation and the safety instructions included in it must be carefully read, understood and observed.

3.3 Intended use

As defined by EN 50178, SD6 drive controllers are electrical devices operating as power electronics to control the flow of energy in high-voltage systems.

They are intended solely for the operation of motors that meet the requirements of EN 60034-1:

- Synchronous servo motors (e.g. of the EZ series)
- Asynchronous motors
- Linear motors
- Torque motors

The connection of other electronic loads or operation outside applicable technical specifications constitutes improper use.

When installing drive controllers in machines, commissioning (i.e. commencing intended operation) may not be performed until it has been determined that the machine is in compliance with local laws and directives. For example, in the European region, the following applies:

- Machinery Directive 2006/42/EC
- Low Voltage Directive 2014/35/EU
- EMC Directive 2014/30/EU

EMC-compliant installation

The SD6 drive controller and accessories must be installed and wired compliant for EMC

Modification

As the user, you may not make any physical, technical or electrical modifications to the SD6 drive controller and the accessories.

Maintenance

The SD6 drive controller and accessories are maintenance-free. However, take appropriate measures to detect or prevent possible errors in the connecting wiring.

3.4 Transport and storage

Inspect the delivery for any transport damage immediately after you receive it. Notify the transport company of any damage immediately. Do not put a damaged product into operation.

To ensure the faultless and safe operation of the products, they must be professionally configured, installed, operated and maintained.

Store the products in a dry and dust-free room if you do not install them immediately.

Transport and store the products in the original packaging and protect the products from mechanical impacts and vibrations. Observe the transport and storage conditions recommended in the technical data.

Reform drive controllers in storage annually or before commissioning (see [Storage](#) [▶ 36]).

3.5 Operational environment and operation

The products are subject to sales restrictions in accordance with EN IEC 61800-3.

The products are not designed for use in a public low-voltage network that supplies residential areas. Radio-frequency interference can be expected if the products are used in this type of network.

The products are intended exclusively for installation in control cabinets with at least protection class IP54.

Always operate the products within the limits specified by the technical data.

The following applications are prohibited:

- Use in potentially explosive atmospheres
- Use in environments with harmful substances as specified by EN 60721, such as oils, acids, gases, vapors, dust and radiation

Implementation of the following applications is permitted only after approval from STOBER:

- Use in non-stationary applications
- The use of active components (drive controllers, supply modules, regenerative feedback modules or discharge units) from third-party manufacturers

The drive controller is designed exclusively for operation in TN networks or on wye sources. At a nominal voltage of 200 to 480 V_{AC}, they are permitted to supply a maximum differential short-circuit current in accordance with the following table:

| Size | Max. differential short-circuit current |
|-----------------|---|
| Size 0 – size 2 | 5000 A |
| Size 3 | 10000 A |

Tab. 2: Maximum differential short-circuit current

The drive controller has a configurable restart. If the drive controller is designed for an automatic restart after energy shutdown, this must be clearly specified on the system in accordance with EN 61800-5-1.

The drive controller has the option of a Safe Torque Off safety function (STO) in accordance with EN 61800-5-2 for safely disconnecting the energy supply to the motor. Measures based on this for protection against unexpected startup are described in EN ISO 12100 and EN ISO 14118, for example.

3.6 Working on the machine

Before all work on machines and systems, apply the 5 safety rules in accordance with DIN VDE 0105-100 (Operation of electrical installations – Part 100: General requirements) in the order listed:

- Disconnect (also ensure that the auxiliary circuits are disconnected).
- Ensure power cannot be switched on again.
- Ensure that everything is de-energized.
- Ground and short circuit.
- Cover adjacent live parts.

Information

Note the discharge time of the DC link capacitors in the general technical data for the devices. You can only determine the absence of voltage after this time period.

3.7 Ensuring traceability

The orderer must ensure traceability of the products using the serial number.

3.8 Decommissioning

In safety-oriented applications, note the mission time $T_M = 20$ years in the safety-relevant key performance indicators. A drive controller with integrated safety module must be taken out of operation 20 years after the production date. The production date of the drive controller is found on the accompanying nameplate.

For detailed information about using the safety technology, refer to the corresponding manual (see [Detailed information \[p. 158\]](#)).

3.9 Disposal

Observe the current national and regional regulations when disposing of the packaging and product! Dispose of the packaging and individual product parts depending on their properties, e.g. as:

- Cardboard
- Electronic waste (circuit boards)
- Plastic
- Sheet metal
- Copper
- Aluminum
- Battery

3.10 Firefighting



Electrical voltage! Risk of fatal injury due to electric shock!

There is a risk of fatal injury due to electric shock when using conductive firefighting equipment.

- Use ABC powder or carbon dioxide (CO₂) for firefighting.

4 UL-compliant use

This chapter contains relevant information for use under UL conditions (UL – Underwriters Laboratories).

Surrounding air temperature and pollution degree

The maximum surrounding air temperature for UL-compliant operation is 45 °C. Use in an environment with pollution degree 2 is permitted.

Network layout

All device types supplied with 480 V_{AC} are intended solely for operation with grounded wye sources at 480/277 V_{AC}.

The drive controller is designed exclusively for operation in TN networks or on wye sources. At a nominal voltage of 240 to 480 V_{AC}, they are permitted to supply a maximum differential short-circuit current in accordance with the following table:

| Size | Max. differential short-circuit current |
|-----------------|---|
| Size 0 – size 2 | 5000 A |
| Size 3 | 10000 A |

Tab. 3: Maximum differential short-circuit current

Power supply and motor overload protection

Obey the specification of $I_{2\max PU}$ at 8 kHz clock frequency in the [electrical data of the drive controller](#) [► 24].

Line fuse

Obey the information on the [UL-compliant line fuse of the supplied drive controllers](#) [► 63].

Overvoltage protection

In accordance with CSA-C22.2 No. 14-13, the following applies for use in Canada:

Depending on the device type, additional overvoltage protection must be installed in the network upstream of the device and must fulfill the following conditions.

- 1-phase drive controller:
 - Overvoltage category 3
 - Phase-ground = 240 V_{AC} (peak permitted rated surge voltage = 4 kV)
 - Phase-phase (or N) = 240 V_{AC} (peak permitted rated surge voltage = 4 kV)
- 3-phase drive controller:
 - Overvoltage category 3
 - Phase-ground = 277 V_{AC} (peak permitted rated surge voltage = 4 kV)
 - Phase-phase (or N) = 480 V_{AC} (peak permitted rated surge voltage = 6 kV)

Motor protection

The drive controller has a certified i²t model, a computational model for thermal monitoring of the motor. This fulfills the requirements for solid state motor overload protection in accordance with the amendment to UL 508C from May 2013. In order to activate it and start the protective function, set the parameters as follows (deviating from the default values): U10 = 2:Warning and U11 = 1.00 s. This model can be used instead of or in addition to temperature-monitored motor protection.

Motor temperature sensor

The drive controller features connections for PTC thermistors (NAT 145 °C), KTY temperature sensors (KTY84-130) or Pt temperature sensors (Pt1000). For a proper connection, obey the terminal description [X2: Motor temperature sensor](#) [► 76].

Information

STOBER recommends the use of PTC thermistors as thermal winding protection.

Power terminals

Sizes 0 to 2: Use only copper conductors for a surrounding temperature of 60/75 °C.

Size 3: Use only copper conductors for a surrounding temperature of 75 °C.

24 V supply and fuses

Low-voltage circuits must be supplied by an isolated source with a maximum output voltage that does not exceed 30 V_{DC}.

Fuses for 24 V_{DC} supplies must be approved for DC voltage in accordance with UL 248.

- Use a 1 A fuse (time delay) before relay 1. Obey the [terminal description for X1](#) [► 76], pin 1.
- Provide the 24 V_{DC} supply of the control unit with a 10 A fuse (time delay). Obey the [terminal description for X11](#) [► 84].
- Provide the 24 V_{DC} supply for the brake with a 4 A fuse (time delay). Obey the [X6: Brake – Feedback and supply \(ST6 option\)](#) [► 81].
- For the STO safety function via terminal X12: Use a 4 A fuse (time delay) to protect the supply voltage of the status signal. Obey the [X12: Safety technology \(option ST6\)](#) [► 85].
- The following applies to interface extensions with terminal module XI6, RI6 or IO6: Protect the 24 V_{DC} supply with a 1 A fuse (time delay). Obey the terminal description for X101, pin 18 or 19.

Branch circuit protection

Integral solid state short circuit protection does not provide branch circuit protection (line fuse) upstream of the drive controller. Branch circuit protection must be provided in accordance with the manufacturer instructions, the National Electrical Code, the Canadian Electrical Code, part I, and any additional local codes.

UL test

Only the risks of electric shock and the risk of fire have been examined during UL acceptance. Functional safety aspects have not been assessed during the UL approval process. These are assessed for STOBER by bodies such as the TÜV SÜD certification service.

5 Technical data

This chapter contains the technical data for the SD6 drive controller, the DC link connection, the safety technology and the brakes. Additional technical data on the drive controller and accessories can be found in the SD6 drive controller manual (see [Detailed information](#) [► 158]).

5.1 Drive controllers

The following chapters contain specifications for the electrical data, dimensions and weight of the drive controller.

5.1.1 General technical data

The following information applies to all device types.

| Device features | |
|--|--|
| Protection class of the device | IP20 |
| Protection class of the installation space | At least IP54 |
| Protection class | Protection class I in accordance with EN 61140 |
| Radio interference suppression | Integrated line filter in accordance with EN 61800-3, interference emission class C3 |
| Overvoltage category | III in accordance with EN 61800-5-1 |
| Marks and test symbols | CE, cULus, RoHS |

Tab. 4: Device features

| Transport and storage conditions | |
|--|---|
| Storage/ transport temperature | –20 °C to +70 °C Maximum change: 20 K/h |
| Relative humidity | Maximum relative humidity 85%, non-condensing |
| Vibration (transport) in accordance with EN 60068-2-6 | 5 Hz ≤ f ≤ 9 Hz: 3.5 mm 9 Hz ≤ f ≤ 200 Hz: 10 m/s ² 200 Hz ≤ f ≤ 500 Hz: 15 m/s ² |
| Fall height for freefall ¹ Weight < 100 kg in accordance with EN 61800-2 (or IEC 60721-3-2, class 2M1) | 0.25 m |

Tab. 5: Transport and storage conditions

| Operating conditions | |
|---|--|
| Surrounding temperature during operation | 0 °C to 45 °C with nominal data 45 °C to 55 °C with derating –2.5% / K |
| Relative humidity | Maximum relative humidity 85%, non-condensing |
| Installation altitude | 0 m to 1000 m above sea level without restrictions 1000 m to 2000 m above sea level with –1.5%/100 m derating |
| Pollution degree | Pollution degree 2 in accordance with EN 50178 |
| Ventilation | Installed fan |
| Vibration (operation) in accordance with EN 60068-2-6 | 5 Hz ≤ f ≤ 9 Hz: 0.35 mm 9 Hz ≤ f ≤ 200 Hz: 1 m/s ² |

Tab. 6: Operating conditions

¹ Only valid for components in original packaging

| Discharge times | |
|---------------------------|-------|
| Self-discharge of DC link | 6 min |

Tab. 7: Discharge times of the DC link circuit

5.1.2 Nameplate

The nameplate is placed on the side of the drive controller.



STÖBER

Kieselbronner Str. 12 | 75177 Pforzheim | Germany
Phone: + 49 7231 582-0 | www.stober.com


| | | |
|---|--|--|
| Type | Date | S/N |
| SD6A06TEX | 2030 | 7002418 |
| Eingangsspannung Input voltage Tension d'entrée | 3 x 400 V _{AC} UL: 3 x 480 V _{AC} | 60Hz 60-60Hz |
| Eingangsstrom Input current Courant d'entrée | | 4.0 A |
| Ausgangsdaten Output data Données de sortie | @8 kHz: | 0..460 V _{AC} 0..700 Hz 3.4 A |
| Schutzart Protection class Protection | | IP20 |



LISTED
POWER
CONVERSION
EQUIPMENT
52PA




**WARNUNG:** GEFAHR DES ELEKTRISCHEN
SCHLAGS. GEFAHRLICHE SPANNUNGEN KÖNNEN
NACH DEM ABSCHALTEN FÜR 6 MINUTEN ANLIEGEN
Inbetriebnahmeanleitung beachten!



WARNING: RISK OF ELECTRIC SHOCK. DANGEROUS
VOLTAGE MAY EXIST FOR 6 MINUTES AFTER REMOVING POWER.
Always observe the commissioning instructions!

AVERTISSEMENT: RISQUE DU CHOC ÉLECTRIQUE.
UNE TENSION DANGEREUSE PEUT ÊTRE PRÉSENTÉE
JUSQU' À 6 MINUTES APRÈS AVOIR COUPÉ L' ALIMENTATION.
Veillez respecter la notice de mise en service!





Safety in Motion



No. Z10 18 05 84451 006

Fig. 1: SD6A06TEX nameplate

01/2023 | ID 442537.09

21

| Designation | Value in example | Meaning |
|------------------|---|--|
| Type | SD6A06TEX | Production information |
| Date | 2030 (year/calendar week) | |
| S/N | 7002418 | |
| Input voltage | 3 × 400 V _{AC} 50 Hz UL: 3 × 480 V _{AC} 50–60 Hz | Input voltage |
| Input current | 4.0 A | Input current |
| Output data | 0 to 460 V _{AC} | Output voltage |
| | 0 to 700 Hz | Output frequency |
| | @8 kHz: 3.4 A | Output current for 8 kHz clock frequency |
| Protection class | IP20 | Protection class |

Tab. 8: Meaning of the specifications on the nameplate

| Information |
|--|
| UL and cUL certified devices with the corresponding test symbol meet the requirements of standards UL 508C and UL 840. |

5.1.3 Type designation

| | | | | | | | |
|-----------|----------|----------|----------|----------|----------|----------|----------|
| SD | 6 | A | 0 | 6 | T | E | X |
|-----------|----------|----------|----------|----------|----------|----------|----------|

Tab. 9: Example code for type designation

| Code | Designation | Design |
|------------------|----------------------|--|
| SD | Series | |
| 6 | Generation | Generation 6 |
| A, B | Version | |
| 0 – 3 | Size | |
| 6 (0 – 9) | Power output stage | Power output stage within the size |
| T | Safety module | ST6: STO via terminals |
| E | | SE6: Expanded safety functionality via terminals |
| N | Communication module | Empty |
| E | | EC6: EtherCAT |
| C | | CA6: CANopen |
| P | | PN6: PROFINET |
| N | Terminal module | Empty |
| X | | XI6: Extended |
| R | | RI6: Resolver |
| I | | IO6: Standard |

Tab. 10: Meaning of the example code

5.1.4 Material variant

On the side of the drive controller above the nameplate, there is another sticker with the material variant (MV) and serial number (SN).



Fig. 2: Sticker with MV and serial number

| Designation | Value in example | Meaning |
|-------------|-------------------|---|
| MV | MV0000012345 | MV number |
| SN | 6001192064 | Serial number |
| — | SD6A06TEX | Device type according to type designation |
| — | 1000914812/001100 | Order number/order item |

Tab. 11: Meaning of the specifications on the sticker

5.1.5 Sizes

| Type | Size |
|--------|--------|
| SD6A02 | Size 0 |
| SD6A04 | Size 0 |
| SD6A06 | Size 0 |
| SD6A14 | Size 1 |
| SD6A16 | Size 1 |
| SD6A24 | Size 2 |
| SD6A26 | Size 2 |
| SD6A34 | Size 3 |
| SD6A36 | Size 3 |
| SD6A38 | Size 3 |

Tab. 12: Available SD6 types and sizes



SD6 in sizes 0, 1, 2 and 3

5.1.6 Electrical data

The electrical data of the available SD6 sizes as well as the properties of the brake chopper can be found in the following chapters.

Information

For the time span between energizing two devices, note that:

- Direct, repeat activation of the supply voltage is possible for cyclical power-on/power-off operation.

Information

The STO safety function is available for safe stopping as an alternative to continuous, cyclical power-on/power-off operation.

For an explanation of the formula symbols used, see [Formula symbols \[► 160\]](#).

5.1.6.1 Control unit

| Electrical data | All types |
|-----------------|--------------------------------|
| U_{1CU} | 24 V _{DC} , +20%/–15% |
| I_{1maxCU} | 1.5 A |

Tab. 13: Control unit electrical data

5.1.6.2 Power unit: Size 0

| Electrical data | SD6A02 | SD6A04 | SD6A06 |
|---------------------|---|---|--------|
| U _{1PU} | 1 × 230 V _{AC} , +20% / -40%, 50/60 Hz | 3 × 400 V _{AC} , +32% / -50%, 50/60 Hz; 3 × 480 V _{AC} , +10% / -58%, 50/60 Hz | |
| f _{2PU} | 0 – 700 Hz | | |
| U _{2PU} | 0 – max. U _{1PU} | | |
| U _{2PU,ZK} | √2 × U _{1PU} | | |
| C _{PU} | 340 μF | 135 μF | 135 μF |
| C _{N,PU} | 1620 μF | 540 μF | 540 μF |

Tab. 14: SD6 electrical data, size 0

Nominal currents up to +45 °C (in the control cabinet)

| Electrical data | SD6A02 | SD6A04 | SD6A06 |
|-----------------|-----------------------------|--------|--------|
| $f_{PWM,PU}$ | 4 kHz | | |
| $I_{1N,PU}$ | 8.3 A | 2.8 A | 5.4 A |
| $I_{2N,PU}$ | 4 A | 2.3 A | 4.5 A |
| I_{2maxPU} | 180% for 5 s; 150% for 30 s | | |

Tab. 15: SD6 electrical data, size 0, for 4 kHz clock frequency

| Electrical data | SD6A02 | SD6A04 | SD6A06 |
|---------------------|----------------------------|--------|--------|
| $f_{\text{PWM,PU}}$ | 8 kHz | | |
| $I_{1\text{N,PU}}$ | 6 A | 2.2 A | 4 A |
| $I_{2\text{N,PU}}$ | 3 A | 1.7 A | 3.4 A |
| $I_{2\text{maxPU}}$ | 250% for 2 s; 200% for 5 s | | |

Tab. 16: SD6 electrical data, size 0, for 8 kHz clock frequency

| Electrical data | SD6A02 | SD6A04 | SD6A06 |
|---------------------|---------------------------|---------------------------|--------|
| U _{onCH} | 400 – 420 V _{DC} | 780 – 800 V _{DC} | |
| U _{offCH} | 360 – 380 V _{DC} | 740 – 760 V _{DC} | |
| R _{2minRB} | 100 Ω | | |
| P _{maxRB} | 1.8 kW | 6.4 kW | |
| P _{effRB} | 1.0 kW | 2.9 kW | |

Tab. 17: Brake chopper electrical data, size 0

5.1.6.3 Power unit: Size 1

| Electrical data | SD6A14 | SD6A16 |
|---------------------|---|---------|
| $U_{1\text{PU}}$ | $3 \times 400 \text{ V}_{\text{AC}}, +32\% / -50\%, 50/60 \text{ Hz};$ $3 \times 480 \text{ V}_{\text{AC}}, +10\% / -58\%, 50/60 \text{ Hz}$ | |
| $f_{2\text{PU}}$ | 0 – 700 Hz | |
| $U_{2\text{PU}}$ | 0 – max. $U_{1\text{PU}}$ | |
| $U_{2\text{PU,ZK}}$ | $\sqrt{2} \times U_{1\text{PU}}$ | |
| C_{PU} | 470 μF | 560 μF |
| $C_{\text{N,PU}}$ | 1400 μF | 1400 μF |

Tab. 18: SD6 electrical data, size 1

Nominal currents up to +45 °C (in the control cabinet)

| Electrical data | SD6A14 | SD6A16 |
|---------------------|-----------------------------|--------|
| $f_{\text{PWM,PU}}$ | 4 kHz | |
| $I_{1\text{N,PU}}$ | 12 A | 19.2 A |
| $I_{2\text{N,PU}}$ | 10 A | 16 A |
| $I_{2\text{maxPU}}$ | 180% for 5 s; 150% for 30 s | |

Tab. 19: SD6 electrical data, size 1, for 4 kHz clock frequency

| Electrical data | SD6A14 | SD6A16 |
|---------------------|----------------------------|--------|
| $f_{\text{PWM,PU}}$ | 8 kHz | |
| $I_{1\text{N,PU}}$ | 9.3 A | 15.8 A |
| $I_{2\text{N,PU}}$ | 6 A | 10 A |
| $I_{2\text{maxPU}}$ | 250% for 2 s; 200% for 5 s | |

Tab. 20: SD6 electrical data, size 1, for 8 kHz clock frequency

| Electrical data | SD6A14 | SD6A16 |
|-----------------|---------------------------|--------|
| U_{onCH} | 780 – 800 V _{DC} | |
| U_{offCH} | 740 – 760 V _{DC} | |
| R_{2minRB} | 47 Ω | |
| P_{maxRB} | 13.6 kW | |
| P_{effRB} | 6.2 kW | |

Tab. 21: Brake chopper electrical data, size 1

5.1.6.4 Power unit: Size 2

| Electrical data | SD6A24 | SD6A26 |
|-----------------|---|---------|
| U_{1PU} | 3 × 400 V _{AC} , +32% / -50%, 50/60 Hz; 3 × 480 V _{AC} , +10% / -58%, 50/60 Hz | |
| f_{2PU} | 0 – 700 Hz | |
| U_{2PU} | 0 – max. U_{1PU} | |
| $U_{2PU,ZK}$ | $\sqrt{2} \times U_{1PU}$ | |
| C_{PU} | 680 μF | 1000 μF |
| $C_{N,PU}$ | 1400 μF | 1400 μF |

Tab. 22: SD6 electrical data, size 2

Nominal currents up to +45 °C (in the control cabinet)

| Electrical data | SD6A24 | SD6A26 |
|-----------------|-----------------------------|--------|
| $f_{PWM,PU}$ | 4 kHz | |
| $I_{1N,PU}$ | 26.4 A | 38.4 A |
| $I_{2N,PU}$ | 22 A | 32 A |
| I_{2maxPU} | 180% for 5 s; 150% for 30 s | |

Tab. 23: SD6 electrical data, size 2, for 4 kHz clock frequency

| Electrical data | SD6A24 | SD6A26 |
|-----------------|----------------------------|--------|
| $f_{PWM,PU}$ | 8 kHz | |
| $I_{1N,PU}$ | 24.5 A | 32.6 A |
| $I_{2N,PU}$ | 14 A | 20 A |
| I_{2maxPU} | 250% for 2 s; 200% for 5 s | |

Tab. 24: SD6 electrical data, size 2, for 8 kHz clock frequency

| Electrical data | SD6A24 | SD6A26 |
|-----------------|---------------------------|--------|
| U_{onCH} | 780 – 800 V _{DC} | |
| U_{offCH} | 740 – 760 V _{DC} | |
| R_{2minRB} | 22 Ω | |
| P_{maxRB} | 29.1 kW | |
| P_{effRB} | 13.2 kW | |

Tab. 25: Brake chopper electrical data, size 2

5.1.6.5 Power unit: Size 3

| Electrical data | SD6A34 | SD6A36 | SD6A38 |
|-----------------|---|--------------|--------------|
| U_{1PU} | $3 \times 400 V_{AC}$, +32% / -50%, 50/60 Hz; $3 \times 480 V_{AC}$, +10% / -58%, 50/60 Hz | | |
| f_{2PU} | 0 – 700 Hz | | |
| U_{2PU} | 0 – max. U_{1PU} | | |
| $U_{2PU,ZK}$ | $\sqrt{2} \times U_{1PU}$ | | |
| C_{PU} | 430 μF | 900 μF | 900 μF |
| $C_{N,PU}$ | 5100 μF | 5100 μF | 5100 μF |

Tab. 26: SD6 electrical data, size 3

Nominal currents up to +45 °C (in the control cabinet)

| Electrical data | SD6A34 | SD6A36 | SD6A38 |
|-----------------|-----------------------------|--------|-------------------|
| $f_{PWM,PU}$ | 4 kHz | | |
| $I_{1N,PU}$ | 45.3 A | 76 A | 76 A |
| $I_{2N,PU}$ | 44 A | 70 A | 85 A ² |
| I_{2maxPU} | 180% for 5 s; 150% for 30 s | | |

Tab. 27: SD6 electrical data, size 3, for 4 kHz clock frequency

| Electrical data | SD6A34 | SD6A36 | SD6A38 |
|-----------------|----------------------------|--------|--------|
| $f_{PWM,PU}$ | 8 kHz | | |
| $I_{1N,PU}$ | 37 A | 62 A | 76 A |
| $I_{2N,PU}$ | 30 A | 50 A | 60 A |
| I_{2maxPU} | 250% for 2 s; 200% for 5 s | | |

Tab. 28: SD6 electrical data, size 3, for 8 kHz clock frequency

| Electrical data | SD6A34 | SD6A36 | SD6A38 |
|-----------------|---|--------|--------|
| U_{onCH} | 780 – 800 V_{DC} | | |
| U_{offCH} | 740 – 760 V_{DC} | | |
| R_{intRB} | 30 Ω (PTC resistance; 100 W; max. 1 kW for 1 s; $\tau = 40$ s) | | |
| R_{2minRB} | 15 Ω | | |
| P_{maxRB} | 42 kW | | |
| P_{effRB} | 19.4 kW | | |

Tab. 29: Brake chopper electrical data, size 3

| Information |
|-------------|
|-------------|

Be aware that the internal braking resistor is not active automatically and must be parameterized in DriveControlSuite.

² Specification applies to the default value of the field weakening voltage limit: B92 = 80%.

5.1.6.6 Enable and relay

You enable the power unit of the drive controller using the enable signal. The function of relay 1 can be parameterized using parameter F75.

| Electrical data | | All types |
|-----------------------------|---------|---|
| Internal device update rate | | Cycle time parameterized in A150 of the application: $t_{\min} = 1 \text{ ms}$ |
| $U_{2\max}$ | Relay 1 | 30 V |
| $I_{2\max}$ | | 1.0 A |
| Life span | | Mechanical min. 5,000,000 switching cycles; at 24 V _{DC} /1 A (ohm. load): 300,000 switching cycles |
| High level | Enable | 12 – 30 V _{DC} |
| Low level | | 0 – 8 V _{DC} |
| $I_{1\max}$ | | 16 mA |

Tab. 30: X1 electrical data

5.1.7 Dimensions

The dimensions of the available SD6 sizes can be found in the following chapters.

5.1.7.1 Dimensions: sizes 0 to 2




Fig. 3: SD6 dimensional drawing, sizes 0 to 2

| Dimension | | | Size 0 | Size 1 | Size 2 |
|---|--------------------------------------|----|-------------|--------|--------|
| Drive controller | Width | W | 70 | 70 | 105 |
| | Depth | D1 | 194 | 284 | |
| | Depth incl. RB 5000 braking resistor | D2 | 212 | 302 | |
| | Depth incl. Quick DC-Link | D2 | 229 | 319 | |
| | Height incl. fastening clips | H1 | 300 | | |
| | Height incl. AES | H2 | 367 | | |
| | Height incl. EMC shroud | H3 | approx. 376 | | |
| EMC shroud incl. shield connection terminal | Depth | D3 | approx. 111 | | |
| Fastening holes | Vertical distance | A | 283+2 | | |
| | Vertical distance to the upper edge | B | 6 | | |

Tab. 31: SD6 dimensions, sizes 0 to 2 [mm]

5.1.7.2 Dimensions: size 3




Fig. 4: SD6 dimensional drawing, size 3

| Dimension | | | Size 3 |
|---|---|----|--------------|
| Drive controller | Width | W1 | 190 |
| | Depth | D1 | 305 |
| | Depth incl. Quick DC-Link | D2 | 340 |
| | Height incl. fastening clips | H1 | 382.5 |
| | Height incl. EMC shroud | H2 | 540 |
| EMC shroud incl. shield connection terminal | Width | W2 | 147 |
| | Depth | D3 | approx. 174 |
| Fastening holes | Vertical distance | A | 365+2 |
| | Vertical distance to the upper edge | B | 11.5 |
| | Horizontal distance between the fastening holes of the drive controller | C | 150+0.2/-0.2 |
| | Horizontal distance to the side edge of the drive controller | E | 20 |

Tab. 32: SD6 dimensions, size 3 [mm]

5.1.8 Weight

| Size | Weight without packaging [g] | Weight with packaging [g] |
|--------|------------------------------|---------------------------|
| Size 0 | 2530 | 3520 |
| Size 1 | 3700 | 5470 |
| Size 2 | 5050 | 6490 |
| Size 3 | 13300 | 14800 |

Tab. 33: SD6 weight [g]

If you intend to order the drive controller with accessory parts, the weight increases as follows.

| Accessories | Weight without packaging [g] |
|----------------------|------------------------------|
| Communication module | 50 |
| Terminal module | 135 |
| Safety module | 110 |

Tab. 34: Weight of the accessory part [g]

5.1.9 Cycle times

Possible cycle times can be found in the following table.

| Type | Cycle times | Relevant parameters |
|--|------------------------|---------------------|
| Application | 1 ms, 2 ms, 4 ms, 8 ms | Adjustable in A150 |
| EtherCAT fieldbus, cyclical communication | 1 ms, 2 ms, 4 ms, 8 ms | Adjustable in A150 |
| PROFINET RT fieldbus, cyclical communication | 1 ms, 2 ms, 4 ms, 8 ms | Adjustable in A150 |
| Motion core (movement calculation) | 250 µs | — |
| Control cascade | 62.5 µs, 125 µs | Depending on B24 |

Tab. 35: Cycle times

5.2 DC link connection

The following chapter includes information on the design, dimensions and weight of the DL6A Quick DC-Link modules.

5.2.1 General technical data

The following information applies to all Quick DC-Link modules and corresponds to the general technical data for the base device.

| Device features | |
|--|---|
| Protection class of the device | IP20 (if built over with drive controller or supply module) |
| Protection class | Protection class I in accordance with EN 61140 (if built over with drive controller or supply module) |
| Protection class of the installation space | At least IP54 |

Tab. 36: Device features

| Transport and storage conditions | |
|--|---|
| Storage/ transport temperature | -20 °C to +70 °C Maximum change: 20 K/h |
| Relative humidity | Maximum relative humidity 85%, non-condensing |
| Vibration (transport) in accordance with EN 60068-2-6 | 5 Hz ≤ f ≤ 9 Hz: 3.5 mm 9 Hz ≤ f ≤ 200 Hz: 10 m/s ² 200 Hz ≤ f ≤ 500 Hz: 15 m/s ² |
| Fall height for freefall ³ Weight < 100 kg in accordance with EN 61800-2 (or IEC 60721-3-2, class 2M1) | 0.25 m |

Tab. 37: Transport and storage conditions

| Operating conditions | |
|--|--|
| Surrounding temperature during operation | 0 °C to 45 °C with nominal data 45 °C to 55 °C with derating -2.5% / K |
| Relative humidity | Maximum relative humidity 85%, non-condensing |
| Installation altitude | 0 m to 1000 m above sea level without restrictions 1000 m to 2000 m above sea level with -1.5%/100 m derating |
| Pollution degree | Pollution degree 2 in accordance with EN 50178 |
| Vibration (operation) in accordance with EN 60068-2-6 | 5 Hz ≤ f ≤ 9 Hz: 0.35 mm 9 Hz ≤ f ≤ 200 Hz: 1 m/s ² |

Tab. 38: Operating conditions

5.2.2 DL6A – SD6 assignment

DL6A is available in the following designs, appropriate for the sizes of the drive controller:

| Type | DL6A0 | DL6A1 | DL6A2 | DL6A3 |
|--------|-------|-------|-------|-------|
| ID No. | 56440 | 56441 | 56442 | 56443 |
| SD6A02 | X | — | — | — |
| SD6A04 | X | — | — | — |
| SD6A06 | X | — | — | — |
| SD6A14 | — | X | — | — |
| SD6A16 | — | X | — | — |
| SD6A24 | — | — | X | — |
| SD6A26 | — | — | X | — |
| SD6A34 | — | — | — | X |
| SD6A36 | — | — | — | X |
| SD6A38 | — | — | — | X |

Tab. 39: Assignment of DL6A to SD6

³ Only valid for components in original packaging

5.2.3 Dimensions




Fig. 5: DL6A dimensional drawing

| Dimension | | | DL6A0 DL6A1 | DL6A2 | DL6A3 |
|-----------------|---|----|----------------|-------|-------|
| Quick DC-Link | Width | W | 62 | 97 | 105 |
| | Depth | D | 35 | | |
| | Height | H1 | 260 | | 358 |
| | Fastening clip height | H2 | 20 | | 15 |
| | Height incl. fastening clips | H3 | 300 | | 393 |
| Fastening holes | Vertical distance (wall mounting) | A | 283+2 | | 380+2 |
| | Vertical distance to the upper edge | B | 7 | | |
| | Horizontal spacing of the fastening holes | C | — | | 150 |
| | Horizontal distance to the side edge | G | — | | 20 |

Tab. 40: DL6A dimensions [mm]

5.2.4 Weight

| Type | Weight without packaging [g] | Weight with packaging [g] |
|-------|------------------------------|---------------------------|
| DL6A0 | 400 | 500 |
| DL6A1 | 390 | 460 |
| DL6A2 | 540 | 620 |
| DL6A3 | 1540 | 1580 |

Tab. 41: DL6A weight [g]

5.3 Safety technology

5.3.1 ST6 safety module

The ST6 safety module adds the STO safety function to the SD6 drive controller via terminal X12.

| Specification | Electrical data |
|------------------------------|---|
| STO _a | $U_{1max} = 30 V_{DC}$ (PELV) High level = 15 – 30 V_{DC} Low level = 0 – 8 V_{DC} $I_{1max} = 100$ mA $I_{1N} = 10 - 15$ mA per channel $C_{1max} = 100$ nF |
| STO _b | |
| STO _{status} | $U_2 = U_1 - (200 \text{ m}\Omega \cdot I_1)$ |
| STO _{status} supply | $U_1 = +24 V_{DC} +20\%/25\%$ $I_{1max} = 100$ mA |
| GND | — |

Tab. 42: X12 electrical data

5.3.2 SE6 safety module

The SE6 safety module adds the expanded safety functions to the SD6 drive controller using terminals X14 and X15.

| Electrical data | Digital input | Value |
|-----------------|---------------|--|
| Low level | I0–I7 | –3 – +5 V_{DC} |
| High level | | 15 – 30 V_{DC} |
| U_{1max} | | 30 V_{DC} |
| I_{1max} | | 10.8 mA |
| f_{1max} | | < 250 Hz; results from the SE6 cycle time and the configurable filter time constant of the input |

Tab. 43: X14 electrical data – Digital inputs (SE6 option)

| Electrical data | Digital output | Value |
|----------------------|--------------------|----------------------|
| I_{2max} | O0 – O4 | 0.5 A |
| Typical voltage drop | | 25 mV |
| U_1 | 24 V_{DC} supply | 20.4 – 28.8 V_{DC} |

Tab. 44: X15 electrical data – Digital outputs (SE6 option)

5.4 Controllable brakes

You can control the following brakes:

- 24 V_{DC} brakes connected directly to X5
- Brakes connected indirectly over contactor to X5

Only in combination with SE6 safety module:

- 24 V_{DC} brakes connected directly to X8
- Brakes connected indirectly over contactor to X8

Information

Control modes 48: SSM-vector control incremental encoder and 70: SLM - vector control with commutation finding using Wake and Shake may only be used in combination with a brake for axes without gravity load.

For more information, see B20 = 48, 64 or 70.

5.4.1 X5

| Electrical data | Brake output |
|-------------------------------------|--------------|
| I_{2max} | 3 A |
| I_{2min} (direct brake control) | 330 mA |
| I_{2min} (indirect brake control) | 20 mA |
| f_{2max} | 1 Hz |
| E_{2max} | 2.84 J |

Tab. 45: Electrical data of the brake output

In combination with the ST6 safety module, the brake connected to X5 is supplied via terminal X6, in combination with the SE6 safety module via terminal X7.

5.4.2 X8 (option SE6)

| Electrical data | Brake output |
|-----------------|--|
| I_{2max} | 3.6 A / 2.5 A at surrounding temperature > 45 °C |
| I_{2min} | 0.5 mA |
| f_{2max} | 1 Hz |
| E_{2max} | 4.5 J |

Tab. 46: Electrical data of the brake output

The brake connected to X8 is supplied over terminal X7.

6 Storage

Store the products in a dry and dust-free room if you do not install them immediately.
Observe the [Transport and storage conditions](#) [► 20] specified in the technical data.

6.1 Drive controllers

The DC link capacitors can lose their electrical strength due to long storage times and must be reformed before commissioning.
This property does not apply to size 3 DC link capacitors. Therefore, size 3 drive controllers do not require reforming even after prolonged storage periods.

ATTENTION!


Material damage due to reduced electrical strength!

Reduced electrical strength can cause considerable material damage when switching on the drive controller.

- Reform drive controllers in storage annually or before commissioning.

6.1.1 Annual reforming

To prevent damage to stored drive controllers, STÖBER recommends connecting stored devices to the supply voltage once per year for one hour.
The following graphics show the basic line connection for 1-phase and 3-phase devices.




- L1 – L3 Lines 1 to 3
- N Neutral conductor
- PE Grounding conductor
- F1 Fuse
- T1 Drive controller

6.1.2 Reforming before commissioning

If annual reforming is not possible, implement reforming on stored devices before commissioning. Note that the voltage levels depend on the storage time.

The following graphic shows the predominant supply connection.



- L1 – L3 Lines 1 to 3
- N Neutral conductor
- PE Grounding conductor
- F1 Fuse
- T1 Variable transformer
- T2 Drive controller




Fig. 6: Voltage levels dependent on storage time

- | | |
|-------------------------------------|---|
| 1 Storage time of 1 – 2 years: | Apply voltage for 1 hour before switching on. |
| 2 Storage time of 2 – 3 years: | Implement reforming according to the graph before switching on. |
| 3 Storage time ≥ 3 years: | Implement reforming according to the graph before switching on. |
| Storage time < 1 year: | No actions required. |

7 Installation

The following chapters describe the installation of a drive controller and the available accessories.

For information on replacing a drive controller, see [Replacement](#) [▶ 142].

7.1 Safety instructions for installation

Installation work is permitted only when no voltage is present. Observe the 5 safety rules (see [Working on the machine](#) [▶ 16]).

To protect the devices from overheating, obey the operating conditions described in the technical data and comply with the required minimum clearances for installation.

Protect the devices against falling parts (bits or strands of wire, pieces of metal, etc.) during installation or other work in the control cabinet. Parts with conductive properties may result in a short circuit inside the devices and device failure as a result.

7.2 Basic assembly instructions

Note the points described below for installation.

7.2.1 Drive controllers

Note the following points for installation:

- Prevent condensation, e.g. with anti-condensation heating elements.
- For reasons related to EMC, use installation plates with a conductive surface (unpainted, etc.).
- Avoid installation above or in the immediate vicinity of heat-generating devices, e.g. output chokes or braking resistors.
- To ensure there is sufficient air circulation in the control cabinet, observe the minimum clearances.
- Install the devices vertically.

Reference code

Attach a sticker to the front on the device with the unique reference code of the drive controller to prevent mix-ups during installation or replacement.

7.3 Minimum clearances

Note the minimum clearances for installation below.




Fig. 7: Minimum clearances

The specified dimensions relate to the outer edges of the drive controller.

| Minimum clearance | A (above) | B (below) | C (one the side) ⁴ |
|---------------------|-----------|-----------|-------------------------------|
| Size 0 – Size 2 | 100 | 100 | 5 |
| ... with EMC shroud | 100 | 120 | 5 |
| Size 3 | 100 | 100 | 5 |
| ... with EMC shroud | 100 | 220 | 5 |

Tab. 47: Minimum clearances [mm]

⁴ Installation without Quick DC-Link module

| Dimension | E | F | G | H |
|---------------------|----|-------|---------------|------|
| Size 0, size 1 | 86 | 283+2 | approx. 89 | 40 |
| ... with EMC shroud | 86 | 283+2 | approx. 109 | 40 |
| Size 2 | 86 | 283+2 | approx. 89 | 57.5 |
| ... with EMC shroud | 86 | 283+2 | approx. 109 | 57.5 |
| Size 3 | 89 | 365+2 | approx. 59.5 | 25 |
| ... with EMC shroud | 89 | 365+2 | approx. 179.5 | 25 |

Tab. 48: Dimensions [mm]

Chokes and filters

Avoid installation below drive controllers or supply modules. For installation in a control cabinet, a distance of approximately 100 mm to other neighboring components is recommended. This distance ensures proper heat dissipation for chokes and filters.

Braking resistors

Avoid installation below drive controllers or supply modules. In order for heated air to flow out unimpeded, a minimum clearance of approximately 200 mm must be maintained in relation to neighboring components or walls and approximately 300 mm must be maintained to components above or ceilings.

7.4 Drilling diagrams and bore dimensions

Drilling diagrams and dimensions can be found in the following chapters.

7.4.1 Drive controllers




Fig. 8: SD6 and DL6A drilling diagram

The drilling dimensions depend on the selected design.

The following specifications apply to installation without a rear section module:

| SD6 dimension | | Size 0, size 1 | Size 2 | Size 3 |
|---|---|----------------|--------|--------------|
| Horizontal fastening holes of SD6 Ø 4.2 (M5) | A | 70 | 105 | — |
| | B | — | — | 20 |
| | E | — | — | 150+0.2/-0.2 |
| | C | Size 0, size 1 | 76±1 | 93.5±1 |
| | C | Size 2 | 93.5±1 | 111±1 |
| | D | Size 0, size 1 | — | 61±1 |
| | D | Size 2 | — | 78.5±1 |
| | D | Size 3 | — | 46±1 |
| Vertical fastening holes of SD6 Ø 4.2 (M5) | F | 283+2 | 283+2 | — |
| | G | — | — | 365+2 |

Tab. 49: Drilling dimensions for SD6 drive controller [mm]


The following specifications apply to installation with a DL6A Quick DC-Link or rear section braking resistor:

| Dimension of DL6A / rear section braking resistor | | Size 0, size 1 | Size 2 | Size 3 |
|--|---|----------------|--------|--------------|
| Horizontal fastening holes for rear section modules Ø 4.2 (M5) | A | 70 | 105 | — |
| | B | — | — | 20 |
| | E | — | — | 150+0.2/-0.2 |
| | C | Size 0, size 1 | 74+1 | 91.5+1 |
| | C | Size 2 | 91.5+1 | 109+1 |
| | D | Size 0, size 1 | — | 63+1 |
| | D | Size 2 | — | 80.5+1 |
| | D | Size 3 | — | 52+1 |
| Vertical fastening holes for rear section modules Ø 4.2 (M5) | F | 283+2 | 283+2 | — |
| | H | — | — | 380+2 |

Tab. 50: Drilling dimensions for DL6A Quick DC-Link or rear section braking resistor [mm]

7.5 Length of copper rails

If you would like to connect SD6 drive controllers in the DC link group using a DL6A Quick DC-Link, you need two copper rails with a cross-section of 5×12 mm in the correct length.



Note the following specifications for determining the length:

| Position | Dimension | Size 0, size 1 | Size 2 | Size 3 |
|-------------------------------|-----------|----------------|--------|--------|
| Beginning or end of the group | A | 62 | 97 | 167 |
| Within the group | M | 74 | 109 | 202 |

Tab. 51: Determination of the correct length of the copper rails [mm]

7.6 Installing the communication module

In order to connect EtherCAT, CANopen or PROFINET, you need an EC6, CA6 or PN6 communication module. The communication module is installed in the upper slot. Installation is identical for all communication modules.

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

ATTENTION!

Damage to property due to electrostatic discharge!

Take appropriate measures when handling exposed circuit boards, e.g. wearing ESD-safe clothing.

Do not touch contact surfaces.


Tools and material

You will need:


- A TORX screwdriver TX10
- The cover and screws included with the communication module

Installation


1. Unscrew the fastening screw of the dummy cover on top of the drive controller and remove the cover.




2. Slide the communication module on the guide rails into the drive controller.




3. Press on the module in order to push the pin contacts into the box header.
4. Set the tabs of the cover included with the communication module in front into the notch at an angle.



5. Place the cover on the drive controller so that the tabs lie under the edge.



6. Attach the cover using both screws.



7.7 Installing the terminal module

Analog and digital signals can be connected only by means of XI6, RI6 or IO6 terminal modules. Installation is identical for all terminal modules.

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

ATTENTION!

Damage to property due to electrostatic discharge!

Take appropriate measures when handling exposed circuit boards, e.g. wearing ESD-safe clothing.

Do not touch contact surfaces.


Tools and material

You will need:


- A TX10 Torx screwdriver
- The accessories included with the terminal module

Installation


1. Lightly press the snap closure on the front cover to unlock it.




2. Push the front cover down as far as it will go.




3. Pull the cover forwards to remove it.




4. Insert the terminal module so that the notches of the module as well as the hold-down devices on the drive controller can be guided past each other. The rear side of the module touches the drive controller.



5. Push the terminal module upwards so that the pin contacts are pushed into the box header.



6. Fasten the terminal module to the drive controller using the fastening screw.



7.8 Installing the drive controller without a rear section module

This chapter describes the installation of the SD6 drive controller without a rear section module. If you would like to connect SD6 drive controllers in the DC link or insert rear section braking resistors, you must mount the required rear section modules and then build the appropriate drive controllers over them.

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

Information

Note that drive controllers in storage require reforming each year or before commissioning at the latest.

Tools and material

You will need:

- Fastening screws
- Tool for tightening the fastening screws

Requirements and installation

Perform the following steps for each drive controller within the group and in the specified order.

- ✓ In accordance with the drilling diagram, taking into consideration the various device dimensions, you have made threaded holes for the threaded bolts on the mounting plate at the mounting position.
 - ✓ The mounting plate has been cleaned (free of oil, grease and swarf).
1. If present, install the communication module (see [Installing the communication module \[► 42\]](#)).
 2. If present, install the terminal module (see [Installing the terminal module \[► 44\]](#)).
 3. Size 3: Mount the EM6A3 EMC shroud (see [Attaching the EMC shroud \[► 57\]](#)).
 4. Fasten the top of the drive controller on the mounting plate.
 5. Sizes 0 to 2: Mount the EM6A0 EMC shroud (see [Attaching the EMC shroud \[► 57\]](#)).
 6. Fasten the bottom of the drive controller on the mounting plate.
 7. Connect the grounding conductor to the ground bolt. Obey the instructions and requirements for [Protective grounding \[► 65\]](#).
- ⇒ The installation is completed. In the next step, connect the drive controller.

7.9 Installing the DC link connection

If you would like to connect the SD6 drive controllers in the DC link group, you must first mount the Quick DC-Link modules of type DL6A and then build the appropriate drive controllers over them.

Information

Note that you cannot combine DL6A Quick DC-Link modules and RB 5000 rear section braking resistors within a group.

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

Tools and material

You will need:


- 2 copper rails with a cross-section of 5 x 12 mm in the correct length (see [Length of copper rails](#) [► 42])
- The M5 threaded bolts included with the Quick DC-Link modules and the accompanying screw and washer assemblies (screws with flat and spring washers)
- An 8 mm hexagonal socket wrench
- The insulation connection pieces and quick fastening clips included with the Quick DC-Link modules
- The insulation end sections for the left and right termination of the group that are available separately

Requirements and installation


Perform the following steps in the specified order.

- ✓ In accordance with the drilling diagram, taking into consideration the various device dimensions, you have made threaded holes for the threaded bolts on the mounting plate at the mounting position.
- ✓ The mounting plate has been cleaned (free of oil, grease and swarf).
- ✓ The copper rails must be straight, smooth, free of burrs and cleaned (free of oil and grease).

1. Fasten the Quick DC-Link modules to the mounting plate using the threaded bolts.




2. Insert the insulation connection pieces between the modules and insulation end section each at the left edge of the first module and at the right edge of the last module.




3. Clean the copper rails, especially at the contact points.

4. Insert both copper rails one after the other.



5. Fasten each of the copper rails with two quick fastening clamps per rail and Quick DC-Link module. Make certain the contact points of the copper rails do not become contaminated.



- ⇒ You have installed the Quick DC-Link. In the next step, build over the Quick DC-Link modules with the appropriate drive controllers.

7.10 Installing a rear section braking resistor

If you employ the RB 5000 rear section braking resistor provided for drive controllers of sizes 0 to 2, you must mount it first and then build over with the appropriate drive controller.

Information

Note that you cannot combine DL6A Quick DC-Link modules and RB 5000 rear section braking resistors within a group.

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.


Tools and material

You will need:

- The M5 threaded bolts included with the rear section braking resistor and the accompanying screw and washer assemblies (screws with flat and spring washers)
- An 8 mm hexagonal socket wrench

Requirements and installation

- ✓ In accordance with the drilling diagram, taking into consideration the various device dimensions, you have made threaded holes for the threaded bolts on the mounting plate at the mounting position.
 - ✓ The mounting plate has been cleaned (free of oil, grease and swarf).
1. Fasten the rear section braking resistor to the mounting plate using the threaded bolts.



⇒ You have installed the rear section braking resistor. In the next step, build over it with the appropriate drive controller.

7.11 Mounting the drive controller on the rear section module

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

Information

Note that drive controllers in storage require reforming each year or before commissioning at the latest.

Tools and material

You will need:

- A PH2 Phillips-head screwdriver

Requirements and installation


Perform the following steps for each drive controller within the group and in the specified order. For size 3 drive controllers, note that terminal X20 cannot be disconnected.

- ✓ There is a circuit diagram of the system that describes the connection of the drive controllers.
 - ✓ For each drive controller, the appropriate DL6A Quick DC-Link rear section modules or rear section braking resistors have already been installed in the installation position.
1. If present, install the communication module; see chapter [Installing the communication module](#) [► 42].
 2. If present, install the terminal module; see the chapter [Installing the terminal module](#) [► 44].
 3. Size 3: Mount the EM6A3 EMC shroud; see the chapter [Attaching the EMC shroud](#) [► 57].
 4. Sizes 0 to 2: Disconnect the X30 terminal from the drive controller.


Further action varies depending on the type of rear section module.

Mounting on a Quick DC-Link module


1. Sizes 0 to 2: Connect the brown cable to D+ of terminal X30 and the black cable to D– of terminal X30. Make sure that the conductors of the Quick DC-Link module are twisted pairs.



2. Position the drive controller on the guides of the rear section module.




3. Press the drive controller downward onto the guides.




4. Sizes 0 to 2: Mount the EM6A0 EMC shroud; see the chapter [Attaching the EMC shroud](#) [► 57].

5. Attach the drive controller to the threaded bolts using the screw and washer assemblies.




6. Connect the grounding conductor of the rear section module to the ground bolt of the rear section module and the grounding conductor of the drive controller to the ground bolt of the drive controller. Note the instructions and requirements in chapter [Protective grounding](#) [▶ 65].
7. Sizes 0 to 2: Attach terminal X30 on the underside of the drive controller.
Size 3: Connect the brown cable to D+ of terminal X20 and the black cable to D- of terminal X20. Ensure that the connection lines of the Quick DC-Link module are twisted pairs.




⇒ The installation is completed. In the next step, connect the drive controller.

Mounting on a rear section braking resistor


1. Sizes 0 to 2: Connect the two cables to R+ and R- of terminal X30. Ensure that the connection lines of the braking resistor are twisted pairs.



2. Position the drive controller on the guides of the rear section module.




3. Press the drive controller downward onto the guides.




4. Sizes 0 to 2: Mount the EM6A0 EMC shroud; see the chapter [Attaching the EMC shroud](#) [► 57].

5. Attach the drive controller to the threaded bolts using the screw and washer assemblies.



6. Connect the grounding conductor of the drive controller to the ground bolt of the drive controller. Note the instructions and requirements in chapter [Connection of the grounding conductor](#) [► 65].
7. Sizes 0 to 2: Attach terminal X30 on the underside of the drive controller.



⇒ The installation is completed. In the next step, connect the drive controller.

7.12 Attaching the EMC shroud

The EMC shroud is used to be able to apply the cable shield of the power cable. You need the EM6A0 shroud for drive controllers of sizes 0 to 2 and the EM6A3 shroud for size 3. Due to the different designs, the attachment of this accessory part to the drive controllers is also different.

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

Tools and material


You will need:

- A PH2 Phillips-head screwdriver
- EM6A3: The two screw and washer assemblies included with the shroud (screw with tooth lock washer, M4×8)


Attaching the EM6A0 to a drive controller up to size 2

- ✓ The drive controller is already installed in the control cabinet, in combination with a Quick DC-Link or a rear section braking resistor if applicable.


1. Unscrew the bottom fastening screw and flat washer of the drive controller.




2. Insert the shroud at a slight angle into the openings on the underside of the drive controller.



3. Press the rear side of the shroud either onto the mounting plate directly or onto the threaded bolts of the rear section module.




4. Fasten the shroud using the fastening screw and flat washers to the drive controller and mounting plate or threaded bolt.



Attaching the EM6A3 to a drive controller of size 3

1. Before installing the drive controller, fasten the shroud to the underside of the drive controller in the threaded holes provided for this purpose using the included screw and washer assemblies (max. tightening torque: 2.4 Nm).



8 Connection

The following chapter describes the connection of the drive controller and the available accessories.

8.1 Safety instructions for connection

Connection work is permitted only when no voltage is present. Observe the 5 safety rules (see [Working on the machine](#) [► 16]).

If you couple the drive controller in the DC link, ensure that all Quick DC-Link modules are built over with a drive controller.

The device housing must be closed before you turn on the supply voltage.

When the power supply voltage is turned on, hazardous voltages may be present on the connection terminals and the cables connected to them.

The device and the cables connected to it are not necessarily de-energized when the supply voltage is switched off and all displays have gone out!

Information

Note the discharge time of the DC link capacitors in the general technical data for the devices. You can only determine the absence of voltage after this time period.

Opening the housing, plugging in or unplugging connection terminals, connecting or removing a connecting wiring, and installing or removing accessories are prohibited while the voltage supply is switched on.

Protect the devices against falling parts (bits or strands of wire, pieces of metal, etc.) during installation or other work in the control cabinet. Parts with conductive properties may result in a short circuit inside the devices and device failure as a result.

Use only copper conductors. For the corresponding conductor cross-sections, consult the standards DIN VDE 0298-4 or EN 60204-1 (Annexes D, G) as well as the relevant terminal specifications in this documentation.

The protection class of the devices is protective grounding (protection class I in accordance with EN 61140). This means that operation is permitted only if the grounding conductor is connected according to requirements.

All protective ground connections are identified by "PE" or the international grounding symbol (IEC 60417, symbol 5019).

The products are not designed for use in a public low-voltage network that supplies residential areas. Radio-frequency interference can be expected if the products are used in this type of network.

8.2 Line routing

Observe the valid provisions for your machine or system, e.g. IEC 60364 or EN 50110, during the installation of electrical equipment.

8.3 Protective measures

Take the following protective measures into account.

8.3.1 Line fuse

The drive controller is designed exclusively for operation in TN networks or on wye sources. At a nominal voltage of 200 to 480 V_{AC}, they are permitted to supply a maximum differential short-circuit current in accordance with the following table:

| Size | Max. differential short-circuit current |
|-----------------|---|
| Size 0 – size 2 | 5000 A |
| Size 3 | 10000 A |

Tab. 52: Maximum differential short-circuit current

The line fuse ensures the line and overload protection in the drive controller. To that end, observe the requirements described below, which vary based on the configuration.

8.3.1.1 Line fuses in stand-alone operation

You can use the following protective devices when operating a single drive controller:

- Full-range safety fuses for cable and line protection with operating class gG in accordance with IEC 60269-2-1 or time delay triggering characteristics in accordance with DIN VDE 0636
- Miniature circuit breakers with triggering characteristic C in accordance with EN 60898
- Circuit breakers

Information

For size 3 device types, only operation with power chokes and line fuses is permitted for operating class gG.

Information on the recommended maximum line fuse can be found in the following table:

| Size | Type | I _{IN,PU} (4 kHz) [A] | Recommended max. line fuse [A] |
|------|--------|--------------------------------|--------------------------------|
| 0 | SD6A02 | 8.3 | 10 |
| | SD6A04 | 2.8 | 10 |
| | SD6A06 | 5.4 | 10 |
| 1 | SD6A14 | 12 | 16 |
| | SD6A16 | 19.2 | 20 |
| 2 | SD6A24 | 26.4 | 35 |
| | SD6A26 | 38.4 | 50 |
| 3 | SD6A34 | 45.3 | 50 |
| | SD6A36 | 76 | 80 |
| | SD6A38 | 76 | 80 |

Tab. 53: Line fuses in stand-alone operation

Information

To ensure problem-free operation, always comply with the recommended trigger limits and trigger characteristics of the fuse elements.

8.3.1.2 Line fuses for DC link connection

Every drive controller connected to the grid in the DC link group must be protected at the line input against overload and short circuit. To do this, a fuse combination consisting of overload protection and semiconductor short-circuit protection is connected in series. A miniature circuit breaker protects against overload and a safety fuse with gR triggering characteristics protects against short circuit.

You can use the following fuse combinations:

| Size | Type | $I_{1N,PU}$ (4 kHz) [A] | I_{1maxPU} (4 kHz) [A] | Fuse selection | |
|------|--------|-------------------------------|--------------------------------|---|---|
| | | | | Miniature circuit breakers | Safety fuse |
| 0 | SD6A02 | 8.3 | 14.9 | EATON Type: FAZ-B10/1, Manufacturer No. 278531 Triggering characteristics: B 10 A | SIBA Type: URZ, Item No. 50 140 06.20 Triggering characteristics: gR 20 A |
| | SD6A04 | 2.8 | 5 | EATON Type: FAZ-B6/3, Manufacturer No. 278841 Triggering characteristics: B 6 A | SIBA Type: URZ, Item No. 50 140 06.20 Triggering characteristics: gR 20 A |
| | SD6A06 | 5.4 | 9.7 | | |
| 1 | SD6A14 | 12 | 21.6 | EATON Type: FAZ-Z20/3, Manufacturer No. 278928 Triggering characteristics: Z 20 A | SIBA Type: URZ, Item No. 50 140 06.32 Triggering characteristics: gR 32 A |
| | SD6A16 | 19.2 | 34.6 | | |
| 2 | SD6A24 | 26.4 | 47.5 | EATON Type: FAZ-Z40/3, Manufacturer No. 278931 Triggering characteristics: Z 40 A | SIBA Type: URZ, Item No. 50 140 06.80 Triggering characteristics: gR 80 A |
| | SD6A26 | 38.4 | 69.1 | | |
| 3 | SD6A34 | 45.3 | 81.5 | EATON Type: FAZ-B63/3, Manufacturer No. 278853 Triggering characteristics: B 63 A ⁵ Siemens Type: SIRUS, Item No. 3RV 1041-4KA10 Triggering characteristics: 57 A–75 A ⁶ | SIBA Type: URZ, Item No. 50 140 06.100 Triggering characteristics: gR 100 A |
| | SD6A36 | 76 | 136.8 | | |
| | SD6A38 | 76 | 136.8 | | |

Tab. 54: Line fuses for DC link connection

⁵The input current is reduced from 73 A to 63 A and the output power is lowered as a result; however, reliable rectifier protection is still guaranteed.

⁶Miniature circuit breaker size S3, CLASS 10, adjustable current range: 57 A – 75 A, electromagnetic triggering: 975 A. The rectifier diodes are not protected in the range of 2x to 13x the nominal current.

Information

To ensure problem-free operation, always comply with the recommended trigger limits and trigger characteristics of the fuse elements.

Maximum number of drive controllers

Multiple drive controllers of the same rating can be connected via a common fuse combination. The fuses and the resulting maximum line input current correspond to that of a single drive controller.

In order to prevent gradual damage to the safety fuse, the maximum number of possible drive controllers on one fuse combination is limited as follows:

- Size 0: Maximum of 4 drive controllers
- Size 1: Maximum 2 drive controllers
- Size 2: Maximum 5 drive controllers
- Size 3: Maximum of 2 drive controllers

ATTENTION!**Damage due to overload!**

In order to ensure an even distribution of charging current on all AC-supplied drive controllers, all circuit breakers must be closed when engaging the power supply.

- In order that the input rectifier is not overloaded in the event of a possible fuse failure in the group, evaluation of the grid monitoring for AC-supplied drive controllers must lead to deactivation of the entire DC link group.

8.3.1.3 UL-compliant line fuses

For UL-compliance, use the following fuses for the powered drive controller:

- Fuses of class RK1 (e.g. Bussmann KTS-R-xxA/600 V), CF, J, T or G
- For drive controllers of sizes 0 and 1, you can alternatively use fuses of class CC
- For drive controllers of sizes 0 to 2, you can alternatively use type E motor starters, which consist of a circuit breaker and supply terminal

More detailed specifications about the appropriate fuses can be found in the following table:

| Size | Type | Class CC [A] | Class RK1, CF, J, T or G [A] | Type E motor starter |
|------|--------|--------------|------------------------------|--------------------------------------|
| 0 | SD6A02 | 10 | 10 | EATON PKZM0-10/SP + BK25/3-PKZ0-E |
| | SD6A04 | 10 | 10 | EATON PKZM0-10/SP + BK25/3-PKZ0-E |
| | SD6A06 | 10 | 10 | EATON PKZM0-10/SP + BK25/3-PKZ0-E |
| 1 | SD6A14 | 15 | 15 | EATON PKZM0-16/SP + BK25/3-PKZ0-E |
| | SD6A16 | 20 | 20 | EATON PKZM0-25/SP + BK25/3-PKZ0-E |
| 2 | SD6A24 | — | 35 | EATON PKZM0-32/SP + BK25/3-PKZ0-E |
| | SD6A26 | — | 50 | EATON PKZM4-50 + BK50/3-PKZ4-E |
| 3 | SD6A34 | — | 50 | — |
| | SD6A36 | — | 80 | — |
| | SD6A38 | — | 80 | — |

Tab. 55: UL-compliant line fuses

The pre-configured Type E motor starters can be assembled as an alternative from the individual components in accordance with the following table:

| Type E motor starter | Circuit breakers | | Supply terminal | | Lockable knob | |
|-----------------------------|------------------|----------|-----------------|----------|---------------|----------|
| | Type | Item No. | Type | Item No. | Type | Item No. |
| PKZM0-10/SP + BK25/3-PKZ0-E | PKZM0-10 | 72739 | BK25/3-PKZ0-E | 262518 | AK-PKZ0 | 30851 |
| PKZM0-16/SP + BK25/3-PKZ0-E | PKZM0-16 | 46938 | | | | |
| PKZM0-25/SP + BK25/3-PKZ0-E | PKZM0-25 | 46989 | | | | |
| PKZM0-32/SP + BK25/3-PKZ0-E | PKZM0-32 | 278489 | | | | |
| PKZM4-50 + BK50/3-PKZ4-E | PKZM4-50 | 222355 | BK50/3-PKZ4-E | 272165 | | |

Tab. 56: Individual components of Type E motor starters

Information

To ensure problem-free operation, always comply with the recommended trigger limits and trigger characteristics of the fuse elements.

8.3.2 Residual current protective device

Depending on the function, leakage currents may occur when operating drive controllers. Leakage currents are interpreted as residual currents by residual current protective devices (RCDs) and may therefore lead to false triggering. Depending on the relevant power supply connections, residual currents may occur with or without a DC current component. Because of this, you should take into consideration both the magnitude as well as the profile of the possible leakage or residual current when selecting a suitable residual current protective device.

Leakage and residual currents with a DC current component can restrict the functionality of type A and AC residual current protective devices.

Protect 1-phase installations using type B universal current-sensitive residual current protective devices or type F mixed frequency-sensitive devices.

Protect 3-phase installations with type B universal current-sensitive residual current protective devices.

DANGER!

Electrical voltage! Risk of fatal injury due to electric shock!

In 3-phase installations, this product can cause a direct current in the protective grounding conductor.

- If a residual current protective device (RCD) or residual current monitoring device (RCM) is used for protection in case of direct or indirect contact, only one RCD or RCM of type B is permitted on the power supply side of this product.

False triggering – Causes

Depending on stray capacitances and imbalances, leakage currents above 30 mA may occur during operation.

Undesirable false triggering occurs under the following conditions:

- Connecting the installation to the supply voltage:
This false triggering can be remedied by using short-time delayed (super-resistant), delayed switch-off (selective) residual current protective devices or those with increased tripping current (e.g. 300 or 500 mA).
- Higher frequency leakage currents for long power cables under normal operating conditions:
For example, use low-capacitance cables or use an output choke.
- High imbalances in the supply grid.
This false triggering can be rectified, e.g. using an isolating transformer.

DANGER!

Electrical voltage! Risk of fatal injury due to electric shock!

Residual current protective devices with increased tripping current as well as with short-time delayed or delayed switch-off trigger characteristics may not meet the requirements for personal protection.

- Check whether the use of the selected residual current protective device is permitted in your application.
-

8.3.3 Protective grounding

In order to dimension the grounding, it must be ensured that the upstream fuse is triggered in the event of a short circuit. Observe the requirements described below for the correct connection of the protective grounding.

8.3.3.1 Minimum cross-section of the grounding conductor

Leakage currents > 10 mA can arise in normal operation. The minimum cross-section of the protective grounding conductor must comply with the local safety regulations for protective grounding conductors with high leakage current. To fulfill regulations such as EN 60204-1, connect a copper conductor according to the following table:

| Cross-section A Power grid line | Minimum cross-section A_{\min} Grounding conductor |
|---|---|
| $A \leq 2.5 \text{ mm}^2$ | 2.5 mm^2 |
| $2.5 \text{ mm}^2 < A \leq 16 \text{ mm}^2$ | A |
| $16 \text{ mm}^2 < A \leq 35 \text{ mm}^2$ | $\geq 16 \text{ mm}^2$ |
| $> 35 \text{ mm}^2$ | A/2 |

Tab. 57: Minimum cross-section of the grounding conductor

8.3.3.2 Cable shields and sheaths

In accordance with DIN EN 60204-1, the following parts of a machine and its electrical equipment must be connected to the grounding conductor system, but must not be used as grounding conductors:

- Metal cable shields
- Sheath

8.3.3.3 Connection of the grounding conductor

You connect the grounding conductor to the drive controller over terminal X10.

Additional requirements for protective equipotential bonding apply in the event of ground leakage currents > 10 mA. At least one of the following conditions must be fulfilled:

- The grounding conductor must have a minimum cross-section of 10 mm^2 Cu over its overall length
- If the grounding conductor has a cross-section of less than 10 mm^2 , a 2nd grounding conductor must be provided with a cross-section of at least the same size, as at terminal X10, up to the point at which the grounding conductor exhibits the minimum cross-section of 10 mm^2

A ground bolt is mounted to the devices for connecting the 2nd grounding conductor. The ground bolt is marked with the grounding symbol according to IEC 60417 (symbol 5019).

You will need an open-ended wrench or external hex key with a width across flats of 10 mm.

Obey a tightening torque of 4.0 Nm (35 Lb.inch).

Observe the order for assembly:




Fig. 9: Connection of the grounding conductor

- 1 M6 ground bolt
- 2 Contact disk
- 3 Cable lug
- 4 Washer
- 5 Nut

The contact disk, washer and nut are supplied with the drive controller.

8.3.4 EMC recommendations

Information

The following information on EMC-compliant installation is only a recommendation. Depending on the application, the ambient conditions as well as the legal requirements, measures beyond these recommendations may be required.

Lay the power line, power cable and signal lines separately from each other, e.g. in separate cable ducts.

Only use shielded, low-capacitance cables as power cables.

If the brake line is carried in the power cable, it must be shielded separately.

Ground and insulate free line ends if they cannot be connected to the terminals provided for this purpose on the drive controller, e.g. using a connecting terminal.

Connect the shield of the power cable to the grounding conductor system over a wide area and in the immediate vicinity of the drive controller. For this purpose, use the shield contact provided for the drive controllers or suitable accessories.

The connection lines for braking resistors as well as the cores of the Quick DC-Link modules must be implemented as twisted pairs. At line lengths of 30 cm or more, the lines also must be implemented with shielding and the shield must be applied over a wide area in the immediate vicinity of the drive controller.

For motors with terminal boxes, connect the shield to the terminal box over large contact areas. For example, use EMC cable screw connections.

Connect the shield of the control lines on one side to the reference potential of the source, e.g. the PLC or CNC.

You may use chokes to improve the EMC and protect the drive system. Power chokes are used to dampen voltage and current peaks and reduce the load of the power feed-in of the drive controllers or supply modules. Output chokes reduce current peaks caused by line capacity at the power output of the drive controller.

8.4 Drive controllers

The following section contains detailed information about the terminals and the correct connection of the drive controller.

| |
|--------------------|
| Information |
|--------------------|

For UL-compliant operation: The connections marked with PE are intended solely for the functional grounding.

8.4.1 Overview with ST6 safety module

The images for the connection overviews show the SD6 drive controller in every size with the following equipment:

- ST6 safety module (STO using terminals)
- XI6 terminal module
- EC6 communication module (EtherCAT)

Alternatively, the following equipment is available:

- RI6 or IO6 terminal modules
- CA6 (CANopen) or PN6 (PROFINET) communication modules

8.4.1.1 Sizes 0 and 1




Fig. 10: Connection overview of sizes 0 and 1 with ST6 safety module

| | | | |
|---|---|----|--|
| 1 | Ground bolt | 9 | X120: Encoder connection on optional XI6 terminal module (alternatively X120 and X140: Encoder connections on RI6 terminal module or IO6 terminal module without encoder connection) |
| 2 | X10: 230/400 V _{AC} supply | 10 | X1: Enable and relay 1 |
| 3 | X11: 24 V _{DC} supply | 11 | X4: Encoder |
| 4 | X12: ST6 safety technology | 12 | X2: Motor temperature sensor |
| 5 | X3A: PC, IGB | 13 | X5: Brake (actuation) |
| 6 | X3B: PC, IGB | 14 | X6: Brake (feedback and supply) |
| 7 | X200: EtherCAT on the optional EC6 communication module (alternatively CANopen on CA6 communication module or PROFINET on PN6 communication module) | 15 | X20: Motor |
| 8 | X201: EtherCAT on the optional EC6 communication module (alternatively PROFINET on PN6 communication module) | 16 | X30: Quick DC-Link, braking resistor |

8.4.1.2 Size 2




Fig. 11: Connection overview of size 2 with ST6 safety module

- | | | | |
|---|---|----|--|
| 1 | Ground bolt | 9 | X120: Encoder connection on optional XI6 terminal module (alternatively X120 and X140: Encoder connections on RI6 terminal module or IO6 terminal module without encoder connection) |
| 2 | X10: 400 V _{AC} supply | 10 | X1: Enable and relay 1 |
| 3 | X11: 24 V _{DC} supply | 11 | X4: Encoder |
| 4 | X12: ST6 safety technology | 12 | X2: Motor temperature sensor |
| 5 | X3A: PC, IGB | 13 | X5: Brake (actuation) |
| 6 | X3B: PC, IGB | 14 | X6: Brake (feedback and supply) |
| 7 | X200: EtherCAT on the optional EC6 communication module (alternatively CANopen on CA6 communication module or PROFINET on PN6 communication module) | 15 | X20: Motor |
| 8 | X201: EtherCAT on the optional EC6 communication module (alternatively PROFINET on PN6 communication module) | 16 | X30: Quick DC-Link, braking resistor |

8.4.1.3 Size 3




Fig. 12: Connection overview of size 3 with ST6 safety module, top of device

- 1 X10: 400 V_{AC} supply
- 2 X11: 24 V_{DC} supply
- 3 X12: ST6 safety technology
- 4 X3A: PC, IGB
- 5 X3B: PC, IGB
- 6 X200: EtherCAT on the optional EC6 communication module (alternatively CANopen on CA6 communication module or PROFINET on PN6 communication module)
- 7 X201: EtherCAT on the optional EC6 communication module (alternatively PROFINET on PN6 communication module)




Fig. 13: Connection overview of size 3 with ST6 safety module, bottom of device

- 8 X120: Encoder connection on optional XI6 terminal module (alternatively X120 and X140: Encoder connections on RI6 terminal module or IO6 terminal module without encoder connection)
- 9 X1: Enable and relay 1
- 10 X4: Encoder
- 11 X5: Brake (actuation)
- 12 X6: Brake (feedback and supply)
- 13 X2: Motor temperature sensor
- 14 X20: Motor, Quick DC-Link, braking resistor

8.4.2 Overview with SE6 safety module

The images for the connection overviews show the SD6 drive controller in every size with the following equipment:

- SE6 safety module (expanded safety functionality via terminals)
- XI6 terminal module
- EC6 communication module (EtherCAT)

Alternatively, the following equipment is available:

- RI6 or IO6 terminal modules
- CA6 (CANopen) or PN6 (PROFINET) communication modules

8.4.2.1 Sizes 0 and 1




Fig. 14: Connection overview of sizes 0 and 1 with SE6 safety module

- | | | | |
|----|---|----|--|
| 1 | Ground bolt | 11 | X120: Encoder connection on optional XI6 terminal module (alternatively X120 and X140: Encoder connections on RI6 terminal module or IO6 terminal module without encoder connection) |
| 2 | X10: 230/400 V _{AC} supply | 12 | X1: Enable and relay 1 |
| 3 | X11: 24 V _{DC} supply | 13 | X4: Encoder |
| 4 | X14: SE6 safety technology – Safe inputs | 14 | X2: Motor temperature sensor |
| 5 | X15: SE6 safety technology – Safe outputs and supply for X50 | 15 | X8: Brake 2 (SBC+/-) |
| 6 | X50: SE6 safety technology – Plausibility encoder | 16 | X5: Brake 1 (BD1/BD2) |
| 7 | X3A: PC, IGB | 17 | X7: Supply for brake(s) |
| 8 | X3B: PC, IGB | 18 | X20: Motor |
| 9 | X200: EtherCAT on the optional EC6 communication module (alternatively CANopen on CA6 communication module or PROFINET on PN6 communication module) | 19 | X30: Quick DC-Link, braking resistor |
| 10 | X201: EtherCAT on the optional EC6 communication module (alternatively PROFINET on PN6 communication module) | | |

8.4.2.2 Size 2




Fig. 15: Connection overview of size 2 with SE6 safety module

- | | | | |
|----|---|----|--|
| 1 | Ground bolt | 11 | X120: Encoder connection on optional XI6 terminal module (alternatively X120 and X140: Encoder connections on RI6 terminal module or IO6 terminal module without encoder connection) |
| 2 | X10: 230/400 V _{AC} supply | 12 | X1: Enable and relay 1 |
| 3 | X11: 24 V _{DC} supply | 13 | X4: Encoder |
| 4 | X14: SE6 safety technology – Safe inputs | 14 | X2: Motor temperature sensor |
| 5 | X15: SE6 safety technology – Safe outputs and supply for X50 | 15 | X8: Brake 2 (SBC+/-) |
| 6 | X50: SE6 safety technology – Plausibility encoder | 16 | X5: Brake 1 (BD1/BD2) |
| 7 | X3A: PC, IGB | 17 | X7: Supply for brake(s) |
| 8 | X3B: PC, IGB | 18 | X20: Motor |
| 9 | X200: EtherCAT on the optional EC6 communication module (alternatively CANopen on CA6 communication module or PROFINET on PN6 communication module) | 19 | X30: Quick DC-Link, braking resistor |
| 10 | X201: EtherCAT on the optional EC6 communication module (alternatively PROFINET on PN6 communication module) | | |

8.4.2.3 Size 3




Fig. 16: Connection overview of size 3 with SE6 safety module, top of device

- 1 X10: 400 V_{AC} supply
- 2 X11: 24 V_{DC} supply
- 3 X14: SE6 safety technology – Safe inputs
- 4 X15: SE6 safety technology – Safe outputs and supply for X50
- 5 X50: SE6 safety technology – Plausibility encoder
- 6 X3A: PC, IGB
- 7 X3B: PC, IGB
- 8 X200: EtherCAT on the optional EC6 communication module (alternatively CANopen on CA6 communication module or PROFINET on PN6 communication module)
- 9 X201: EtherCAT on the optional EC6 communication module (alternatively PROFINET on PN6 communication module)




Fig. 17: Connection overview of size 3 with SE6 safety module, bottom of device


- 10 X120: Encoder connection on optional XI6 terminal module (alternatively X120 and X140: Encoder connections on RI6 terminal module or IO6 terminal module without encoder connection)
- 11 X1: Enable and relay 1
- 12 X4: Encoder
- 13 X5: Brake 1 (BD1/BD2)
- 14 X7: Supply for brake(s)
- 15 X8: Brake 2 (SBC+/-)
- 16 X2: Motor temperature sensor
- 17 X20: Motor, Quick DC-Link, braking resistor

8.4.3 X1: Enable and relay 1

You enable the power unit of the drive controller using the enable signal. The function of relay 1 can be parameterized using parameter F75.

Technical data

Note the technical data for X1 (see [Enable and relay](#) [► 28]).

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---|
|  1 2 3 4 | 1 | NO contact | Relay 1; recommended fuse protection: max. 1 AT ⁷ |
| | 2 | | |
| | 3 | 0 V GND | Enable |
| | 4 | Input | |

Tab. 58: X1 connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [FMC 1,5 -ST-3,5](#) [► 151].

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 59: Cable length [m]

8.4.4 X2: Motor temperature sensor

Terminal X2 is provided for connecting motor temperature sensors. The following can be connected to all SD6 drive controller device types:

- A KTY84-130 in one winding
- A Pt1000 in one winding
- A PTC triplet

Information

Evaluation of the temperature sensor is always active. If operation without a temperature sensor is permitted, the connections must be bridged to X2. Otherwise a fault is triggered when the device is switched on.

Information


STOBER recommends the use of PTC thermistors as thermal winding protection.

Motor temperature sensor wires in the resolver or EnDat cable for SDS 4000

If you replace an SDS 4000 with an SD6, the wires of the motor temperature sensor are maintained in the previously used encoder cable. To be able to continue using the cable, you need the RI6 terminal module, to which you can connect the cable via an AP6 interface adapter. The adapter is available in three different designs.

⁷ For fuse protection, use a 1 A fuse (time delay) before relay 1. For UL-compliant use, be sure that the fuse meets certification requirements for DC voltage in accordance with UL 248.

Connection description

| | Pin | Designation | Function |
|--|-----|-------------|---------------------------|
|  7 8 | 7 | 1TP1/1K1 | PTC/Pt1000/KTY connection |
| | 8 | 1TP2/1K2 | |

Tab. 60: X2 connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [BFL 5.08HC 180 SN |▸ 149](#)].

Cable requirements


| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 100 m |

Tab. 61: Cable length [m]

8.4.5 X3A, X3B: PC, IGB

You can implement the IGB function (Integrated Bus) using the X3A and X3B interfaces:

- Direct connection to the PC
- IGB motion bus
- Remote maintenance

| Socket | Pin | Designation | Function |
|--|-----|-------------|------------------------|
|  1 2 ... 7 8 | 1 | Tx+ | Ethernet communication |
| | 2 | Tx- | |
| | 3 | Rx+ | |
| | 4 | — | — |
| | 5 | — | — |
| | 6 | Rx- | Ethernet communication |
| | 7 | — | — |
| | 8 | — | — |

Tab. 62: X3A and X3B connection description

Cable requirements

| Information |
|---|
| To ensure proper functionality, we recommend using cables from STOBER that are matched to the complete system. If unsuitable cables are used, we reserve the right to reject claims under the warranty. |

STOBER offers ready-made cables for:

- Direct connection of PC and drive controller
- Setup of Integrated Bus

It is also possible to use cables with the following specification:

Ethernet patch cables or crossover cables meeting the CAT 5e quality level are the ideal cables. The Fast Ethernet technology allows a maximum cable length of 100 m between two nodes.

Information

Ensure that you only use shielded cables with an SF/FTP, S/FTP or SF/UTP design.

8.4.6 X4: Encoder

The encoders described below can be connected to X4.

ATTENTION!


Risk of encoder destruction!

X4 may not be plugged in or unplugged when the device is switched on!

Evaluable encoders


The technical data of the evaluable encoders at X4 can be found in the manual for the SD6 drive controller (see [Detailed information](#) [► 158]).

EnDat 2.1/2.2 digital encoders and SSI encoders

| Socket | Pin | Designation | Function |
|---|-----|----------------------|--|
|  | 1 | — | — |
| | 2 | 0 V GND | Reference potential for encoder supply to pin 4 |
| | 3 | — | — |
| | 4 | U ₂ | Encoder supply |
| | 5 | Data + | Differential input for DATA |
| | 6 | — | — |
| | 7 | — | — |
| | 8 | Clock + | Differential input for CLOCK |
| | 9 | — | — |
| | 10 | 0 V Sense | Optional reference potential of the Sense connection for regulating the encoder supply |
| | 11 | — | — |
| | 12 | U ₂ Sense | Sense connection for regulating the encoder supply |
| | 13 | Data – | Inverse differential input for DATA |
| | 14 | — | — |
| | 15 | Clock – | Inverse differential input for CLOCK |


Tab. 63: X4 connection description for EnDat 2.1/2.2 digital encoders and SSI encoders

Differential HTL incremental encoders

| Socket | Pin | Designation | Function |
|---|-----|----------------------|--|
|  | 1 | B + | Differential input for B channel |
| | 2 | 0 V GND | Reference potential for encoder supply to pin 4 |
| | 3 | N + | Differential input for N channel |
| | 4 | U ₂ | Encoder supply |
| | 5 | — | — |
| | 6 | A + | Differential input for A channel |
| | 7 | — | — |
| | 8 | — | — |
| | 9 | B – | Inverse differential input for B channel |
| | 10 | N – | Inverse differential input for N channel |
| | 11 | A – | Inverse differential input for A channel |
| | 12 | U ₂ Sense | Sense connection for regulating the encoder supply |
| | 13 | — | — |
| | 14 | — | — |
| | 15 | — | — |

Tab. 64: X4 connection description for differential HTL incremental encoders

Differential TTL incremental encoders

| Socket | Pin | Designation | Function |
|---|-----|----------------------|--|
|  | 1 | — | — |
| | 2 | 0 V GND | Reference potential for encoder supply to pin 4 |
| | 3 | — | — |
| | 4 | U ₂ | Encoder supply |
| | 5 | B + | Differential input for B channel |
| | 6 | — | — |
| | 7 | N + | Differential input for N channel |
| | 8 | A + | Differential input for A channel |
| | 9 | — | — |
| | 10 | — | — |
| | 11 | — | — |
| | 12 | U ₂ Sense | Sense connection for regulating the encoder supply |
| | 13 | B – | Inverse differential input for B channel |
| | 14 | N – | Inverse differential input for N channel |
| | 15 | A – | Inverse differential input for A channel |

Tab. 65: X4 connection description for differential TTL incremental encoders

Cable requirements

| Feature | All sizes |
|-------------------|-----------------|
| Max. cable length | 100 m, shielded |

Tab. 66: Cable length [m]

Information

To ensure proper functionality, we recommend using cables from STOBER that are matched to the complete system. If unsuitable cables are used, we reserve the right to reject claims under the warranty.

8.4.7 X5: Brake – Actuation

The brake is connected to X5.

Information


Note that brakes from other manufacturers may be connected only after consultation with STOBER.

Controllable brakes

Note the technical data of the brakes controllable at X5 (see [X5](#) [► 35]).

Information

In the parameters F93 and F100, you can set whether the brake is connected directly or indirectly and whether brake monitoring is deactivated.

| | Pin | Designation | Function |
|--|-----|-------------|---------------------|
|  5 6 | 5 | 1BD1 | Brake actuation |
| | 6 | 1BD2 | Reference potential |

Tab. 67: X5 connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [BFL 5.08HC 180 SN](#) [► 149].

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 100 m |


Tab. 68: Cable length [m]

8.4.8 X6: Brake – Feedback and supply (ST6 option)

X6 is used for brake diagnostics and supply. The X6 connection is part of the ST6 safety module.

| Electrical data | All types |
|-----------------|---------------------------|
| U_1 | 24 V _{DC} , +25% |
| I_{1max} | 6 A, UL: 4 A |

Tab. 69: Electrical data for the brake supply

| Terminal | Pin | Designation | Function |
|--|-----|-------------|--|
|  1 2 3 4 | 1 | Feedback | Feedback input of an optional switching amplifier for braking diagnostics; if the brake is connected to SD6 indirectly over a contactor and the switching amplifier is to be monitored, pins 1 and 2 must be connected via an external N/O contact |
| | 2 | 0 V GND | Reference potential for feedback |
| | 3 | + | 24 V _{DC} supply for the brake; recommended fuse protection: max. 6 AT ⁸ |
| | 4 | – | Reference potential for supply voltage of the brake |

Tab. 70: X6 connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [BFL 5.08HC 180 SN \[► 149\]](#).

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |


Tab. 71: Cable length [m]

8.4.9 X7: Brake 2 – Supply (SE6 option)

X7 serves as the brake supply for brake 2. The X7 connection is part of the SE6 safety module.

| Electrical data | All types |
|-----------------|---------------------------|
| U_1 | 24 V _{DC} , +20% |
| I_{1max} | 8 A, UL: 4 A |

Tab. 72: Electrical data for the brake supply

| | Pin | Designation | Function |
|--|-----|-------------|--|
|  1 2 | 1 | + | 24 V _{DC} supply for the brakes at X5 and X8; recommended fuse protection: max. 8 AT ⁹ |
| | 2 | – | Reference potential for supply voltage of the brakes |

Tab. 73: X7 connection description

⁸For UL-compliance, use of a 4 A fuse (time delay) is required. Be sure that the fuse meets certification requirements for DC voltage in accordance with UL 248.

⁹For UL-compliance, use of a 4 A fuse (time delay) is required. Note that the fuse meets certification requirements for the relevant DC voltage in accordance with UL 248.

Connecting wiring

For the connecting wiring, obey the terminal specification [BFL 5.08HC 180 SN](#) [► 149].

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |


Tab. 74: Cable length [m]

8.4.10 X8: Brake 2 – Safe brake control (SE6 option)

X8 serves as the safe brake control for brake 2. The X8 connection is part of the SE6 safety module.

Controllable brakes

Note the technical data of the brakes controllable at X8 (see [X8 \(option SE6\)](#) [► 35]).

| | Pin | Designation | Function |
|--|-----|-------------|------------------------------|
|  3 4 | 3 | SBC+ | Output for brake control 2 + |
| | 4 | SBC– | Output for brake control 2 – |

Tab. 75: X8 connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [BFL 5.08HC 180 SN](#) [► 149].

Cable requirements

| Feature | All sizes |
|-------------------|--|
| Max. cable length | 100 m; shielded on drive controllers of size 3 |

Tab. 76: Cable length [m]


8.4.11 X10: 230/400 V supply

Terminal X10 serves to connect the drive controller to the supply grid.


Conductor cross-sections for the power connection

When selecting the conductor cross-section, note the line fuse, the maximum permitted conductor cross-section of terminal X10, the routing method and the surrounding temperature.

Size 0

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---------------------|
|  1 2 3 | 1 | L1 | Power supply |
| | 2 | N | Neutral conductor |
| | 3 | PE | Grounding conductor |


Tab. 77: X10 connection description – Size 0, 1-phase line connection

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---------------------|
|  1 2 3 4 | 1 | L1 | Power supply |
| | 2 | L2 | |
| | 3 | L3 | |
| | 4 | PE | Grounding conductor |

Tab. 78: X10 connection description – Size 0, 3-phase line connection

For the connecting wiring, obey the terminal specification [GFKC 2,5 -ST-7,62 \[► 152\]](#).


Size 1

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---------------------|
|  1 2 3 4 | 1 | L1 | Power supply |
| | 2 | L2 | |
| | 3 | L3 | |
| | 4 | PE | Grounding conductor |

Tab. 79: X10 connection description – Size 1, 3-phase line connection

For the connecting wiring, obey the terminal specification [SPC 5 -ST-7,62 \[► 155\]](#).


Size 2

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---------------------|
|  1 2 3 4 | 1 | L1 | Power supply |
| | 2 | L2 | |
| | 3 | L3 | |
| | 4 | PE | Grounding conductor |

Tab. 80: X10 connection description – Size 2, 3-phase line connection

For the connecting wiring, obey the terminal specification [SPC 16 -ST-10,16 \[► 155\]](#).

Size 3

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---------------------|
|  1 2 3 4 | 1 | L1 | Power supply |
| | 2 | L2 | |
| | 3 | L3 | |
| | 4 | PE | Grounding conductor |

Tab. 81: X10 connection description – Size 3, 3-phase line connection

For the connecting wiring, note the [MKDSP 25 -15,00 \[► 154\]](#) terminal specification.

8.4.12 X11: 24 V supply

The connection of 24 V_{DC} to X11 is required for the power supply of the control unit.

ATTENTION!


Device damage due to overload!

If the 24 V_{DC} power supply is looped to multiple devices over the terminal, the terminal may be damaged by a current that is too high.

- Make sure that the current over the terminal does not exceed the value 15 A (UL: 10 A).

| Electrical data | All types |
|---------------------|--------------------------------|
| U _{1CU} | 24 V _{DC} , +20%/–15% |
| I _{1maxCU} | 1.5 A |

Tab. 82: Control unit electrical data

| | Pin | Designation | Function |
|--|-----|-------------|--|
|  | 1 | + | 24 V _{DC} supply for the control unit; bridged in the terminal; design in accordance with EN 60204: PELV, secondary grounded, recommended fuse protection: max. 15 AT ¹⁰ |
| | 2 | | |
| | 3 | – | Reference potential for +24 V _{DC} , bridged in the terminal |
| | 4 | | |

Tab. 83: X11 connection description

Information

The device may not be connected to a DC supply grid. Instead, supply it over a local 24 V_{DC} power supply unit.

Connecting wiring

For the connecting wiring, obey the terminal specification [BLDF 5.08 180 SN](#) [► 150].

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 84: Cable length [m]

¹⁰ For UL-compliance, use of a 10 A fuse (time delay) is required. Be sure that the fuse meets certification requirements for DC voltage in accordance with UL 248.

8.4.13 X12: Safety technology (option ST6)

The ST6 safety module adds the STO safety function to the SD6 drive controller via terminal X12.


Information

If you would like to use the STO safety function via terminals, be sure to read the manual for the ST6 safety module (see [Detailed information](#) [► 158]).

If you do not want to use the safety function, connect 24 V_{DC} at STO_a and STO_b, e.g. using a connection with terminal X11.

Technical data

Obey the technical data of the safety options at X12 (see [ST6 safety module](#) [► 34]).

| Terminal | Pin | Designation | Function |
|--|-----|-----------------------|---|
|  1 2 3 4 5 6 7 8 | 1 | STO _a | Input of safety channel 1 |
| | 2 | | |
| | 3 | STO _b | Input of safety channel 2 |
| | 4 | | |
| | 5 | 0 V GND | Reference potential for STO _a and STO _b , internally bridged with pin 7 |
| | 6 | STO _{status} | Feedback signal of safety channels 1 and 2 for diagnostic purposes |
| | 7 | 0 V GND | Reference potential for STO _a and STO _b , internally bridged with pin 5 |
| | 8 | U _{1status} | STO supply _{status} ; recommended fuse protection: max. 3.15 AT ¹¹ |

Tab. 85: X12 connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [BCF 3,81 180 SN](#) [► 149].

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 86: Cable length [m]

¹¹ For UL-compliance, use of a 3.15 A fuse (time delay) is required. The fuse must be certified for DC voltage in accordance with UL 248.

8.4.14 X14: Safety technology – Safe inputs (SE6 option)


The SE6 safety module adds the expanded safety functions to the SD6 drive controller using terminals X14 and X15.

Information

If you would like to use the expanded safety functionality via terminals, be sure to read the manual for the SE6 safety module (see [Detailed information](#) [► 158]).

Technical data

Note the technical data of the safety options at X14 and X15 (see [SE6 safety module](#) [► 34]).

| Terminal | Pin | Designation | Function |
|--|-----|-------------|--|
| <div>6 7 8 9 10</div>  <div>1 2 3 4 5</div> | 1 | I0 | Safe digital input |
| | 2 | I1 | Safe digital input |
| | 3 | I2 | Safe digital input |
| | 4 | I3 | Safe digital input |
| | 5 | 0 V GND | Reference potential for digital inputs; internally connected to pin 10 |
| | 6 | I4 | Safe digital input |
| | 7 | I5 | Safe digital input |
| | 8 | I6 | Safe digital input |
| | 9 | I7 | Safe digital input |
| | 10 | 0 V GND | Reference potential for digital inputs; internally connected to pin 5 |

Tab. 87: X14 connection description

Connecting wiring

For the connecting wiring, note the [DFMC 1.5 -ST-3.5](#) [► 150] terminal specification.

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 88: Cable length [m]

8.4.15 X15: Safety technology – Safe outputs, supply for X50 (SE6 option)

The SE6 safety module adds the expanded safety functions to the SD6 drive controller using terminals X14 and X15.

Information

If you would like to use the expanded safety functionality via terminals, be sure to read the manual for the SE6 safety module (see [Detailed information](#) [► 158]).


ATTENTION!

Loss of safety!

Overvoltages > 40 V_{DC} in the coupling between the safety module and safety controller can lead to loss of safety. Exposing the digital 1-pole outputs of the safety module to an overvoltage of the safety controller can cause the deactivated outputs to output a 1 signal. For the safety controller, use a power supply unit with overvoltage protection for the output voltage. The output voltage must be limited to a maximum of 40 V_{DC}.

Technical data

Note the technical data of the safety options at X14 and X15 (see [SE6 safety module](#) [► 34]).

| Terminal | Pin | Designation | Function |
|---|-----|----------------|---|
|  | 1 | +24 V | 24 V _{DC} supply for digital outputs (PELV); fuse protection: max. 4 AT; the supply voltage is also needed if no safe outputs are used |
| | 2 | O0 | Safe digital output |
| | 3 | O1 | Safe digital output |
| | 4 | U ₂ | Power supply voltage for external encoder |
| | 5 | O2 | Safe digital output |
| | 6 | O3 | Safe digital output |
| | 7 | O4 | Safe digital output |
| | 8 | 0 V GND | Reference potential for external encoder |

Tab. 89: X15 connection description

Connecting wiring

For the connecting wiring, note the [DFMC 1.5 -ST-3.5](#) [► 150] terminal specification.

Cable requirements


| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 90: Cable length [m]

8.4.16 X20: Motor

The motor is connected to X20. For size 3 device types, there is also the connection for the DC link connection and for a braking resistor at terminal X20.


Size 0

| Terminal | Pin | Designation | Function |
|--|-----|-------------|--------------------------|
|  1 2 3 4 | 1 | U | Motor phase U connection |
| | 2 | V | Motor phase V connection |
| | 3 | W | Motor phase W connection |
| | 4 | PE | Grounding conductor |

Tab. 91: X20 connection description – Size 0

For the connecting wiring, obey the terminal specification [GFKC 2,5 -ST-7,62](#) [► 152].


Size 1

| Terminal | Pin | Designation | Function |
|---|-----|-------------|--------------------------|
|  1 2 3 4 | 1 | U | Motor phase U connection |
| | 2 | V | Motor phase V connection |
| | 3 | W | Motor phase W connection |
| | 4 | PE | Grounding conductor |

Tab. 92: X20 connection description – Size 1

For the connecting wiring, obey the terminal specification [SPC 5 -ST-7,62](#) [► 155].


Size 2

| Terminal | Pin | Designation | Function |
|--|-----|-------------|--------------------------|
|  1 2 3 4 | 1 | U | Motor phase U connection |
| | 2 | V | Motor phase V connection |
| | 3 | W | Motor phase W connection |
| | 4 | PE | Grounding conductor |

Tab. 93: X20 connection description – Size 2

For the connecting wiring, obey the terminal specification [SPC 16 -ST-10,16](#) [► 155].

Size 3

| Terminal | Pin | Designation | Function |
|--|-----|-------------|--------------------------|
|  1 2 3 4 5 6 7 8 | 1 | R– | Braking resistor |
| | 2 | R+ | |
| | 3 | W | Motor phase W connection |
| | 4 | V | Motor phase V connection |
| | 5 | U | Motor phase U connection |
| | 6 | D– | DC link connection |
| | 7 | D+ | |
| | 8 | PE | Grounding conductor |

Tab. 94: X20 connection description – Size 3

For the connecting wiring, note the [MKDSP 25 -15,00 \[► 154\]](#) terminal specification.

Cable requirements

| Motor type | Connection | Size 0 to 2 | Size 3 |
|---|----------------------|-----------------|-----------------|
| Synchronous servo motor, asynchronous motor | Without output choke | 50 m, shielded | 100 m, shielded |
| Synchronous servo motor, asynchronous motor | With output choke | 100 m, shielded | — |

Tab. 95: Maximum cable length of the power cable [m]

Information

To ensure proper functionality, we recommend using cables from STOBER that are matched to the complete system. If unsuitable cables are used, we reserve the right to reject claims under the warranty.

Shielded connection of the power cable

Note the following points for the connection of the power cable:


- Ground the shield of the power cable on the shield contact on the drive controller intended for this.
- Keep the exposed conductors as short as possible. All devices and circuits that are sensitive to EMC must be kept at a distance of at least 0.3 m.

8.4.17 X30: DC link connection, braking resistor

Terminal X30 is available in sizes 0 to 2 for the DC link connection of the drive controller and for the connection of a braking resistor.

For setting up the Quick DC-Link, note the information on project configuration in the manual for the SD6 drive controller (see [Detailed information](#) [[▶ 158](#)]).


Size 0

| Terminal | Pin | Designation | Function |
|--|-----|-------------|-----------------------------|
|  1 2 3 4 | 1 | D– | DC link connection |
| | 2 | D+ | |
| | 3 | R+ | Braking resistor connection |
| | 4 | R– | |

Tab. 96: X30 connection description – Size 0

For the connecting wiring, obey the terminal specification [GFKIC 2.5 -ST-7.62](#) [[▶ 153](#)].


Size 1

| Terminal | Pin | Designation | Function |
|---|-----|-------------|-----------------------------|
|  1 2 3 4 | 1 | D– | DC link connection |
| | 2 | D+ | |
| | 3 | R+ | Braking resistor connection |
| | 4 | R– | |

Tab. 97: X30 connection description – Size 1

For the connecting wiring, obey the terminal specification [SPC 5 -ST-7,62](#) [[▶ 155](#)].

Size 2

| Terminal | Pin | Designation | Function |
|--|-----|-------------|-----------------------------|
|  1 2 3 4 | 1 | D– | DC link connection |
| | 2 | D+ | |
| | 3 | R+ | Braking resistor connection |
| | 4 | R– | |

Tab. 98: X30 connection description – Size 2

For the connecting wiring, obey the terminal specification [SPC 16 -ST-10,16](#) [[▶ 154](#)].

Size 3

For size 3 device types, the connections for the braking resistor and Quick DC-Link are part of terminal X20.


8.4.18 X50: Plausibility encoder (SE6 option)

At X50, differential TTL incremental encoders or SSI encoders can be connected. X50 is part of the SE6 safety module. X50 serves as the encoder plausibility check when using asynchronous motors or when using the SLP safety function.

Evaluable encoders


The technical data of the evaluable encoders at X50 can be found in the manual for the SD6 drive controller (see [Detailed information](#) [► 158]).

SSI encoders

| Socket | Pin | Designation | Function |
|---|-----|----------------|---|
| 1 3 5 7  2 4 6 8 | 1 | U ₂ | Encoder supply (see terminal X15, pin 4) |
| | 2 | 0 V GND | Reference potential for encoder supply to pin 1 (see terminal X15, pin 8) |
| | 3 | — | — |
| | 4 | Clock + | Differential input for CLOCK |
| | 5 | Clock – | Inverse differential input for CLOCK |
| | 6 | — | — |
| | 7 | Data + | Differential input for DATA |
| | 8 | Data – | Inverse differential input for DATA |

Tab. 99: X50 connection description for SSI encoders

Differential TTL incremental encoders


| Socket | Pin | Designation | Function |
|---|-----|----------------|---|
| 1 3 5 7  2 4 6 8 | 1 | U ₂ | Encoder supply (see terminal X15, pin 4) |
| | 2 | 0 V GND | Reference potential for encoder supply to pin 1 (see terminal X15, pin 8) |
| | 3 | — | — |
| | 4 | A + | Differential input for A channel |
| | 5 | A – | Inverse differential input for A channel |
| | 6 | — | — |
| | 7 | B + | Differential input for B channel |
| | 8 | B – | Inverse differential input for B channel |

Tab. 100: X50 connection description for differential TTL incremental encoders

8.4.18.1 X50 adapter cable (SE6 option)

The adapter cable with open cable ends for connection to X50 is used to connect the plausibility encoder.

Differential TTL incremental encoders

| Connector | Pin | Designation | Color |
|---|-----|----------------|-------|
|  | 1 | U ₂ | WH |
| | 2 | 0 V GND | BN |
| | 3 | N + | GN |
| | 4 | A + | GY |
| | 5 | A – | PK |
| | 6 | N – | YE |
| | 7 | B + | BU |
| | 8 | B – | RD |

Tab. 101: X50 connector description for differential TTL incremental encoders

8.4.19 Connecting a drive controller (ST6 option)

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

Tools and material

You will need:


- Tool for assembling the accessory part and tightening the fastening screws.

Requirements and connection


Bottom of the device:

- ✓ You have a system circuit diagram describing the connection of the drive controller.
1. Disconnect all terminals on the underside of the drive controller. For size 3 drive controllers, note that terminal X20 cannot be disconnected.

2. Sizes 0 to 2: In order to connect the motor temperature sensor, the control of the brake and the motor itself to the drive controller, wire the cores of the power cable with terminals X2, X5 and X20. Attach the power cable to the EMC shroud.



3. Size 3: Start by attaching the power cable to the EMC shroud. Then wire the cores of the power cable to terminals X2, X5 and X20 in order to connect the motor temperature sensor, the brake control and the motor itself to the drive controller.



4. Sizes 0 to 2: Attach terminal X20.
5. Connect the supply voltage for the brake to terminal X6 and attach it.
6. Attach terminals X2 and X5.
7. Optional: Connect an encoder to terminal X4.
8. Wire the enable signal (pins 3 and 4) and optional relay 1 (pins 1 and 2) to terminal X1 and attach them.

Top of the device:

- ✓ There is a circuit diagram of the system that describes the connection of the drive controller
- 1. Connect the power supply to terminal X10.
- 2. Connect the 24 V_{DC} power supply for the control electronics to terminal X11.
- 3. Connect terminal X12 according to your safety configuration.
- 4. Optional: In order to use the IGB Motion Bus function, connect additional drive controllers to an IGB network via sockets X3A and X3B.
- 5. Optional: Connect the EtherCAT, CANopen or PROFINET fieldbuses via the EC6, CA6 or PN6 modules to the sockets X200 and X201.

Wiring examples can be found in the appendix (see [Wiring examples](#) [► 156]).

8.4.20 Connecting a drive controller (SE6 option)

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

Tools and material


You will need:

- Tool for assembling the accessory part and tightening the fastening screws.


Requirements and connection

Bottom of the device:

- ✓ You have a system circuit diagram describing the connection of the drive controller.
- 1. Disconnect all terminals on the underside of the drive controller. For size 3 drive controllers, note that terminal X20 cannot be disconnected.
- 2. Sizes 0 to 2: In order to connect the motor temperature sensor, the brakes and the motor itself to the drive controller, wire the cores of the power cables to terminals X2, X5, X8 and X20. Attach the power cable to the EMC shroud.



3. Size 3: Start by attaching the power cable to the EMC shroud. Then wire the cores of the power cable to terminals X2, X5, X8 and X20 in order to connect the motor temperature sensor, the brakes and the motor itself to the drive controller.



4. Sizes 0 to 2: Attach terminal X20.
5. Connect the supply voltage for the brakes to terminal X7 and attach it.
6. Attach terminals X2, X5 and X8.
7. Optional: Connect an encoder to terminal X4.
8. Wire the enable signal (pins 3 and 4) and optional relay 1 (pins 1 and 2) to terminal X1 and attach them.

Top of the device:

- ✓ You have a system circuit diagram describing the connection of the drive controller.

1. Connect the power supply to terminal X10.
2. Optional: Connect the 24 V_{DC} power supply for the control electronics to terminal X11.
3. Connect terminals X14 and X15 according to your safety configuration and, optionally, connect the plausibility encoder to X50.
4. Optional: In order to use the IGB Motion Bus function, connect additional drive controllers to an IGB network via sockets X3A and X3B.
5. Optional: Connect the EtherCAT, CANopen or PROFINET fieldbuses via the EC6, CA6 or PN6 modules to the sockets X200 and X201.

Wiring examples can be found in the appendix (see [Wiring examples](#) [► 156]).

8.5 Communication module

The connection descriptions of the optional communication modules can be found in the following chapters.

8.5.1 EC6: EtherCAT

For the EtherCAT connection, you need the optional EC6 accessory part.

8.5.1.1 Overview




Fig. 18: Connection overview for EC6 communication module

- 1 X200: EtherCAT In
- 2 X201: EtherCAT Out

8.5.1.2 X200, X201: EtherCAT

The drive controllers have both RJ-45 sockets X200 and X201. The sockets are located on top of the device. The associated pin assignment and color coding correspond to the EIA/TIA-T568B standard.

X200 is to be connected as an input with the cable coming from the EtherCAT master. X201 is to be connected as an output with any subsequent EtherCAT nodes.

| Socket | Pin | Designation | Function |
|--------------------------|-----|-------------|---------------|
| <div>1 2 ... 7 8</div> | 1 | Tx+ | Communication |
| | 2 | Tx- | |
| | 3 | Rx+ | |
| | 4 | — | — |
| | 5 | — | — |
| | 6 | Rx- | Communication |
| | 7 | — | — |
| | 8 | — | — |

Tab. 102: X200 and X201 connection description

Cable requirements

Information

To ensure proper functionality, we recommend using cables from STOBER that are matched to the complete system. If unsuitable cables are used, we reserve the right to reject claims under the warranty.

STOBER provides ready-made cables for the EtherCAT connection. It is also possible to use cables with the following specification:

Ethernet patch cables or crossover cables meeting the CAT 5e quality level are the ideal cables. The Fast Ethernet technology allows a maximum cable length of 100 m between two nodes.

Information

Ensure that you only use shielded cables with an SF/FTP, S/FTP or SF/UTP design.

Detailed information about the fieldbus connection can be found in the corresponding manual for communication with EtherCAT.

8.5.2 CA6: CANopen

The optional CA6 accessory part is available for the CANopen connection.

8.5.2.1 Overview





Fig. 19: Connection overview for CA6 communication module

- 1 Terminating resistor; must be activated at the last networked drive controller (slider to "ON")
- 2 X200: CANopen

8.5.2.2 X200: CANopen

The CA6 communication module provides a 9-pole D-sub connector for connecting the drive controllers to each other.

| Connector | Pin | Designation | Function |
|---|-----|-------------|---------------------|
|  | 1 | — | — |
| | 2 | CAN-L | CAN low wire |
| | 3 | GND | Reference potential |
| | 4 | — | — |
| | 5 | — | — |
| | 6 | — | — |
| | 7 | CAN-H | CAN high wire |
| | 8 | — | — |
| | 9 | — | — |

Tab. 103: X200 connection description

Cable requirements

In order to ensure error-free operation—especially at high transmission rates—we recommend using bus wires that meet the requirements listed in ISO 11898-2, such as the following:

- Characteristic impedance: 95 – 140 Ω
- Maximum operating capacitance: 60 nF/km
- Conductor resistance: 70 mΩ/m

For detailed information about the fieldbus connection, refer to the corresponding manual (see [Detailed information \[p. 158\]](#)).

8.5.3 PN6: PROFINET

For a PROFINET connection, you need the optional PN6 accessory part.

8.5.3.1 Overview





Fig. 20: Connection overview for PN6 communication module

- 1 X200: PROFINET
- 2 X201: PROFINET

8.5.3.2 X200, X201: PROFINET

In order to be able to connect the drive controllers to other PROFINET nodes, an integrated switch with both X200 and X201 RJ-45 sockets is provided. The sockets are located on top of the device. The associated pin assignment and color coding correspond to the EIA/TIA-T568B standard.

Connect X200 or X201 with the IO controller and the remaining connection with the next drive controller.

| Socket | Pin | Designation | Function |
|---|-----|-------------|---------------|
|  | 1 | Tx+ | Communication |
| | 2 | Tx- | |
| | 3 | Rx+ | |
| | 4 | — | — |
| | 5 | — | — |
| | 6 | Rx- | Communication |
| | 7 | — | — |
| | 8 | — | — |

Tab. 104: X200 and X201 connection description

Cable requirements

The connections between the nodes of a PROFINET network generally consist of symmetrical, shielded copper cables twisted in pairs (shielded twisted pair, CAT 5e quality level). Fiber-optic cables are also a possible means of transmission.

Signals are transmitted according to the 100BASE TX method, i.e. with a transfer rate of 100 Mbps at a frequency of 125 MHz. A maximum of 1440 bytes can be transferred per frame. The maximum cable length is 100 m.

PROFINET cables exist in different versions that are tailored to different application scenarios and ambient conditions.

We recommend using the cables and plug connectors specified in the PROFINET installation guidelines. They are adjusted for use in automation technology with regard to usage, resistance, EMC properties and color coding.

There are type A, B and C cables, differentiated by installation type:

- Type A
4-wire shielded copper cable for fixed installation
- Type B
4-wire shielded copper cable for flexible installation
- Type C
4-wire shielded copper cable for constant movements

Detailed information about the fieldbus connection can be found in the corresponding manual for communication with PROFINET.

8.6 Terminal module

The connection descriptions of the optional terminal modules can be found in the following chapters.

You can find the technical data for the terminal modules in the manual for the SD6 drive controller (see [Detailed information](#) [[► 158](#)]).

8.6.1 XI6

8.6.1.1 Overview





Fig. 21: Connection overview for the XI6 terminal module

- 1 X100: AI1 – AI2, AO1 – AO2
- 2 X101: DI1 – DI5, DO1 – DO2
- 3 X120: X120 encoder connection
- 4 X102: AI3
- 5 X103A: DO3 – DO6
- 6 X103B: DI6, DO7 – DO10
- 7 X103C: DI7 – DI13

8.6.1.2 X100: AI1 – AI2, AO1 – AO2

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---|
|  1 2 3 4 5 6 7 8 | 1 | AI1 + | AI1+ input |
| | 2 | AI1 shunt | Current input; shunt connection pin 2 is to be bridged to pin 1 |
| | 3 | AI1 – | AI1– input |
| | 4 | AI2 + | AI2+ input |
| | 5 | AI2 – | AI2– input |
| | 6 | AO1 | AO1 output |
| | 7 | AO2 | AO2 output |
| | 8 | 0 V AGND | Reference potential |

Tab. 105: X100 connection description

Connecting wiring


For the connecting wiring, note the [FK-MCP 1,5 -ST-3,5](#) [[► 151](#)] terminal specification.

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 106: Cable length [m]

8.6.1.3 X101: DI1 – DI5, DO1 – DO2


| Terminal | Pin | Designation | Function |
|---|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | Digital inputs |
| | 12 | DI2 | |
| | 13 | DI3 | |
| | 14 | DI4 | |
| | 15 | DI5 | |
| | 16 | DO1 | Digital outputs |
| | 17 | DO2 | |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ¹² |
| | 19 | | |

Tab. 107: X101 connection description for digital signals

Use the digital inputs DI3 to DI5 to evaluate incremental or pulse/direction signals. For the simulation, use the digital outputs DO1 and DO2.

Hall sensors with single-ended HTL signal levels can be connected to digital inputs DI1 through DI3 directly.

Single-ended HTL incremental encoders


| Terminal | Pin | Designation | Function |
|---|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | — |
| | 12 | DI2 | — |
| | 13 | DI3 | Evaluation: N channel |
| | 14 | DI4 | Evaluation: A channel |
| | 15 | DI5 | Evaluation: B channel |
| | 16 | DO1 | Simulation: A channel |
| | 17 | DO2 | Simulation: B channel |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ¹³ |
| | 19 | | |

Tab. 108: X101 connection description for single-ended HTL incremental signals

¹² For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements for DC voltage in accordance with UL 248.


¹³ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements in accordance with UL 248.

Single-ended HTL pulse/direction interface

| Terminal | Pin | Designation | Function |
|---|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | — |
| | 12 | DI2 | — |
| | 13 | DI3 | — |
| | 14 | DI4 | Evaluation: Pulse |
| | 15 | DI5 | Evaluation: Direction |
| | 16 | DO1 | Simulation: Pulse |
| | 17 | DO2 | Simulation: Direction |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ¹⁴ |
| | 19 | | |

Tab. 109: X101 connection description for single-ended HTL pulse/direction signals

Single-ended HTL Hall sensor

| Terminal | Pin | Designation | Function |
|--|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | HALL A |
| | 12 | DI2 | HALL B |
| | 13 | DI3 | HALL C |
| | 14 | DI4 | Digital inputs |
| | 15 | DI5 | |
| | 16 | DO1 | Digital outputs |
| | 17 | DO2 | |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ¹⁵ |
| | 19 | | |

Tab. 110: X101 connection description for single-ended HTL Hall sensor signals

Connecting wiring

For the connecting wiring, note the [FK-MCP 1,5 -ST-3,5](#) [151] terminal specification.

Cable requirements


| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 111: Cable length [m]

¹⁴ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements in accordance with UL 248.

¹⁵ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements for relevant DC voltage in accordance with UL 248.

8.6.1.4 X102: AI3

| | Pin | Designation | Function |
|--|-----|-------------|--|
|  1 2 | 1 | AI3 + | AI3+ input; differential input voltage |
| | 2 | AI3 – | AI3– input |

Tab. 112: X102 connection description

Connecting wiring


For the connecting wiring, obey the terminal specification [FMC 1,5 -ST-3,5](#) [▶ 151](#).

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 113: Cable length [m]

8.6.1.5 X103A: DO3 – DO6

| Terminal | Pin | Designation | Function |
|---|-----|-------------|-----------------|
|  1 2 3 4 | 1 | DO3 | Digital outputs |
| | 2 | DO4 | |
| | 3 | DO5 | |
| | 4 | DO6 | |

Tab. 114: X103A connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [FMC 1,5 -ST-3,5](#) [▶ 151](#).

Cable requirements


| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 115: Cable length [m]

8.6.1.6 X103B: DI6, DO7 – DO10

Information

In the event of failure of the 24 V_{DC} supply, the digital input DI6 displays the signal state 0, regardless of the physical signal state.

| Terminal | Pin | Designation | Function |
|--|-----|-------------|-----------------|
|  5 6 7 8 9 | 5 | DO7 | Digital outputs |
| | 6 | DO8 | |
| | 7 | DO9 | |
| | 8 | DO10 | |
| | 9 | DI6 | Digital input |

Tab. 116: X103B connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [FMC 1,5 -ST-3,5](#) [► 151].

Cable requirements


| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 117: Cable length [m]

8.6.1.7 X103C: DI7 – DI13

Information

In the event of failure of the 24 V_{DC} supply, the digital inputs DI7 to DI13 display the signal state 0, regardless of the physical signal state.

| Terminal | Pin | Designation | Function |
|--|-----|-------------|----------------|
|  10 11 ... 15 16 | 10 | DI7 | Digital inputs |
| | 11 | DI8 | |
| | 12 | DI9 | |
| | 13 | DI10 | |
| | 14 | DI11 | |
| | 15 | DI12 | |
| | 16 | DI13 | |

Tab. 118: X103C connection description

Connecting wiring

For the connecting wiring, obey the terminal specification [FMC 1,5 -ST-3,5](#) [► 151].


Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 119: Cable length [m]


8.6.1.8 X120

SSI encoders

| Connector | Pin | Designation | Function |
|---|-----|----------------|---|
|  | 1 | GND Enc | Reference potential for pin 2 to pin 7 |
| | 2 | — | — |
| | 3 | — | — |
| | 4 | Clock – | Inverse differential input/output for CLOCK |
| | 5 | Clock + | Differential input/output for CLOCK |
| | 6 | Data + | Differential input/output for DATA |
| | 7 | Data – | Inverse differential input/output for DATA |
| | 8 | U ₂ | Encoder supply |
| | 9 | 0 V GND | Reference potential for pin 8 |


Tab. 120: X120 connection description for SSI encoders

Differential TTL incremental encoders

| Connector | Pin | Designation | Function |
|--|-----|----------------|---|
|  | 1 | GND Enc | Reference potential for pin 2 to pin 7 |
| | 2 | N + | Differential input/output for N channel |
| | 3 | N – | Inverse differential input/output for N channel |
| | 4 | A – | Inverse differential input/output for A channel |
| | 5 | A + | Differential input/output for A channel |
| | 6 | B + | Differential input/output for B channel |
| | 7 | B – | Inverse differential input/output for B channel |
| | 8 | U ₂ | Encoder supply |
| | 9 | 0 V GND | Reference potential for pin 8 |

Tab. 121: X120 connection description for differential TTL incremental encoder


Differential TTL Hall sensor

| Connector | Pin ¹⁶ | Designation | Function |
|---|-------------------|----------------|--|
|  | 1 | GND Enc | Reference potential for pin 2 to pin 7 |
| | 2 | HALL C + | Differential input for HALL C |
| | 3 | HALL C – | Inverse differential input for HALL C |
| | 4 | HALL A – | Inverse differential input for HALL A |
| | 5 | HALL A + | Differential input for HALL A |
| | 6 | HALL B + | Differential input for HALL B |
| | 7 | HALL B– | Inverse differential input for HALL B |
| | 8 | U ₂ | Encoder supply |
| | 9 | 0 V GND | Reference potential for pin 8 |

Tab. 122: X120 connection description for differential TTL Hall sensors

¹⁶ 1:1 connection to LA6: Pin assignment corresponds to terminal X301

Differential TTL pulse/direction interface

| Connector | Pin ¹⁷ | Designation | Function |
|---|-------------------|----------------|--|
|  | 1 | GND Enc | Reference potential for pin 2 to pin 7 |
| | 2 | — | — |
| | 3 | — | — |
| | 4 | Pulse – | Inverse differential input for pulses |
| | 5 | Pulse + | Differential input for pulses |
| | 6 | Direction + | Differential input for direction |
| | 7 | Direction – | Inverse differential input for direction |
| | 8 | U ₂ | Encoder supply |
| | 9 | 0 V GND | Reference potential for pin 8 |

Tab. 123: X120 connection description for differential TTL pulse/direction signals

Cable requirements

| Feature | All sizes |
|-------------------|----------------|
| Max. cable length | 50 m, shielded |

Tab. 124: Cable length [m]

8.6.2 RI6

8.6.2.1 Overview





Fig. 22: Connection overview for the RI6 terminal module

- 1 X100: AI1 – AI2, AO1 – AO2
- 2 X101: DI1 – DI5, DO1 – DO2
- 3 X120: Encoder connection
- 4 3 sliders for the HTL/TTL level conversion
- 5 X140: Encoder connection

¹⁷ 1:1 connection to LA6: Pin assignment corresponds to terminal X301

8.6.2.2 X100: AI1 – AI2, AO1 – AO2

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---|
|  1 2 3 4 5 6 7 8 | 1 | AI1 + | AI1+ input |
| | 2 | AI1 shunt | Current input; shunt connection pin 2 is to be bridged to pin 1 |
| | 3 | AI1 – | AI1– input |
| | 4 | AI2 + | AI2+ input |
| | 5 | AI2 – | AI2– input |
| | 6 | AO1 | AO1 output |
| | 7 | AO2 | AO2 output |
| | 8 | 0 V AGND | Reference potential |

Tab. 125: X100 connection description

Connecting wiring


For the connecting wiring, note the [FK-MCP 1,5 -ST-3,5 \[151\]](#) terminal specification.

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 126: Cable length [m]

8.6.2.3 X101: DI1 – DI5, DO1 – DO2

| Terminal | Pin | Designation | Function |
|---|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | Digital inputs |
| | 12 | DI2 | |
| | 13 | DI3 | |
| | 14 | DI4 | |
| | 15 | DI5 | |
| | 16 | DO1 | Digital outputs |
| | 17 | DO2 | |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ¹⁸ |
| | 19 | | |


Tab. 127: X101 connection description for digital signals

Use the digital inputs DI3 to DI5 to evaluate incremental or pulse/direction signals. For the simulation, use the digital outputs DO1 and DO2.

Hall sensors with single-ended HTL signal levels can be connected to digital inputs DI1 through DI3 directly.


¹⁸ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements for DC voltage in accordance with UL 248.

Single-ended HTL and single-ended TTL incremental encoders

| Terminal | Pin | Designation | Function |
|---|-----|---------------------|--|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | — |
| | 12 | DI2 | — |
| | 13 | DI3 | Evaluation: N channel |
| | 14 | DI4 | Evaluation: A channel |
| | 15 | DI5 | Evaluation: B channel |
| | 16 | DO1 | Simulation: A channel |
| | 17 | DO2 | Simulation: B channel |
| | 18 | +24 V _{DC} | 24 V _{DC} supply, internally bridged; recommended fuse protection: max. 1 A ¹⁹ |
| | 19 | | |

Tab. 128: X101 connection description for single-ended HTL and single-ended TTL incremental signals

Single-ended HTL and single-ended TTL pulse/direction interface


| Terminal | Pin | Designation | Function |
|--|-----|---------------------|--|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | — |
| | 12 | DI2 | — |
| | 13 | DI3 | — |
| | 14 | DI4 | Evaluation: Pulse |
| | 15 | DI5 | Evaluation: Direction |
| | 16 | DO1 | Simulation: Pulse |
| | 17 | DO2 | Simulation: Direction |
| | 18 | +24 V _{DC} | 24 V _{DC} supply, internally bridged; recommended fuse protection: max. 1 A ²⁰ |
| | 19 | | |

Tab. 129: X101 connection description for single-ended HTL and single-ended TTL pulse/direction signals

¹⁹ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements in accordance with UL 248.

²⁰ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements in accordance with UL 248.

Single-ended HTL Hall sensor

| Terminal | Pin | Designation | Function |
|---|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | HALL A |
| | 12 | DI2 | HALL B |
| | 13 | DI3 | HALL C |
| | 14 | DI4 | Digital inputs |
| | 15 | DI5 | |
| | 16 | DO1 | Digital outputs |
| | 17 | DO2 | |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ²¹ |
| | 19 | | |

Tab. 130: X101 connection description for single-ended HTL Hall sensor signals

Connecting wiring

For the connecting wiring, note the [FK-MCP 1,5 -ST-3,5](#) [\[151 \]](#) terminal specification.

Cable requirements


| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 131: Cable length [m]

²¹ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements for relevant DC voltage in accordance with UL 248.


8.6.2.4 X120

SSI encoders

| Connector | Pin | Designation | Function |
|---|-----|----------------|---|
|  | 1 | GND Enc | Reference potential for pin 2 to pin 7 |
| | 2 | — | — |
| | 3 | — | — |
| | 4 | Clock – | Inverse differential input/output for CLOCK |
| | 5 | Clock + | Differential input/output for CLOCK |
| | 6 | Data + | Differential input/output for DATA |
| | 7 | Data – | Inverse differential input/output for DATA |
| | 8 | U ₂ | Encoder supply |
| | 9 | 0 V GND | Reference potential for pin 8 |


Tab. 132: X120 connection description for SSI encoders

Differential TTL incremental encoders

| Connector | Pin | Designation | Function |
|--|-----|----------------|---|
|  | 1 | GND Enc | Reference potential for pin 2 to pin 7 |
| | 2 | N + | Differential input/output for N channel |
| | 3 | N – | Inverse differential input/output for N channel |
| | 4 | A – | Inverse differential input/output for A channel |
| | 5 | A + | Differential input/output for A channel |
| | 6 | B + | Differential input/output for B channel |
| | 7 | B – | Inverse differential input/output for B channel |
| | 8 | U ₂ | Encoder supply |
| | 9 | 0 V GND | Reference potential for pin 8 |

Tab. 133: X120 connection description for differential TTL incremental encoder


Differential TTL Hall sensor

| Connector | Pin ²² | Designation | Function |
|---|-------------------|----------------|--|
|  | 1 | GND Enc | Reference potential for pin 2 to pin 7 |
| | 2 | HALL C + | Differential input for HALL C |
| | 3 | HALL C – | Inverse differential input for HALL C |
| | 4 | HALL A – | Inverse differential input for HALL A |
| | 5 | HALL A + | Differential input for HALL A |
| | 6 | HALL B + | Differential input for HALL B |
| | 7 | HALL B – | Inverse differential input for HALL B |
| | 8 | U ₂ | Encoder supply |
| | 9 | 0 V GND | Reference potential for pin 8 |

Tab. 134: X120 connection description for differential TTL Hall sensors

²² 1:1 connection to LA6: Pin assignment corresponds to terminal X301

Differential TTL pulse/direction interface

| Connector | Pin ²³ | Designation | Function |
|--|-------------------|----------------|--|
|  <p>1 2 3 4 5 6 7 8 9</p> | 1 | GND Enc | Reference potential for pin 2 to pin 7 |
| | 2 | — | — |
| | 3 | — | — |
| | 4 | Pulse – | Inverse differential input for pulses |
| | 5 | Pulse + | Differential input for pulses |
| | 6 | Direction + | Differential input for direction |
| | 7 | Direction – | Inverse differential input for direction |
| | 8 | U ₂ | Encoder supply |
| | 9 | 0 V GND | Reference potential for pin 8 |

Tab. 135: X120 connection description for differential TTL pulse/direction signals


Cable requirements

| Feature | All sizes |
|-------------------|----------------|
| Max. cable length | 50 m, shielded |

Tab. 136: Cable length [m]

8.6.2.5 X140


EnDat 2.1/2.2 digital encoders

| Socket | Pin | Designation | Function |
|--|-----|----------------------|--|
|  <p>8 7 6 5 4 3 2 1 15 14 13 12 11 10 9</p> | 1 | — | — |
| | 2 | 0 V GND | Reference potential for encoder supply to pin 4 |
| | 3 | — | — |
| | 4 | U ₂ | Encoder supply |
| | 5 | Data + | Differential input for DATA |
| | 6 | — | — |
| | 7 | — | — |
| | 8 | Clock + | Differential input for CLOCK |
| | 9 | — | — |
| | 10 | 0 V Sense | Optional reference potential of the Sense connection for regulating the encoder supply |
| | 11 | — | — |
| | 12 | U ₂ Sense | Sense signals for voltage regulation |
| | 13 | Data – | Inverse differential input for DATA |
| | 14 | — | — |
| | 15 | Clock – | Inverse differential input for CLOCK |

Tab. 137: X140 connection description for EnDat 2.1/2.2 digital encoders


²³ 1:1 connection to LA6: Pin assignment corresponds to terminal X301

Resolver

| Socket | Pin | Designation | Function |
|---|-----|-------------|-------------------------------|
|  | 1 | S4 Sin + | Sin input |
| | 2 | R1 Ref – | Reference potential for pin 6 |
| | 3 | S3 Cos + | Cos input |
| | 4 | — | — |
| | 5 | — | — |
| | 6 | R2 Ref + | Resolver excitation signal |
| | 7 | 1TP1 | Reserve |
| | 8 | — | — |
| | 9 | S2 Sin – | Reference potential for pin 1 |
| | 10 | — | — |
| | 11 | S1 Cos – | Reference potential for pin 3 |
| | 12 | — | — |
| | 13 | — | — |
| | 14 | 1TP2 | Reserve |
| | 15 | — | — |


Tab. 138: X140 connection description for resolvers

EnDat 2.1 sin/cos encoders

| Socket | Pin | Designation | Function |
|---|-----|----------------------|--|
|  | 1 | B – (Sin –) | Reference potential for sin input |
| | 2 | 0 V GND | Reference potential for encoder supply to pin 4 |
| | 3 | A – (Cos –) | Reference potential for cos input |
| | 4 | U ₂ | Encoder supply |
| | 5 | Data + | Differential input for DATA |
| | 6 | — | — |
| | 7 | 1TP1 | Reserve |
| | 8 | Clock + | Differential input for CLOCK |
| | 9 | B + (Sin +) | Sin input |
| | 10 | 0 V Sense | Optional reference potential of the Sense connection for regulating the encoder supply |
| | 11 | A + (Cos +) | Cos input |
| | 12 | U ₂ Sense | Sense signals for voltage regulation |
| | 13 | Data – | Inverse differential input for DATA |
| | 14 | 1TP2 | Reserve |
| | 15 | Clock – | Inverse differential input for CLOCK |

Tab. 139: X140 connection description for EnDat 2.1 sin/cos encoders

Sin/cos encoders

| Socket | Pin | Designation | Function |
|--|-----|----------------------|---|
| <div> <div>8 7 6 5 4 3 2 1</div>  <div>15 14 13 12 11 10 9</div> </div> | 1 | B – (Sin –) | Reference potential for sin input |
| | 2 | 0 V GND | Reference potential for encoder supply to pin 4 |
| | 3 | A – (Cos –) | Reference potential for cos input |
| | 4 | U ₂ | Encoder supply |
| | 5 | — | — |
| | 6 | — | — |
| | 7 | — | — |
| | 8 | — | — |
| | 9 | B + (Sin +) | Sin input |
| | 10 | 0 V Sense | Optional Sense connection for regulating the encoder supply |
| | 11 | A + (Cos +) | Cos input |
| | 12 | U ₂ Sense | Sense signals for voltage regulation |
| | 13 | — | — |
| | 14 | — | — |
| | 15 | — | — |

Tab. 140: X140 connection description for sin/cos encoders



Cable requirements

| Feature | All sizes |
|-------------------|-----------------|
| Max. cable length | 100 m, shielded |

Tab. 141: Cable length [m]

8.6.2.6 AP6 interface adapter (resolver)



AP6A00 – Resolver (9-pin to 15-pin)

| Socket ²⁴ | Pin | Designation | Function | Pin | Connector ²⁵ |
|---|-----|-------------|--|-----|---|
|  | 1 | — | — | — |  |
| | 2 | 1TP1 | — | — | |
| | 3 | S2 Sin – | Reference potential for sin input | 9 | |
| | 4 | S1 Cos – | Reference potential for cos input | 11 | |
| | 5 | R1 Ref – | Reference potential for resolver excitation signal | 2 | |
| | 6 | 1TP2 | — | — | |
| | 7 | S4 Sin + | Sin input | 1 | |
| | 8 | S3 Cos + | Cos input | 3 | |
| | 9 | R2 Ref + | Resolver excitation signal | 6 | |

Tab. 142: AP6A00 connection description for resolver (9-pin to 15-pin)

AP6A01 – Resolver and motor temperature sensor (9-pin to 15-pin)

Interface adapter with temperature sensor cores routed out on the side.

| Socket ²⁶ | Pin | Designation | Function | Pin | Connector ²⁷ |
|---|-----|-------------|--|-----|---|
|  | 1 | — | — | — |  |
| | 2 | 1TP1 | Motor temperature sensor connection, if included in the encoder cable connector; routed out for the direct connection to terminal X2 | — | |
| | 3 | S2 Sin – | Reference potential for sin input | 9 | |
| | 4 | S1 Cos – | Reference potential for cos input | 11 | |
| | 5 | R1 Ref – | Reference potential for resolver excitation signal | 2 | |
| | 6 | 1TP2 | Motor temperature sensor connection, if included in the encoder cable connector; routed out for the direct connection to terminal X2 | — | |
| | 7 | S4 Sin + | Sin input | 1 | |
| | 8 | S3 Cos + | Cos input | 3 | |
| | 9 | R2 Ref + | Resolver excitation signal | 6 | |

Tab. 143: AP6A01 connection description for the resolver and motor temperature sensor (9-pin to 15-pin)

²⁴ View of 9-pin D-sub for connecting the SDS 4000-compatible resolver cable

²⁵ View of 15-pin D-sub for connecting to SD6, terminal X140 (RI6)



²⁶ View of 9-pin D-sub for connecting the SDS 4000-compatible resolver cable

²⁷ View of 15-pin D-sub for connecting to SD6, terminal X140 (RI6)

8.6.2.7 AP6 interface adapter (EnDat 2.1 sin/cos)

AP6A02 – EnDat 2.1 sin/cos encoder (15-pin to 15-pin)

Interface adapter with temperature sensor cores routed out on the side.

| Socket ²⁸ | Pin | Designation | Function | Pin | Connector ²⁹ |
|---|-----|----------------------|---|-----|---|
|  | 1 | B – (Sin –) | Reference potential for sin input | 1 |  |
| | 2 | 0 V GND | Reference potential for encoder supply | 2 | |
| | 3 | A – (Cos –) | Reference potential for cos input | 3 | |
| | 4 | U ₂ | Encoder supply | 4 | |
| | 5 | Data + | Differential input for DATA | 5 | |
| | 6 | — | — | 6 | |
| | 7 | 1TP1 | Motor temperature sensor connection, if included in the encoder cable; routed out for the direct connection to X2 | — | |
| | 8 | Clock + | Differential input for CLOCK | 8 | |
| | 9 | B + (Sin +) | Sin input | 9 | |
| | 10 | 0 V Sense | Optional reference potential of the Sense connection for regulating the encoder supply | 10 | |
| | 11 | A + (Cos +) | Cos input | 11 | |
| | 12 | U ₂ Sense | Sense signals for voltage excitation | 12 | |
| | 13 | Data – | Inverse differential input for DATA | 13 | |
| | 14 | 1TP2 | Motor temperature sensor connection, if included in the encoder cable; routed out for the direct connection to X2 | — | |
| | 15 | Clock – | Inverse differential input for CLOCK | 15 | |

Tab. 144: AP6A02 connection description for EnDat 2.1 sin/cos encoder and motor temperature sensor (15-pin to 15-pin)

²⁸ View of 15-pin D-sub for connecting the SDS 4000-compatible EnDat cable

²⁹ View of 15-pin D-sub for connecting to SD6, terminal X140 (RI6)

8.6.3 I06

8.6.3.1 Overview





Fig. 23: Connection overview for the IO6 terminal module

- 1 X100: AI1 – AI2, AO1 – AO2
- 2 X101: DI1 – DI5, DO1 – DO2

8.6.3.2 X100: AI1 – AI2, AO1 – AO2

| Terminal | Pin | Designation | Function |
|--|-----|-------------|---|
|  1 2 3 4 5 6 7 8 | 1 | AI1 + | AI1+ input |
| | 2 | AI1 shunt | Current input; shunt connection pin 2 is to be bridged to pin 1 |
| | 3 | AI1 – | AI1– input |
| | 4 | AI2 + | AI2+ input |
| | 5 | AI2 – | AI2– input |
| | 6 | AO1 | AO1 output |
| | 7 | AO2 | AO2 output |
| | 8 | 0 V AGND | Reference potential |

Tab. 145: X100 connection description

Connecting wiring


For the connecting wiring, note the [FK-MCP 1,5 -ST-3,5](#) [\[151 \]](#) terminal specification.

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 146: Cable length [m]

8.6.3.3 X101: DI1 – DI5, DO1 – DO2


| Terminal | Pin | Designation | Function |
|---|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | Digital inputs |
| | 12 | DI2 | |
| | 13 | DI3 | |
| | 14 | DI4 | |
| | 15 | DI5 | |
| | 16 | DO1 | Digital outputs |
| | 17 | DO2 | |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ³⁰ |
| | 19 | | |

Tab. 147: X101 connection description for digital signals

Use the digital inputs DI3 to DI5 to evaluate incremental or pulse/direction signals. For the simulation, use the digital outputs DO1 and DO2.

Hall sensors with single-ended HTL signal levels can be connected to digital inputs DI1 through DI3 directly.

Single-ended HTL incremental encoders


| Terminal | Pin | Designation | Function |
|---|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | — |
| | 12 | DI2 | — |
| | 13 | DI3 | Evaluation: N channel |
| | 14 | DI4 | Evaluation: A channel |
| | 15 | DI5 | Evaluation: B channel |
| | 16 | DO1 | Simulation: A channel |
| | 17 | DO2 | Simulation: B channel |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ³¹ |
| | 19 | | |

Tab. 148: X101 connection description for single-ended HTL incremental signals

³⁰ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements for DC voltage in accordance with UL 248.


³¹ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements in accordance with UL 248.

Single-ended HTL pulse/direction interface

| Terminal | Pin | Designation | Function |
|---|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | — |
| | 12 | DI2 | — |
| | 13 | DI3 | — |
| | 14 | DI4 | Evaluation: Pulse |
| | 15 | DI5 | Evaluation: Direction |
| | 16 | DO1 | Simulation: Pulse |
| | 17 | DO2 | Simulation: Direction |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ³² |
| | 19 | | |

Tab. 149: X101 connection description for single-ended HTL pulse/direction signals

Single-ended HTL Hall sensor

| Terminal | Pin | Designation | Function |
|--|-----|---------------------|---|
|  9 10 11 ... 17 18 19 | 9 | 0 V DGND | Reference potential, internally bridged |
| | 10 | | |
| | 11 | DI1 | HALL A |
| | 12 | DI2 | HALL B |
| | 13 | DI3 | HALL C |
| | 14 | DI4 | Digital inputs |
| | 15 | DI5 | |
| | 16 | DO1 | Digital outputs |
| | 17 | DO2 | |
| | 18 | +24 V _{DC} | External 24 V _{DC} supply; recommended fuse protection: max. 1 A ³³ |
| | 19 | | |

Tab. 150: X101 connection description for single-ended HTL Hall sensor signals

Connecting wiring

For the connecting wiring, note the [FK-MCP 1,5 -ST-3,5](#) [151] terminal specification.

Cable requirements

| Feature | All sizes |
|-------------------|-----------|
| Max. cable length | 30 m |

Tab. 151: Cable length [m]

³² For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements in accordance with UL 248.

³³ For the fuse protection, use a 1 A fuse (time delay). For UL-compliant use, be sure that the fuse meets certification requirements for relevant DC voltage in accordance with UL 248.

9 Operation

The operating unit of the drive controller consists of a graphic display (LCD) and buttons.

9.1 Overview



Fig. 24: Operating unit of the SD6 drive controller



Select levels, parameter groups and parameters or apply modified parameter values



Display parameters of the start display, navigate to a previous level, reject modified parameter values or acknowledge fault



Select parameters within a parameter group or change parameter values



Select a parameter group or select a character position of a parameter



Activate or deactivate local operation; a deactivation causes the enable signal to be cleared



Enable drive in local operation, if parameterized



Store in non-volatile memory: press key for 3 seconds

9.2 Menu structure and navigation




Fig. 25: Menu structure and navigation using the SD6 operating unit

Parameters – Quick access

Using quick access, you get direct access to the status of the most important (diagnostic) parameters. This level consists of the **STATUS DISPLAY** start display and three additional topic-specific overviews: **STATUS DISPLAY 1**, for example, provides information about the causes of a possible switch-on lockout, **STATUS DISPLAY 2** provides information about analog and digital inputs and outputs, **STATUS DISPLAY 3** provides information about the general data of the drive controller, such as type, firmware, integrated option modules, etc. You can navigate within this level using the left and right arrow keys. You can use the up and down arrow keys to navigate within the current overview to see more information.

For drive controllers with expanded safety technology via the SE6 safety module, a monitoring safety function (e.g. SLI, SLP or SLS) is shown on the display. If a monitoring safety function is active, **STATUS DISPLAY 1** shows the **SAFETY ACTIVE** ticker as long as the status of the safety module = FSRUN (S01, bits 8–15 = 24 hex).

You can access parameters hidden behind the four values on the **STATUS DISPLAY** start display by using [Esc]. These four parameters can be configured individually using parameter A144.

Parameter groups

Parameters are combined into groups by their functional properties, such as "Drive controller", "Motor", "Machine", "Terminal", etc. You can navigate within this level using the right and left arrow buttons; you can select one of the possible groups with [OK].

Parameter

Within a parameter group, you can navigate using the up and down arrow buttons; you can select one of the possible parameters with [OK]. If you would like to change a parameter value, select the corresponding character position using the right and left arrow buttons and select the new value using the up and down arrow buttons. You can apply changes with [OK] or reject them with [Esc].

| |
|--------------------|
| Information |
|--------------------|

Note that modified values can be stored in non-volatile memory via an operating unit using the save button or parameter A00.

10 What you should know before commissioning

The following chapters provide a quick introduction to the structure of the program interface and accompanying window designations as well as relevant information about parameters and generally saving your project configuration.

10.1 DS6 program interface

Using the graphical interface of the DriveControlSuite commissioning software (DS6), you can project, parameterize and commission your drive project quickly and efficiently. In case of service, you can evaluate diagnostic information such as operating states, fault memories and fault counters of your drive project using DriveControlSuite.

Information

The program interface of DriveControlSuite is available in German, English and French. To change the language of the program interface, select Settings > Language.

Information

The DriveControlSuite help in the menu bar can be reached via Help > Help or via the [F1] key on your keyboard. When you press [F1] in an area of the program, the corresponding help topic opens.




Fig. 26: DS6: Program interface


| No. | Area | Description |
|-----|--------------------------|--|
| 1 | Menu bar | Using the File, View, Settings and Window menus, you can open and save projects, display and hide program windows, select the interface language and access level and change between different windows in the workspace. |
| 2 | Toolbar | The toolbar enables quick access to frequently needed functions, like opening and saving projects and hiding and displaying windows in the program interface. |
| 3 | Project tree | The project tree forms the structure of your drive project in the form of modules and drive controllers. Select an element using the project tree first in order to edit it using the project menu. |
| 4 | Project menu | The project menu offers you various functions for editing the project, module and drive controller. The project menu adapts to the element that you selected in the project tree. |
| 5 | Workspace | The different windows which can be used to edit your drive project, such as the configuration dialog, wizards, the parameter list or the scope analysis tool, open in the workspace. |
| 6 | Parameter check | The parameter check points out irregularities and inconsistencies that were detected in the plausibility check of calculable parameters. |
| 7 | Messages | The entries in the messages log the connection and communication status of the drive controllers, incorrect inputs caught by the system, errors when opening a project or rule violations in the graphical programming. |
| 8 | Variable parameter lists | You can use variable parameter lists to compile any parameters in individual parameter lists for a quick overview. |
| 9 | Status bar | In the status bar, you can find the specifications of the software version and get additional information about the project file, the devices and the progress of the process during processes such as loading projects. |

10.2 Meaning of parameters

You can use parameters to adapt the function of the drive controller to your individual application. In addition, parameters visualize the current actual values (actual velocity, actual torque, etc.) and trigger actions such as Save values, Test phase, etc.

Interpretation of parameter identification

Parameter identification consists of the following elements, where short forms are also possible, i.e. only specifying a coordinate or the combination of coordinate and name.



10.2.1 Parameter groups

Parameters are assigned to individual groups by topic. The 6th generation of STOBBER drive controllers differentiates between the following parameter groups.

| Group | Topic |
|-------|--|
| A | Drive controllers, communication, cycle times |
| B | Motor |
| C | Machine, velocity, torque/force, comparators |
| D | Set value |
| E | Display |
| F | Terminals, analog and digital inputs and outputs, brake |
| G | Technology – Part 1 (application-dependent) |
| H | Encoder |
| I | Motion (all motion settings) |
| J | Motion blocks |
| K | Control panel |
| L | Technology – Part 2 (application-dependent) |
| M | Profiles (application-dependent) |
| N | Additional functions (application-dependent; e.g. extended cam control unit) |
| P | Customer-specific parameters (programming) |
| Q | Customer-specific parameters, instance-dependent (programming) |
| R | Production data for the drive controller, motor, brakes, motor adapter, gear unit and geared motor |
| S | Safety (safety technology) |
| T | Scope |
| U | Protection functions |
| Z | Fault counter |

Tab. 152: Parameter groups

10.2.2 Parameter types and data types

In addition to topic-based sorting in individual groups, all parameters belong to a certain data type and parameter type. The data type of a parameter is displayed in the parameter list, properties table. The connections between parameter types, data types and their value range can be found in the following table.

| Data type | Parameter type | Length | Value range (decimal) |
|---|------------------------------------|-----------------------------------|--|
| INT8 | Integer or selection | 1 byte (signed) | -128 – 127 |
| INT16 | Integer | 2 bytes (1 word, signed) | -32768 – 32767 |
| INT32 | Integer or position | 4 bytes (1 double word, signed) | -2147483648 – 2147483647 |
| BOOL | Binary number | 1 bit (internal: LSB in 1 byte) | 0, 1 |
| BYTE | Binary number | 1 byte (unsigned) | 0 – 255 |
| WORD | Binary number | 2 bytes (1 word, unsigned) | 0 – 65535 |
| DWORD | Binary number or parameter address | 4 bytes (1 double word, unsigned) | 0 – 4294967295 |
| REAL32 (single type according to IEE754) | Floating-point number | 4 bytes (1 double word, signed) | $-3.40282 \times 10^{38} - 3.40282 \times 10^{38}$ |
| STR8 | Text | 8 characters | — |
| STR16 | Text | 16 characters | — |
| STR80 | Text | 80 characters | — |

Tab. 153: Parameters: data types, parameter types, possible values

Parameter types: Use

- Integer, floating-point number
For general computing processes
Example: Set and actual values
- Selection
Numeric value to which a direct meaning is assigned
Example: Sources for signals or set values
- Binary number
Bit-oriented parameter information that is collected in binary
Example: Control and status words
- Position
Integer combined with associated units and decimal places
Example: Actual and set values of positions
- Velocity, acceleration, deceleration, jerk
Floating-point number combined with associated units
Example: Actual and set values for velocity, acceleration, deceleration, jerk
- Parameter address
Referencing of a parameter
Example: In F40 AO1 source, for example, E08 n-motor filtered can be parameterized
- Text
Outputs or messages

10.2.3 Parameter types


The following types of parameters are differentiated.

| Parameter type | Description | Example |
|-------------------|---|---|
| Simple parameters | Consist of one group and one line with a defined value. | A21 Brake resistor R: Value = 100 ohms |
| Array parameters | Consist of a group, a line and multiple sequential (listed) elements, which have the same properties but different values. | A10 Access level <ul style="list-style-type: none"> A10[0] access level: Value = Access level via operating unit A10[2] access level: Value = Access level via CANopen and EtherCAT A10[4] access level: Value = Access level via PROFINET |
| Record parameters | Consist of a group, a line and multiple sequential (listed) elements, which can have different properties and different values. | A00 Save values <ul style="list-style-type: none"> A00[0] Start: Value = Start action A00[1] Progress: Value = Display action progress A00[2] Result: Value = Display action result |

Tab. 154: Parameter types

10.2.4 Parameter structure

Every parameter has specific coordinates with the following structure.



- **Axis (optional)**
In case of multiple axes, the one to which a parameter is assigned; not applicable for global parameters (value range: 1 – 4).
- **Group**
The thematic group to which a parameter belongs (value range: A – Z).
- **Line**
Distinguishes the parameters within a parameter group (value range: 0 – 999).
- **Element (optional)**
Elements of an array or record parameter (value range: 0 – 16000).
- **Bit (optional)**
Selection of a single bit for complete data addressing; depends on the data type (value range: 0 – 31).

10.2.5 Parameter visibility

The visibility of a parameter is primarily controlled by the access level you set in DriveControlSuite and by the properties you project for the respective drive controller (e.g. hardware, firmware and application). A parameter can also be shown or hidden depending on other parameters or settings. For example, the parameters of an additional function are only shown as soon as you activate the relevant additional function.

Access level

The access options for the individual software parameters are ranked hierarchically and divided into individual levels. This means that parameters can be hidden for a specific purpose and, relatedly, their configuration options can be locked starting from a specific level.

Each parameter has one access level for read access (visibility) and one access level for write access (editability). The following levels are present:

- Level 0
Elementary parameters
- Level 1
Important parameters of an application
- Level 2
Important parameters for service with extensive diagnostic options
- Level 3
All parameters needed for commissioning and optimizing an application

The parameter A10 Access level controls general access to parameters:

- Over the SD6 drive controller display (A10[0])
- Over CANopen or EtherCAT (A10[2])
- Over PROFINET (A10[3])

| |
|--------------------|
| Information |
|--------------------|

It is not possible to write to or read the parameter hidden in DriveControlSuite during communication via fieldbus.

Hardware

Which parameters are available to you in DriveControlSuite is determined by which series you select in the configuration dialog for the drive controller, for example, or whether you project an option module. Basically, the only parameters that are displayed are the ones you need to parameterize the configured hardware.

For example, a drive controller can evaluate an encoder using terminal X120, provided that terminal module XI6 has been installed. The accompanying evaluation is activated using parameter H120. However, this parameter is visible only if terminal module XI6 was initially selected during the drive project configuration.

Firmware

Due to the further development and updating of functions for the 6th generation of STOBER drive controllers, new parameters and also new versions of existing parameters are continuously being implemented in DriveControlSuite and in the firmware. The parameters are displayed in the software according to the DriveControlSuite version used and the configured firmware version of the respective drive controller.

Applications

Applications generally differ in terms of functions and their control. For this reason, different parameters are available with each application.

10.3 Signal sources and process data mapping

The transmission of control signals and set values in DriveControlSuite meets the following principles.

Signal sources

Drive controllers are controlled either over a fieldbus, using mixed operation consisting of a fieldbus system and terminals or exclusively using terminals.

You can use the corresponding selection parameters, referred to as signal sources, to configure whether the control signals and set values of the application are obtained over a fieldbus or using terminals.

In case of activation over a fieldbus, parameters that are selected as data sources for control signals or set values must be part of the subsequent process data mapping. In the case of activation using terminals, the respective analog or digital inputs are specified directly.

Process data mapping

If you are working with a fieldbus system and have selected the source parameters for control signals and set values, configure the fieldbus-specific settings, e.g. the assignment of the process data channels for transmitting receive and transmit process data, as the last step. The respective procedure can be found in the accompanying STOBER fieldbus manuals.

10.4 Non-volatile memory

All project configurations, parameterizations and related changes to parameter values are in effect after transmission to the drive controller, but are only stored in volatile memory.

Saving to a drive controller

To save the configuration in non-volatile memory on a drive controller, you have the following options:

- Saving the configuration using the **Save values wizard**:
Project menu > Wizards area > Projected axis > Save values wizard: Select the Save values action
- Saving the configuration using the **parameter list**:
Project menu > Parameter list area > Projected axis > Group A: Drive controller > A00 Save values: Set the parameter A00[0] to the value 1: Active
- Saving the configuration using the **operating unit**:
SD6 drive controller > Operating unit: Press the save button for 3 seconds

Saving to all drive controllers within a project

To save the configuration in non-volatile memory on several drive controllers, you have the following options:

- Saving the configuration using the **toolbar**:
Toolbar > Save values icon: Click the Save values icon
- Saving the configuration using the **Online functions window**:
Project menu > Online connection button > Online functions window: Click on Save values (A00)

Information

Do not shut off the drive controller while saving. If the supply voltage to the control unit is interrupted while saving, the drive controller will start without an executable configuration the next time it is switched on. In this case, the configuration must be transferred to the drive controller again and stored in non-volatile memory.

11 Commissioning

The following chapters describe how to commission your drive system using the DriveControlSuite software.

For the components of your axis model, **as an example**, we require a STOBER synchronous servo motor with EnDat 2.1/2.2 digital encoder and optional brake. These motors are saved along with all relevant data for the project configuration in the DriveControlSuite motor database and in the electronic nameplate.

Upon selecting the motor from the database, such as when reading out the nameplate, all data is transferred to the corresponding parameters. There is no need for complex parameterization of the motor, brake or encoder.

For STOBER asynchronous motors, the motor data relevant for project configuration is also taken from the motor database. All other motor types need to have their parameters configured manually.

Make sure that the system nodes are wired and supplied with control voltage before commissioning.

Information

The commissioning process described below is particularly suitable for quick initial commissioning of your drive system with subsequent testing of your projected axis model. Since steps or their sequence may vary depending on the application, refer to the corresponding application manual for detailed information.

Information

Always perform the steps described below in the specified order!

Some parameters are interdependent and do not become accessible to you until you have first configured certain settings. Follow the steps in the specified sequence so that you can finish the parameterization completely.

11.1 Initiating the project

In order to be able to configure all drive controllers and axes of your drive system using DriveControlSuite, you must record them as part of a project.

11.1.1 Projecting the drive controller and axis

Create a new project and project the first drive controller along with the accompanying axis.

Creating a new project

1. Start DriveControlSuite.
2. On the start screen, click **Create new project**.
 - ⇒ The new project is created and the configuration dialog for the first drive controller opens.
 - ⇒ The **Drive controller** button is active.

Projecting the drive controller

1. **Properties tab:**
 Establish the relationship between your circuit diagram and the drive controller to be projected in DriveControlSuite.
 Reference: Specify the reference code (equipment code) of the drive controller.
 Designation: Give the drive controller a unique name.
 Version: Version your project configuration.
 Description: If necessary, specify additional supporting information, such as the change history of the project configuration.
2. **Drive controller tab:**
 Select the series and device type of the drive controller.
3. **Option modules tab:**
 Communication module: If the drive controller communicates using a fieldbus with a controller, select the corresponding communication module.
 Terminal module: If you are controlling the drive controller using analog and digital inputs, select the corresponding terminal module (in addition to the communication module in mixed operation).
 Safety module: If the drive controller is part of a safety circuit, select the corresponding safety module.
4. **Device controller tab:**
 Device controller: Select the device controller that defines the underlying activation signals for the drive controller.
 Rx process data, Tx process data: If you use a fieldbus to control the drive controller, select the fieldbus-specific receive and transmit process data.

Information

Make sure that you project the correct series in the **Drive controller** tab. The projected series cannot be changed afterwards.

Projecting the axis

1. Click on **Axis 1**.
2. **Properties tab:**
 Establish the connection between your circuit diagram and the axis to be projected in DriveControlSuite.
 Reference: Specify the reference code (equipment code) of the axis.
 Designation: Give the axis a unique name.
 Version: Version your project configuration.
 Description: If necessary, specify supporting additional information such as the change history of the project configuration.
3. **Application tab:**
 Select the desired control or drive-based application.
4. **Motor tab:**
 Select the motor category, the series and the type of motor operated using this axis. If you are working with motors from third-party suppliers, enter the accompanying motor data at a later time.
5. Confirm with **OK**.

11.1.2 Configuring safety technology

If the drive controller is part of a safety circuit, you must configure the safety technology in accordance with the commissioning steps outlined in the corresponding manual in the next step (siehe [Detailed information \[► 158\]](#)).

11.1.3 Creating other modules and drive controllers

We recommend sorting all drive controllers of your project in DriveControlSuite either functionally by groups and combining a group under a module, or organizing several drive controllers in corresponding modules based on their distribution to different control cabinets.

1. Select your P1 project in the project tree > Context menu **Create new module**.
⇒ Your M2 module is created in the project tree.
2. Select your M2 module in the project tree > Context menu **Create new drive controller**.
⇒ Your T2 drive controller is created in the project tree.
3. Mark your T2 drive controller in the project tree.
4. Change to the project menu and click **Project configuration**.
5. Project the drive controller and specify the newly created module.
6. Repeat the steps for all other drive controllers and modules of your project.

11.1.4 Projecting the module

Give your module a unique name, enter the reference code and, as an option, store additional information like the version and change history of the module.

1. Select the module in the project tree and click on **Project configuration** in the project menu.
⇒ The configuration dialog for the module opens.
2. Establish the relationship between your circuit diagram and the module in DriveControlSuite.
Reference: Specify the reference code (equipment code) of the module.
Designation: Give the module a unique name.
Version: Version the module.
Description: If necessary, specify additional supporting information, such as the change history of the module.
3. Confirm with **OK**.

11.1.5 Projecting the project

Give your project a unique name, enter the reference code and, as an option, store additional information like the version and change history of the project.

1. Mark the project in the project tree and click on **Project configuration** in the project menu.
⇒ The configuration dialog for the project opens.
2. Establish the relationship between your circuit diagram and the project in DriveControlSuite.
Reference: Specify the reference code (equipment code) of the project.
Designation: Give the project a unique name.
Version: Version the project.
Description: If necessary, specify additional supporting information, such as the change history of the project.
3. Confirm with **OK**.

11.2 Mapping the mechanical axis model

To be able to put your real drive train with one or more drive controllers into operation, you must map your complete mechanical environment in DriveControlSuite.

11.2.1 Parameterizing the STOBER motor

You have projected a STOBER synchronous servo motor with EnDat 2.1/2.2 digital encoder and optional brake.

By projecting the corresponding motor, limit values for currents and torques as well as associated temperature data are automatically transferred to the respective parameters of the individual wizards. All additional data on the brake and encoder is transferred at the same time.

Motor protection

All models of the 6th STOBER drive controller generation feature an i²t model – a computational model for thermal monitoring of the motor. To activate it and set up the protective function, configure the following settings (deviating from the presets): U10 = 2: Warning and U11 = 1.00 s. This model can be used instead of or in addition to temperature-monitored motor protection.

11.2.2 Parameterizing the axis model

Parameterize the setup of your drive in this order:

- Define the axis model
- Scale the axis
- Parameterize the position and velocity window
- Limit the axis (optional)
 - Limit the position
 - Limit the velocity, acceleration and jerk
 - Limit the torque and force

11.2.2.1 Define the axis model

1. Select the relevant drive controller in the project tree and click on the first projected axis in the Project menu > Wizard area.
2. Select the Axis model wizard.
3. I05 Type of axis:
Define whether the axis type is rotational or translational.
 - 3.1. If you would like to configure the units of measure and the number of decimal places individually for specifying and displaying positions, velocities, accelerations and jerk, select 0: User defined, rotational or 1: User defined, translational.
 - 3.2. If the units of measure and the number of decimal places for specifying and displaying positions, velocities, accelerations and jerk are to be fixed, select 2: Rotational or 3: Translational.
4. B26 Motor encoder:
Define the interface to which the motor encoder is connected.
5. I02 Position encoder (optional):
Define the interface to which the position encoder is connected.
6. I00 Position range:
Define whether the travel range of the axis is limited or endless (modulo).
7. If you have selected 1: Endless for I00, parameterize a revolution length (see [Scale the axis](#) [► 134]).

Information

When you parameterize I05 Type of axis, you can either use the selection 0: User defined, rotational or 1: User defined, translational to configure units of measure and the number of decimal places for the axis model individually or use the selections 2: Rotational and 3: Translational to revert to preset values.

Selection 0: User defined, rotational and selection 1: User defined, translational let you configure the unit of measure (I09) and the decimal places (I06) individually. Velocity, acceleration and jerk are represented as the derivative of the unit of measure with respect to time.

Selection 2: Rotational sets the following units of measure for the axis model: position in °, velocity in rpm, acceleration in rad/s^2 , jerk in rad/s^3 .

Selection 3: Translational sets the following units of measure for the axis model: position in mm, velocity in m/s, acceleration in m/s^2 , jerk in m/s^3 .

Information

If you do not parameterize it differently for I02 Position encoder, B26 Motor encoder is used for position control as standard.

11.2.2.2 Scale the axis

1. Select the relevant drive controller in the project tree and click on the first projected axis in the Project menu > Wizard area.
2. Select the Axis model wizard > Axis: Scaling.
3. Scale the axis by configuring the overall gear ratio between the motor and output.
To simplify this scaling for you, you are provided with the scaling calculator *Conversion of positions, velocities, accelerations, torque/force*, which calculates the effects of changed motion variables on the entire system.
4. I01 Circular length:
If you have selected 1: Endless for I00 Position range, enter the revolution length.
5. I06 Decimal places position (optional):
If you have selected 0: User defined, rotational or 1: User defined, translational for I05 Type of axis, define the desired number of decimal places.
6. I09 Measure unit (optional):
If you have selected 0: User defined, rotational or 1: User defined, translational for I05 Type of axis, define the desired unit of measure.

Information

A change to parameter I06 moves the decimal separator for all axis-specific values!
Ideally, change I06 before parameterizing other axis-specific values and then check them afterwards.

Information

Parameter I297 Maximum speed position encoder must be parameterized according to your application case. If I297 is set too low, the permitted maximum speed is exceeded even at normal operating speeds. On the other hand, if I297 is set too high, measuring errors of the encoder can be overlooked.

I297 depends on the following parameters: I05 Type of axis, I06 Decimal places position, I09 Measure unit as well as I07 Distance factor numerator position and I08 Distance factor denominator position for applications of type Drive Based or PROFIdrive or A585 Feed constant for applications of type CiA 402. If you have made changes to one of the parameters listed, select I297 accordingly as well.

11.2.2.3 Parameterize the position and velocity window

Enter position limits and velocity zones for set values. To do so, parameterize boundary values for reaching a position or velocity.

1. Select the Axis model wizard > Window position, velocity.
2. C40 Velocity window:
Parameterize a tolerance range for velocity tests.
3. I22 Target window:
Parameterize a tolerance range for position tests.
4. I87 Actual position in window time:
Parameterize how long a drive must stay in the specified position range before a corresponding status message is output.
5. Parameterize a tolerance range for lag tests.

11.2.2.4 Limiting the axis

If necessary, limit the movement variables for position, velocity, acceleration, jerk as well as torque/force according to the applicable conditions for your axis model.

Limiting the position (optional)

1. Select the relevant drive controller in the project tree and click on the first projected axis in the Project menu > Wizard area.
2. Select the Axis model wizard > Limit: Position.
3. If necessary, limit the position of your axis using a software or hardware limit switch to secure the travel range.

Limiting velocity, acceleration, jerk (optional)

The default values are designed for slow velocities without gear units. For this reason, adapt the saved values.

For example, verify the maximum velocity of the motor (B83) against the velocity of the output (I10).

1. Select the Motor wizard.
2. Determine the maximum possible motor velocity in parameter B83 v-max motor.
3. Select the Axis model wizard > Axis: Scaling > Conversion of positions, velocities, accelerations, torque/force area.
4. Velocity line:
Enter the maximum motor velocity from B83 in the Velocity line of the Motor column and confirm with ENTER.
⇒ The maximum velocity of the motor has been transferred to the output.
5. Repeat the procedure for other limits, such as for the gear unit input speed (C11).
6. Select the Axis model wizard > Limit: Velocity, acceleration, jerk.
7. I10 Maximal speed:
Limit the maximum velocity of the output, taking into account the determined system limits and the maximum motor velocity B83.
8. Determine the limiting values for acceleration and jerk if necessary and enter them into the associated parameters.

Limiting torque/force (optional)

The default values take into account the rated operation together with the overload reserves.

1. Select the Axis model wizard > Limit: Torque/force.
2. If the motor force must be limited, adapt the saved values as necessary.

11.3 Transmitting and saving a configuration

In order to transmit and save the configuration to one or more drive controllers, you must connect your PC and the drive controllers over the network.



WARNING!

Injury to persons and material damage due to axis movement!

If there is an online connection between DriveControlSuite and the drive controller, changes to the configuration can lead to unexpected axis movements.

- Only change the configuration if you have visual contact with the axis.
- Make sure that no people or objects are within the travel range.
- For access via remote maintenance, there must be a communication link between you and a person on site with eye contact to the axis.

Information

During the search, all drive controllers within the broadcast domain are found via IPv4 limited broadcast.

Requirements for finding a drive controller in the network:

- Network supports IPv4 limited broadcast
- All drive controllers and the PC are in the same subnet (broadcast domain)

11.3.1 Transmitting the configuration

The steps for transmitting the configuration vary depending on the safety technology.

Drive controller without SE6 option

- ✓ You have verified the plausibility of the predefined test motion variables.
 - ✓ The drive controllers are switched on.
1. In the project tree, select the module under which you have recorded your drive controller and click **Online connection** in the project menu.
 - ⇒ The **Add connection** dialog box opens. All drive controllers found via IPv4 limited broadcast are displayed.
 2. **Direct connection** tab > **IP address** column:
 Activate the IP addresses in question and confirm your selection with **OK**.
 - ⇒ The **Online functions** window opens. All drive controllers connected through the previously selected IP addresses are displayed.
 3. Select the drive controller to which you want to transmit a configuration and change the selection of the transmission type from **Read** to **Send**.
 4. Change the selection **Create new drive controller**:
 Select the configuration that you would like to transfer to the drive controller.
 5. Repeat steps 3 and 4 for all other drive controllers to which you would like to transfer your configuration.
 6. **Online** tab:
 Click **Establish online connection**.
 - ⇒ The configurations are transferred to the drive controllers.

Drive controller with SE6 option

- ✓ You have verified the plausibility of the predefined test motion variables.
- ✓ The drive controllers are switched on.
- 1. In the project tree, select the module under which you have recorded your drive controller and click **Online connection** in the project menu.
 - ⇒ The **Add connection** dialog box opens. All drive controllers found via IPv4 limited broadcast are displayed.
- 2. **Direct connection tab > IP address column:**
 Activate the IP addresses in question and confirm your selection with **OK**.
 - ⇒ The **Online functions** window opens. All drive controllers connected through the previously selected IP addresses are displayed.
- 3. Select the drive controller to which you want to transmit a configuration and change the selection of the transmission type from **Read** to **Send**.
- 4. Change the selection **Create new drive controller:**
 Select the configuration that you would like to transfer to the drive controller.
- 5. Repeat steps 3 and 4 for all other drive controllers to which you would like to transfer your configuration.
- 6. **Online tab:**
 Click **Establish online connection**.
 - ⇒ The configurations are transferred to the drive controllers.
 - ⇒ A dialog box prompts you to open the **PASmotion** configuration tool.
- 1. Confirm the dialog box with **Yes**.
 - ⇒ **PASmotion** opens.
- 2. In the **PASmotion** project administration, navigate to the safety module for the drive controller and double-click to open it.
 - ⇒ The dialog box for the password prompt opens.
- 3. Enter the password and confirm with **OK**.
 - ⇒ The wizard for device synchronization opens.
 - ⇒ Device configuration and configuration are checked against each other automatically.
- 4. Optional: If the configurations match, click on **Done** after device synchronization has finished.
- 5. Optional: If the configurations do not match, click on **Next** after device synchronization has finished.
 - 5.1. Confirm the production number of the safety module and click **Next**.
 - 5.2. Enter the password for the configuration on the safety module and click **Next**.
 - 5.3. Click **Upload** to transfer the device configuration to the project.
 - 5.4. After the successful transfer, click **Done**.
- 6. Exit **PASmotion**.
 - ⇒ The safety configuration is transferred to the selected drive controller.

11.3.2 Saving the configuration

- ✓ You have successfully transmitted the configuration.
- 1. Online functions window:
Click Save values (A00).
⇒ The Save values (A00) window opens.
- 2. Click Start action.
⇒ The configuration is stored on the drive controllers in non-volatile memory.
- 3. Close the Save values (A00) window.

Information

For the configuration to take effect on the drive controller, a restart is required when the configuration is saved on the drive controller for the first time or when changes are made to the firmware or process data mapping.

Restarting a drive controller

- ✓ You have stored the configuration on the drive controller in non-volatile memory.
- 1. Online functions window:
Click Restart (A09).
⇒ The Restart (A09) window opens.
- 2. Select which of the connected drive controllers you want to restart.
- 3. Click Start action.
- 4. Confirm the safety instruction with OK.
⇒ The Restart (A09) window closes.
- ⇒ The fieldbus communication and connection between DriveControlSuite and drive controllers are interrupted.
- ⇒ The selected drive controllers restart.

11.4 Testing the configuration

Before you continue with the parameterization, we recommend testing your projected axis model using the jog control panel.

Check your projected axis model as well as your configured electrical and mechanical data for plausibility by transferring your configuration to one of your drive controllers for test purposes and controlling the drive using the jog control panel instead of using a controller.

Information

Check the suitability of the default values for your application before starting the test. If they appear too large or unsuitable compared with the results of the scaling calculator, replace them with values that are more suitable for test operation.

You can quickly and easily test the project configuration using the DriveControlSuite software or directly using the drive controller display.

11.4.1 Testing using DriveControlSuite

WARNING!

Injury to persons and material damage due to axis movement!

When you activate the control panel, DriveControlSuite gives you sole control of the motions of the axis. If you are using a controller, it no longer monitors the axis movements after the control panel is activated. The controller cannot intervene to prevent collisions. The controller takes over control again when the control panel is deactivated, which can cause unexpected axis movements.

- Do not switch to other windows when the control panel is active.
- Only use the control panel if you have visual contact with the axis.
- Make sure that no people or objects are within the travel range.
- For access via remote maintenance, there must be a communication link between you and a person on site with eye contact to the axis.

- ✓ You have successfully saved the configuration.
 - ✓ There must not be any active safety function.
 - ✓ The drive controller is switched on and connected to the network.
 - ✓ There is an online connection between DriveControlSuite and the drive controller.
1. Select the relevant drive controller in the project tree and click on the first projected axis in the Project menu > Wizard area.
 2. Select the Jog control panel wizard.
 3. Click Control panel on and then Enable.
 - ⇒ The drive is controlled using the activated control panel.
 4. Move the axis step-by-step and test the direction of motion, velocity, distances, etc. using the Jog+, Jog-, Jog step+ and Jog step- buttons.
 5. Optimize your project configuration based on your test results as necessary.
 6. To deactivate the control panel, click on Control panel off.

Information

Jog+ and Jog- cause a continual manual movement in the positive or negative direction. Jog step+ and Jog step- move the axis relative to the current actual position by the increment specified in I14.

Jog+ and Jog- have a higher priority than Jog step+ and Jog step-.

11.4.2 Testing using the operating unit

You have connected the SD6 drive controller along with its accessories as described and would like to test the components in the group for correct wiring and functionality. STOBER standard parameterization enables an initial function test if you are operating the drive controller together with a STOBER synchronous servo motor and an EnDat encoder. In this case, the electronic nameplate of the motor is read out when the device starts and the accompanying data is transferred into the drive controller.

11.4.2.1 Schematic test sequence

Schematic test sequence

The following illustration shows the schematic sequence of the wiring and function test.




Fig. 27: Schematic test sequence for wiring and function test

11.4.2.2 Practical test sequence



DANGER!

Danger to life from moving parts!

Motor shaft rotates during the wiring and function test described below!

- Clear the danger area before the test.
- Do not connect any downstream mechanical parts to the motor or gear unit until the test has finished.
- Make sure that components attached to the motor, such as feather keys or coupling elements, are sufficiently secured against centrifugal forces.

Perform the individual steps in the specified order.

Preparing for the test

1. Switch on the 24 V_{DC} supply of the brake.
 2. Switch on the 24 V_{DC} supply of the drive controller.
 3. Switch on the power grid supply.
 4. Optional: If you are using the ST6 safety module, deactivate the STO safety function, such as by connecting 24 V_{DC} to terminal X12.
 5. Optional: If you use the SE6 safety module, deactivate the STO safety function by connecting terminals X14 and X15 according to your safety configuration.
- ⇒ The drive controller either switches to the "ready to switch on" or "locked" state.

Performing the test

✓ Drive controller is ready to switch on:

1. Activate local operation using the [Manual] button.
 2. Enable the drive controller using the [I/O] button.
 3. Rotate the motor axis using the left and right arrow buttons at the velocity and acceleration configured in parameter I12.
- ⇒ You have correctly wired all components; the function test completed successfully.

✓ Drive controller is locked (display = 1: Switch-on disable, parameter E48):

1. Determine the causes for the switch-on lockout and remedy them:
Parameter E49 outputs possible causes in code and parameter E47 shows them in plain text.
2. Then, carry out the test (see the section "Drive controller is ready to switch on").

Information

If the lack of enable signal for the CiA 402 application is the sole cause for the switch-on lockout, switch to local operation directly and carry out the test (see the section "Drive controller is ready to switch on").

Finishing the test

1. Lock the drive controller using the [I/O] button.
2. Switch to normal operation using the [Manual] button.

12 Replacement

The following chapters describe the replacement of a drive controller and the available accessories.

12.1 Safety instructions for device replacement

Replacement work is permitted only when no voltage is present. Obey the 5 safety rules (see [Working on the machine](#) [► 16]).

When the power supply voltage is turned on, hazardous voltages may be present on the connection terminals and the cables connected to them.

The device and the cables connected to it are not necessarily de-energized when the supply voltage is switched off and all displays have gone out!

Information

Note the discharge time of the DC link capacitors in the general technical data for the devices. You can only determine the absence of voltage after this time period.

Protect the devices against falling parts (bits or strands of wire, pieces of metal, etc.) during installation or other work in the control cabinet. Parts with conductive properties may result in a short circuit inside the devices and device failure as a result.

Opening the housing, plugging in or unplugging connection terminals, connecting or removing a connecting wiring, and installing or removing accessories are prohibited while the voltage supply is switched on.

If you couple the drive controllers in the DC link, make sure that all Quick DC-Link modules are built over with a drive controller again after replacement.

The device housing must be closed before you turn on the supply voltage.

12.2 Notes on the safety configuration

A drive controller with expanded safety function through the SE6 safety module always requires a valid safety configuration. If this is missing, an error message is generated.

The safety configuration of the safety module has a unique CRC overall checksum which also uses encryption to store the serial number of the safety module. Various safety modules can have identical safety functions despite this. In this case, the CRC checksums match the safety functions.

The safety configuration is saved on the safety module. In addition, a copy of the configuration is saved on the Paramodul. If you replace a drive controller, you can continue using the Paramodul and, as a result, the safety configuration of the drive controller being replaced. For information on how to do this, see [Replacing the drive controller](#) [► 143].

The checksums are displayed using parameter S09 Safety modul SE6 checksum of safety configuration. The checksum of the safety functions is output in element 2.

12.3 Notes on motor replacement

When replacing a STOBER synchronous servo motor with EnDat encoder and electronic nameplate, the drive controller detects that a motor replacement has been performed upon switching on the drive controller (prerequisite: B04 = 64: Active).

As a response, the drive controller reads out the changed data from the electronic nameplate, transmits this data to the corresponding parameters and reports the process using a fault of type 81: Motor allocation. Based on the cause of the fault, you can recognize what has changed.

In order to take over the changed data onto the Paramodul and thus store it in non-volatile memory, you must carry out the Save values action in parameter A00. As an alternative, save the data using the save button on the display.

Otherwise, the next time the drive controller is switched on, the electronic nameplate is read out again and the changed data is reported using a fault of type 81: Motor allocation.

12.4 Replacing the drive controller

WARNING!

Electrical voltage! Risk of fatal injury due to electric shock!

- Always switch off all power supply voltage before working on the devices!
- Note the discharge time of the DC link capacitors in the general technical data. You can only determine the absence of voltage after this time period.

ATTENTION!

Loss of absolute position!

The absolute position in the encoder is lost if the encoder cable is disconnected from the AES battery module.

- Do not disconnect the encoder cable from the AES during service work! Disconnect the AES from the drive controller.

ATTENTION!

Damage to property due to electrostatic discharge!

Take appropriate measures when handling exposed circuit boards, e.g. wearing ESD-safe clothing.

Do not touch contact surfaces.

Information

The safety module is a permanently integrated component in the drive controller where any design, technical and electrical modifications are prohibited!

Tools and material

You will need:

- Tool for loosening and tightening the fastening screws

Requirements and replacement

- ✓ Drive controllers of the same series and same power can be replaced interchangeably.
- ✓ The hardware and firmware of the drive controller being installed have the same or a newer version than the drive controller being replaced. For information on firmware updates, see [Replacing or updating firmware using DS6](#) [► 146].

- ✓ The Paramodul of the drive controller being replaced is present; the original project is stored on the Paramodul.
- 1. Optional: If an AES battery module is present, disconnect the AES from the drive controller.
- 2. Remove all terminals from the drive controller being uninstalled.
- 3. Release the grounding conductor from the ground bolt.
- 4. Sizes 0 to 2: Unscrew the upper fastening screw slightly and remove the lower one to allow removal of the EM6A0 EMC shroud.
- 5. Remove the fastening screws and take the drive controller out of the control cabinet. Note that, if you couple the drive controller to the DC link over Quick DC-Link or you use a rear section braking resistor, you first have to press the drive controller up at the guides before you can remove it from the control cabinet.
- 6. Remove the Paramodul of the new drive controller being installed.
- 7. Insert the Paramodul with the original project into the drive controller being installed.
- 8. Optional: Remove the communication and terminal modules from the drive controller being replaced if no accessories have been provided with the new drive controller.
- 9. Optional: Install the accessories into the new drive controller.
- 10. Install the new drive controller in the control cabinet.
- 11. Connect the grounding conductor to the ground bolt. Obey the instructions and requirements for [Protective grounding](#) [► 65].
- 12. Reattach the terminals.
- 13. Optional: If an AES battery module was present, attach it to the drive controller with the associated encoder cable. Tighten the knurled screws so that AES is securely connected to the drive controller.
- 14. Start the drive controller.
- 15. Optional: If you are using the expanded safety functionality through the SE6 safety module, press the left and right arrow buttons simultaneously for 2 seconds after the corresponding prompt in order to activate the safety functions.
 - ⇒ The transmission of configuration data from the Paramodul starts.
 - ⇒ Data transmission is shown on the display.
 - ⇒ The safety configuration saved on the Paramodul is saved in the safety module.
 - ⇒ After successful data transmission, a fault event is shown on the display.
- 16. Optional: If the safety functions have activated in the previous step, acknowledge the fault event with [Esc].
- 17. Take the inserted Paramodul back out and insert the new Paramodul removed in step 5 into the drive controller.
- 18. Press the [Save] button for 3 seconds.
 - ⇒ All data is stored in non-volatile memory on the Paramodul.
- 19. Then restart the drive controller, such as using the control unit's 24 V_{DC} power supply.
- 20. Optional: If you are using the expanded safety functionality through the SE6 safety module, check whether the checksum stored in the replaced drive controller's machine documentation for the safety functions matches the checksum of the new drive controller. The checksum is shown on the display. Acknowledge the display with [Esc]. Alternatively, parameter S09 Safety modul SE6 checksum of safety configuration in element 2 is used to display the checksum.

12.5 Replacing the Paramodul

If you need to replace the original Paramodul supplied with the drive controller with a new one, you can reorder it from STOBER (see Removable data storage).

Information

A new Paramodul from STOBER is always empty. It must be prepared for operation in the drive controller.

If a spare empty Paramodul from STOBER is plugged in when the drive controller is started, the drive controller starts in emergency operation and an error message appears on the display (see Drive controller state: Display).

Preparation

To replace an original Paramodul and prepare the new one for operation in the drive controller, proceed as described below:

- ✓ The original Paramodul is plugged into the drive controller.
- 1. Switch on the 24 V_{DC} supply of the control unit.
- 2. Replace the original Paramodul with the new one.
- 3. Execute the A00 action and wait until saving is finished.
- ⇒ The new Paramodul is prepared for operation in the drive controller.

12.6 Replacing or updating firmware using DS6

If you require a different firmware version or want to update the firmware of a drive controller, you can change the firmware using the DriveControlSuite commissioning software. You can prepare a live firmware update while the drive controller and machine are operating. The update does not take effect until after a restart. This dual firmware behavior prevents a firmware loss or appearance of a case of service, since it ensures, for example, that the existing firmware can be accessed if the connection is interrupted.

In order to perform a live firmware update, you must connect your PC and the drive controller over the network.

Information

During the search, all drive controllers within the broadcast domain are found via IPv4 limited broadcast.

Requirements for finding a drive controller in the network:

- Network supports IPv4 limited broadcast
- All drive controllers and the PC are in the same subnet (broadcast domain)

Carrying out a live firmware update

✓ The drive controller is switched on.

1. Start DriveControlSuite.
2. Click Assignment and live firmware update.
 - ⇒ The Add connection dialog box opens.
3. Direct connection tab > IP address column:
Activate the IP address in question and confirm your selection with OK.
 - ⇒ The Online functions window opens. The drive controller that is connected by the selected IP address is displayed.
4. Live firmware update tab:
By default, the newest firmware version suitable for the DriveControlSuite version is selected. Click Assign default version to all drive controllers.
 - ⇒ The selection No live firmware update for the drive controller changes to Default version.
5. Optional: If you want to assign an alternative, locally saved firmware version to a drive controller, proceed as follows:
 - 5.1. Click on Add new firmware version, navigate to the directory and load the file.
 - 5.2. Then change the selection from Default version of the drive controller to Alternative version and select the previously uploaded firmware version from the associated picklist.
6. Live firmware update tab:
Click Start live firmware update.
7. Confirm the safety instruction with OK.
 - ⇒ The firmware update is transferred.
8. Since the firmware update only takes effect after the drive controller is restarted, click Restart all drive controllers after completing the transfer.
9. Confirm the restart with Yes.
 - ⇒ The fieldbus communication and connection to DriveControlSuite are interrupted and the drive controller restarts.

13 Appendix

13.1 Terminal specifications

Relevant information for project configuration of the connecting wiring can be taken from the following chapters.

EN 60204-1 contains basic recommendations that should be taken into account when selecting conductors. The chapter "Conductors and cables" provides specifications for the maximum current carrying capacity of conductors based on the way they are laid as well as tips for derating, for example in the case of increased surrounding temperatures or lines with multiple loaded individual conductors.

WARNING!

Personal injury and material damage due to electric shock and thermal overload!

- Prepare the conductor ends according to the terminal specifications.
- In the case of pre-made cables and conductors, check the conductor ends and adjust them if necessary.

13.1.1 Overview

The following tables clarify which specifications must be observed for which connections depending on the type of drive controller or accessory.

Drive controller

| Type | X1 | X10, X20 | X11 | X30 |
|--------|--|---|--|---------------------------|
| SD6A02 | <u>FMC 1,5 -ST-3,5</u> [▶ 151] | <u>GFKC 2,5 -ST-7,62</u> | <u>BLDF 5.08 180 SN</u> [▶ 150] | <u>GFKIC 2.5 -ST-7.62</u> |
| SD6A04 | | [▶ 152] | | [▶ 153] |
| SD6A06 | | | | |
| SD6A14 | | <u>SPC 5 -ST-7,62</u> [▶ 155] | | <u>ISPC 5 -STGCL-7,62</u> |
| SD6A16 | | | | [▶ 153] |
| SD6A24 | | <u>SPC 16 -ST-10,16</u> | | <u>ISPC 16 -ST-10,16</u> |
| SD6A26 | | [▶ 155] | | [▶ 154] |
| SD6A34 | | <u>MKDSP 25 -15,00</u> | | — |
| SD6A36 | | [▶ 154] | | |
| SD6A38 | | | | |

Tab. 155: Terminal specifications for the base device

Safety module

| Type | X2, X5, X6 ³⁴ | X12 |
|------|---|---|
| ST6 | BFL 5.08HC 180 SN [► 149] | BCF 3,81 180 SN [► 149] |

Tab. 156: Terminal specifications of the ST6 safety module

| Type | X2, X5, X7, X8 ³⁵ | X14, X15 |
|------|---|--|
| SE6 | BFL 5.08HC 180 SN [► 149] | DFMC 1.5 -ST-3.5 [► 150] |

Tab. 157: Terminal specifications of the SE6 safety module

Terminal modules

| Type | X100, X101 | X102, X103 |
|------|--|---|
| XI6 | FK-MCP 1,5 -ST-3,5 [► 151] | FMC 1,5 -ST-3,5 [► 151] |
| RI6 | | — |
| IO6 | | — |

Tab. 158: Terminal specifications for the terminal modules

Encoder adapter box

| Type | X302, X305, X306 | X303 |
|------|--|---|
| LA6 | FK-MCP 1,5 -ST-3,5 [► 151] | BFL 5.08HC 180 SN [► 149] |

Tab. 159: Terminal specifications for the encoder adapter box

Braking resistors

| Type | Braking resistor |
|-------------|--------------------------------|
| FZMU, FZZMU | G 10/2 [► 152] |
| FGFKU | G 10/2 [► 152] |

Tab. 160: Terminal specifications for the braking resistors

³⁴ In addition to connections for the safety technology, the functional connections X2, X5, X6 are also located on the ST6 safety module (not related to the safety technology).

³⁵ In addition to connections for the safety technology, the connections X2 and X5 are also located on the SE6 safety module (not related to the safety technology).

13.1.2 BCF 3,81 180 SN

| Feature | Line type | Value |
|--|--|-------------------------------|
| Contact spacing | — | 3.81 mm |
| Nominal current at $\vartheta_{\text{amb}} = 40\text{ °C}$ | — | CE/UL/CSA: 16 A/10 A/ 11 A |
| Max. conductor cross-section | Flexible without end sleeve | 1.5 mm ² |
| | Flexible with end sleeve without plastic collar | 1.0 mm ² |
| | Flexible with end sleeve with plastic collar | 1.0 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 16 |
| Min. conductor cross-section | Flexible without end sleeve | 0.14 mm ² |
| | Flexible with end sleeve without plastic collar | 0.25 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 26 |
| Insulation stripping length | — | 10 mm |
| Tightening torque | — | — |

Tab. 161: BCF 3.81 180 SN BK specification

13.1.3 BFL 5.08HC 180 SN

| Feature | Line type | Value |
|--|--|-------------------------------|
| Contact spacing | — | 5.08 mm |
| Nominal current at $\vartheta_{\text{amb}} = 40\text{ °C}$ | — | CE/UL/CSA: 16 A/10 A/ 10 A |
| Max. conductor cross-section | Flexible without end sleeve | 2.5 mm ² |
| | Flexible with end sleeve without plastic collar | 2.5 mm ² |
| | Flexible with end sleeve with plastic collar | 2.5 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 12 |
| Min. conductor cross-section | Flexible without end sleeve | 0.2 mm ² |
| | Flexible with end sleeve without plastic collar | 0.2 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 26 |
| Insulation stripping length | — | 10 mm |
| Tightening torque | — | — |

Tab. 162: BFL 5.08HC 180 SN specification

13.1.4 BLDF 5.08 180 SN

| Feature | Line type | Value |
|--|--|-------------------------------|
| Contact spacing | — | 5.08 mm |
| Nominal current at $\vartheta_{\text{amb}} = 40\text{ °C}$ | — | CE/UL/CSA: 14 A/10 A/ 10 A |
| Max. conductor cross-section | Flexible without end sleeve | 2.5 mm ² |
| | Flexible with end sleeve without plastic collar | 2.5 mm ² |
| | Flexible with end sleeve with plastic collar | 2.5 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 12 |
| Min. conductor cross-section | Flexible without end sleeve | 0.2 mm ² |
| | Flexible with end sleeve without plastic collar | 0.2 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 26 |
| Insulation stripping length | — | 10 mm |
| Tightening torque | — | — |

Tab. 163: BLDF 5.08 180 SN specification

13.1.5 DFMC 1.5 -ST-3.5

| Feature | Line type | Value |
|--|--|----------------------|
| Contact spacing | — | 3.5 mm |
| Nominal current at $\vartheta_{\text{amb}} = 40\text{ °C}$ | — | CE/UL/CSA: 8 A |
| Max. conductor cross-section | Flexible without end sleeve | 1.5 mm ² |
| | Flexible with end sleeve without plastic collar | 1.5 mm ² |
| | Flexible with end sleeve with plastic collar | 0.75 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 16 |
| Min. conductor cross-section | Flexible without end sleeve | 0.2 mm ² |
| | Flexible with end sleeve without plastic collar | 0.25 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 24 |
| Insulation stripping length | — | 10 mm |
| Tightening torque | — | — |

Tab. 164: Specification for DFMC 1.5 -ST-3.5

13.1.6 FK-MCP 1,5 -ST-3,5

| Feature | Line type | Value |
|---|--|----------------------|
| Contact spacing | — | 3.5 mm |
| Nominal current at $\vartheta_{amb} = 40\text{ °C}$ | — | CE/UL/CSA: 8 A |
| Max. conductor cross-section | Flexible without end sleeve | 1.5 mm ² |
| | Flexible with end sleeve without plastic collar | 1.5 mm ² |
| | Flexible with end sleeve with plastic collar | 0.5 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 16 |
| Min. conductor cross-section | Flexible without end sleeve | 0.14 mm ² |
| | Flexible with end sleeve without plastic collar | 0.25 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 28 |
| Insulation stripping length | — | 9 mm |
| Tightening torque | — | — |

Tab. 165: FK-MCP 1,5 -ST-3,5 specification

13.1.7 FMC 1,5 -ST-3,5

| Feature | Line type | Value |
|---|--|----------------------|
| Contact spacing | — | 3.5 mm |
| Nominal current at $\vartheta_{amb} = 40\text{ °C}$ | — | CE/UL/CSA: 8 A |
| Max. conductor cross-section | Flexible without end sleeve | 1.5 mm ² |
| | Flexible with end sleeve without plastic collar | 1.5 mm ² |
| | Flexible with end sleeve with plastic collar | 0.75 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 16 |
| Min. conductor cross-section | Flexible without end sleeve | 0.2 mm ² |
| | Flexible with end sleeve without plastic collar | 0.25 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | — |
| | AWG according to UL/CSA | 24 |
| Insulation stripping length | — | 10 mm |
| Tightening torque | — | — |

Tab. 166: FMC 1,5 -ST-3,5 specification

13.1.8 G 10/2

| Feature | Line type | Value |
|--|--|-------------------------------|
| Contact spacing | — | 17.5 mm |
| Nominal current at $\vartheta_{\text{amb}} = 40\text{ °C}$ | — | CE/UL/CSA: 57 A/65 A/ 65 A |
| Max. conductor cross-section | Flexible without end sleeve | 10.0 mm ² |
| | Flexible with end sleeve without plastic collar | 16.0 mm ² |
| | Flexible with end sleeve with plastic collar | 16.0 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 6.0 mm ² |
| | AWG according to UL/CSA | 6 |
| Min. conductor cross-section | Flexible without end sleeve | 0.5 mm ² |
| | Flexible with end sleeve without plastic collar | 0.5 mm ² |
| | Flexible with end sleeve with plastic collar | 0.5 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 0.5 mm ² |
| | AWG according to UL/CSA | 24 |
| Insulation stripping length | — | 12 mm |
| Tightening torque | — | 1.5 – 1.8 Nm |

Tab. 167: G 10/2 specification

13.1.9 GFKC 2,5 -ST-7,62

| Feature | Line type | Value |
|--|--|-------------------------------|
| Contact spacing | — | 7.62 mm |
| Nominal current at $\vartheta_{\text{amb}} = 40\text{ °C}$ | — | CE/UL/CSA: 12 A/10 A/ 10 A |
| Max. conductor cross-section | Flexible without end sleeve | 2.5 mm ² |
| | Flexible with end sleeve without plastic collar | 2.5 mm ² |
| | Flexible with end sleeve with plastic collar | 2.5 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 1.5 mm ² |
| | AWG according to UL/CSA | 12 |
| Min. conductor cross-section | Flexible without end sleeve | 0.2 mm ² |
| | Flexible with end sleeve without plastic collar | 0.25 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 0.5 mm ² |
| | AWG according to UL/CSA | 24 |
| Insulation stripping length | — | 10 mm |
| Tightening torque | — | 0.3 – 0.7 Nm |

Tab. 168: GFKC 2,5 -ST-7,62 specification

13.1.10 GFKIC 2.5 -ST-7.62

| Feature | Line type | Value |
|--|--|-------------------------------|
| Contact spacing | — | 7.62 mm |
| Nominal current at $\vartheta_{\text{amb}} = 40^\circ\text{C}$ | — | CE/UL/CSA: 12 A/10 A/ 10 A |
| Max. conductor cross-section | Flexible without end sleeve | 2.5 mm ² |
| | Flexible with end sleeve without plastic collar | 2.5 mm ² |
| | Flexible with end sleeve with plastic collar | 2.5 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 1.0 mm ² |
| | AWG according to UL/CSA | 12 |
| Min. conductor cross-section | Flexible without end sleeve | 0.2 mm ² |
| | Flexible with end sleeve without plastic collar | 0.25 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 0.5 mm ² |
| | AWG according to UL/CSA | 26 |
| Insulation stripping length | — | 10 mm |
| Tightening torque | — | — |

Tab. 169: Specification for GFKIC 2.5 -ST-7.62

13.1.11 ISPC 5 -STGCL-7,62

| Feature | Line type | Value |
|--|--|-------------------------------|
| Contact spacing | — | 7.62 mm |
| Nominal current at $\vartheta_{\text{amb}} = 40^\circ\text{C}$ | — | CE/UL/CSA: 32 A/35 A/ 35 A |
| Max. conductor cross-section | Flexible without end sleeve | 6.0 mm ² |
| | Flexible with end sleeve without plastic collar | 6.0 mm ² |
| | Flexible with end sleeve with plastic collar | 4.0 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 1.5 mm ² |
| | AWG according to UL/CSA | 8 |
| Min. conductor cross-section | Flexible without end sleeve | 0.2 mm ² |
| | Flexible with end sleeve without plastic collar | 0.25 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 0.25 mm ² |
| | AWG according to UL/CSA | 24 |
| Insulation stripping length | — | 15 mm |
| Tightening torque | — | — |

Tab. 170: ISPC 5 -STGCL-7,62 specification

13.1.12 ISPC 16 -ST-10,16

| Feature | Line type | Value |
|---|--|-------------------------------|
| Contact spacing | — | 10.16 mm |
| Nominal current at $\vartheta_{amb} = 40\text{ °C}$ | — | CE/UL/CSA: 55 A/66 A/ 66 A |
| Max. conductor cross-section | Flexible without end sleeve | 16.0 mm ² |
| | Flexible with end sleeve without plastic collar | 16.0 mm ² |
| | Flexible with end sleeve with plastic collar | 10.0 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 4.0 mm ² |
| | AWG according to UL/CSA | 4 |
| Min. conductor cross-section | Flexible without end sleeve | 0.75 mm ² |
| | Flexible with end sleeve without plastic collar | 0.75 mm ² |
| | Flexible with end sleeve with plastic collar | 0.75 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 0.75 mm ² |
| | AWG according to UL/CSA | 20 |
| Insulation stripping length | — | 18 mm |
| Tightening torque | — | — |

Tab. 171: SPC 16 -ST-10,16 specification

13.1.13 MKDSP 25 -15,00

| Feature | Line type | Value |
|---|--|----------------------------------|
| Contact spacing | — | 15.0 mm |
| Nominal current at $\vartheta_{amb} = 40\text{ °C}$ | — | CE/UL/CSA: 125 A/ 115 A/115 A |
| Max. conductor cross-section | Flexible without end sleeve | 35.0 mm ² |
| | Flexible with end sleeve without plastic collar | 35.0 mm ² |
| | Flexible with end sleeve with plastic collar | 35.0 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 16.0 mm ² |
| | AWG according to UL/CSA | 2 |
| Min. conductor cross-section | Flexible without end sleeve | 0.5 mm ² |
| | Flexible with end sleeve without plastic collar | 1.0 mm ² |
| | Flexible with end sleeve with plastic collar | 1.5 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 0.5 mm ² |
| | AWG according to UL/CSA | 20 |
| Insulation stripping length | — | 18 mm |
| Tightening torque | Conductor cross-sections $\leq 25.0\text{ mm}^2$ | 2.5 Nm |
| | Conductor cross-sections $> 25.0\text{ mm}^2$ | 4.5 Nm |

Tab. 172: MKDSP 25 -15,00 specification

13.1.14 SPC 5 -ST-7,62

| Feature | Line type | Value |
|---|--|-------------------------------|
| Contact spacing | — | 7.62 mm |
| Nominal current at $\vartheta_{amb} = 40\text{ °C}$ | — | CE/UL/CSA: 32 A/35 A/ 35 A |
| Max. conductor cross-section | Flexible without end sleeve | 6.0 mm ² |
| | Flexible with end sleeve without plastic collar | 6.0 mm ² |
| | Flexible with end sleeve with plastic collar | 4.0 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 1.5 mm ² |
| | AWG according to UL/CSA | 8 |
| Min. conductor cross-section | Flexible without end sleeve | 0.2 mm ² |
| | Flexible with end sleeve without plastic collar | 0.25 mm ² |
| | Flexible with end sleeve with plastic collar | 0.25 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 0.25 mm ² |
| | AWG according to UL/CSA | 24 |
| Insulation stripping length | — | 12 – 15 mm |
| Tightening torque | — | 0.3 – 0.7 Nm |

Tab. 173: SPC 5 -ST-7,62 specification

13.1.15 SPC 16 -ST-10,16

| Feature | Line type | Value |
|---|--|-------------------------------|
| Contact spacing | — | 10.16 mm |
| Nominal current at $\vartheta_{amb} = 40\text{ °C}$ | — | CE/UL/CSA: 55 A/66 A/ 66 A |
| Max. conductor cross-section | Flexible without end sleeve | 16.0 mm ² |
| | Flexible with end sleeve without plastic collar | 16.0 mm ² |
| | Flexible with end sleeve with plastic collar | 10.0 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 4.0 mm ² |
| | AWG according to UL/CSA | 4 |
| Min. conductor cross-section | Flexible without end sleeve | 0.75 mm ² |
| | Flexible with end sleeve without plastic collar | 0.75 mm ² |
| | Flexible with end sleeve with plastic collar | 0.75 mm ² |
| | 2 conductors, flexible, with double end sleeve with plastic collar | 0.75 mm ² |
| | AWG according to UL/CSA | 20 |
| Insulation stripping length | — | 18 mm |
| Tightening torque | — | 0.3 – 0.7 Nm |

Tab. 174: SPC 16 -ST-10,16 specification

13.2 Wiring examples

The following chapters show the basic connection using examples.

Information

For UL-compliant operation: The connections marked with PE are intended solely for the functional grounding.

13.2.1 Stand-alone operation with direct brake control

The following graphic shows a wiring example for the stand-alone operation of SD6 with direct brake control.

Note the information on EMC-compliant installation (see [EMC recommendations](#) [▶ 66]).




Fig. 28: Wiring example of stand-alone operation with direct brake control

- A1 Controller
- F1 – F4 Fuse
- K1 Safety relay
- L1 – L3 Three-phase power supply
- M Reference potential
- M1 Motor
- R1 Braking resistor
- T1 Drive controller
- 1 Optional connection

13.2.2 Stand-alone operation with indirect brake control

The following graphic shows a wiring example for the stand-alone operation of SD6 with indirect brake control.

Note the information on EMC-compliant installation (see [EMC recommendations](#) [► 66]).




Fig. 29: Wiring example of stand-alone operation with indirect brake control

| | |
|--------------------|----------------------------|
| A1 | Controller |
| F1 – F5 | Fuse |
| K1 | Safety relay |
| K2 | Contactor |
| L | 230 V _{AC} supply |
| L1 – L3 | Three-phase power supply |
| M | Reference potential |
| 24 V _{DC} | 24 V _{DC} supply |
| M1 | Motor |
| N | Neutral conductor |
| R1 | Braking resistor |
| T1 | Drive controller |
| T2 | Brake rectifier |
| Y1 | Brake |
| 1 | Optional connection |

13.3 Detailed information

The documentation listed below provides you with further relevant information on the 6th STOBER drive controller generation. You can find the current status of the documentation in the STOBER download center at <http://www.stober.de/en/downloads/>, if you enter the ID of the documentation in the search.

The grouping of the documentation is intended to provide you with assistance, but is only relevant if you control the drive controller using a fieldbus.

PROFINET

| Title | Documentation | Contents | ID |
|---|---------------|---|--------|
| PROFINET communication – SD6 | Manual | Installation, electrical installation, data transfer, commissioning, detailed information | 442710 |
| SD6 drive controller | Manual | System design, technical data, project configuration, storage, installation, connection, commissioning, operation, service, diagnostics | 442426 |
| Drive Based (DB) application | Manual | Project planning, configuration, parameterization, function test, detailed information | 442706 |
| Drive Based Synchronous (DBS) application | Manual | Project planning, configuration, parameterization, function test, detailed information | 443046 |
| ST6 safety technology – STO via terminals | Manual | Technical data, installation, commissioning, diagnostics, detailed information | 442478 |
| SE6 safety technology – Safe drive monitoring via terminals | Manual | Technical data, installation, commissioning, diagnostics | 442796 |
| Connection method | Manual | Selection of encoder, power and hybrid cables, accessories, technical data, connection | 443102 |

EtherCAT

| Title | Documentation | Contents | ID |
|---|---------------|---|--------|
| EtherCAT communication – SD6 | Manual | Installation, electrical installation, data transfer, commissioning, detailed information | 442516 |
| SD6 drive controller | Manual | System design, technical data, project configuration, storage, installation, connection, commissioning, operation, service, diagnostics | 442426 |
| CiA 402 application – SD6 | Manual | Project planning, configuration, parameterization, function test, detailed information | 443077 |
| Drive Based (DB) application | Manual | Project planning, configuration, parameterization, function test, detailed information | 442706 |
| Drive Based Synchronous (DBS) application | Manual | Project planning, configuration, parameterization, function test, detailed information | 443046 |
| ST6 safety technology – STO via terminals | Manual | Technical data, installation, commissioning, diagnostics, detailed information | 442478 |
| SE6 safety technology – Safe drive monitoring via terminals | Manual | Technical data, installation, commissioning, diagnostics | 442796 |
| Connection method | Manual | Selection of encoder, power and hybrid cables, accessories, technical data, connection | 443102 |

CANopen

| Title | Documentation | Contents | ID |
|---|---------------|---|--------|
| CANopen communication – SD6 | Manual | Installation, electrical installation, data transfer, commissioning, detailed information | 442637 |
| SD6 drive controller | Manual | System design, technical data, project configuration, storage, installation, connection, commissioning, operation, service, diagnostics | 442426 |
| CiA 402 application – SD6 | Manual | Project planning, configuration, parameterization, function test, detailed information | 443077 |
| Drive Based (DB) application | Manual | Project planning, configuration, parameterization, function test, detailed information | 442706 |
| Drive Based Synchronous (DBS) application | Manual | Project planning, configuration, parameterization, function test, detailed information | 443046 |
| ST6 safety technology – STO via terminals | Manual | Technical data, installation, commissioning, diagnostics, detailed information | 442478 |
| SE6 safety technology – Safe drive monitoring via terminals | Manual | Technical data, installation, commissioning, diagnostics | 442796 |
| Connection method | Manual | Selection of encoder, power and hybrid cables, accessories, technical data, connection | 443102 |

13.4 Formula symbols

| Symbol | Unit | Explanation |
|--------------|----------|--|
| $C_{N,PU}$ | F | Nominal charging capacity of the power unit |
| C_{PU} | F | Self-capacitance of the power unit |
| f_{2PU} | Hz | Output frequency of the power unit |
| $f_{PWM,PU}$ | Hz | Frequency of the pulse width modulation of the power unit |
| I_{1maxCU} | A | Maximum input current of the control unit |
| I_{1maxPU} | A | Maximum input current of the power unit |
| $I_{1N,PU}$ | A | Nominal input current of the power unit |
| I_{2max} | A | Maximum output current |
| I_{2maxPU} | A | Maximum output current of the power unit |
| $I_{2N,PU}$ | A | Nominal output current of the power unit |
| P_{effRB} | W | Effective power at the external braking resistor |
| P_{maxRB} | W | Maximum power at the external braking resistor |
| $P_{2N,PU}$ | W | Nominal output power of the power unit |
| R_{2minRB} | Ω | Minimum resistance of the external braking resistor |
| R_{intRB} | Ω | Resistance of the internal braking resistor |
| T_M | Year, a | Mission time |
| U_{1CU} | V | Input voltage of the control unit |
| U_{1PU} | V | Input voltage of the power unit |
| U_2 | V | Output voltage |
| U_{2max} | V | Maximum output voltage |
| U_{2PU} | V | Output voltage of the power unit |
| $U_{2PU,ZK}$ | V | Output voltage of the power unit for the DC link connection (typical values: 400 V _{AC} corresponds to 560 V _{DC} , 480 V _{AC} corresponds to 680 V _{DC}) |
| U_{offCH} | V | Switch-off threshold of the brake chopper |
| U_{onCH} | V | On limit of the brake chopper |

13.5 Abbreviations

| Abbreviation | Meaning |
|--------------|---|
| AC | Alternating Current |
| AI | Analog Input |
| AO | Analog Output |
| BG | Baugröße (size) |
| CAN | Controller Area Network |
| CiA | CAN in Automation |
| CNC | Computerized Numerical Control |
| DC | Direct Current |
| DI | Digital Input |
| DMZ | Demilitarized zone |
| DO | Digital Output |
| EMC | Electromagnetic Compatibility |
| EtherCAT | Ethernet for Control Automation Technology |
| HTL | High Threshold Logic |
| I/O | Input/Output |
| IE | International Efficiency |
| IE class | Energy efficiency class |
| IP | International Protection |
| IP | Internet Protocol |
| NAT | Nennansprechtemperatur (nominal response temperature) |
| PE | Protective Earth (grounding conductor) |
| PELV | Protective Extra Low Voltage |
| PL | Performance Level |
| PTC | Positive Temperature Coefficient |
| RCD | Residual Current protective Device |
| RoHS | Restriction of Hazardous Substances |
| SBC | Safe Brake Control |
| SD | Secure Digital (memory card) |
| S/FTP | Screened/Foiled Twisted Pair |
| SF/FTP | Screened Foiled/Foiled Twisted Pair |
| SF/UTP | Screened Foiled/Unshielded Twisted Pair |
| SIL | Safety Integrity Level |
| PLC | Programmable Logic Controller |
| SSI | Serial Synchronous Interface |
| STO | Safe Torque Off |
| TTL | Transistor-Transistor Logic |
| UL | Underwriters Laboratories |

14 Contact

14.1 Consultation, service and address

We would be happy to help you!

We offer a wealth of information and services to go with our products on our website:

<http://www.stoeber.de/en/service>

For additional or personalized information, contact our consultation and support service:

<http://www.stoeber.de/en/support>

If you need our system support:

Phone +49 7231 582-3060

systemsupport@stoeber.de

If you need a replacement device:

Phone +49 7231 582-1128

replace@stoeber.de

Call our 24-hour service hotline:

Phone +49 7231 582-3000

Our address:

STÖBER Antriebstechnik GmbH + Co. KG

Kieselbronner Strasse 12

75177 Pforzheim, Germany

14.2 Your opinion is important to us

We created this documentation to the best of our knowledge with the goal of helping you build and expand your expertise productively and efficiently with our products.

Your suggestions, opinions, wishes and constructive criticism help us to ensure and further develop the quality of our documentation.

If you want to contact us for a specific reason, we would be happy to receive an e-mail from you at:

documentation@stoeber.de


Thank you for your interest.

Your STÖBER editorial team

14.3 Close to customers around the world

We offer you committed, expert advice and support in over 40 countries worldwide:

| | |
|--|--|
| STOBER AUSTRIA www.stoeber.at Phone +43 7613 7600-0 sales@stoeber.at | STOBER CHINA www.stoeber.cn Phone +86 10 6590 7391 sales@stoeber.cn |
| STOBER FRANCE www.stober.fr Phone +33 4 78.98.91.80 sales@stober.fr | STOBER Germany www.stober.de Phone +49 4 7231 582-0 sales@stoeber.de |
| STOBER ITALY www.stober.it Phone +39 02 93909570 sales@stober.it | STOBER JAPAN www.stober.co.jp Phone +81 3 5395 6788 sales@stober.co.jp |
| STOBER SWITZERLAND www.stoeber.ch Phone +41 56 496 96 50 sales@stoeber.ch | STOBER TAIWAN www.stober.tw Phone +886 2 2216-3428 sales@stober.tw |
| STOBER TURKEY www.stober.com Phone +90 216 510 2290 sales-turkey@stober.com | STOBER UK www.stober.co.uk Phone +44 1543 458 858 sales@stober.co.uk |
| STOBER USA www.stober.com Phone +1 606 759 5090 sales@stober.com | |



4 4 2 5 3 7 . 0 9

01/2023

STÖBER Antriebstechnik GmbH + Co. KG
Kieselbronner Str. 12
75177 Pforzheim
Germany
Tel. +49 7231 582-0
mail@stoeber.de
www.stober.com

24 h Service Hotline
+49 7231 582-3000

www.stober.com