

Intern



PMC SY6 safety module

Pilz

1	Foreword	4
2	User information	5
2.1	Storage and transfer	5
2.2	Described product	5
2.3	Timeliness	5
2.4	Original language	5
2.5	Limitation of liability	5
2.6	Formatting conventions	6
2.6.1	Use of symbols	6
2.6.2	Markup of text elements	7
2.6.3	Mathematics and formulas	8
2.7	Trademarks	8
3	General safety instructions	9
3.1	Standards	9
3.2	Qualified personnel	9
3.3	Intended use	10
3.4	Decommissioning	10
4	Safety module PMC SY6	11
5	System design and function	12
6	Technical data	14
7	What you should know before commissioning	15
7.1	Program interfaces	15
7.1.1	DS6: Structure of the program interface	15
7.2	Power-loss protected storage	15
8	Commissioning	16
8.1	PMC SY6: Assigning the FSoE address	16
8.2	Recommended time settings	17
8.3	DS6: Configuring the drive controller	17
8.3.1	Initiating the project	17
8.3.1.1	Projecting the drive controller and axis	17
8.3.2	Parameterizing general EtherCAT settings	19
8.3.3	Configuring PDO transmission	19
8.3.3.1	Adapting RxPDO	19
8.3.3.2	Adapting TxPDO	20
8.3.4	Transmitting and saving the configuration	20
8.3.5	Creating and saving ESI files	21
8.4	Putting the EtherCAT system into operation	21
9	Diagnostics	22
9.1	LED display	22
9.1.1	EtherCAT state	22
9.1.2	FSoE state	24
9.1.3	EtherCAT network connection	25

9.2	Parameters	26
9.2.1	E54 Information safety module G6 V0	26
9.2.2	E67 STO state G6 V1	26
9.2.3	S20 FSoE status indicator SI6 V0.....	26
9.2.4	S21 FSoE slave address SI6 V0.....	27
9.2.5	S25 Diagnostic code SY6 SI6 V0	27
9.2.6	S27 FSoE watchdog time SI6 V0.....	28
9.2.7	S130 Run time G6 V0	28
9.2.8	S544 Safety controlword SI6 V0	28
9.2.9	S545 Safety statusword SI6 V0	28
9.2.10	S593 SS1 time until STO SI6 V0	28
9.3	Events	29
9.3.1	Event 50: Safety module.....	29
9.3.2	Event 70: Parameter consistency	30
9.4	Parameter from the FSoE master.....	30
10	More information on FSoE, safety functions and PMC SY6?.....	31
10.1	FSoE: Fail Safe over EtherCAT	31
10.2	Safety functions	31
10.2.1	Safe Torque Off – STO	32
10.2.2	Safe Stop 1 – SS1-t.....	33
10.3	PMC SY6: Assigning the FSoE address.....	34
10.4	Safety system time	35
10.5	FSoE watchdog time.....	35
11	Appendix	36
11.1	Supported communication objects.....	36
11.1.1	ETG.6100.3 Safety over EtherCAT Drive Profile: 6600 hex – 67FF hex.....	36
11.1.2	ETG.5001.4 Safety over EtherCAT: E000 hex – EFFF hex	37
11.2	Detailed information.....	38
11.3	Abbreviations	39
	Glossary	40
	List of figures	42
	List of tables.....	43

1 Foreword

The PMC SY6 safety module adds the **Safe Torque Off (STO)** and **Safe Stop 1 (SS1)** safety functions, both described as standard in DIN EN 61800-5-2, to Pilz drive controllers of the PMC SC6 or PMC SI6 series.

STO prevents an electrical rotating magnetic field, needed for the operation of synchronous or asynchronous motors, from being generated in a drive controller immediately once the safety function has been activated. In the case of SS1-t, the switch-off happens after a configurable amount of time.

For a combination consisting of a drive controller and PMC SY6 safety module, the STO and SS1 safety functions are actuated via EtherCAT (FSoE).

PMC SY6 is a fast and wear-free fully electronic solution. The safety module is designed so that regular system tests that interrupt operation are eliminated. In practical terms, this means increased availability of machines and systems. The often complex planning and documentation of function tests are also eliminated.

Drive controllers with an integrated safety module can be used in systems with high safety requirements up to SIL 3, PL e, category 4. Compliance with standard requirements has been certified by an independent testing institute as part of type-examination.

Drive controllers of the PMC SC6 and PMC SI6 series successfully passed the EtherCAT as well as Fail Safe over EtherCAT (FSoE) Conformance Test. There, the communication interface was tested to ensure the reliability and function of the lower-level communication regardless of vendor.

2 User information

This documentation provides all information on the intended use of the drive controller in combination with the PMC SY6 safety module.

2.1 Storage and transfer

As this documentation contains important information for handling the product safely and efficiently, it must be stored in the immediate vicinity of the product until product disposal and be accessible to qualified personnel at all times.

Also pass on this documentation if the product is transferred or sold to a third party.

2.2 Described product

This documentation is binding for:

Drive controllers of the PMC SC6 or PMC SI6 series in combination with the PMC SY6 safety module and DriveControlSuite (DS6) software in V 6.4-E or later and associated firmware in V 6.4-E or later.

2.3 Timeliness

Check whether this document is the most up-to-date version of the documentation. We make the latest document versions for our products available for download on our website:

<https://www.pilz.com/en-INT>.

2.4 Original language

The original language of this documentation is German; all other language versions are derived from the original language.

2.5 Limitation of liability

This documentation was created taking into account the applicable standards and regulations as well as the current state of technology.

No warranty or liability claims for damage shall result from failure to comply with the documentation or from use that deviates from the intended use of the product. This is especially true for damage caused by individual technical modifications to the product or the project configuration and operation of the product by unqualified personnel.

2.6 Formatting conventions

Orientation guides in the form of signal words, symbols and special text markups are used to emphasize specific information so that you are able identify it in this documentation quickly.

2.6.1 Use of symbols

Safety instructions are identified with the following symbols. They indicate special risks when handling the product and are accompanied by relevant signal words that express the extent of the risk. Furthermore, useful tips and recommendations for efficient, error-free operation are specially highlighted.



ATTENTION!

Notice indicates that damage to property may occur

- if the stated precautionary measures are not taken.



CAUTION!

Caution with a warning triangle indicates that minor personal injury may occur

- if the stated precautionary measures are not taken.



WARNING!

Warning with a warning triangle means there may be a considerable risk of fatal injury

- if the stated precautionary measures are not taken.



DANGER!

Danger with a warning triangle indicates that there is a considerable risk of fatal injury

- if the stated precautionary measures are not taken.



Information

Information indicates important information about the product or serves to emphasize a section in the documentation that deserves special attention from the reader.

2.6.2 Markup of text elements

Certain elements of the continuous text are distinguished as follows.

Important information	Words or expressions with a special meaning
Interpolated position mode	Optional: File or product name or other name
<u>Detailed information</u>	Internal cross-reference
http://www.samplelink.com	External cross-reference

Software and other displays

The following formatting is used to identify the various information content of elements referenced by the software interface or a drive controller display, as well as any user entries.


Main menu Settings	Window names, dialog box names, page names or buttons, combined proper nouns, functions referenced by the interface
Select Referencing method A	Predefined entry
Save your <own IP address>	User-defined entry
EVENT 52: COMMUNICATION	Displays (status, messages, warnings, faults) for status information referenced by the interface

Keyboard shortcuts and command sequences or paths are represented as follows.

[CTRL], [CTRL] + [S]	Key, shortcut
Table > Insert table	Navigation to menus/submenus (path specification)

Interpretation of parameter identification

Parameter identification consists of the following elements, where short forms are also possible, i.e. only specifying a coordinate or the combination of coordinate and name.



2.6.3 Mathematics and formulas

The following signs are used to represent mathematical relationships and formulas.

-	Subtraction
+	Addition
×	Multiplication
÷	Division
	Amount

2.7 Trademarks

The following names used in connection with the device, its optional equipment and its accessories are trademarks or registered trademarks of other companies:

EtherCAT®,
Safety over EtherCAT®

EtherCAT® and Safety over EtherCAT® are registered trademarks and patented technologies, licensed by Beckhoff Automation GmbH, Germany.

TwinCAT®

TwinCAT® is a registered and licensed trademark of Beckhoff Automation GmbH, Germany.

All other trademarks not listed here are the property of their respective owners.

Products that are registered as trademarks are not specially indicated in this documentation. Existing property rights (patents, trademarks, protection of utility models) are to be observed.

3 General safety instructions

There are risks associated with the product described in this documentation that can be prevented by complying with the described warning and safety instructions as well as the included technical rules and regulations.

3.1 Standards

The following standards are relevant to the product specified in this documentation:

- ▶ DIN EN ISO 13849-1:2016
- ▶ DIN EN ISO 13849-2:2013
- ▶ DIN EN 61800-5-2:2017-11
- ▶ DIN EN 61508-x:2011
- ▶ DIN EN 60204-1:2007
- ▶ DIN EN 62061:2016
- ▶ IEC 61784-3:2010

Subsequent references to the standards do not specify the respective year in order to improve readability.

3.2 Qualified personnel

In order to be able to perform the tasks described in this documentation, the persons instructed to perform them must have the appropriate professional qualification and be able to assess the risks and residual hazards when handling the products. For this reason, all work on the products as well as their operation and disposal may be performed only by professionally qualified personnel.

Qualified personnel are persons who have acquired authorization to perform these tasks either through training to become a specialist and/or instruction by specialists.

Furthermore, valid regulations, legal requirements, applicable basic rules, this documentation and the safety instructions included in it must be carefully read, understood and observed.

3.3 Intended use

The PMC SY6 safety module can be combined with Pilz drive controllers of the PMC SC6 or PMC SI6 series.

If a drive controller with the integrated PMC SY6 safety module is used in a safety-related application, the safety module must be activated by a safety relay or a safety controller.



DANGER!

Electrical voltage! Risk of fatal injury due to electric shock!

An active STO safety function only means that generation of the rotating magnetic field at the motor has been interrupted. The motor may still be energized with dangerous high voltages.

- Make sure that persons cannot come into contact with conductive parts.
- If the supply voltage must be switched off, observe the requirements of DIN EN 60204-1.

Improper use

The safety module may not be operated outside of the drive controller or operated not in compliance with the applicable technical specifications.



Information

An emergency off in accordance with DIN EN 60204-1 is not possible with the PMC SY6 safety module!

Observe this standard regarding the difference between **emergency off** and **emergency stop** in conjunction with **Safe Torque Off**.

Modification

As the user, you may not make any technical or electrical modifications to the PMC SY6 safety module. Any removal of the module from the drive controller as well as any attempt at repair or replacement is prohibited.

Maintenance

The safety module does not require maintenance.

Product life span

A drive controller with integrated safety module must be taken out of operation 20 years after the production date. The production date of the drive controller is found on the accompanying nameplate.

3.4 Decommissioning

In safety-oriented applications, note the mission time $T_M = 20$ years in the safety-relevant key performance indicators.

4 Safety module PMC SY6

The PMC SY6 safety module adds the STO (Safe Torque Off) and SS1 (Safe Stop 1) safety functions to the drive controller. The module prevents the formation of a rotating magnetic field in the power unit of the drive controller and, in the event of an error or by external request, switches the drive controller to the STO state immediately or after a time delay (SS1-t).

Features

- ▶ Possible safety functions:
 - Safe Torque Off – STO in accordance with DIN EN 61800-5-2
 - Stop category 0 in accordance with DIN EN 60204-1
 - Safe Stop 1 (time-delayed) – SS1-t in accordance with DIN EN 61800-5-2
 - Stop category 1 in accordance with DIN EN 60204-1
- ▶ Activation of the safety functions using Safety over EtherCAT (FSoE)
- ▶ STO switch-off time: < 50 ms
- ▶ Wear-free

Certifications in accordance with DIN EN 61800-5-2 and DIN EN ISO 13849-1

- ▶ Safety Integrity Level (SIL) 3
- ▶ Performance Level (PL) e
- ▶ Category 4

5 System design and function




Fig. 1: Components of the FSoE-based safety concept

System components

Central components of the FSoE-based safety concept are:

- ▶ Drive controller with integrated PMC SY6 safety module
... for implementing the STO and SS1-t safety functions
- ▶ Controller (PLC) with integrated EtherCAT master
-... for organizing all network communication
- ▶ Bus coupler (EtherCAT coupler)
... as a connector between the controller and safety controller; the bus coupler passes messages from the safety controller to the EtherCAT master
- ▶ Safety controller (S-PLC) with integrated FSoE master
... for FSoE communication and logic gate links between FSoE nodes; the safety controller includes certified safety function modules that can be configured to the specific application using suitable automation software
- ▶ Safety terminals with digital failsafe inputs and outputs
... for the connection of 24 V_{DC} safety sensors such as emergency stop or position switches, light barriers, pressure mats etc.
- ▶ FSoE protocol
... for the transmission of safety-related data
- ▶ EtherCAT
... as the underlying fieldbus system

Function

The control unit of the drive controller generates pulse patterns (PWM) to produce a rotating magnetic field at the IGBT module in the power unit. This rotating magnetic field is necessary for operating synchronous and asynchronous motors.

If the safety function is not active, the PMC SY6 safety module allows for the generation of a rotating magnetic field in the power unit; the connected motor can create a rotating magnetic field. If the safety function is active, PMC SY6 disables the generation of the rotating magnetic field in the power unit and the drive controller cannot generate any torque in the connected motor.

The PMC SY6 safety module implements an FSoE slave. It exchanges control and status information with the FSoE master via the EtherCAT master in accordance with the black channel principle. The slave extracts the safety-related data, checks it for plausibility and enables or disables the two safety channels in the power unit.

The STO and SS1-t safety functions relate to the device and are not axis-specific. On double-axis controllers, both axes are brought to a safe state at the same time.

An activated SS1 cannot be interrupted.



WARNING!

Increased overrun distance! Residual motion!

The safety module cannot prevent a failure of the functional part of the drive controller (e.g. during a controlled stop) while the SS1-t safety function is executed. Therefore, SS1-t cannot be used if this failure could cause a dangerous situation in the end application. Observe this during project configuration.

In the event of an error in the power unit of the drive controller, static energization of the motor is possible despite active STO. In this case, the motor shaft can move by an angle of up to $360^\circ \div (p \times 2)$.

6 Technical data

The transport, storage and operating conditions of the safety module can be found in the technical data of the drive controller (see the chapter [Detailed information \[38\]](#)).

The following table contains the variables relevant to safety technology for the PMC SY6 module.

<u>SIL CL</u>	3
<u>SIL</u>	3
<u>PL</u>	e
<u>Category</u>	4
<u>PFH_D</u>	5×10^{-9} [1/h]
<u>Mission time</u>	20 years
<u>STO switch-off time</u>	< 50 ms
<u>SS1 delay time</u>	10 – 655350 ms ($\pm 1\%$)

PMC SY6 – Safety-related variables

7 What you should know before commissioning

The following chapters provide a quick introduction to the structure of the program interface and accompanying window designations as well as relevant information about generally saving your project configuration.

7.1 Program interfaces

The following chapters include an overview of the program interfaces for the described software components.

7.1.1 DS6: Structure of the program interface

The DriveControlSuite commissioning software (DS6) offers a graphic interface that you can use to project, parameterize and start up your axis model quickly and efficiently.




Fig. 2: DS6: Program interface

- 1 Project tree
- 2 Project menu
- 3 Workspace
- 4 Parameter description
- 5 Parameter check
- 6 Messages

7.2 Power-loss protected storage

All project configurations, parameterizations and related changes to parameter values are in effect after transmission to the drive controller, but are not yet stored in non-volatile memory.

You save the data using the Save values function in parameter A00 (Project menu > Wizards area > Projected axis > Save values wizard).

Only then is the data stored with power-loss protection.

8 Commissioning

The following sections describe the commissioning process for your drive controller and PMC SY6 safety module using the DriveControlSuite commissioning software.


We put forward the following system environment as an example so that you can follow the individual commissioning steps exactly:

- ▶ Drive controller of the PMC SC6 or PMC SI6 series in firmware version 6.4-E or later with integrated PMC SY6 safety module
- ▶ DriveControlSuite commissioning software in version 6.4-E or later
- ▶ Controller
- ▶ Automation software of the controller

Commissioning is divided into the following steps:

1. PMC SY6 safety module
Enter a valid FSoE address.
2. Observe the time setting recommendations for the following configuration.
3. DriveControlSuite
Configure all drive controllers including safety modules, device control systems, process data for fieldbus communication and the axes of your drive system in DriveControlSuite. Generate an ESI file then transmit your project configuration to the drive controller of the system network.
4. EtherCAT system
Make the generated ESI file available to the controller. Next, map your entire hardware environment and configure it. Then activate your system and check the EtherCAT communication of the system devices.

8.1 PMC SY6: Assigning the FSoE address

In order to be able to identify the PMC SY6 safety module in the FSoE network, you must assign it a unique address in the FSoE network. The address is based on values from the DIP switches that are switched to ON (for detailed information, see the chapter [PMC SY6: Assigning the FSoE address](#) [ 34]).



Information

Note that the drive controller must be switched off before you enter the FSoE address using the DIP switches. The drive controller has to be restarted to apply the address.

8.2 Recommended time settings

In order to ensure that the power unit is not switched off and the axis movement is continues to be controlled by the drive controller in case of a quick stop with subsequent STO (stop category 1 in accordance with DIN EN 60204-1 or Safe Stop 1 (SS1) in accordance with DIN EN 61800 5 2) or in case of an interruption of the communication during controlled braking, the delay time that occurs during a quick stop (quick stop time) is taken into account when parameterizing the SS1 delay time and FSoE watchdog time.


Quick stop time

The quick stop time is a result of the application-specific quick stop deceleration and maximum velocity. In applications in accordance with CiA 402, parameterize the quick stop deceleration in A578 Quick stop deceleration. Parameterize the maximum velocity in I10 Maximal speed.

SS1 delay time

Set a larger value for T_SS1 in the FSoE master than for the resulting quick stop time. The reserve should generally be 10% and should not fall below 50 ms. You can check the SS1 delay time in S593 SS1 time until STO.

FSoE watchdog time

Set a larger value for the watchdog time in the FSoE master than for the resulting quick stop time plus PDO timeout (A258 EtherCAT PDO-Timeout). The reserve should generally be 10% and should not fall below 100 ms. You can check the watchdog time in S27 FSoE watchdog time. More information on the watchdog time can be found in the chapter [FSoE watchdog time](#) [ 35].

8.3 DS6: Configuring the drive controller

Project and configure all drive controllers for your drive system using DriveControlSuite.

8.3.1 Initiating the project

In order to be able to configure all drive controllers and axes of your drive system using DriveControlSuite, you must record them as part of a project.

8.3.1.1 Projecting the drive controller and axis

Creating a new project

1. Start DriveControlSuite.
 2. Click Create new project.
- ⇒ The project configuration window opens and the Drive controller button is active.

Projecting the drive controller

1. **Properties tab:**
Establish the relationship between your circuit diagram and the drive controller to be projected in DriveControlSuite.
Reference: Specify the reference code (equipment code) of the drive controller.
Designation: Give the drive controller a unique name.
Version: Version your project configuration.
Description: If necessary, specify additional supporting information, such as the change history of the project configuration.
2. **Drive controller tab:**
Select the series and device type of the drive controller.
3. **Option modules tab:**
Safety module: Select the PMC SY6 module.
4. **Device controller tab:**
Device controller: Select the device controller that defines the underlying activation signals for the drive controller.
Process data Rx, Process data Tx: Select EtherCAT Rx and EtherCAT Tx for transmitting the EtherCAT process data.

Projecting the axis

1. Click on Axis 1.
2. **Properties tab:**
Establish the connection between your circuit diagram and the axis to be projected in DriveControlSuite.
Reference: Specify the reference code (equipment code) of the axis.
Designation: Give the axis a unique name.
Version: Version your project configuration.
Description: If necessary, specify additional supporting information, such as the change history of the project configuration.
3. **Application tab:**
Select the CiA 402 application (incremental version).
4. **Motor tab:**
Select the type of motor operated using this axis. If you are working with motors from third-party suppliers, enter the accompanying motor data at a later time.
5. Repeat steps 2 – 4 for the 2nd axis (only for double-axis controllers).
6. Confirm with OK.

8.3.2 Parameterizing general EtherCAT settings

- ✓ You have projected the PMC SY6 safety module and the device control with the EtherCAT Rx and EtherCAT Tx process data as part of drive controller and axis project configuration.
- 1. Highlight the relevant drive controller in the project tree and click on the first projected axis in the project menu > Wizard area.
- 2. Select the EtherCAT wizard.
- 3. A213 Fieldbus scaling:
Leave the default setting at 1: Native (values are passed unchanged).
- 4. A258 EtherCAT PDO-Timeout:
In order to be able to detect a communication failure, monitor the arrival of cyclical process data by defining a PDO timeout.
Permitted value range: 0 – 65535 ms.
Please note:
0 and 65535 = Monitoring is inactive
1 to 65531 = Monitoring is active
65532 = Monitoring is active but the loss of an individual data packet is ignored
65533 = Monitoring is active but the loss of 3 data packets in a row is ignored

8.3.3 Configuring PDO transmission

PDO channels are able to transmit control and status information in real time as well as actual and set values from an EtherCAT master to EtherCAT slaves and vice versa.

PDO communication allows for several PDO channels to be operated simultaneously per transmission and sending direction. The channels for axes A and B each include a PDO with a defined sequence of up to 24 parameters to be transmitted. These are free to be configured in any way. One channel is reserved for FSoE communication and is parameterized automatically.

In order to guarantee error-free communication between the controller and drive controller, Pilz offers an application-dependent pre-assignment of the channels which can be changed at any time.

8.3.3.1 Adapting RxPDO

- ✓ You have configured the global EtherCAT settings.
- 1. Highlight the relevant drive controller in the project tree and click on the first projected axis in the project menu > Wizard area.
- 2. Select the EtherCAT wizard > Received process data RxPDO.
- 3. Check the default settings and/or configure the process data according to your requirements.
A225[0] – A225[23], A226[0] – A226[23]:
Parameters whose values are received by the drive controller from the controller. The position of the parameters provides information about the associated receiving sequence.

8.3.3.2 Adapting TxPDO

- ✓ You have configured the global EtherCAT settings.
- 1. Highlight the relevant drive controller in the project tree and click on the first projected axis in the project menu > Wizard area.
- 2. Select the EtherCAT wizard > Transmitted process data TxPDO.
- 3. Check the default settings and/or configure the process data according to your requirements.
A233[0] – A233[23], A234[0] – A234[23]:
Parameters whose values the respective drive controller sends to the controller. The position of the parameters provides information about the associated transmission sequence.

8.3.4 Transmitting and saving the configuration

In order to transmit and save the configuration to one or more drive controllers, your PC must be located in the same network with the respective devices.

Transmitting the configuration

- ✓ The drive controllers are ready for operation.
- 1. In the project tree, highlight the module under which you have recorded your drive controller and click Assignment and live firmware update in the project menu.
 - ⇒ The Add connection window opens. All drive controllers found via IPv4 limited broadcast are displayed.
- 2. Direct connection tab > IP address column:
Activate the IP address in question or activate all listed using the context menu. Confirm your selection with OK.
 - ⇒ The Assignment and live firmware update window opens. All drive controllers connected through the previously selected IP addresses are displayed.
- 3. Select the drive controller to which you would like to transfer the configuration. Change the selection of transmission type from Read to Send.
- 4. Change the selection Create new drive controller:
Select the configuration that you would like to transfer to the drive controller.
- 5. Repeat steps 3 and 4 for all other drive controllers to which you would like to transfer your configuration.
- 6. Online tab:
Click on Establish online connections.
 - ⇒ The configurations are transferred to the drive controllers.



Information

During the search, all drive controllers within the broadcast domain are found via IPv4 limited broadcast.

Prerequisites for finding a drive controller in the network:

- Network supports IPv4 limited broadcast
- All drive controllers are in the same subnet (broadcast domain)

Saving the configuration

- ✓ You have successfully transferred the configuration.
- 1. Assignment and live firmware update window:
Click on Save values (A00).
⇒ The Save values (A00) window opens.
- 2. Click on Start action.
⇒ The configuration is saved.
- 3. Close the Save values (A00) window.
- 4. Assignment and live firmware update window:
Click on Restart (A09).
⇒ The Restart (A09) window opens.
- 5. Click on Start action.
- 6. Confirm the safety instruction with OK.
⇒ The Restart (A09) window closes.
⇒ The fieldbus communication and connection to DriveControlSuite are interrupted.
⇒ The drive controllers restart.

8.3.5

Creating and saving ESI files

The functions and properties of the Pilz drive controllers are described in the form of various objects and collected in an ESI file.

In order to map and configure one or more drive controllers in the network, generate an ESI for your configured application and make it available to the automation software of your controller.



Information

Note that a new ESI file must be generated and made available to the controller after each change to the configuration.

- ✓ You are in DriveControlSuite.
- ✓ You have configured the PDO transmission.
- 1. Highlight the relevant drive controller in the project tree and click on the first projected axis in the project menu > Wizard area.
- 2. Select the EtherCAT wizard.
- 3. Click on Create ESI.
⇒ The Write ESI file dialog box opens.
- 4. Save the XML file in the directory provided by the controller for this purpose.

8.4

Putting the EtherCAT system into operation

Make the generated ESI file available to the controller. Next, map your entire hardware environment and configure it. Then activate your system and check the EtherCAT communication of the system devices.

9 Diagnostics

In the event of fault, the various diagnostic options described below are available.

9.1 LED display

The drive controllers feature diagnostic LEDs that visualize the state of fieldbus communication and the states of the physical connection.

9.1.1 EtherCAT state





There are 2 LEDs on the front of the drive controller that provide information about the connection between EtherCAT master and slave and about the state of the data exchange. This information can also be read out in parameter A255 EtherCAT Device State. If the drive controller includes the PMC SY6 safety module, the STO and SS1 safety functions are activated via EtherCAT FSoE. In this case, an additional LED on the front of the device provides information about the FSoE state.







Fig. 3: LEDs for the EtherCAT state

- 1 Red: Error
- 2 Green: Run

Intern

Red LED	Conduct	Error	Description
	Off	No Error	No error
	Flashing	Invalid Configuration	Invalid configuration
	Single flash	Unsolicited State Change	The EtherCAT slave changed operating states by itself
	2x flashing	Application Watchdog Timeout	The EtherCAT slave did not receive new PDO data during the configured watchdog timeout

Meaning of the red LED (error)

Green LED	Conduct	Operating state	Description
	Off	Init	No communication between the EtherCAT master and slave; the configuration starts, saved values are loaded
	Flashing	Pre-operational	No PDO communication; the EtherCAT master and slave exchange application-specific parameters via SDOs
	1x flash	Safe-operational	The EtherCAT slave sends the current actual values to the EtherCAT master, ignores its set values and refers to internal default values
	On	Operational	Normal operation: The EtherCAT master and slave exchange set and actual values

Meaning of the green LED (Run)

9.1.2 FSoE state

If the drive controller includes the PMC SY6 safety module, the STO and SS1 safety functions are activated via EtherCAT FSoE. In this case, an LED on the front of the device provides information about the state of FSoE communication. This information can also be read out in parameter S20 FSoE status indicator.



Fig. 4: LED for the FSoE state

1 Green: FSoE

Green LED	Conduct	Description
	Off	Initialization
	Flashing	Ready for parameterization
	On	Normal operation
	Single blink	Failsafe command from FSoE master received
	Rapid blinking	Undefined connection error
	Rapid blinking with 1x flash	Error in the safety-related communication settings
	Rapid blinking with 2x flash	Error in the safety-related application settings
	Rapid blinking with 3x flash	Incorrect FSoE address
	Rapid blinking with 4x flash	Prohibited command received
	Rapid blinking with 5x flash	Watchdog error
	Rapid blinking with 6x flash	CRC error

Meaning of the green LED (FSoE status indicator in accordance with IEC 61784-3)

9.1.3 EtherCAT network connection

The LEDs LA_{EC}IN and LA_{EC}OUT at X200 and X201 on the top of the device indicate the state of the EtherCAT network connection.




Fig. 5: LEDs for the state of the EtherCAT network connection

- 1 Green: LA_{EC}OUT at X201
- 2 Yellow: No function
- 3 Green: LA_{EC}IN at X200
- 4 Yellow: No function

Green LED	Behavior	Description
	Off	No network connection
	Flashing	Active data exchange with other EtherCAT nodes
	On	Network connection exists

Meaning of the green LEDs (LA)

9.2 Parameters

The following diagnostic parameters are available in the safety technology with drive controllers of the PMC SC6 or PMC SI6 series and PMC SY6 safety module.

9.2.1 E54 | Information safety module | G6 | V0

Signifying data of the safety module.

- ▶ [0]: Type
- ▶ [1]: Hardware version
- ▶ [2]: Production number
- ▶ [3] – [5]: Reserved
- ▶ [6]: Diagnostic code

9.2.2 E67 | STO state | G6 | V1

STO state of the safety module:

- ▶ [0]: STO was triggered by input signal $STO_a = 0$ or $STO_b = 0$
 - 0: Inactive = not triggered
 - 1: Active = triggered
- ▶ [1]: STO was triggered by input signal $STO_a = 0$
 - 0: Inactive = not triggered
 - 1: Active = triggered
- ▶ [2]: STO was triggered by input signal $STO_b = 0$
 - 0: Inactive = not triggered
 - 1: Active = triggered

9.2.3 S20 | FSoE status indicator | SI6 | V0

State of the transmission of safety-related data via FSoE.

Corresponds to the FSoE status indicator in accordance with IEC 61784-3.

Standard

- ▶ 0 hex = Initialization
Possible in the FSoE state Pre-Reset
- ▶ 1 hex = Ready for parameterization by the FSoE master
Possible in the FSoE states Reset, Session, Connection, Parameter
- ▶ 2 hex = normal operation
Possible in the FSoE state Process Data
- ▶ 3 hex = Failsafe command received by the FSoE master
Possible in the FSoE state Failsafe Data

Error

- ▶ 4 hex = Undefined connection error
Possible in all FSoE states
- ▶ 5 hex = Error in the safety-related communication settings
Possible in the FSoE state Parameter
- ▶ 6 hex = Error in the safety-related application settings
Possible in the FSoE state Parameter
- ▶ 7 hex = Incorrect FSoE address
Possible in the FSoE state Connection
- ▶ 8 hex = Prohibited command received via FSoE communication interface
Possible in all FSoE states
- ▶ 9 hex = Data transmission timeout (watchdog)
Possible in all FSoE states
- ▶ A hex = Inconsistent data transmission (CRC checksum)
Possible in all FSoE states

9.2.4 S21 | FSoE slave address | SI6 | V0

Drive controller address (FSoE slave) in the EtherCAT network (prerequisite: FSoE master is active; source: DIP switch).

Address changes are applied when the drive controller is restarted.

9.2.5 S25 | Diagnostic code SY6 | SI6 | V0

Status byte with diagnostic code of the safety module.

- ▶ Bit 0: Internal OSSD channel error
- ▶ Bit 1: Reserved
- ▶ Bit 2: FSoE communication error
- ▶ Bit 3: Reserved
- ▶ Bit 4: Overtemperature
- ▶ Bit 5: Reserved
- ▶ Bit 6: SS1 time
0 = not running; 1 = running
- ▶ Bit 7: STO state
1 = in safe state

If not otherwise specified: 0 = inactive; 1 = active.

9.2.6 S27 | FSoE watchdog time | SI6 | V0

Tolerated failure time of FSoE frames for monitoring FSoE communication in the EtherCAT network (use: triggering internal STO; source: FSoE master).

The FSoE monitoring does not depend on PDO monitoring and is specified by the FSoE master (PDO monitoring: A258).

9.2.7 S130 | Run time | G6 | V0

Operating time of the safety module.

9.2.8 S544 | Safety controlword | SI6 | V0

Control byte for FSoE.

Corresponds to the Safety controlword communication object in accordance with ETG.6100.1; object 6620 hex.

▶ [0]: First byte

Corresponds to the 1st byte communication object in accordance with ETG.6100.1; subindex 1 hex

- Bit 0: STO
0 = Activate STO; 1 = Do not activate STO
- Bit 1: SS1
0 = Activate SS1; 1 = Do not activate SS1
- Bit 2 – 7: Reserved

▶ [1]: Second byte: Reserved

Corresponds to the 1st byte communication object in accordance with ETG.6100.1; subindex 2 hex

Enabling the power unit requires that bit 0 and bit 1 are set to 1.

9.2.9 S545 | Safety statusword | SI6 | V0

Status byte for FSoE.

Corresponds to the Safety statusword communication object in accordance with ETG.6100.1; object 6621 hex.

▶ [0]: First byte

Corresponds to the 1st byte communication object in accordance with ETG.6100.1; subindex 1 hex

- Bit 0: STO
1 = STO active
- Bit 1 – 7: Reserved

▶ [1]: Second byte: Reserved

Corresponds to the 1st byte communication object in accordance with ETG.6100.1; subindex 2 hex

9.2.10 S593 | SS1 time until STO | SI6 | V0

SS1 delay time, i.e. the duration between the activation of a time-based SS1 by S544 Safety controlword, bit 1, and the internal triggering of the STO function (unit: 10 ms; source: FSOE master).

Corresponds to the SS1 time until STO communication object in accordance with ETG.6100.1; object 6651 hex.

A change to the SS1 delay time in the FSoE master takes effect and becomes visible in parameter S593 the next time the FSoE master is restarted.

9.3 Events

The drive controller has a self-monitoring system that uses test rules to protect the drive system from damage. Violating the test rules triggers a corresponding event. There is no possible way for you as the user to intervene in some events, such as the Short/ground event. In others, you can influence the effects and responses.

Possible effects include:

- ▶ Message: Information that can be evaluated by the controller
- ▶ Warning: Information that can be evaluated by the controller and becomes a fault after a defined time span has elapsed without the cause being resolved
- ▶ Fault: Immediate drive controller response; the power unit is disabled and axis movement is no longer controlled by the drive controller or the axis is brought to a standstill by a quick stop or emergency braking



ATTENTION!

Damage to property due to interruption of a quick stop or emergency braking

If, when executing a quick stop or emergency braking, another fault occurs or a safety function is activated, the quick stop or emergency braking is interrupted. In this case, the machine can be damaged by the uncontrolled axis movement.

Events, their causes and suitable measures are listed below. If the cause of the error is corrected, you can usually acknowledge the error immediately. If the drive controller has to be restarted instead, a corresponding note can be found in the measures.

9.3.1 Event 50: Safety module

The drive controller is interrupted:

- ▶ The power unit is disabled and axis movement is no longer controlled by the drive controller
- ▶ The brakes are no longer controlled by the drive controller and engage in the event of an inactive release override (F06)

Cause		Check and action
2: Wrong safety module	The projected E53 safety module does not match the E54[0] detected by the system	Check the project configuration and drive controller and correct the project configuration or exchange the drive controller if necessary; fault cannot be acknowledged
3: Internal error	Defective safety module	Exchange drive controller; fault cannot be acknowledged
16: Remove enable!	STO request with active power unit	Only request STO with inactive power unit
		Request Enable-off without quick stop at the same time as the STO request (Drive Based A44)

Event 50 – Causes and actions

9.3.2 Event 70: Parameter consistency

The drive controller is interrupted:

- ▶ The power unit is disabled and axis movement is no longer controlled by the drive controller
- ▶ The brakes are no longer controlled by the drive controller and engage in the event of an inactive release override (F06)

Cause		Check and action
15: FSoE watchdog time	Ratio of FSoE watchdog time to EtherCAT PDO timeout too small	Check the FSoE watchdog time in the FSoE master and EtherCAT PDO timeout in the drive controller; if necessary, increase the watchdog time or reduce the PDO timeout (guide value: FSoE watchdog time = EtherCAT PDO timeout + 100 ms; S27, A258)

Event 70 – Causes and actions

9.4 Parameter from the FSoE master

When establishing a connection, the PMC SY6 safety module expects the following process data units (PDU) in the specified order in the FSoE state parameter from the FSoE master. Process data units are the data packets exchanged between the FSoE master and FSoE slave:

PDU	Byte	Value	Description
PDU 1	SafeData[0]	0x02	2 bytes, length of the communication parameters
	SafeData[1]	0x00	
PDU 2	SafeData[0]	T_WD Low Byte	FSoE watchdog time in ms; Value range: 12 to 65534 ms
	SafeData[1]	T_WD High Byte	
PDU 3	SafeData[0]	0x06	6 bytes, length of the application parameters
	SafeData[1]	0x00	
PDU 4	SafeData[0]	0x01	PMC SY6 identification number; Value = 1 (permanently set!)
	SafeData[1]	0x00	
PDU 5	SafeData[0]	0x00	
	SafeData[1]	0x00	
PDU 6	SafeData[0]	T_SS1 Low Byte	
	SafeData[1]	T_SS1 High Byte	

Process data units in the FSoE state Parameter

10 More information on FSoE, safety functions and PMC SY6?

This chapter summarizes the important terms, relationships and measures regarding FSoE, the STO and SS1 safety functions and the PMC SY6 safety module.

10.1 FSoE: Fail Safe over EtherCAT

The safety protocol known as **Safety over EtherCAT** (FSoE = Fail Safe over EtherCAT) exists in parallel with the real-time Ethernet system **EtherCAT** for transmitting safety-related messages between FSoE devices in a network. The protocol is TÜV-certified and internationally standardized in accordance with the IEC 61784-3 standard. The design of FSoE is based on the black channel principle.

Secure communication

During each FSoE cycle, a FSoE master sends safety-related data to a FSoE slave and simultaneously starts a watchdog timer. The FSoE slave acknowledges the received data before sending it back to the master and also begins runtime monitoring via a watchdog timer. The master receives and processes the confirmation from the slave and stops the watchdog timer. If the data has been fully processed, the FSoE master generates a new data package.

Unique FSoE addressing

It must be possible to identify each FSoE slave using a unique FSoE address.

The address is assigned to the device using a DIP switch. A valid address is within the address range 1 – 255 (8 bit, 0 address may not be assigned).

10.2 Safety functions

The PMC SY6 safety module supports the Safe Torque Off (STO) and Safe Stop 1 (SS1-t) safety functions. The safety controller must activate the STO as well as the SS1 output of the drive controller if the drive axis is to be moved. If only one of the outputs is configured, the drive controller remains in a safe state (STO active).

The safety functions relate to the device and are not axis-specific. This means that for multi-axis controllers, only the entire drive controller can be set to a safe state, not individual axes.

10.2.1 Safe Torque Off – STO




Fig. 6: STO function principle in accordance with ETG.6100.2

STO corresponds to stop category 0 in accordance with EN 60204.

STO is the most fundamental drive-integrated safety function. STO prevents energy that generates torque from acting on the connected motor and prevents unintentional start-up. The goal is to safely eliminate material damage and injuries to persons caused by a rotating, unintentionally activated motor.

The use of STO is always suitable if the motor comes to a standstill on its own in a sufficiently short time period due to load torque or friction or in an environment in which motor coasting does not have safety-related implications.

10.2.2 Safe Stop 1 – SS1-t




Fig. 7: SS1-t function principle in accordance with ETG.6100.2

- t_0 SS1 activation
- t_1 STO activation
- T_{SS1} SS1 delay time

SS1 corresponds to stop category 1 in accordance with IEC 60204-1.

In the case of SS1-t, the switch-off happens after a configurable amount of time.

The SS1-t safety function enables controlled stopping of a motor and switches it to a torque-free state after the parameterized SS1 delay time has passed, i.e. the STO safety function is activated. STO is triggered after a time delay, regardless of whether the motor has already reached a standstill.



Information

Be aware that the drive controller continues to follow the set values of the controller during the SS1 delay time, which enables controlled stopping in multi-axis applications.

The SS1 delay time T_{SS1} is a safety-related parameter configured in the automation software and transmitted to the FSoE master. Upon initialization of the FSoE protocol, the value of this parameter is transferred from the safety controller to the drive controller and displayed in DriveControlSuite via parameter S593 SS1 time until STO.

10.3 PMC SY6: Assigning the FSoE address

In order to be able to identify the safety module in the FSoE network, you must assign it an FSoE address from the address range 1 – 255 manually using a DIP switch. An address of 0 is invalid, i.e. the value is ignored if an address of 0 is assigned and the PMC SY6 remains in the STO state.



Information

Note that the drive controller must be switched off before you enter the FSoE address using the DIP switches. The drive controller has to be restarted to apply the address.

FSoE address input using a DIP switch

The DIP switch for entering the address is located on the top of the drive controller. The address is based on the values from the DIP switches that are switched ON. The following graphic shows the safety module along with the DIP switches with the values 2 and 8; the associated FSoE address is 10.




Fig. 8: PMC SY6 – DIP switches

Switch number	1	2	3	4	5	6	7	8
Value – FSoE address	1	2	4	8	16	32	64	128

DIP switches and FSoE addresses

Checking the FSoE address in PMC SY6

You can verify the FSoE address you have entered for the safety module using the parameter S21 FSoE slave address of DriveControlSuite.

10.4 Safety system time




Fig. 9: Reaction times and safety system time

STO system time is understood as the time span from the request for safe switch-off (STO) at a sensor until the actual safe switch-off at the EtherCAT connection of the drive controller.

The system time depends on the response times of the individual system components and the communication and transmission times in the EtherCAT group.

The accompanying processes are:

- ▶ Sensor:
Providing the STO request signal
- ▶ Safety terminal (safe input):
Detecting the STO request signal
- ▶ EtherCAT master:
Transmitting the state of the safe input to the FSoE master
- ▶ FSoE master:
Evaluating the STO request signal
- ▶ EtherCAT master:
Transmitting the STO request signal to the drive controller
- ▶ Drive controller:
Activating and switching off STO (STO switch-off time); this process is divided into the following:
 - EtherCAT processing time in the control unit
 - Transfer time of the data packet to the PMC SY6 safety module
 - PMC SY6: Duration for evaluating the data packet
 - Switch-off time of the power unit

10.5 FSoE watchdog time

In order to detect possible faults, the communication between FSoE master and slave is monitored by a FSoE watchdog. Once a FSoE frame has been sent, the master as well as slave start a watchdog. If the master or slave receive no corresponding response message before the watchdog time runs out, the respective device switches into a safe state. The watchdog time is taken into account when calculating the worst case response time.

The watchdog time is parameterized individually for each slave in the FSoE master.

11 Appendix

11.1 Supported communication objects

11.1.1 ETG.6100.3 Safety over EtherCAT Drive Profile: 6600 hex – 67FF hex

The following table includes the supported communication objects of the standardized ETG.6100.3 Safety over EtherCAT Drive Profile and their mapping to the corresponding Pilz-specific parameters.

Index	Subindex	TxPDO	RxPDO	Name	Comment
6600 hex	0 hex	—	—	Time unit	Unit: 10 ms
6620 hex				Safety controlword	Array
6620 hex	0 hex	—	—	Highest subindex supported	Number of array elements: 2
6620 hex	1 hex	—	—	Safety controlword, 1st byte	S544[0]
6620 hex	2 hex	—	—	Safety controlword, 2nd byte	S544[1]; no function
6621 hex				Safety statusword	Array
6621 hex	0 hex	—	—	Highest subindex supported	Number of array elements: 2
6621 hex	1 hex	—	—	Safety statusword, 1st byte	S545[0]
6621 hex	2 hex	—	—	Safety statusword, 2nd byte	S545[1]; no function
6640 hex	0 hex	—	—	STO command supported	Function is supported = 1
6641 hex	0 hex	—	—	STO restart acknowledge	STO restart without acknowledge = 0
6650 hex	0 hex	—	—	SS1 command supported	Function is supported = 1
6651 hex	0 hex	—	—	SS1 time to STO	S593, unit defined in object 6600 hex

ETG.6100.3 communication objects: 6600 hex – 67FF hex

11.1.2 ETG.5001.4 Safety over EtherCAT: E000 hex – EFFF hex

The following table includes the supported communication objects of the standardized ETG.5001.4 Safety over EtherCAT profile.

Index	Subindex	TxPDO	RxPDO	Name	Comment
E901 hex				FSoE connection communication parameter	Structure
E901 hex	0 hex	—	—	Highest subindex supported	Number of structure elements: 8
E901 hex	1 hex	—	—	Version	
E901 hex	2 hex	—	—	FSoE slave address	
E901 hex	3 hex	—	—	Connection ID	
E901 hex	4 hex	—	✓	Watchdog time	
E901 hex	5 hex	—	—	Reserved	
E901 hex	6 hex	—	—	Connection type	
E901 hex	7 hex	—	—	ComParameterLength	
E901 hex	8 hex	—	—	ApplParameterLength	
F980 hex	0 hex	—	—	FSoE slave address	

ETG.5001.4 communication objects: E000 hex – EFFF hex

11.2 Detailed information

The documentation listed in the following table offers additional information relevant to the drive controller.

Current document versions can be found at <https://www.pilz.com/en-INT>.

Device/Software	Documentation	Contents	ID
PMC SC6 drive controller	Manual	System design, technical data, project configuration, storage, installation, connection, commissioning, operation, service, diagnostics	1005343
PMC SC6 drive controller	Commissioning instructions	System design, technical data, storage, installation, connection, commissioning	1005357
Multi-axis drive system with PMC SI6 and PMC PS6	Manual	System design, technical data, project configuration, storage, installation, connection, commissioning, operation, service, diagnostics	1005342
Multi-axis drive system with PMC SI6 and PMC PS6	Commissioning instructions	System design, technical data, storage, installation, connection, commissioning	1005356
EtherCAT communication – PMC SC6, PMC SI6	Manual	Installation, electrical installation, data transfer, commissioning, detailed information	1005346

Additional information and sources that form the basis of this documentation or are referenced by the documentation:

EtherCAT Technology Group (ETG), 2012. *ETG.1300 : EtherCAT Indicator and Labeling*. ETG.1300 S (R) V1.1.0. Specification. 2012-01-27.

EtherCAT Technology Group (ETG), 2016. *ETG.5001: Modular Device Profile, Part 4: Safety Modules Specification*. ETG.5001.4 S (D) V0.2.1. Specification. 2016-08-05.

EtherCAT Technology Group (ETG), 2016. *ETG.6100: Safety Drive Profile, Part 1: Overview, Scope*. ETG.6100.1 S (R) V1.2.0. Specification. 2016-02-08.

EtherCAT Technology Group (ETG), 2016. *ETG.6100: Safety Drive Profile, Part 2: Generic Safety Drive Profile for adjustable speed electrical power drive systems that are suitable for use in safety-related applications PDS(SR)*. ETG.6100.2 S (R) V1.2.0. Specification. 2016-02-08.

EtherCAT Technology Group (ETG), 2016. *ETG.6100: Safety Drive Profile Part 3: Mapping to Safety-over-EtherCAT*. ETG.6100.3 S (WD) V1.2.0. Specification. 2016-02-08.

11.3 Abbreviations

Abbreviation	Meaning
μC	Microcontroller
CRC	Cyclic Redundancy Check
EMC	Electromagnetic Compatibility
ESI	EtherCAT Slave Information
ETG	EtherCAT Technology Group
EtherCAT	Ethernet for Control Automation Technology
FSoE	Fail Safe over EtherCAT
IGBT	Insulated Gate Bipolar Transistor
I/O	Input/Output
PDO	Process Data Objects
PDS(SR)	Power Drive System(Safety Related)
PDU	Process data units
PL	Performance Level
PWM	Pulse Width Modulation
RxPDO	Receive PDO
SIL	Safety Integrity Level
SIL CL	Safety Integrity Level Claim Limit
PLC	Programmable Logic Controller
SRECS	Safety-Related Electrical Control System
SRP/CS	Safety-Related Part of a Control System
SS1	Safe Stop 1
SS1-t	Safe Stop 1-time
STO	Safe Torque Off
TxPDO	Transmit PDO

Black channel principle

Technology that allows secure data to be transmitted over unsecure network or bus lines. Safety components can transmit safety-related data regardless of hardware using a secure protocol that tunnels through the underlying network channel. Possible transmission errors are noted in the standards IEC 61784-3 and IEC 61508.

Broadcast domain

Logical grouping of network devices within a local network that reaches all nodes via broadcast.

Category

In accordance with DIN EN ISO 13849-1: Classification of safety-related parts of a controller regarding their resistance to faults and their subsequent behavior in the event of a fault. A category is attained through the structure and the arrangement of parts, their fault detection and/or their reliability. Possible category designations, i.e. classifications, are B, 1, 2, 3, 4.

ESI file

Device description file for EtherCAT slaves. In accordance with ETG.2000: XML file that contains all relevant data for an EtherCAT node in the EtherCAT system, such as the identity of the manufacturer, the product code, the version or the production number. The EtherCAT master requires this file to configure the EtherCAT system.

Fail Safe over EtherCAT (FSoE)

Protocol for transferring safety-related data via EtherCAT using a FSoE master and an indefinite number of FSoE slaves (i.e. devices that have a Safety over EtherCAT interface). The protocol enables the realization of functional safety via EtherCAT. FSoE and its implementation are TÜV-certified and comply with the SIL 3 requirements in accordance with IEC 61508.

FSoE address

Each FSoE slave has an address that provides unique identification for it in the FSoE network. The address is generally configured on the device itself, for example, using a DIP switch. In a FSoE system, a maximum of 65,534 (16-bit, 0 address is prohibited) nodes can be differentiated by their addresses.

Insulated Gate Bipolar Transistor (IGBT)

Bipolar transistor with insulated gate electrode. Four-layer semiconductor component that is controlled using a gate and combines the advantages of bipolar and field-effect transistor. An IGBT is primarily used in power electronics.

IPv4 limited broadcast

Type of broadcast in a network with IPv4 (Internet Protocol version 4). The IP address 255.255.255.255 is entered as the destination. The content of the broadcast is not redirected by a router, which limits it to the local network.

Mission time (T_M)

In accordance with DIN EN 61800-5-2: Determined cumulative length of operation of the PDS(SR) during its overall service life.

PDO

Communication objects in a CANopen or EtherCAT network that transmit data such as set and actual values, control commands or status information based on events or objectives, in cycles or in real time on request. PDOs are generally exchanged over the process data channel with high priority. Depending on the view of the respective node, a distinction is made between receive PDOs (RxPDO) and transmit PDOs (TxPDO).

Performance Level (PL)

In accordance with DIN EN 13849-1: Measure for the reliability of a safety function or a component. The Performance Level is measured on a scale of a – e (lowest – highest PL). The higher the PL, the safer and more reliable the function in question is. The PL can be assigned to a specific SIL. A reversed inference from a SIL to a PL is not possible.

Probability of a dangerous failure per hour (PFH_D)

In accordance with DIN EN 61508/DIN EN 62061: Average probability of a dangerous device failure per hour. Together with PFH, one of the most important bases for calculating the safety function reliability of devices, the SIL.

Safe Stop 1 (SS1)

In accordance with DIN EN 61800-5-2: Procedure for stopping a PDS(SR). With the SS1 safety function, the PDS(SR) performs one of the following functions: a) Triggering and controlling the motor delay variable within defined limits and triggering the STO function if the motor speed falls below a specified limit value (SS1-d), or b) triggering and monitoring the motor delay variable within defined limits and triggering the STO function if the motor speed falls below a specified limit value (SS1-r), or c) triggering the motor delay and triggering the STO function after an application-specific delay (SS1-t). In this case, SS1(-t) corresponds to the time-controlled stop in accordance with IEC 60204-1, stop category 1(-t).

Safe Torque Off (STO)

In accordance with DIN EN 61800-5-2: Procedure for stopping a PDS(SR). The STO safety function prevents the motor from being supplied with any energy that could cause rotation (or motion in a linear motor). The PDS(SR) does not supply the motor with any energy that could generate torque (or force in a linear motor). STO is the most fundamental drive-integrated safety function. It corresponds to an uncontrolled stop in accordance with DIN EN 60204-1, stop category 0.

Safety Integrity Level (SIL)

In accordance with DIN EN 61800-5-2: Probability of a safety function failure. SIL is divided into levels 1 – 4 (lowest – highest level). SIL precisely assesses systems or subsystems based on the reliability of their safety functions. The higher the SIL, the safer and more reliable the function in question is.

Safety Integrity Level Claim Limit (SIL CL)

Maximum SIL that can be claimed, based on the structural limitations and systematized safety integrity of a SRECS subsystem. A SIL CL is determined by the hardware fault tolerance (HFT) and the safe failure fraction (SFF) of the subsystems.

STO switch-off time

Time span starting from the activation of the safety function until the power unit of the drive controller is safely switched off.

Worst case response time

Maximum time span required in order to switch off the actuator in the event of an error.

Fig. 1	Components of the FSoE-based safety concept.....	12
Fig. 2	DS6: Program interface.....	15
Fig. 3	LEDs for the EtherCAT state	22
Fig. 4	LED for the FSoE state.....	24
Fig. 5	LEDs for the state of the EtherCAT network connection.....	25
Fig. 6	STO function principle in accordance with ETG.6100.2.....	32
Fig. 7	SS1-t function principle in accordance with ETG.6100.2	33
Fig. 8	PMC SY6 – DIP switches	34
Fig. 9	Reaction times and safety system time	35

Intern

Tab. 1	PMC SY6 – Safety-related variables	14
Tab. 2	Meaning of the red LED (error).....	23
Tab. 3	Meaning of the green LED (Run)	23
Tab. 4	Meaning of the green LED (FSoE status indicator in accordance with IEC 61784-3)	24
Tab. 5	Meaning of the green LEDs (LA)	25
Tab. 6	Event 50 – Causes and actions.....	29
Tab. 7	Event 70 – Causes and actions.....	30
Tab. 8	Process data units in the FSoE state Parameter.....	30
Tab. 9	DIP switches and FSoE addresses	34
Tab. 10	ETG.6100.3 communication objects: 6600 hex – 67FF hex.....	36
Tab. 11	ETG.5001.4 communication objects: E000 hex – EFFF hex.....	37

Intern

► Support

Technical support is available from Pilz round the clock.

Americas

Brazil

+55 11 97569-2804

Canada

+1 888-315-PILZ (315-7459)

Mexico

+52 55 5572 1300

USA (toll-free)

+1 877-PILZUSA (745-9872)

Asia

China

+86 21 60880878-216

Japan

+81 45 471-2281

South Korea

+82 31 450 0680

Australia

+61 3 95600621

Europe

Austria

+43 1 7986263-0

Belgium, Luxembourg

+32 9 3217575

France

+33 3 88104000

Germany

+49 711 3409-444

Ireland

+353 21 4804983

Italy, Malta

+39 0362 1826711

Scandinavia

+45 74436332

Spain

+34 938497433

Switzerland

+41 62 88979-30

The Netherlands

+31 347 320477

Turkey

+90 216 5775552

United Kingdom

+44 1536 462203

You can reach our international hotline on:

+49 711 3409-444

support@pilz.com

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies. Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.



Pilz GmbH & Co. KG
Felix-Wankel-Straße 2
73760 Ostfildern, Germany
Tel.: +49 711 3409-0
Fax: +49 711 3409-133
info@pilz.com
www.pilz.com

CMSE®, IndurANET p®, PAS4000®, PASscal®, PASconfig®, Pilz®, PIT®, PLID®, PMCPprime®, PMCPprotect®, PMCIendo®, PMD®, PMI®, PNOZ®, Pirmo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, THE SPIRIT OF SAFETY® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries. We would point out that product features may vary from the details stated in this document, depending on the status at the time of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy and entirety of the text and graphics presented in this information. Please contact our Technical Support if you have any questions.

1005345-en-US-03_05/2024 Printed in Germany
© Pilz GmbH & Co. KG, 2015