

PROFIBUS-DP Link for:

- POSIDRIVE® FAS 4000
- POSIDRIVE® FDS 4000
- POSIDYN® SDS 4000

Documentation

Before commissioning, it is essential to read and adhere to this documentation and the installation and commissioning instructions for

- POSIDRIVE® FAS 4000 (no. 441581) and
- POSIDRIVE® FDS 4000 (no. 441408) and
- POSIDYN® SDS 4000 (no. 441449)

MANAGEMENTSYSTEM



certified by DQS according to
ISO 9001, ISO 14001
Reg-No. 25780



SV. 4.5

GB 07/2002



Table of Contents

1	Introduction	1
1.1	<i>Profibus</i>	1
1.2	<i>Profile for variable-speed drives: Profidrive</i>	1
2	Installation of Kommubox / option board	1
2.1	<i>Installation for FAS/FDS</i>	1
2.2	<i>Installation for SDS</i>	2
3	Electrical installation	2
3.1	<i>General layout of a Profibus system</i>	2
3.2	<i>Possible layouts</i>	2
3.3	<i>Suitable bus cable</i>	3
3.4	<i>Connection of bus cable to Kommubox FAS/Fds</i>	3
3.5	<i>Connection of bus cable to SDS</i>	3
4	Configuration of the bus system	4
4.1	<i>GSD files</i>	4
4.2	<i>Process data object parameter (PPO)</i>	4
4.3	<i>Configuration with SIMATIC manager</i>	5
4.4	<i>Diagnosis of Profibus-DP on the device</i>	6
5	Data transmission via Profibus-DP	7
6	Parameter communication with PKW routine	7
6.1	<i>Consistency</i>	8
6.2	<i>Time sequence for a PKW routine</i>	8
7	Process data assignment	9
7.1	<i>Process output data assignment</i>	9
7.2	<i>Process input data assignment</i>	11
8	Control with control- and status bits	12
8.1	<i>Specification of the source for control signals</i>	12
9	Control with control/status word and speed reference/actual value	15
9.1	<i>Device control</i>	15
9.2	<i>Local / remote</i>	15
9.3	<i>Input enable</i>	15
9.4	<i>"Device control" state machine</i>	15
9.5	<i>States of device control</i>	16
9.6	<i>State transitions of device control</i>	16
9.7	<i>Control word</i>	17
9.8	<i>Device-control commands in the control word</i>	17
9.9	<i>Status word</i>	17
9.10	<i>Indication of the device states in the status word</i>	18
9.11	<i>Example of controlling via fieldbus: Start drive with speed RV 3000 rpm</i>	18
10	Positioning with the fieldbus	19
10.1	<i>Preference of process block 1</i>	19
10.2	<i>Special function of E124 "start position 1"</i>	19
11	Expansion of the inverter to I/O module for fieldbus	19
11.1	<i>Using all the AE1/AE2 functions via Profibus-DP</i>	20
11.2	<i>Using the keys and display via Profibus-DP</i>	20
12	Fault diagnosis	21
12.1	<i>Has a fault occurred?</i>	21
12.2	<i>Which fault has occurred?</i>	21
12.3	<i>Reading E41 (fault time 1)</i>	21
12.4	<i>Acknowledging a fault via fieldbus</i>	21
12.5	<i>Diagnostic telegram</i>	22
13	Process data monitoring	22
14	Parameter list	22
14.1	<i>Explanation of the tables</i>	22
14.2	<i>Switchable scaling</i>	23
14.3	<i>Profidrive parameters</i>	23
14.4	<i>Parameters from groups A.. (inverter) to Z.. (fault memory)</i>	24
15	Notes	38

Profibus-DP link

1. Introduction
2. Installation of Kommubox / option board

1 INTRODUCTION



To prevent problems during commissioning and/or operation, it is essential to read the complete installation and commissioning instructions of POSIDRIVE® FAS 4000 / FDS 4000 or POSIDYN® SDS 4000 and also this documentation prior to installation and commissioning.

1.1 PROFIBUS

PROFIBUS is an open, vendor-independent fieldbus standard for a wide variety of applications in production, process and building automation. International standards IEC 61158 (part 3) and EN 50170 ensure vendor-independence and openness. During the past few years this standard has become the most important fieldbus system on the international market.

1.2 PROFILE FOR VARIABLE-SPEED DRIVES: PROFIDRIVE

Working together, the leading manufacturers of drive technology have prepared the PROFIDRIVE profile. This profile specifies how the drives are to be parameterized and how the reference and actual values are to be transmitted.


STÖBER Antriebstechnik offers a link to PROFIBUS-DP (Distributed Periphery) via the PROFIDRIVE profile for all inverters of the **POSIDRIVE®** FAS/FDS 4000 and **POSIDYN®** SDS 4000 series. This turns these devices into intelligent DP slaves run by a PROFIBUS master (controller, PLC, PC).

Installed on the outside of the housing, Kommubox provides the FAS/FDS with PROFIBUS capability. The SDP 4000 option board opens the door to PROFIBUS for the SDS. Bus operation offers speeds of up to 12 Mbit/sec. An LED indicates the function of the accessory portion, the data transmission over the bus, and any malfunctions. The supplement to this coupling ensures unrestricted functionality and operator control. The inverters can continue to be controlled via display/keys, Controlbox, and FDS Tool.


When a PROFIBUS system is commissioned, the manuals/commissioning instructions of all involved components (DP master/controller, additional slaves, etc.) must be adhered to. If additional information on the PROFIBUS or PROFIDRIVE profile is required, extensive literature can be accessed at or ordered from the PROFIBUS user organizations under www.profibus.com.

2 INSTALLATION OF KOMMUBOX / OPTION BOARD

2.1 INSTALLATION FOR FAS/FDS



POSIDRIVE®
FDS 4000



POSIDRIVE®
FAS 4000



Only use special STÖBER cable here. Failure to do so may destroy the FAS/FDS.

See chap. 9.9 of the documentations for:


- **POSIDRIVE®** FDS 4000 (publ. no. 441408)
- **POSIDRIVE®** FAS 4000 (publ. no. 441581)

1. Turn off the 400 V and the 24 V power supply via the option board.
Insert Kommubox on plug connector X3 (9-pin sub D) on the front of the FAS/FDS. To secure, tighten the screw on the top (FAS) or right-hand (FDS) side of Kommubox.
2. Kommubox requires no separate voltage supply. It is powered by the sub D plug connector of the FAS/FDS.

Profibus-DP link

3. Electrical installation

2.2 INSTALLATION FOR SDS



1. **Turn off** both the 400 V and the 24 V power supply of the SDS.
2. **Remove** the housing cover by pinching out the 6 metal cutouts. Do not saw! Do not allow metal shavings to penetrate the device!
3. Carefully slide the **SDP 4000** option board into the housing of the SDS until the three-row plug connector of the board is securely connected to the device. Caution! **Adhere to ESD regulations**. Avoid overvoltage when touching the board!
First touch PE and the metallic housing of the SDS, and then the board!
4. Secure metal cover of the option board to the housing of the SDS with two **M3 screws**.
5. The option board does **not** require an additional voltage supply.

3 ELECTRICAL INSTALLATION


3.1 GENERAL LAYOUT OF A PROFIBUS SYSTEM

PROFIBUS is the bus system for communication in a wide variety of applications in production, process and building automation. This system is available in three versions - PROFIBUS-FMS, PROFIBUS-DP and PROFIBUS-PA. PROFIBUS-DP offers high-speed cyclic communication of small amounts of data. This system usually has one or two masters and up to 124 slaves. The master is the active station on PROFIBUS. It can send or request data to/from other stations. The slaves are the passive stations on PROFIBUS. They only exchange data when the master requests. This bus system is normally designed with shielded, two-wire cables (RS 485). It can also be designed with fiber-optic conductors for special applications. STÖBER Antriebstechnik offers the link to the two-wire cable. This covers a maximum distance of 10,000 m. If suitable measures are provided on the master side, slaves can be added or removed during operation without interrupting data communication on the bus.

3.2 POSSIBLE LAYOUTS

PROFIBUS-DP consists of at least one bus segment. A segment is comprised of at least two stations which are all physically connected with a bus cable. One of these stations is the master. A bus segment consists of up to 32 stations. The beginning and end of the bus must be equipped with terminating resistors.

Layout of a bus system with one segment:




Station (master or slave)

Station with terminating resistance

Layout of a bus system with several segments:

If more than 32 stations are to be operated on one bus or the maximum line lengths of a bus segment are exceeded, several bus segments must be coupled with RS 485 repeaters.

With each repeater, the maximum number of masters and slaves within a bus segment must be reduced by one. However, the number of masters and slaves in the total bus system remains 126.



The maximum line length depends on the baud rate used. The table shows the maximum lengths for one segment and for all segments.

Baud Rate	One Segment	Over All Segments
9.6 to 187.5 kBaud	1000 m	10000 m
500 kBaud	400 m	4000 m
1.5 Mbaud	200 m	2000 m
3 to 12 Mbaud	100 m	1000 m

The length informations only apply when a suitable bus cable is used.

Profibus-DP link

3. Electrical installation

3.3 SUITABLE BUS CABLE

To achieve the above baud rates and distance without interference or faults, we recommend the type A cable described in PROFIBUS literature.


Cable specifications for type A cables for PROFIBUS-FMS and PROFIBUS-DP

Wave resistance:	135 to 165 Ohm, at a meas. frequency of 3 to 20 MHz
Cable capacity:	< 30 pF per meter
Core cross section:	> 0.34 mm ²
Cable type:	Twisted pair
Loop resistance:	< 110 Ohm per km
Signal attenuation:	Max. of 9 dB over entire length of the cable section
Shielding:	Braided copper shield or braided shield and foil shield


Use of other types of cables is not recommended since this might lower baud rates and reduce distances.

3.4 CONNECTION OF BUS CABLE TO KOMMUBOX FAS/FDS


With **POSIDRIVE**® FDS 4000, the bus cables are screwed to the terminal strip of Kommubox. With devices located within the bus branch, the incoming and outgoing lines are connected to contacts A and B. A separate screw terminal can be used for each core. The terminals are jumpered internally. Contacts R- and R+ are not required here!



With devices which are located at the beginning or end of the bus branch, only one bus cable is connected. In this case, the terminating resistors must be circuited. Kommubox is already equipped internally with the resistor combination 390/220/390 Ohm. It must only still be contacted with two wire jumpers on R+ and R-.



Two (2) centimeters of the bus cable insulation is bared about 12 cm (FDS) or 22 cm (FAS) before the end of the cable. The now visible shield is clamped under the EMC clip on the bottom of the FDS's housing. This ensures a large-surface connection between shield and PE.




Kommubox is powered from the FAS/FDS. If the power network is turned off on the FAS/FDS and there is no option board with external 24 V power, this Kommubox is no longer part of PROFIBUS-DP (however, this does not interfere with the rest of the bus).

Tip: Option boards with external 24 V power (FDS: GB4001, EA4001, 24 V supply / FAS: 24 V-LC) allow full fieldbus access even when the network voltage is missing! We recommend externally powering inverters with activated terminating resistance. See also note at the end of chap. 3.5.

3.5 CONNECTION OF BUS CABLE TO SDS

For connection of PROFIBUS-DP, the **SDP 4000** option board is equipped with a 9-pin sub D socket connector with the pin allocation specified in the PROFIBUS standard.



Plug conn. allocation
PROFIBUS-DP

- 3: TxD/RxD (P) = B
- 4: RTS
- 5: DGND
- 6: VP
- 8: TxD/RxD (N) = A

To connect the bus cable(s), we recommend using suitable bus connection plugs offered by various vendors especially for PROFIBUS-DP.

The incoming **and** outgoing bus cable can be inserted and screwed down in this plug connector. There is no outgoing bus cable for the last station. In this case, the sliding switch on the plug connector is set to "on" thus circuiting the bus terminating resistors.

Profibus-DP link

4. Configuration of the bus system



Note: To ensure that this bus connection functions correctly, the supply voltage may not fail on the stations with circuited terminating resistors!
To circumvent the risk of a total bus failure when the last station fails, active bus terminating components can also be used.

4 CONFIGURATION OF THE BUS SYSTEM

4.1 GSD FILES

When commissioning PROFIBUS-DP, it is not sufficient to just wire all bus stations. The following additional measures are also required.

- Different bus addresses must be set on the master and on all slaves.
- With older slaves which are unable to find the baud rate automatically, the same baud rate must be set as on the master. (Kommubox PROFIBUS-DP and option board PROFIBUS-DP are able to find the baud rate automatically.)
- In addition, the master must be informed of the number of slaves (with characteristics and bus addresses) which are connected.

The baud rate must be set on the master, based on the segment lengths and the total distance of the bus.
On the master side, this is done with configuration software. The device master files (GSD files) of all stations must be read in by this software. The GSD files are electronic data sheets containing information on PROFIBUS characteristics such as supported baud rates, supported modules, and so on. They are provided by the manufacturer of each PROFIBUS device.

The GSD file for the **POSIDRIVE®** FAS 4000 / FDS 4000 with Kommubox DP is called *STOE4000.GSD*. The GSD file for the **POSIDYN®** SDS 4000 with option **SDP-4000** is called *STOE4001.GSD*. These files can be downloaded from the Internet under www.stoeber.de.

4.2 PROCESS DATA OBJECT PARAMETER (PPO)

When user data are transferred over PROFIBUS-DP, the FAS/FDS with Kommubox and the SDS with option board adhere to the specifications of the profile for variable-speed drives - PROFIDRIVE. There the user data are divided into process data (PZD) which are used for process management and, if necessary, requested data which are used for parameter communication (PWK = parameter

identifier value). The profile offers five different types for the organization of this user data structure. They are known as PPO types 1 to 5 (PPO = parameter process data object). The FAS/FDS with Kommubox and the SDS with option SDP/SEA + DP 4000 support PPO types 1 to 4, starting with SW version 4.5. All earlier versions only support types 1 + 3.

The following valid configurations are available.

Configuration
Modules="PPO 1: 4 PKW 2 PZD"
Modules="PPO 2: 4 PKW 6 PZD"
Modules="PPO 3: 2 PZD"
Modules="PPO 4: 6 PZD"
Modules="PPO 2: 4 PKW 6 PZD consistency 2 words"
Modules="PPO 4: 6 PZD consistency 2 words"


The same PKW area must be used for all types. Only the PZD area has differences.

For improved adaptation to different controllers, two additional modules were set up for PPO 2 + 4 in which the data consistency covers only 2 words instead of 6 words. This means that 3 double words are available for the PZD. This makes it possible to address PZD data directly in the I/O area of the controller if its address scope permits (S7-400 or similar).



When setting the process data assignment **A110**, ... (see chap. 7.1) of the data to be transferred, make sure that the data are selected with double-word lengths first and then these with single-word length. If not, inconsistent data will cause malfunctions.

The above information can be disregarded if you are using data consistency with 6 words. If you are using SIMATIK controllers or similar, make sure that the data are transferred in blocks. The data must be transferred to a data area in whole blocks and cannot be accessed by bit/word.



PKW: Parameter identifier value
PZD: Process data
PKE: Parameter identifier
IND: Subindex in byte 2; byte 3 is reserved.
PWE: Parameter value

Profibus-DP link

4. Configuration of the bus system

4.3 CONFIGURATION WITH SIMATIC MANAGER




Since different configuration software tools are used for different PROFIBUS masters, an example of the SIMATIC Manager for the S7 (version 5) is explained here. Other tools require other procedures.

In all cases, read and adhere to the appropriate documentation of your master and the configuration software.


Download the GSD files from the Internet, and store them locally. Starting with the SIMATIC Manager, change to the hardware configuration, and then call the menu item "Extras/Neue GSD installieren."




In the dialog screen which appears, specify the directory from which the GSD file is to be installed.



After this installation procedure, the appropriate slave can be linked to an S7 project. After a project has been opened or a new one has been created, the new slave(s) can be added to the project. To do this, click the device (FAS, FDS or SDS) in the folder "weitere Feldgeräte/Antriebe" of the hardware catalog, and drag and drop it to the PROFIBUS line in the project screen.




The dialog screen for selecting the desired configuration now appears. Four different PPO types are available, from which you can select a configuration.



The PROFIBUS address of the slave must then be specified. The system automatically specifies the I/O addresses under which the slave is addressed from the S7 program.

The following figure shows an example of how a configuration might look.




Profibus-DP link

4. Configuration of the bus system

4.4 DIAGNOSIS OF PROFIBUS-DP ON THE DEVICE

Commissioning of the bus is supported by an LED on the Kommubox/option board and by the menu display **A84** (PROFIBUS baud). No matter which baud rate is selected by the PROFIBUS master, Kommubox and the SDP 4000 option support all baud rates up to 12 Mbaud and are able to automatically detect the baud rate and indicate on the display and in FDS-Tool (Kommubox, 12 Mbaud).

The following flowchart shows the state machine of the PROFIBUS slave on the Kommubox/option board during startup and operation on the bus.



Using Controlbox and FDS Tool, you can now monitor on the FDS's display whether the parameters or process data sent to the device have actually arrived. (With the default setting, the process data reference values in **E45** (control word) and **E47** (n-field-bus) arrive). Using this method, errors (e.g., wrong slave addresses or I/O memory areas on the master) can be found quickly.


Profibus-DP link

5. Data transmission via Profibus-DP

5 DATA TRANSMISSION VIA PROFIBUS-DP

Two different methods of transmission are available to exchange data between master and inverter.

The display values of the slave can be read with the parameter channel, and all parameters can be read and changed. The PKW routine specified by PROFIDRIVE is used for this.




The process data channel quickly transmits data which are used to control and monitor the running process and which require particularly short transmission times. When the bus system is configured, selection of the PPO type (→ see chap. 4.2) specifies whether the parameter channel will be used and how many bytes the process data channel will contain.

The following **transmission times** show the throughput times via the PROFIBUS interface and of the inverter.

Transmission Channel	FAS/FDS with PROFIBUS Kommubox	SDS with SDP-4000 Option
Process data ref. val. - from the bus to processing on the device	Approx. 2 to 10 msec	Approx. 1 to 4 msec (normal reference value) for A100=1 AND D99=1 fast ref. val. ≤ 1 msec
Complete processing of a PKW service	Approx. 50 to 75 msec Exceptions: <ul style="list-style-type: none"> Writing process block 1 and changes of C60 can take much longer Reading E30, E31 - approx. 150 msec 	Approx. 20 to 40 msec Exceptions: <ul style="list-style-type: none"> Writing process block 1 and changes of C60 can take much longer

6 PARAMETER COMMUNICATION WITH PKW ROUTINE

If PPO type 1 or 2 is selected when PROFIBUS-DP is configured, the parameter identifier value (PKW) routine defined by PROFIDRIVE is available for parameter communication. All parameters, displays, and inverter actions can be accessed. The parameter is selected with the parameter number and subindex. The values for parameter number and subindex are listed for each parameter in chapter 9.



PKE: Parameter identifier, Bit 11 is reserved.
IND: Subindex in byte 2; byte 3 is reserved.
PWE: Parameter value

The two-byte parameter identifier contains the bits for the parameter number, and the job and response identifier (the SPM bit for spontaneous message processing is not supported).

The master sends the job identifier, the parameter number, the subindex and, for write-accesses, the new value to the inverter. The inverter then responds with the response identifier, parameter number, subindex and, for read-accesses, the current value. All values are shown on the PROFIBUS as double words (4 bytes in length). This means that the master no longer has to detect and distinguish between bytes, words and double words.

Profibus-DP link

6. Parameter communication with PKW routine

The job identifier is used to distinguish between reset, write and read jobs. The master (PLC) must repeat the same job at least until the appropriate response arrives from the slave.

Job Identifier	Meaning
0	No job (reset job)
1	Request parameter value (read)
3	Change parameter value (write)
Rest	Do not use!

The inverter replies to the same bit positions with the response identifier. The response identifier remains unchanged until the current job is finished. The response identifier must be kept constant during this time.

Response ID	Meaning
0	No response or also: OK for job identifier " <i>kein Auftrag</i> "
2	Parameter value transferred (sent to master)
7	Job cannot be executed.

The inverter deletes all response bytes together with response identifier 0. With job identifier 2, the parameter number and the subindex from the job are echoed in the response. The slave continues to send the complete response until the master formulates a new job. When the display values of the slave are read-accessed, the slave cyclically sends new current values until the master formulates a new job.

If the slave responds with 7: Auftrag nicht ausführbar, the least significant byte of the parameter value (PWE) (i.e., byte 7) contains the appropriate error number.

Error Number	Meaning
0	Illegal parameter number
1	Parameter value cannot be changed.
2	Upper or lower limit exceeded
3	Illegal subindex
17	Write-access not permitted in current operating state (enable is off!)
101	Wrong job identifier (vendor-specific)
102	Internal communication with inverter faulty (vendor-specific)
103	Read-access not permitted (vendor-specific)

Other rules for job/response processing:

- The job identifier "*kein Auftrag*" must be sent for a short time to ensure that the inverter with the PROFIBUS interface always stops responding to the last job and is available for the next job.
- Transmission on the bus is in Motorola format (Big-endian). The high parameter value is sent first, both within one word and as the words within one double word.
- If no information is required from the PKW interface during cyclic operation, the job identifier should be set to "*kein Auftrag*."

6.1 CONSISTENCY

Since PROFIBUS-DP sends all bytes from the address area of the PLC to the stations cyclically and asynchronously to the PLC cycle, the PLC program must also ensure that data are consistent. All 8 PKW bytes must be consistent for parameter communication with the slave. STEP7 from Siemens offers the system functions SFC13, 14 and 15 for this job. If such functions cannot be utilized, a special time sequence must be adhered to when writing the bytes.

6.2 TIME SEQUENCE FOR A PKW ROUTINE

The following example shows how to change the parameter **D00** (reference value accel) from parameter set 1 to the value 300 msec/3000 rpm with a controller which supports transfer commands for the 16-bit format.

Look up values from the parameter list: PNU = 1060_{dec} = 424_{hex}, subindex = 0 (→ see chapter 9).

Parameter value 300_{dec} = 12C_{hex}.

Step	Set PLC Output Bytes (xx = Old Contents)	Explanation
1	Byte: 0 1 2 3 4 5 6 7 Hex val: 00 00 00 00 xx xx xx xx	Delete job identifier and reserved byte 3.
2	Byte: 0 1 2 3 4 5 6 7 Hex val: 00 00 00 00 xx xx xx xx	Wait until the input bytes of the slave contain the response identifier 0. Mask out bits 4 to 7, and check for 0. The PNU of the last job may still be in byte 1 and the other bits. Wait time depends on the bus rotation time (number of stations).
3	Byte: 0 1 2 3 4 5 6 7 Hex val: 00 00 00 00 00 00 01 2C	Expand parameter value 12C _{hex} to 4 bytes and enter in bytes 4 to 7 .

Profibus-DP link

7. Process data assignment

Step	Set PLC Output Bytes (xx = Old Contents)	Explanation
4	Byte: 0 1 2 3 4 5 6 7 Hex val: 00 00 01 00 00 00 01 2C	Enter subindex 1 in byte 2.
6	Byte: 0 1 2 3 4 5 6 7 Hex val: 34 24 00 00 00 00 01 2C	Enter parameter number 424 _{hex} in bits 0 to 10 of the PKE. Enter job identifier in bits 12 to 15. Bit 11 remains 0.
7	Byte: 0 1 2 3 4 5 6 7 Hex val: 34 24 00 00 00 00 01 2C	Wait until a response arrives in input byte. Example: Byte: 0 1 2 3 4 5 6 7 Hex val: 24 24 00 00 00 00 00 00 The 2 in byte 0 marks the response identifier . "Transfer parameter value" and the new value is accepted correctly by the slave.
8	Byte: 0 1 2 3 4 5 6 7 Hex value: 00 00 00 00 00 00 00 xx xx	Delete job identifier again to shorten the wait time for the next PKW service.

7 PROCESS DATA ASSIGNMENT

The master sends the reference values with the process output data to the slaves (FAS, FDS or SDS) on the process data channel (PZD). The slaves respond with the actual values of the process input data.

Example:

Layout of process data (PZD)

Data from master to inverter

MSB	LSB	MSB	LSB
-----	-----	-----	-----

E45 control word | Speed reference value:
E47 n-field-bus

Data from inverter to master

MSB	LSB	MSB	LSB
-----	-----	-----	-----

E46 status word | Speed actual value:
E08 n-motor

The definition of the data which are transferred by the process data channel (PZD) is called process data assignment. The FAS/FDS with PROFIBUS Kommubox and the SDS with the **SDP-4000** option support flexible assignment of communication objects (parameter and display values) to the process data. If the drive is to be exclusively controlled via PROFIBUS in speed mode, the controller offers control words/status words and speed reference values/actual values. These communication objects are assigned to the process data (default setting). If this is the case, the assignment does not need to be changed, and you can skip this chapter.

If the drive uses posi mode or the controller of the inverter uses both PROFIBUS-DP and terminals, the inverter can be controlled in a wide variety of ways with the parameters and indications **E100** to **E128**. If this is the case, we recommend transmitting these communication objects via the high-speed process data channel and not via the PKW routine, and then adjusting the assignment accordingly.

7.1 PROCESS OUTPUT DATA ASSIGNMENT

The length of the process output data is 4 bytes or 12 bytes. The number of process data bytes is selected when PROFIBUS is configured. After the new GSD file is read in, one of the four possible PPO types can be selected as the configuration (e.g., PPO type 1 has 4 bytes of PZD and PPO type 2 has 12 bytes of PZD). The data to be transferred are specified with the parameters **A110** to **A113** in FDS Tool.

Any communication object which can be assigned to process data (see list below) can be assigned to the process data with one of the parameters **A110** to **A113**. All combinations and sequences are permitted. When a parameter is not to be used, it can be set to "inactive" with the values 0 or FFFFFFFF_{hex}.



The parameters for the process data assignment can only be set on a PC with FDS Tool or via PROFIBUS-DP.

Default setting of the assignment of the process output data:

1. Byte	2. B	3. B	4. B	5. B	6. B	7. B	8. B	9. B	10. B	11. B	12. B
MSB	LSB	MSB	LSB	0	0	0	0	0	0	0	0
E45		E47									Not used
control word		n-field-bus									
		(Motorola format)									

Profibus-DP link

7. Process data assignment

Parameters for the process output data assignment:

Name	PNU	Subindex	Use
A110 process output data 0	1000	110	Describes the communication object assigned to the first few bytes of the process output data
A111 process output data 1	1000	111	Describes the communication object assigned to the next bytes. The location of this object within the process data varies depending on the length of the object described by A110 .
A112 process output data 2	1000	112	Describes the communication object assigned to the next bytes. The location of this object within the process data varies depending on the length of the previous objects.
A113 process output data 3	1000	113	Describes the communication object assigned to the next bytes. The location of this object within the process data varies depending on the length of the previous objects.
A119 proc.output data enable	1000	119	This value must be set to 1 (default setting) before the process output data can be transferred to the inverter. The data must be disabled briefly (set value = 0) so that parameters A110 to A113 can be changed.
A130 proc. out length	1000	130	Display value which may only be read. Specifies how many bytes are required for the process output data in the current parameterization. This can be used to check the selection of the PPO type.



Remarks: When the parameters are changed (e.g., with FDS Tool), the inverter contains the new parameters. However, Kommubox must also be "informed" of these changes. This is done by reading at least one process output data parameter or by using **A00** "save parameters" and subsequently turning the inverter off and on.

List of the parameters which can be assigned to process output data (communication objects):

Name	Length in Bytes	Value to be set via PROFIBUS	Value composed of		Use
			PNU	Subindex	
inactive	0	FFFFFFFF _{hex} or 0	-	-	Valid selection ! (e.g., for A112 and A113 with PPO type 1)
D12 fix reference value 1	2	04240C00 _{hex} / 69471232 _{dec}	1060	12	Reference value specified via fieldbus and via terminal strip (fixed ref. value 1 from parameter set 1)
E45 control word	2	04382D00 _{hex} / 70790400 _{dec}	1080	45	Control commands in acc. w. CiA/DS-402 / DRIVECOM
E47 n-field-bus	2	04382F00 _{hex} / 70790912 _{dec}	1080	47	Speed reference value in acc. w. CiA/DS-402 / DRIVECOM
E101 control bits	4	04386500 _{hex} / 70804736 _{dec}	1080	101	32 control bits for mixed operation
E102 torque-limit	2	04386600 _{hex} / 70804992 _{dec}	1080	102	Torque limit
E103 power-limit	2	04386700 _{hex} / 70805248 _{dec}	1080	103	Power limit
E104 additional RV	2	04386800 _{hex} / 70805504 _{dec}	1080	104	Additive offset reference value
E105 RV-factor	2	04386900 _{hex} / 70804760 _{dec}	1080	105	Multiplicative offset value
E106 posi.override	2	04386A00 _{hex} / 70806016 _{dec}	1080	106	Factor for posi speed
E107 posi.offset	4	04386B00 _{hex} / 70806272 _{dec}	1080	107	Offset for reference position. Scaling as w. every target position in I05 * 10 ¹⁰⁶
E108 ¹ wind. diameter	2	04386C00 _{hex} / 70806528 _{dec}	1080	108	Measured value for winding diameter
E109 ¹ M-rot.magnet	2	04386D00 _{hex} / 70806784 _{dec}	1080	109	Torque setting / rotation field magnet (not with FAS)
E110 ¹ analog output 1	2	04386E00 _{hex} / 70807040 _{dec}	1080	110	Output of analog voltage 1 for F40 =0. Is affected by F41 , F42 and F43 .
E111 BA2	1	04386F00 _{hex} / 70807296 _{dec}	1080	111	Direct switching of relay 2/BA2 and other BA when applicable parameters for BA function (F80 to F86) are set to 0:inactive
E112 ¹ BA1	1	04387000 _{hex} / 70807552 _{dec}	1080	112	
E113 ¹ BA3	1	04387100 _{hex} / 70807808 _{dec}	1080	113	
E114 ¹ BA4	1	04387200 _{hex} / 70808064 _{dec}	1080	114	
E115 ¹ BA5	1	04387300 _{hex} / 70808320 _{dec}	1080	115	
E116 ^{1:2} BA6	1	04387400 _{hex} / 70808576 _{dec}	1080	116	
E117 ^{1:2} BA7	1	04387500 _{hex} / 70808832 _{dec}	1080	117	
E118 ^{1:2} analog output 2	2	04387600 _{hex} / 70809088 _{dec}	1080	119	Output of analog voltage 2 (only with SDS) for F45 =0. Is affected by F46 and F47 .

Profibus-DP link

7. Process data assignment

Name	Length in Bytes	Value to be set via PROFIBUS	Value composed of PNU Subindex		Use
E119 reference value	2	04387700 _{hex} / 70809344 _{dec}	1080	119	Speed/torque reference value on input of ref. val. characteristic curve Use depends on C60 .
E120 ¹ tension reduction	2	04387800 _{hex} / 70809600 _{dec}	1080	120	Tension drop (dependent on diameter) for winder software
E121 ¹ PID-reference	2	04387900 _{hex} / 70809856 _{dec}	1080	121	Reference value for PID controller
E122 ¹ winder-roller	2	04387A00 _{hex} / 70810112 _{dec}	1080	122	Roller position for winder software
E123 ¹ sync.offset	4	04387B00 _{hex} / 70810368 _{dec}	1080	123	Winding offset of slave axis in relation to master
E125 ¹ synchron n-RV	2	04387D00 _{hex} / 70810880 _{dec}	1080	125	Speed pre-control for winding synchronous run in rpm (A100 =0)
E126 n-Max	2	04387E00 _{hex} / 70811136 _{dec}	1080	126	Limitation of the max. speed
P1.G14 ¹ begin.winding	2	04600E00 _{hex} / 73403904 _{dec}	1120	14	G14 in parameter set 1
P2.G14 ¹ diameter	2	06540E00 _{hex} / 106171904 _{dec}	1620	14	G14 in parameter set 2

¹ not available with FAS ² not available with FDS

All parameters listed here can also be accessed with the PKW routine.

Please remember: When a parameter is transferred with PZD and PKW, the cyclic PZD overwrites the PKW value of the parameter.



E45 control word and **E47** n-field-bus (default setting) are only effective when **A30** operation input is set to "2:field-bus." If you are using **E100** and **E101** via PROFIBUS, we recommend setting **A30** to "0:ctrl.inter."

7.2 PROCESS INPUT DATA ASSIGNMENT

The length of the process input data is also 4 bytes or 12 bytes. The number of process data bytes is selected during configuration of PROFIBUS. After the new GSD file has been read in, one of the four possible PPO types can be selected as the configuration (e.g., PPO type 1 has 4 bytes of PZD and PPO type 2 has 12 bytes of PZD). The data to be transferred are specified with the parameters **A120** to **A123**.

Any communication object which can be assigned to process data (see list below) can be assigned to the process data with one of the parameters **A120** to **A123**. All combinations and sequences are permitted. When a parameter is not to be used, it can be set to "inactive" with the values 0 or FFFFFFFF_{hex}.



The parameters for the process data assignment can only be set on a PC with FDS Tool or via PROFIBUS-DP.

Default setting of the assignment of the process input data:

1. B	2. B	3. B	4. B	5. B	6. B	7. B	8. B	9. B	10. B	11. B	12. B
MSB	LSB	MSB	LSB	0	0	0	0	0	0	0	0
E46		E08		Not used							
Status word		Actual speed									
<i>(Motorola format)</i>											

Parameters for the process input data assignment:

Name	PNU	Subindex	Use
A120 process input data 0	1000	120	Describes the communication object assigned to the first few bytes of the process input data
A121 process input data 1	1000	121	Describes the communication object assigned to the next bytes. The location of this object within the process data varies depending on the length of the object described by A120 .
A122 process input data 2	1000	122	Describes the communication object assigned to the next bytes. The location of this object within the process data varies depending on the length of the previous objects.
A123 process input data 3	1000	123	Describes the communication object assigned to the next bytes. The location of this object within the process data varies depending on the length of the previous objects.
A132 proc. in. length	1000	132	Display value which may only be read. Specifies how many bytes are required for the process input data in the current parameterization. This can be used to check the selection of the PPO type.

The coding of these parameters is the same as that of the parameters for the process output data assignment except that no switch is required for the process data enable.

Profibus-DP link

8. Control with control- and status bits

List of the parameters which can be assigned to process input data (communication objects):

Name	Length in Bytes	Value to be set via PROFIBUS	Value composed of:		Use
			PNU	Subindex	
inactive	0	FFFFFFFF _{hex} or 0	-	-	Valid selection ! (e.g., for A112 and A113 with PPO type 1)
E02 M-motor	2	04380200 _{hex} / 70779392 _{dec}	1080	2	Current motor torque
E08 n-motor	2	04380800 _{hex} / 70780928 _{dec}	1080	8	Actual speed value in acc. w. CiA/DS-402 / DRIVECOM
E08 n-motor smoothed	2	062C0800 _{hex} / 103548928 _{dec}	1580	8	Actual speed value smoothed
E10 analog input 1	2	04380A00 _{hex} / 70781440 _{dec}	1080	10	Level on analog input 1/2 without effects of F21-F24 / F26- F27 . $\pm 10V = \pm 100\% = \pm 8192$
E11 ¹ analog input 2	2	04380B00 _{hex} / 70781696 _{dec}	1080	11	
E16 ¹ analog output 1	2	04381000 _{hex} / 70782976 _{dec}	1080	16	Level on analog output 1 after inclusion of F41 , F42 , F43
E19 BE15...BE1 & enable	2	04381300 _{hex} / 70783744 _{dec}	1080	19	Level of all binary inputs
E27 BA15..BA1 & Relais 1	2	04381B00 _{hex} / 70785792 _{dec}	1080	27	Level of all binary outputs
E28 ^{1,2} analog output 2	2	04381C00 _{hex} / 70786048 _{dec}	1080	28	Level on analog output 2 (only SDS) after inclusion of F46 , F47
E46 status word	2	04382E00 _{hex} / 70790656 _{dec}	1080	46	Status word in acc. w. CiA/DS-402 / DRIVECOM
E100 status bits	4	04386400 _{hex} / 70804480 _{dec}	1080	100	Summary of internal status signals
E127 BE-encoder-position	2	04387F00 _{hex} / 70811392 _{dec}	1080	127	Increment number of encoder on BEs
E128 ¹ X20-encoder-position	2	04388000 _{hex} / 70811648 _{dec}	1080	128	Increment number of encoder on X20.
E131 Posi next latched	4	04388300 _{hex} / 70812416 _{dec}	1080	131	Actual position for rising posi-next edge within one process block chain. Only takes effect for limited traversing range. Only with FAS (starting SV 4.5 E).
E132 ¹ SSI raw value	4	04388400 _{hex} / 70812672 _{dec}	1080	132	Raw value of SSI encoder in 1/4096 r.
G19 ¹ act. winding diameter	2	04601300 _{hex} / 73405184 _{dec}	1120	19	Actual winding diameter
I80 actual position	4	04885000 _{hex} / 76042240 _{dec}	1160	80	Actual position
I84 following error	4	04885400 _{hex} / 76043264 _{dec}	1160	84	Following error
I88 posi speed	4	04885800 _{hex} / 76044288 _{dec}	1160	88	Speed during positioning

¹ not available with FAS ² not available with FDS

8 CONTROL WITH CONTROL- AND STATUS BITS

Controlling the inverter with **E101** control bits and **E100** status bits makes possible the flexible utilization of the wide range of capabilities offered by the inverter (FAS, FDS and SDS) such as positioning mode, synchronous operation, winder control and even simple speed control with fixed reference values.

Tip: The following setting is recommended for this: **A110=E101**, **A120=E100**, **A30=0**.

The parameters **A30** (operation input), the process output data assignment parameters **A110**, **A111**, **A112**, **A113**, and the functions of the binary and analog inputs (e.g., **F31** BE1-function) determine which signals are used to control the inverter. These parameters can be used to specify whether a control signal of an input is sent from the terminal strip or the fieldbus.

We recommend using the **E101** control bits to set parameter **A30** (operation input) to "0:ctrl.inter." This provides an easy way to control the device's state using the additional enable (bit 6 in **E101**) and the acknowledgment (bit 3 in **E101**).


Assignment of the control and status bits to the process input and output data requires that one of the process output data parameters **A110**, **A111**, **A112**, **A113** be set to **E101** (control bits) and one of the process input data parameters **A120**, **A121**, **A122**, **A123** be set to **E100** (status bits).

8.1 SPECIFICATION OF THE SOURCE FOR CONTROL SIGNALS

One of the 32 functions (e.g., halt, posi start) can be assigned to each binary input of the control terminal strip (see parameter **F31**, **F32** and so on, FAS documentation, publ. no. 441581, FDS documentation, publ. no. 441408 and SDS documentation, publ. no. 441449).

Each control signal which was not assigned to a binary input can be addressed via fieldbus (**E101** control bits). One of the 14 functions can be assigned to the analog inputs. (See parameter **F20** and **F25** in the above documentation.)

The missing functions can be specified via fieldbus (e.g., **E102** torque limit,...).



Profibus-DP link

8. Control with control- and status bits

 The binary and analog signals from the terminal strip have priority over specification via fieldbus!

Meaning of the bits in E101 control bits:

Bit	Name	Meaning for Bit = 1	F31*
0	halt	Drive is decelerated to standstill on selected ramp. Then brake is applied if activated by F00 or F08 . Manual traversing (tip) is now possible. (Allow min. of 4 msec pause until manual traversing, <i>posi-start</i> , ...).	8
1	quick stop	At change from 0→1, drive is decelerated at D81 (decel-quick). Then brake is applied if activated by F00 or F08 . Short pulse (≥ 4 msec) is sufficient to trigger brake. Quick stop can be terminated with F19 =1.	9
2	ext.fault	At rising edge, inverter assumes fault "44:ext.fault."	12
3	fault reset	Rising edge acknowledges fault if cause no longer exists.	13
4	wind.setD-ini	The current value of the winding diameter is set to G14 (wind.setD-ini).	29
5	parameter set-select	0 selects parameter set 1. 1 selects parameter set 2. Parameter set can only be selected if A41 =0. Selected set does not become active until enable is removed.	11
6	additional enable	Additional enable (must be on together with enable X1.x) to enable inverter. (Allow pause of at least 4 msec until manual traversing (tip), <i>posi-start</i> , ...).	7
7	torque select	Switching of torque limit from C03 M-max 1 to C04 M-max 2	10
8	RV-select 0	Used together with bit 19 (only SDS) to select process blocks or fixed reference values. The bits on RV-select 0 to 4 are interpreted as binary coded numbers. See chapter 10.3 of FAS/FDS/SDS documentation ¹ and chapter 4.3 of FAS-Posi-Upgrade documentation (publ. no. 441587).	1
9	RV-select 1		2
10	RV-select 2		3
11	RV-select 3		30
12	disable PID-controller	PID controller is disabled, and integrator is reset.	26
13	direction of rotation	Negation of the current speed reference value during speed mode	6
14	motorpoti up	With D90 =1, motor potentiometer can be simulated. D00 and D01 are used as ramps.	4
15	motorpoti down		5
16	posi.start	Starts movement (the process block selected with RV-select 0 to 4). Any positioning procedure in progress is terminated, and the new target is approached (changing targets on the fly).	19
17	posi.step	Starts movement (same as above but the running positioning procedure is not interrupted). Used primarily for manual block stepping with a process block sequence (cf. J17 =0).	16
18	posi.next	With chained process blocks, the running block is interrupted, and a jump is made to the next block. Important: A braking path may be defined there, for example. The <i>posi.next</i> evaluation must be programmed for the specific process block (cf. J17 =3:posi.next.). Otherwise the drive does not react to <i>posi.next</i> .	20
19	RV-select 4	See bits 8 to 11.	31
20	start reference	Change in edge from low to high starts reference traversing.	24
21	tip +	Manual traversing (tip) in positive direction. Halt function must be active.	17
22	tip -	Manual traversing (tip) in negative direction. Halt function must be active.	18
23	brake release	Manual releasing of the brake. Has priority over internal braking function.	32
24	stop +	"Stop input" at positive end of the traversing area. In position mode (C60 =2), "stop input" causes malfunctions. In speed and torque mode, the direction of rotation is disabled.	21
25	stop -	"Stop input" at negative end of the traversing area	22
26	reference input	Defines the reference position for I30 =0	23
27	synchron free-run	The ref. value for synchronous free run is decoupled. For example, the drive can be handled as desired via E46 . Speed is adjusted on the current ref. value ramp (e.g., D00).	27
28	synchron reset	The angle of deviation of synchronous running control is reset.	28
29 31	In reserve		-

* This column shows the available selections with the same function for the BE functions (**F31**, ...).

¹ FAS standard documentation (publ. no: 441581)
FDS documentation (publ. no.: 441408)
SDS documentation (publ. no.: 441449)

Profibus-DP link

8. Control with control- and status bits

Meaning of the bits in E100 (status bits):

Bit	Name	Meaning for Bit = 1	F00
0	standstill	Amount of E08 n-motor < C40 n-window	2
1	refVal-reached	With C60=0:torque : Operation is enabled. With C60=1:speed : Amount of (E06 n-reference value – E08 n-motor) < C40 n-window. With C60=2:position : Changes to 1 when posi controller reaches target position and amount of (I80 – I81) < I22 is reached. During pauses, bit remains = 1. Changes to 0 when process block or reference traversing was started or axis was shifted out of window I22 (only if enable=0).	3
2	acceleration	Drive is accelerated or delayed.	-
3	standstill ramp reached	Only with C60=1 : Ramp generator is at zero (± 0.5 Hz for FAS/FDS).	-
4	ref. value ramp reached	Only with C60=1 : Ramp generator has reached reference value.	-
5	ramp diff. > 0	Only with C60=1 : Ramp generator accelerates.	-
6	torque limit	Drive is at current torque limit during static operation.	4
7	Accel. overload	Drive is at torque limit during an acceleration procedure.	-
8	Decel overload	Drive is at the tension limit during a braking procedure.	-
9	relay 1	Relay 1 (ready relay) is closed (no fault, warning, message).	-
10	clockwise (n-motor>0)	E08 n-motor is positive. During zero crossing, hysteresis with C40 .	14
11	capturing active	Only for FAS/FDS with C60=1 : FAS/FDS captures running motor.	-
12	skip speed active	Only for FAS/FDS with C60=1 : Reference value in skip speed range	-
13	load start active	Only for FAS/FDS with C60=1 : Load start (breakaway) is active.	-
14	active parameter set	0 = parameter set 1 is active. 1 = parameter set 2 is active. The bit changes at the beginning of the parameter-set switch-over. Bit 15 indicates the end of the switchover.	7
15	parameters active	0 = not all parameters are available internally. 1 = parameter assignment after write-access with PKW service or change via device menu, parameter set switch-over. Actions are completely executed and active.	32
16	referenced	Indicates that the drive is referenced (reference traversing concluded). Only applies when C60=2 .	13
17	electronic cam 1	Actual axis position is between I60 and I61 . Only valid when C60=2 .	8
18	operation range	Drive is within the defined operation range (C41 to C46).	6
19	posi traversing	Indicates when E80 operating condition = "18:moving" (when a process block was started - not with manual traversing)	-
20	M-motor>0	E02 M-motor is positive (without hysteresis).	-
21	switch-memory 1	Output of switch memory 1, 2 and 3. Each posi switching point defined in group N.. can simultaneously address switch memory 1, 2 and 3.	19
22	switch-memory 2		20
23	switch-memory 3		21
24	RV-ackn.0	Only valid for C60=2:position . If no <i>posi.start</i> or <i>posi.next</i> signal is queued, the reference-value-select signals are output inverted . Otherwise the active I82 process block is output.	23
25	RV-ackn.1		24
26	RV-ackn.2	See chapter 10.3 of FAS/FDS/SDS documentation ¹ and FAS-Posi-Upgrade documentation (publ. no. 441587) chap. 4.3.	25
27	RV-ackn.3		26
28	RV-ackn.4		27
29	In reserve	-	-
30	posi.active	Is 1 when E80 (operating condition) = 17:posi.active. This is true when C60=2 , and power section is on, and a traversing job can be started (no process block or sequence in progress). This permits a concluded sequence to be indicated. Is also 0 when E80=19:delay or 20:wait is indicated.	10
31	ready for ref. value	The drive is powered, the brakes are released, and, with the FAS/FDS, magnetization is established.	22

* This column shows the available selection with the same function for the BA/relay functions (F00, ...).

¹ FAS standard documentation (publ.-no.: 441581)
FDS documentation (publ. no.: 441408)
SDS documentation (publ. no.: 441449)

Profibus-DP link

9. Control with control/status word and speed reference/actual value

9 CONTROL WITH CONTROL/STATUS WORD AND SPEED REFERENCE/ACTUAL VALUE

Control of the inverter with **E45** control word, **E46** status word, **E47** n-field-bus and **E08** n-motor allows the drive to be controlled with variable speed. This type of control is based on the specifications of DRIVECOM profile 21. It is explained in this chapter.

Tip: The following settings are recommended: **A110=E45**, **A111=E47**, **A120=E46**, **A121=E08**, **A30=2:field-bus** for FAS/FDS or **A30=3:Profibus-DP** for SDS.

Controlling the inverter based on DRIVECOM profile 21 involves specification of the reference value and various control commands for the drive (e.g., turn on, shutdown, and so on).

The "device control" function block processes the control commands. The "speed" function block handles processing of the reference value. The function blocks will now be explained in more detail.

Process data **E45** and **E47** of PROFIBUS will not reach the internal memory locations in the device (**E45**, **E47**) unless **A30=3:Profibus DP**.


9.1 DEVICE CONTROL

The "device control" function block controls the entire device function (drive function and power section). A state machine handles the control sequence.

The device control is affected by the "control word" and the following internal signals.

The "local/remote" switch, the status of the drive function and faults.

The device control affects the drive functions. The "status word" is generated from the device state and internal signals and can be read via the fieldbus.



9.2 LOCAL / REMOTE

This internal signal indicates whether the inverter can be controlled by the fieldbus. This signal is set to "remote" when parameter **A30** (operation input) is set to "3:Profibus-DP" (SDS) or "2:Fieldbus" (FAS/FDS). Other settings set the signal to "local." If the signal is set to "local," the inverter disregards the control commands in the "status word." Regardless of this signal, the inverter can be controlled from terminals and fieldbus (mixed mode).

See chapter 9. This is true when at least one of the parameters for the function of the BEs or **F20** AE2-function is not set to "0:inactive."




If control is to be exclusively performed via fieldbus, all parameters for the functions of the BEs and for AE2 must be parameterized to "0:inactive" in both parameter sets.

9.3 INPUT ENABLE

The binary input enable (X1.x) on the terminals must be addressed with a high level so that the control commands from the "control word" can take effect on the "device control" state machine and the drive can be started. If the input is not high, the drive function is disabled immediately and the power section is turned off. This function can be used to turn off the drive on site.

9.4 "DEVICE CONTROL" STATE MACHINE

The state machine describes the states of the device and the possible control sequence on the drive. A state represents a certain internal and external status. It can only be exited via defined events. Appropriate state transitions are assigned to the events. The state can be changed with device-control commands and internal events. This can be used to execute a control sequence. The current device state can be read with the "status word."



Profibus-DP link

9. Control with control/status word and speed reference/actual value

9.5 STATES OF DEVICE CONTROL

State	Description	Drive Function
Not ready for switch-on	Voltage supply on inverter has just been turned on. Self-test and initialization are running.	Disabled
Switch-on disable	Initialization concluded. Switch-on is disabled.	Disabled
Ready for switch-on	Switch-on is enabled.	Disabled
Switched on	Switch to operation is enabled.	Disabled
Operation enabled	Power section is on. Drive follows the reference value.	Enabled
Quick stop active	Quick stop function. Drive is slowed to standstill.	Disabled
Fault	Power section is off.	Disabled
Fault reaction active	Power section is off.	Disabled

Definitions:

Drive function is disabled: Inverter does not process speed reference value.

Drive function is enabled: Inverter processes speed reference value, and the power section is enabled. (Motor is powered.)

Drive faults: Faults can occur in any state of device control. They always cause a change to the state "fault reaction active." In this state, the inverter turns off the power section immediately and logs the fault in fault memory. After these actions have been executed, a change is made to the "malfunction" state. This state can only be exited with the "fault reset" command. The reason for the fault must have been corrected.

9.6 STATE TRANSITIONS OF DEVICE CONTROL

A change in state only occurs when the actions have been completely performed.

After the actions have been fully processed, the next state is assumed, and new commands are accepted.

State Transition	Event/Commands	Action
0 Input, state machine → Not ready for switch-on	Turn on voltage	Start self-test. Start initialization.
1 Not ready for switch-on → switch-on disable	Self-test okay Initialization okay	None
2 Switch-on disable → ready for switch-on	"Shutdown" command and "enable" input on high	None
3 Ready for switch-on → switched on	"Turn on" command and "enable" input on high	None
4 Switched on → operation enabled	"Enable operation" command and "enable" input on high	Enable drive function
5 Operation enabled → switched on	"Disable operation" command and "enable" input on high	Decelerate drive on the currently selected ramp. Then change to "switched on" state and turn off power section.
6 Switched on → ready for switch-on	"Shutdown" command and "enable" input on high	None
7 Ready for switch-on → switch-on disable	"Quick stop" command or "disable voltage" command or "enable" input on low	None
8 Enable operation → ready for switch-on	"Shutdown" command and "enable" input on high	Disable drive function Turn off power section immediately
9 Enable operation → switch-on disable	"Disable voltage" command or "enable" input on low	Disable drive function Turn off power section immediately
10 Switched on → switch-on disable	"Quick stop" command or "enable" input on low	None
11 Enable operation → quick stop active	"Quick stop" command and "enable" input on high	Drive is decelerated on quick-stop ramp until standstill.
12 Quick stop active → switch-on disable	Quick stop is concluded or "enable" input on low	Disable drive function Turn off power section
13 All states → fault reaction active	Drive fault detected	Turn off power section (motor coasts down). Disable drive function. Store fault on device.
14 Fault reaction active → malfunction	Reaction to fault concluded	None
15 Fault → switch-on disable	"Fault reset" command when fault no longer present	Fault is reset.

Profibus-DP link

9. Control with control/status word and speed reference/actual value

9.7 CONTROL WORD

The "control word" and the level of the "enable" binary input use logical links to produce the device-control commands which affect the state machine of the device controller. The control word consists of 16 bits whose meaning is shown below.

Bit Number	Name	Meaning
0	Turn on	Device-control command
1	Disable voltage	Device-control command
2	Quick stop	Device-control command
3	Enable operation	Device-control command
4	Disable HLG (HLG = ramp function generator)	If the bit = 0, the drive is decelerated on the selected ramp (without mixed mode, D01 RV-Decel). If the bit = 1, the drive is accelerated on the selected ramp (without mixed mode, D00 RV-Accel).
5	Stop HLG	If the bit = 0, the current output value of the ramp function generator is retained. If the bit = 1, the drive follows the reference value over the ramp function.
6	HLG zero	Same function as bit 4 (disable HLG)
7	Reset fault	Device-control command
8 ... 15	Reserved	

9.8 DEVICE-CONTROL COMMANDS IN THE CONTROL WORD

	Reset fault	HLG zero	HLG stop	HLG disable	Enable operation	Quick stop	Disable voltage	Turn on	
Command \ Bit	7	6	5	4	3	2	1	0	Transitions
Shut down	X	X	X	X	X	1	1	0	2, 6, 8
Turn on	X	X	X	X	X	1	1	1	3
Disable voltage	X	X	X	X	X	X	0	X	7, 9, 10, 12
Quick stop	X	X	X	X	X	0	1	X	7, 10, 11
Disable operation	X	X	X	X	0	1	1	1	5
Enable operation	X	X	X	X	1	1	1	1	4
Reset fault	0 → 1	X	X	X	X	X	X	X	15

Explanation:

X This bit has no meaning at this location.

0→1 A change from 0 to 1 is expected (rising edge).

9.9 STATUS WORD

Bit Number	Name	Meaning
0	Ready for switch-on	Device state
1	Switched on	Device state
2	Operation enabled	Device state
3	Fault	Device state
4	Voltage disabled	If the bit = 0, the control word contains the request to disable voltage or the "enable" binary input is not high.
5	Quick stop	Device state
6	Switch-on disable	Device state
7	Warning	Inverter has a warning which is indicated on Controlbox and can be read via E82 (event name). The inverter continues operation until the warning time expires and then changes to the "fault reaction active" state.
8	Message	The inverter cannot fully handle the requested drive task. The type of message is shown on the display and can be read via E82 (event name).
9	Remote	Is 1 if parameter A30 is set to "2:field bus" (FAS/FDS) or "3:Profibus-DP" (SDS). Otherwise 0.
10	Reference value reached	Indicates 1 when the drive has reached the requested reference value (speed or position). The bit only enables this function in the "operation" device state. The HLG bits in the control word must all be set so that this signal is indicated correctly. Otherwise the bit is set to 1.
11	Limit value	Is 1 when the speed limit is active (C00 n-min, C01 n-max).
12 ... 15	Reserved	

Profibus-DP link

9. Control with control/status word and speed reference/actual value

9.10 INDICATION OF THE DEVICE STATES IN THE STAUTS WORD

	Switch-On Disable	Quick Stop	Voltage Disabled	Fault	Operation Enabled	Switched On	Ready for Switch-On
State/Bit	6	5	4	3	2	1	0
Not ready for switch-on	0	X	X	0	0	0	0
Switch-on disable	1	X	X	0	0	0	0
Ready for switch-on	0	1	X	0	0	0	1
Switched on	0	1	X	0	0	1	1
Operation enabled	0	1	X	0	1	1	1
Fault	0	X	X	1	0	0	0
Fault reaction active	0	X	X	1	1	1	1
Quick stop active	0	0	X	0	1	1	1

9.11 EXAMPLE OF CONTROLLING VIA FIELDBUS: START DRIVE WITH SPEED RV 3000 RPM

No.	Action	Reaction of the inverter	Indicated on Controlbox, FDS-Tool or FDS display
1	<p>SDS: Install SDP+EA 4000 option board, and turn on supply voltage. Set parameter A30 (operation input) to "3:Profibus-DP." Enable H-level</p> <p>FAS/FDS: Fix the Kommubox. Set parameter A30 (operation input) to "2:fieldbus." Apply high level to input "enable" (X1.x).</p>	<p>SDS: Startup of SDS with SDP option</p> <p>FAS/FDS: Startup of FAS/FDS with Kommubox</p>	<p>SDS: After startup the LED of the SDP+EA option is on continuously. Line 2 in the display indicates: 12:Inhibited</p> <p>FAS/FDS: LED of the Kommubox is on continuously. Line 2 in the display indicates: 12:Inhibited</p>
2	Start PROFIBUS-DP: Set entire startup of bus and master to "Operate" (turn PLC to RUN).	DP state changes to " cyclic data communication ." The inverter remains in "switch-on disable" since the process output data = 00.	LED of SDP+EA option flashes slowly at $T_{\text{ein}} = T_{\text{aus}} = 1$ seconds.
3	Enter the " shut down " command in the control word. <div> <div>15</div> <div>Control word</div> <div>0</div> <div>000000000000000110</div> </div>	<p>Device status on inverter changes to "ready for switch-on." Status word then changes to:</p> <div> <div>15</div> <div>Status word</div> <div>0</div> <div>000000010000110001</div> </div> <p>Bit 0 to 3 = 1: Ready for switch-on Bit 4 = 1: "Disable voltage" command is not active. Bit 5 = 1: "Quick stop" command isn't active. Bit 9 = 1: The inverter is on remote.</p>	Line 2 of the display indicates: 0:Ready
4	Change control command to switch on . <div> <div>15</div> <div>Control word</div> <div>0</div> <div>000000000000000111</div> </div>	<p>Device state changes to "switched on." Inverter then updates the status word.</p> <div> <div>15</div> <div>Status word</div> <div>0</div> <div>000000010000110011</div> </div> <p>Bit 0 to 3 = 1: Switched on Bit 4 = 1: "Disable voltage" command is not active. Bit 5 = 1: "Quick stop" command isn't active. Bit 9 = 1: Inverter is on remote.</p>	Line 2 of display indicates: 14:Enabled
5	<p>Specify enable operation control command, and set the three HLG bits.</p> <div> <div>15</div> <div>Control word</div> <div>0</div> <div>000000000001111111</div> </div> <p>And specify reference value as 3000 Rpm. (= 0BB8_{hex}).</p> <div> <div>15</div> <div>Ref. value</div> <div>0</div> <div>000010111011110000</div> </div>	<p>Device states changes immediately to "operation enabled."</p> <div> <div>15</div> <div>Status word</div> <div>0</div> <div>000000110001100111</div> </div> <p>Bit 0 to 3 = 1: Switched on Bit 4 = 1: "Disable voltage" command is not active. Bit 5 = 1: "Quick stop" command isn't active. Bit 9 = 1: Inverter is on remote. Bit 10 = 1: Reference value reached (Bit 10 = 0: For time for acceleration and deceleration)</p> <p>The drive runs up until the reference value. The actual speed after reaching the reference value is indicated as 2999 rpm (= 0BB7_{hex}).</p> <div> <div>15</div> <div>Actual value</div> <div>0</div> <div>000010111011101111</div> </div>	<p>Line 2 of display indicates:</p> <p>1:Clockwise</p> <p>(Divergend texts are displayed for other reference values or load states.)</p>

Profibus-DP link


10. Positioning with the fieldbus

10 POSITIONING WITH THE FIELDBUS

The control/status bits are available for positioning with the fieldbus. To utilize the function, make the following settings. **A30=0:ctrl.inter.;** **A110=E101 control bits;** **A120=E100 status bits.** For a detailed description of the bits, see chap. 8.1 of this documentation.

Important: For all control bits which are handled by the bus, set the appropriate assignment to inactive in the F parameters (BE functions).

Sample application:



In control, **the drive must be enabled with bit 6 in E101**. When bit 30 in E100 then becomes high, a process block selected with bit 8/9 in E101 can be started with edge bit 16 in E101 (> 10 msec). The active process block is indicated with bits 24/25 in E100 as long as the start signal is available. Bit 19 in E100 signals the movement of the axis, and the end of the process block can be evaluated with a positive edge on bit 1 in E100 (only when block processing > 10 msec).

With the larger PZD is used, additional parameters (e.g., E106 override, I80 actual position) can be transferred cyclically from and to the controller. For PPO types, see chapters 4.2 and 4.3.

10.1 PREFERENCE OF PROCESS BLOCK 1

If you only want to use one process block in which you continuously enter a new target, we recommend using process block 1 (J10 to J18, L10 to L12). A PKW service for these parameters receives special handling on the device. The data for process block 1 are immediately imaged on the internal posi controller. The service is not acknowledged until these internal routines have been concluded. The process block can be started immediately after PKW acknowledgment. With all others, the internal imaging takes place in the background after PKW acknowledgment. You can query when the data will become useable on the device via PZD - E100:bit 5.

10.2 SPECIAL FUNCTION OF E124 "START POSITION 1"

Writing a value with the PKW service to this parameter has the effect.

1. The value in J10 position is copied and imaged immediately for internal positioning control.
2. Process block 1 is then started with *posi.start*.
3. The PKW service is not concluded until now.

This saves having to parameterize and start process blocks separately on the controller.

11 EXPANSION OF THE INVERTER TO I/O MODULE FOR FIELDBUS

When the inverter is controlled via fieldbus, the inputs of the terminals may not be needed for operation of the inverter. These inputs can then be read for other purposes via the fieldbus. Communication objects E10 and E11 can be used to measure the analog input level. E12, E13 or E19 can be used for the binary inputs (several binary inputs are shown here as individual bits). In E12 and E13, bit 5 of the least significant byte contains the current level of "input enable." Bit 4 indicates BE1, ..., and bit 0 shows BE5. In E19, these inputs and additional inputs are indicated by the option board in a different order. Bit 0 contains the level of "input enable," bit 1 contains the level of BE1, and so on.

If the inverter does not need the outputs for relay 2, analog output and BA1 to generate signals on the device (e.g., brake or analog speed indication), these outputs can be controlled with the fieldbus for other purposes. The applicable parameters which describe the function of the outputs must then be set to "0:inactive" in both parameter sets.

For example, if parameter F00 (relay 2 function) is set to "0:inactive," the relay can be circuited from the fieldbus with E111 (1 = make contact). The same procedure can be used with F20 and E110 for the analog output and with F80 and E112 (BA1) on the SEA 4000 option board.

Additional binary outputs can be addressed with E112 (BA1), E114 (BA4), E115 (BA5), E116 (BA6), E117 (BA7).

Profibus-DP link

11. Expansion of the inverter to I/O module for fieldbus


11.1 USING ALL THE AE1/AE2 FUNCTIONS VIA PROFIBUS-DP

F20 and **F25** can be used to execute one of several functions with analog inputs 1 and 2. The fieldbus also permits direct access to all available selections which are not selected under **F20** and **F25**.

Selection of AE1/AE2 Function	Parameter via PROFIBUS-DP	Remarks
0: inactive	-	
1: additional RV	E104 additional reference value	
2: torque-limit	E102 torque limit	
3: power-limit (for FDS) 3: inactive (for SDS)	E103 power limit	
4: RV-factor	E105 multiplication ref. value	
5: Override	E106 Posi.override	
6: Posi.offset	E107 Posi. offset	
7: mind.diameter	E108 Winding meas. diameter	
8: M-rot. magnet (for FDS) 8:inactive (for SDS)	E109 M-max. rotating magnet	
9: n-Max	E126 n-Max	
10: reference value	E119 reference value	
11: PID-reference	E121 PID reference	
12: winder-roller	E122 winder roller	
13: sync.offset	E123 sync. offset	
14: sync. n-RV	E125 synchronous n-ref. value	
-	E110 analog output	When F40/F45 = "0:inactive," the level of analog outputs 1 and 2 can be specified directly via the bus. $\pm 10 \text{ V} = \pm 100\% = \pm 8192_{\text{dec}} = 2000_{\text{hex}}$
-	E118 analog output 2	
-	E120 tension reduction	

While only up to two variables can be controlled with the analog inputs, all variables (**E104** to **F120**) are available simultaneously with the fieldbus.

11.2 USING THE KEYS AND DISPLAY VIA PROFIBUS-DP



When parameterization, control and diagnosis are completely handled via the fieldbus, the keys and the display of the FDS and Controlbox are no longer needed. In such cases, these resources can be used with the fieldbus like an operator panel. The currently pressed key can be read with parameter **A142** (key code). The text on the display can be read from the device as ASCII characters (one character in each byte) with parameters **A140** and **A141** and then written from the fieldbus to the display when **A143** (display source) changes to "1:external."

! If **A143** (display source) was changed to "1:external," faults, warnings and messages can no longer be indicated. This task must then be handled by the controller! The device only sets parameter **A143** to "0:internal" when the device is turned on.

A142 (key code) can only recognize one pressed key (approx. 100 msec). The relationship between pressed key and read number is: 0 = no key, 1 = , 2 = , 3 = , 4 = , 5 = , 6 = , 7=F1, 8=F2, 9=F3, 10=F4, 11= key, 12= key (green), 13= key (red).

Profibus-DP link

12. Fault diagnosis


12 FAULT DIAGNOSIS

12.1 HAS A FAULT OCCURRED?

If bit 3 of **E46** (status word) equals 1, the inverter is in "fault" status. The status word can be read via process process data or via PKW communication.

Example of PKW job and response for reading **E46** (status word):

PNU = 1080_{dec} = 438_{hex}
Subindex = 46_{dec} = 2E_{hex}




12.2 WHICH FAULT HAS OCCURRED?

The inverter store the last 10 faults (type/time) in **E40** (fault type) and **E41** (fault time). They are stored in the sequence in which they occur. Fault 1 = latest fault is located in PNU 1080, fault 2 in PNU 1081, and so on.

When a fault occurs, the current type of fault is determined with **E40** (faultType1), and the fault time is determined with **E41** (faultTime1).

Example of PKW job and response for reading **E40** (faultType1):

PNU = 1080_{dec} = 438_{hex}
Subindex = 40_{dec} = 28_{hex}



The following table can then be used to determine the type of fault. For detailed explanations, see the device documentation.

31:short/ground.	36:high voltage	42:tempBrakeRes	47:device overl.	52:communication
32:short/gr.int.	38:tempDev.Sens	43:RV wire brk	48:accel. overl.	53:stop input
33:overcurrent	39:tempDev. i2t	44:ext.fault	49:decel. overl.	54:follow.error
34:hardw.fault	40:invalid data	45:oTempMot.i2t	50:operat.area	55:optionBoard
35:watchdog	41:temp.motorTMP	46:low voltage	51:refused	56:overspeed

As you can see, this is an example of the fault "41:temp.motorTMP."


12.3 READING E41 (FAULT TIME 1)

This indication can be used to read the operation time at which the last fault occurred. The value is coded in a 4-byte value in hours, minutes and seconds.

Example of a PKW job and

response for reading **E41** (faultTime1):

PNU = 1080_{dec} = 438_{hex}
Subindex = 41_{dec} = 29_{hex}



12.4 ACKNOWLEDGING A FAULT VIA FIELDBUS

The reason for the fault must be corrected before a fault can be acknowledged (e.g., for "temp.motorTMP" let motor cool off). An acknowledgment only takes place at the rising edge (i.e., when the bit changes from 0 to 1) so the bit must be set to 0 first. Although there are several ways to perform acknowledgments, all methods are not permitted by all settings.

- **Change in state (0 → 1) of bit 7 (reset fault) in E45 (control word)**

Operation input **A30** must be set to "3:Profibus-DP" otherwise the control word has no effect.

- **Change in state (0 → 1) of bit 3 (acknowledgment) of the parameter E101 (control bits)**

No binary input (parameter **F31** ... **F35** / with option board **F60** ... **F64**) may be set to "13:faultReset" since the binary inputs always take precedence over **E101** control signals.

- **Change in state (0 → 1) of bit 6 (additional enable) of the parameter E101 (control bits)**

No binary input (parameter **F31** ... **F35** / with option board **F60** ... **F64**) may be set to "7:addit.enable" since the binary inputs always take precedence over **E101** control signals. The enable on the inverter must be turned on or jumpered since it is AND-linked to the additional enable.

When **E45** or **E101** was imaged on process data (**A110** ...), these values must also be specified via PZD. Changes via PKW are disregarded.

Profibus-DP link

13. Process data monitoring

12.5 DIAGNOSTIC TELEGRAM

The bus master automatically manages the diagnostic telegram as part of the PROFIBUS system. The host system (e.g., the PLC) does not have to transmit this telegram. On the PLC, the address area for the I/O contains an area for the diagnostic information of the DP slaves. When a message appears here, this can be used to trigger an alarm on the PLC, for instance, or the cause of the fault can be read via PKW communication.

The **POSIDYN®** SDS 4000 with the SDP 4000 option supports a device-specific expansion of the diagnostic telegram defined by the PROFIBUS standard. Not only is the fact that a diagnosis occurred transferred but also the cause of the diagnosis in two additional bytes.

Byte 1: Value = 0

Byte 2: Value = 1: The inverter is in status "fault" or "fault reaction active."

Value = 0: The inverter is not in "fault" status.

E41 (faultType 1) must also be read to determine the exact cause of the fault on the inverter.

13 PROCESS DATA MONITORING

Process data monitoring should be activated to prevent the inverter from continuing with the last received reference values if PROFIBUS or the PROFIBUS master fails. The Kommubox/option board monitors the receipt of user data telegrams (see PPO type 1) sent cyclically by the PROFIBUS master during normal operation. Parameter **A109** (proc.output control time) is used to activate this monitoring routine.

A time between 1⁽¹⁾ or 100⁽²⁾ msec and 65534 msec is set here. The default setting is 65535. This value also means that monitoring is inactive. This setting is recommended when commissioning the inverter on PROFIBUS and for service and maintenance work. Monitoring should only be activated during the running process when a bus master is cyclically sending process data to the inverter. The monitoring time must be adapted to the maximum total cycle time on PROFIBUS plus a sufficient reserve for possible delays.

If process data monitoring is triggered on the inverter and parameter **A30** (operation input) is set to "2:fieldbus" (FAS/FDS) or to "3:profibus-DP" (SDS), the fault "52:communication" is triggered.


The PROFIBUS system itself offers a similar protection routine - trigger monitoring.

Every configuration of a PROFIBUS system contains the time for trigger monitoring. If a slave does not receive a telegram during this time, all user-data output bytes (data to the inverter) are set to 0. If the assignment of the process data is changed to the point that **E45** (control word) is no longer transferred as process data to the device, trigger monitoring is unable to turn off the drive.

If this happens, it is essential that parameter **A109** (proc.output control time) be used.

⁽¹⁾ SDS

⁽²⁾ FAS/FDS



14 PARAMETER LIST

14.1 EXPLANATION OF THE TABLES

The following tables are the directory of all communication objects. Most of the parameters, displays and actions which can be edited with the menu of the device are also available with PROFIBUS. The only parameters which cannot be accessed with PROFIBUS are those parameters which directly affect the menu and those actions which can only be executed directly on the device.

The parameter number and subindex for the access via PROFIBUS are easy to determine from the coordinates of the particular parameter in the menu of the inverter. The following rules apply.

PNU = 1000 + 20 * letter of the menu coordinate + 500 for parameter set 2
Subindex = Number value of the menu coordinate

There is an appropriate menu on the FDS or SDS for all coordinates between 00 and 99. Only the coordinates above 99 are no longer included in the inverter's menu. These parameters can be disregarded for devices without fieldbus coupling.

The parameters from groups **B to G** are present once in parameter set 1 and then again in parameter set 2. The menu has only one coordinate for this. Parameter numbers for the parameters from parameter set 1 (between 1000 and 1499) and for parameter set 2 (starting with 1500) were selected for access via PROFIBUS access.

Column	Meaning
PNU	These two pieces of information uniquely identify each communication object via PROFIBUS.
Subindex	
Coordinate	This information defines the object as a known parameter or display of the inverter. For details, see the device documentation.
Name	

Profibus-DP link

14. Parameter list

Column	Meaning
Value range	Contains the valid range. It is given as the "lower limit" to "upper limit" or is separated by commas for list types. If the value cannot be changed, only one value is given. Letters enclosed in quotation marks are listed for strings. Consecutive strings are shown for individual objects which have the same index but a different subindex. These subareas of strings contain 4 ASCII characters.
Scaling/unit	The unit and scaling with the resolution of the parameter is shown here. A blank column indicates a selection parameter and not a number. For the meaning of the choices, see the applicable documentation (FAS, publ. no. 441581; FDS, publ. no. 441408; SDS, publ. no. 441449).
Access	Specifies the PROFIBUS access rights separately for the devices (FAS, FDS or SDS). r Read access permitted rw Read and write access permitted rs Read access and setting (write access) of value 1 permitted (only for actions)
Rounding	If rounding errors can occur when converting scaling between the representation type of the object on PROFIBUS and the internal resolution on the device, the possible rounding error is given here.

14.2 SWITCHABLE SCALING

The representation of the value (scaling) can be switched on PROFIBUS for some parameters and displays. Parameter **A100** (scaling deviceintern) can be used for this (earlier: speed scaling).

Selection *0:standard*: Values are transferred as shown in the table (e.g., speed in rpm).
 Selection *1:device raw*: Values are transferred in internal-device scaling via PROFIBUS. This achieves the full resolution of the internal parameters and saves computing time for rescaling.

Auxiliary scaling variables (other parameters) are read (when Kommubox starts) from the FAS/FDS to Kommubox for the rescaling of certain parameters/displays on the PROFIBUS unit. If these parameters are changed by another unit than PROFIBUS (with menu of FAS/FDS or with FDS Tool), they are no longer current in Kommubox and some parameters/displays can no longer be converted correctly. The following list shows the parameters/displays which have auxiliary scaling variables. With such parameters/displays, these auxiliary scaling variables should be read first via PROFIBUS before the related parameters/displays are accessed (not necessary with SDS).

Parameter/Display	Scaling for A100=0	Scaling for A100=1	Auxiliary Scaling Variable (for A100=0)
All speeds except group E..	rpm	FAS/FDS: $\pm 32768 = \pm 400\text{Hz}$ SDS: rpm	FAS/FDS: B10 Number of poles of the applicable parameter set
Speeds from group E..	rpm	FAS/FDS: $\pm 32768 = \pm 400\text{Hz}$ SDS: rpm	FAS/FDS: B10 Number of poles from active param. set SDS: 0.25 rpm
E01 P-motor	0.01 kW	Same as A100=0	FAS/FDS: B11 P-nominal from parameter set 1 SDS: B11 P-nominal from active parameter set
E02 M-motor	0.01 Nm	Same as A100=0	FAS/FDS: B11 and B13 n-nominal from param. set 1 SDS: B11 and B13 n-nominal from active param. set
E09 rotor position	0.001 U	Motor increments	E84, B26, C60, F36, H20, H22, H41, G27, I02
G29 synchron difference	°	Motor increments	E84, B26, C60, F36, H20, H22, H41, G27, I02
I80, I81, I84, I88 (all posi actual values)	Posi unit without positions after decimal point I05 * 10°I06	Posi increments	E84, B26, C60, F36, H20, H22, H41, G27, I02

14.3 PROFIDRIVE PARAMETERS

Parameter numbers 900 to 999 are permanently defined in the profile for adjustable-speed PROFIDRIVE drives. The following table shows the parameters which **POSIDRIVE**® FAS 4000, **POSIDRIVE**® FDS 4000 and **POSIDYN**® SDS 4000 with PROFIBUS-DP link support in conformance with the profile. These parameters can also be addressed under other parameter numbers in the vendor-specific area (1 to 899, 1000, ... 1999).

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Rounding
						FAS	FDS	SDS	
918	0	A83	Station address	0 to 125		rw	rw	rw	
919	0	E55	Device system no.	0 to 65535		rw	rw	rw	
928	0	A30	Operation input	FAS/FDS: 0 to 2 SDS: 0 to 4		rw	rw	rw	
963	0	A84	Current baud rate	0 to 10		r	r	r	
967	0	E45	Control word	0000 to FFFF _{hex}		rw	rw	rw	
968	0	E46	Status word	0000 to FFFF _{hex}		r	r	r	
970	0	A04	Load parameter set	0 to 1 (set 1 for start)		rs	rs	rs	
971	0	A00	Store in non-vol. memory	0 to 1 (set 1 for start)		rs	rs	rs	

Profibus-DP link

14. Parameter list

14.4 PARAMETERS FROM GROUPS A.. (INVERTER) TO Z.. (FAULT MEMORY)

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1000	0	A00	start save parameter	0 to 1 (set 1 for start)		rs	rs	rs	
1000	0	A00	result save parameter	0 to 1 (set 1 for start)		rs	rs	rs	
1000	2	A02	start check parameter	0 to 1 (set 1 for start)		rs	rs	rs	
1000	2	A02	result check parameter	0 to 1 (set 1 for start)		rs	rs	rs	
1000	4	A04	start default settings	0 to 1 (set 1 for start)		rs	rs	rs	
1000	4	A04	result default settings	0 to 1 (set 1 for start)		rs	rs	rs	
1000	5	A05	load saved parameters	0 to 1		rs	rs	rs	
1000	5	A05	result load saved parameters	0 to 1		rs	rs	rs	
1000	10	A10	menu level	0 to 2		rw	rw	rw	
1000	12	A12	language	0 to 1		rw	rw	rw	
1000	15	A15	auto-return	0 to 1		rw	rw	rw	
1000	20	A20	braking resistor type	FAS: 0 to 5 (type-dep.) FDS: 0 to 7 (type-dep.) SDS: 19 to 26 (type-dep.)		rw	rw	rw	
1000	21	A21	braking resistor resist.	FAS: 100 to 600 (type-d.) FDS: 30 .. 600 (type-dep.) SDS: 10 to 600 (type-dep.)	0.1 Ohm	rw	rw	rw	
1000	22	A22	braking resistor rating	FAS/FDS: 0 to 3000 (type-d.) SDS: 0 to 600 (type-dep.)	10 W	rw	rw	rw	
1000	23	A23	braking resistor therm.	1 to 1000	0.01 sec	rw	rw	rw	
1000	30	A30	operation input	FAS/FDS: 0 to 2 SDS: 0 to 4		rw	rw	rw	
1000	31	A31	Esc-reset	0 to 1		rw	rw	rw	
1000	32	A32	auto-reset	0 to 1		rw	rw	rw	
1000	33	A33	time auto-reset	1 to 255	min	rw	rw	rw	
1000	34	A34	auto-start	0 to 1		rw	rw	rw	
1000	35	A35	low voltage limit	1500 to 5700 (type-dep.)	0.1 V DC	rw	rw	rw	
1000	36	A36	mains voltage	FAS/FDS: 1~: 1400 to 2500 3~: 2200 to 4800 SDS: 1400 to 4800	0.1 V eff.	rw	rw	rw	-2
1000	37	A37	reset memorized values	0 to 1 (set 1 for start)		rs	rs	rs	
1000	37	A37	result reset memorized values	0 to 1 (set 1 for start)		rs	rs	rs	
1000	38	A38	DC power-input	0 to 1		-	-	rw	
1000	41	A41	select parameter set	0 to 2		rw	rw	rw	
1000	42	A42	copy parameter set 1>2	0 to 1 (set 1 for start)		rs	rs	rs	
1000	42	A42	result copy parameter set 1>2	0 to 1 (set 1 for start)		rs	rs	rs	
1000	43	A43	copy parameter set 2>1	0 to 1 (set 1 for start)		rs	rs	rs	
1000	43	A43	result copy parameter set 2>1	0 to 1 (set 1 for start)		rs	rs	rs	
1000	51	A51	tip reference value	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	rw	rw	rw	
1000	55	A55	key hand function	0 to 1		rw	rw	rw	
1000	82	A82	CAN-baudrate	0 to 8		rw	rw	rw	
1000	80	A80	Serial address	0 to 31		rw	rw	rw	
1000	83	A83	busaddress	0 to 125		rw	rw	rw	
1000	84	A84	profibus baudrate	0 to 10		r	r	r	
1000	100	A100	scaling deviceintern	0 to 1		rw	rw	rw	
1000	108	A108	emergencyservice	0 to 1		rw	rw	rw	
1000	109	A109	proc.output control time	FAS/FDS: 100 to 65535 SDS: 1 to 65535	msec	rw	rw	rw	
1000	110	A110	process output data 0	70790400 (E45), ...		rw	rw	rw	
1000	111	A111	process output data 1	70790912 (E47), ...		rw	rw	rw	
1000	112	A112	process output data 2	70790400 (E45), ...		rw	rw	rw	
1000	113	A113	process output data 3	70790912 (E47), ...		rw	rw	rw	
1000	114	A114	Can process output data 0	70790400 (E45), ...		-	-	rw	
1000	115	A115	Can process output data 1	70790912 (E47), ...		-	-	rw	
1000	116	A116	Can process output data 2	70790400 (E45), ...		-	-	rw	
1000	117	A117	Can process output data 3	70790912 (E47), ...		-	-	rw	
1000	119	A119	proc.output data enable	0 to 1		rw	rw	rw	

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1000	120	A120	process input data 0	70790656 (E46), ...		rw	rw	rw	
1000	121	A121	process input data 1	70780928 (E08), ...		rw	rw	rw	
1000	122	A122	process input data 2	70790656 (E46), ...		rw	rw	rw	
1000	123	A123	process input data 3	70780928 (E08), ...		rw	rw	rw	
1000	124	A124	Can process input data 0	70790656 (E46), ...		-	-	rw	
1000	125	A125	Can process input data 1	70780928 (E08), ...		-	-	rw	
1000	126	A126	Can process input data 2	70790656 (E46), ...		-	-	rw	
1000	127	A127	Can process input data 3	70780928 (E08), ...		-	-	rw	
1000	130	A130	proc. out. length	0 to 12		r	r	r	
1000	131	A131	Can proc. out. length	0 to 12		-	-	r	
1000	132	A132	proc. in. length	0 to 12		r	r	r	
1000	133	A133	Can proc. in. length	0 to 12		-	-	r	
1000	140	A140	Displayline0 B0-3	„1“		rw	rw	rw	
1001	140	A140	Displayline0 B4-7	„23. „		-	-	-	
1002	140	A140	Displayline0 B8-11	„rpm „		-	-	-	
1003	140	A140	Displayline0 B12-15	„1.2A „		-	-	-	
1000	141	A141	Displayline1 B0-3	„1:Vo“		rw	rw	rw	
1001	141	A141	Displayline1 B4-7	„rwr“		-	-	-	
1002	141	A141	Displayline1 B8-11	„ts “		-	-	-	
1003	141	A141	Displayline1 B12-15	„ “		-	-	-	
1000	142	A142	key code	0 to 6		rw	rw	rw	
1000	143	A143	Display source	0 to 1		rw	rw	rw	

Note on using actions (e.g., **A00** store values):

To start actions, value 1 is written to the object with subindex 0. The PROFIBUS master must then continue to read this object and wait until the value 0 is read again. This concludes the action. Subindex 1 can now be used to query the result of the last executed action. The result of the last executed action is always returned by the inverter even when another action was started directly.

The result must, therefore, be evaluated directly after the action started via PROFIBUS is concluded. For the meaning of the values of the result of the action, see result table of the device documentation (publ. no.: FAS 4000 = 441581, FDS 4000 = 441408, SDS 4000 = 441449).

PNU(s) Pset 1/2		Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
							FAS	FDS	SDS	
1020	1520	0	B00	motor-type	FAS: 0 to 26 (type-dep.) FDS: 0 to 29 (type-dep.) SDS: 60 to 69 (type-dep.)		rw	rw	rw	
1020	1520	2	B02	EMC-constant	200 to 2500	0.1 V / 1000 rpm	-	-	rw	
1020	1520	3	B03	Motor fan	0 to 1		-	-	rw	
1020	1520	10	B10	poles	2, 4, to 16		rw	rw	rw	-1
1020	1520	11	B11	P-nominal	FAS: 12 to 1100 (type-d.) FDS: 12 to 2500 (type-d.) SDS: 12 to 4500 (type-d.)	10 W	rw	rw	rw	
1020	1520	12	B12	I-nominal	FAS: 0 to 2000 (type-d.) FDS: 0 to 4400 (type-d.) SDS: 0 to 16000 (type-d.)	10 mA	rw	rw	rw	
1020	1520	13	B13	n-nominal	FAS/FDS: 0 to 12000 SDS: 0 to 6000	rpm ¹	rw	rw	rw	
1020	1520	14	B14	V-nominal	0 to 4800 (type-dep.)	0.1 V eff	rw	rw	-	-2
1020	1520	15	B15	f-nominal	819 to 27034	8192 = 100Hz	rw	rw	-	
1020	1520	16	B16	cos PHI	50 to 100	%	rw	rw	-	
1020	1520	17	B17	M0 (standstill)	0 to 32767	0.01 Nm	-	-	rw	
1020	1520	20	B20	control mode	FAS/FDS: 0 to 2 SDS: 0 to 3		rw	rw	-	
1020	1520	21	B21	V/f-characteristic	0 to 1		rw	rw	-	
1020	1520	22	B22	V/f-gain	7373 to 9011	8192 = 100%	rw	rw	-	
1020	1520	23	B23	boost	0 to 32767	8192 = 100%	rw	rw	-	
1020	1520	24	B24	switching frequency	4, 6, 8, 10, 12, 14, 16	kHz	rw	rw	-	-1
1020	1520	25	B25	halt flux	FAS/FDS: 1 to 4		rw	rw	-	
1020	1520	26	B26	motor-encoder	FAS: 0 FDS: 0 to 1 SDS: 2 to 3		rw	rw	rw	

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU(s) Pset 1/2		Sub- index	Coor- dinate	Name	Value range	Scaling / measure unit	Access			Round- ing
							FAS	FDS	SDS	
1020	1520	27	B27	time halt flux	0 to 255	sec	rw	rw	-	
1020	1520	30	B30	addit.motor-operation	0 to 1		rw	rw	-	
1020	1520	31	B31	oscillation damping	FAS/FDS: 0 to 100		rw	rw	-	
1020	1520	32	B32	SLVC-dynamics	0 to 100	%	rw	rw	-	
1020	1520	51	B51	J-motor	1 to 32767	1E-6 kgm ²	-	-	rw	
1020	1520	52	B52	L-motor	1 to 32767	10 µH	-	-	rw	
1020	1520	53	B53	R1-motor	1 to 32767	0.01 Ohm	rw	rw	rw	
1020	1520	60	B60	X1S-motor	1 to 32767	0.01 Ohm	rw	rw	-	
1020	1520	61	B61	therm-motor	1 to 32767	sec	rw	rw	-	
1020	1520	62	B62	TB-motor	1 to 255	msec	rw	rw	-	
1020	1520	63	B63	Mbreakdown / Mnom.	1 to 255	0.1	rw	rw	-	
1020	1520	64	B64	Ki-IQ (moment)	0 to 32767	8192 = 100%	rw	rw	rw	
1020	1520	65	B65	Kp-IQ (moment)	0 to 32767	8192 = 100%	rw	rw	rw	
1020	1520	66	B66	Ki-ID (flux)	0 to 32767	8192 = 100%	rw	rw	-	
1020	1520	67	B67	Kp-ID (flux)	0 to 32767	8192 = 100%	rw	rw	-	

PNU(s) Pset 1/2		sub- index	coor- dinate	name	value range	scaling / measure unit	access			Round ing
							FAS	FDS	SDS	
1040	1540	0	C00	n-Min	0 to C01	rpm ¹	rw	rw	rw	
1040	1540	1	C01	n-Max	FAS/FDS: C01 to 12000 SDS: C01 to 6000	rpm ¹	rw	rw	rw	
1040	1540	2	C02	perm.direction of rotat.	0 to 2		rw	rw	rw	
1040	1540	3	C03	M-Max 1	0 to C04	8192 = 100%	rw	rw	rw	
1040	1540	4	C04	M-Max 2	C03 to 32767	8192 = 100%	rw	rw	rw	
1040	1540	10	C10	skip speed 1	0 to 12000	rpm ¹	rw	rw	-	
1040	1540	11	C11	skip speed 2	0 to 12000	rpm ¹	rw	rw	-	
1040	1540	12	C12	skip speed 3	0 to 12000	rpm ¹	rw	rw	-	
1040	1540	13	C13	skip speed 4	0 to 12000	rpm ¹	rw	rw	-	
1040	1540	20	C20	startup mode	0 to 3		rw	rw	-	
1040	1540	21	C21	M-load start	0 to 32767	8192 = 100%	rw	rw	-	
1040	1540	22	C22	t-load start	0 to 99	0.1 sec	rw	rw	-	
1040	1540	30	C30	J-mach/J-motor	0 to 10000	0.1	rw	rw	rw	
1040	1540	31	C31	n-controller Kp	0 to 32767	8192 = 100%	rw	rw	rw	
1040	1540	32	C32	n-controller Ki	0 to 32767	8192 = 100%	rw	rw	rw	
1040	1540	33	C33	n-reference value lowpass	0 to 32767	0.1 msec	-	-	rw	
1040	1540	34	C34	n-motor lowpass	5 to 32767	0.1 msec	-	-	rw	
1040	1540	35	C35	n-control. Kp standstill	5 to 255	1%	rw	rw	rw	
1040	1540	40	C40	n-window	0 to 300	rpm ¹	rw	rw	rw	
1040	1540	41	C41	operating range n-Min.	0 to C42	rpm ¹	rw	rw	rw	
1040	1540	42	C42	operating range n-Max.	FAS/FDS: C41 to 12000 SDS: C41 to 6000	rpm ¹	rw	rw	rw	
1040	1540	43	C43	operating range M-Min.	0 to C44	8192 = 100%	rw	rw	rw	
1040	1540	44	C44	operating range M-Max.	C43 to 32767	8192 = 100%	rw	rw	rw	
1040	1540	45	C45	operating range X-Min.	0 to C46	8192 = 100%	rw	rw	rw	
1040	1540	46	C46	operating range X-Max.	-32768 to C46	8192 = 100%	rw	rw	rw	
1040	1540	47	C47	operat. range C45/C46	0 to 12		rw	rw	rw	
1040	1540	48	C48	operat. range C47abs	0 to 1		rw	rw	rw	
1040	1540	49	C49	operat. range accel&ena	0 to 1		rw	rw	rw	
1040	1540	50	C50	display function	0 to 4		rw	rw	rw	
1040	1540	51	C51	display factor	- 10000000 to 10000000	0.0001	rw	rw	rw	
1040	1540	52	C52	display decimals	0 to 5		rw	rw	rw	
1040	1540	53	C53	display text	„xxxx“ (4 Zeichen)		rw	rw	rw	
1040	1540	60	C60	run mode	FAS/FDS: 1 to 2 SDS: 0 to 2		rw	rw	rw	

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU(s) Pset 1/2		Sub- index	Coord- inate	Name	Value range	Scaling / measure unit	Access			Round ing
							FAS	FDS	SDS	
1060	1560	0	D00	reference value accel	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	1	D01	reference value decel	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	2	D02	speed (max.ref.value)	FAS/FDS: 0 to 12000 SDS: 0 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	3	D03	reference value-Max.	D05 to 8191	8192 = 100%	rw	rw	rw	
1060	1560	4	D04	speed (min.ref.value)	FAS/FDS: 0 to 12000 SDS: 0 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	5	D05	reference value-Min.	0 to D03	8192 = 100%	rw	rw	rw	
1060	1560	6	D06	reference value offset	-8192 to 8181	8192 = 100%	rw	rw	rw	
1060	1560	7	D07	reference value enable	0 to 1		rw	rw	rw	
1060	1560	8	D08	monitor reference value	0 to 1		rw	rw	rw	
1060	1560	9	D09	fix reference value no.	0 to 7		rw	rw	rw	
1060	1560	10	D10	accel 1	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	11	D11	decel 1	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	12	D12	fix reference value 1	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	20	D20	accel 2	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	21	D21	decel 2	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	22	D22	fix reference value 2	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	30	D30	accel 3	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	31	D31	decel 3	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	32	D32	fix reference value 3	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	40	D40	accel 4	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	41	D41	decel 4	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	42	D42	fix reference value 4	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	50	D50	accel 5	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	51	D51	decel 5	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	52	D52	fix reference value 5	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	60	D60	accel 6	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	61	D61	decel 6	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	62	D62	fix reference value 6	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	70	D70	accel 7	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	71	D71	decel 7	FAS/FDS: 0 to 30000*D98 SDS: 0 to 30000	0.1 sec / 150 Hz 1 msec/3000 rpm	rw	rw	rw	
1060	1560	72	D72	fix reference value 7	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹ rpm	rw	rw	rw	
1060	1560	80	D80	ramp shape	0 to 1		rw	rw	-	
1060	1560	81	D81	decel-quick	1 to 30000	0.1 sec/150Hz	rw	rw	rw	
1060	1560	90	D90	reference value source	0 to 2		rw	rw	rw	

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU(s) Pset 1/2	Sub- index	Coor- dinate	Name	Value range	Scaling / measure unit	Access			Round- ing
						FAS	FDS	SDS	
1060	1560	91	D91	motorpoti function	0 to 1		rw	rw	rw
1060	1560	92	D92	negate reference value	0 to 1		rw	rw	rw
1060	1560	93	D93	RV-generator	0 to 1		rw	rw	rw
1060	1560	94	D94	ref. val. generator time	0 to 32767	msec	rw	rw	rw
1060	1560	98	D98	Ramp factor	0=1; -1=0.1; 2=0.01		rw	rw	-
1060	1560	99	D99	fast reference value	0 to 1		-	-	rw

PNU	Sub- index	Coor- dinate	Name	Value range	Scaling / measure unit	Access			Round- ing
						FAS	FDS	SDS	
1080	0	E00	I-motor	0 to 32767	0.1 A	r	r	r	-1
1080	1	E01	P-motor	-32768 to 32767	0.01 kW	r	r	r	-1
1080	2	E02	M-motor (fast)	-32768 to 32767	0.01 Nm	r	r	r	-2
1580	2	E02	M-Motor (smoothed)	-32768 to 32767	0.01 Nm	r	r	r	-2
1080	3	E03	DC-link-voltage	0 to 32767	0.1 V=	r	r	r	
1080	4	E04	V-motor	0 to 32767	0.1 V eff	r	r	-	-2
1080	5	E05	f1-motor	-16384 to 16383	8192 = 100 Hz	r	r	-	
1080	6	E06	n-reference value	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	r	r	r	
1080	7	E07	n-post-ramp	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	r	r	r	
1080	8	E08	n-motor (fast)	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	r	r	r	
1580	8	E08	n-motor (smoothed)	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	r	r	r	
1080	9	E09	rotor position	-2147483647 to 2147483647	0.001 r	r	r	r	-1
1080	10	E10	AE1-level	-8192 to 8191	8192 = 100%	r	r	r	
1080	11	E11	AE2-level	-8192 to 8191	8192 = 100%	-	r	r	
1080	12	E12	ENA-BE1-BE2-level	0 to 63		r	r	-	
1080	13	E13	BE3-BE4-BE5-level	0 to 63		r	r	-	
1080	14	E14	BE5-frequence ref.value	0 to 32767	8192 = 100%	r	r	-	
1080	15	E15	n-encoder	-12000 to 12000	rpm ¹	r	r	-	
1080	16	E16	analog-output1-level	0 to 32767	8192 = 100%	-	r	r	
1080	17	E17	relay 1	0 to 1		r	r	r	
1080	18	E18	BA2	0 to 1		-	-	r	
1080	18	E18	relay 2	0 to 1		r	r	-	
1080	19	E19	BE15...BE1 & enable	0 to 65535	one Bit for every BE	r	r	r	
1080	20	E20	device utilization	0 to 32767	8192 = 100%	r	r	r	
1080	21	E21	motor utilization	0 to 32767	8192 = 100%	r	r	r	
1080	22	E22	i2t-device	0 to 105	%	r	r	r	
1080	23	E23	i2t-motor	0 to 100	%	r	r	r	
1080	24	E24	i2t-braking resistor	0 to 100	%	r	r	r	
1080	25	E25	device temperature	-128 to 127	°C	r	r	r	
1080	26	E26	binary output 1	0 to 1		r	r	r	
1080	27	E27	BA15...BA1 & Relais1	0000 to FFFF _{hex}	one Bit for every BA	r	r	r	
1080	28	E28	analog-output2-level	0 to 32767	8192 = 100%	-	-	r	
1080	29	E29	n-ref. value raw	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	r	r	r	
1080	30	E30	run time	0 to FFFF3B3B _{hex}	h/min/sec	r	r	r	
1080	31	E31	enable time	0 to FFFF3B3B _{hex}	h/min/sec	r	r	r	
1080	32	E32	energy counter	0 to FFFFFFFF _{hex}	Wh	r	r	r	
1080	33	E33	Vi-max-memorized value	0 to 32767	0.1 V DC	r	r	r	
1080	34	E34	I-max-memorized value	0 to 32767	0.1 A	r	r	r	-1
1080	35	E35	Tmin-memorized value	-128 to 127	°C	r	r	r	
1080	36	E36	Tmax-memorized value	-128 to 127	°C	r	r	r	
1080	37	E37	Pmin-memorized value	-32768 to 32767	0.01 kW	r	r	r	
1080	38	E38	Pmax-memorized value	-32768 to 32767	0.01 kW	r	r	r	

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1080 ... 1089	40	E40	fault type fault 1, - 2, -3, to fault type fault 10	0, 31 to 56		r	r	r	
1080 ... 1089	41	E41	fault time fault 1, -2, -3, to fault time fault 10	0 to FFFF3B3B _{hex}	h/min/sec	r	r	r	
1080	45	E45	control word	0000 to FFFF _{hex}		rw	rw	rw	
1080	46	E46	status word	0000 to FFFF _{hex}		r	r	r	
1080	47	E47	n-field-bus	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	rw	rw	rw	
1080	50	E50	device byte 0 to 3 of the String	„FDS“		r	r	r	
1081	50	E50	device byte 4 to 7 of the String	„402“		r	r	r	
1082	50	E50	device byte 8 to 11 of the String	„4/B“		r	r	r	
1083	50	E50	device byte 12 to 15 of the String	„ „		r	r	r	
1080	51	E51	softw.-vers. b. 0 to 3 of the String	„V 4.“		r	r	r	
1081	51	E51	softw.-vers. b. 4 to 7 of the String	„5 „		r	r	r	
1082	51	E51	softw.-vers. b. 8-11 of the String	„ „		r	r	r	
1083	51	E51	softw.-vers. b. 12-15 of the String	„ „		r	r	r	
1080	52	E52	device-number	8000000 ...		r	r	r	
1080	53	E53	variant-number	xxxxxxx		r	r	r	
1080	54	E54	option-board	0, 1, 2, ...		r	r	r	
1080	55	E55	identity-number	0 to 65535		rw	rw	rw	
1080	56	E56	parameter set ident.1	0 to 255		rw	rw	rw	
1080	57	E57	parameter set ident.2	0 to 255		rw	rw	rw	
1080	58	E58	Kommubox b. 0-3 of the String	„KBX“		r	r	-	
1081	58	E58	Kommubox b. 4-7 of the String	„PRO“		r	r	-	
1082	58	E58	Kommubox b. 8-11 of the String	„FI V“		r	r	-	
1083	58	E58	Kommubox b. 12-15 of the String	„4.5“		r	r	-	
1080	59	E59	FAS with Posi-Upgrade	0 to 2		r	-	-	
1080	60	E60	reference value selector	FAS/FDS: 0 to 7 SDS: 0 to 31		r	r	r	
1080	61	E61	additional ref.value	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	r	r	r	
1080	62	E62	actual M-Max	-32768 to 32767	8192 = 100%	r	r	r	
1080	63	E63	PID-controller limit	0 to 1		-	r	r	
1080	64	E64	brake	0 to 1		-	-	r	
1080	65	E65	PID-error	-32768 to 32767	8192 = 100%	r	r	r	
1080	71	E71	AE1 scaled	-32767 to 32767	8192 = 100%	r	r	r	
1080	72	E72	AE2 scaled	-32767 to 32767	8192 = 100%	-	r	r	
1080	73	E73	AE2 scaled 2	-32767 to 32767	8192 = 100%	-	r	r	
1080	80	E80	operating condition	0 to 26		r	r	r	
1080	81	E81	event level	0 to 3		r	r	r	
1080	82	E82	event name	30 to 56		r	r	r	
1080	83	E83	warning time	0 to 255	sec	r	r	r	
1080	84	E84	active parameter set	1 to 2		r	r	r	
1080	85	E85	not saved	0 to 1		r	r	r	
1080	100	E100	statusbits	0 to 4294967295		r	r	r	
1080	101	E101	control bits	0 to 4294967295		rw	rw	rw	
1080	102	E102	torque-limit	-32767 to 32767	8192 = 100% M-mot-N	rw	rw	rw	
1080	103	E103	power-limit	-32767 to 32767	8192 = 100% P-mot-N	rw	rw	rw	
1080	104	E104	additional RV	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	rw	rw	rw	
1080	105	E105	RV-factor	-32767 to 32767	8192 = 100%	rw	rw	rw	
1080	106	E106	posi.override	0 to 32767	8192 = 100%	rw	rw	rw	
1080	107	E107	Posi.Offset	-2147483647 to 2147483647	105 * 10 ¹⁰⁶	rw	rw	rw	
1080	108	E108	wind. diameter	G12 to G13	mm	-	rw	rw	
1080	109	E109	M-rot.magnet	-32767 to 32767	8192 = 100%	-	rw	rw	
1080	110	E110	analog output	-32767 to 32767	8192 = 100%	-	rw	rw	
1080	111	E111	BA2	0 to 1		-	rw	rw	

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round- ing
						FAS	FDS	SDS	
1080	112	E112	BA1	0 to 1		-	rw	rw	
1080	113	E113	BA3	0 to 1		-	rw	rw	
1080	114	E114	BA4	0 to 1		-	rw	rw	
1080	115	E115	BA5	0 to 1		-	rw	rw	
1080	116	E116	BA6	0 to 1		-	-	rw	
1080	117	E117	BA7	0 to 1		-	-	rw	
1080	118	E118	analog output2	-32767 to 32767	8192 = 100%	-	rw	rw	
1080	119	E119	reference value	-32767 to 32767	8192 = 100%	rw	rw	rw	
1080	120	E120	tension reduction	0 to 8192	8192 = 100%	-	rw	rw	
1080	121	E121	PID-reference	-32767 to 32767	8192 = 100%	-	rw	rw	
1080	122	E122	winder-roller	-32767 to 32767	8192 = 100%	-	rw	rw	
1080	123	E123	sync.offset	2147483648 to -2147483647	°	-	rw	rw	-4
1080	124	E124	start position 1	-2147483647 to 2147483647	I05 * 10 ¹⁰⁶	rw	rw	rw	
1080	125	E125	synchron n-RV	FAS/FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	-	rw	rw	
1080	126	E126	n-Max	FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	rw	rw	rw	
1080	127	E127	BE-encoder-position	-32767 to 32767	Increments	r	r	r	
1080	128	E128	X20-encoder-position	-32767 to 32767	Increments	-	r	r	
1080	130	E130	Posi-Upgrade orderconf.	0 to 2147483647	Increments	r	-	-	
1080	131	E131	Posi-Next latched	-2147483648 to 2147483647	I05 * 10 ¹⁰⁶	rw	rw	rw	-2
1080	132	E132	SSI raw value	±16777215	1/4096 r	-	r	r	

PNU(s) Pset 1/2		Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round- ing
							FAS	FDS	SDS	
1100	1600	0	F00	BA2-function	0 to 31		-	-	rw	
1100	1600	0	F00	relay2-function	0 to 31		rw	rw	-	
1100	1600	1	F01	brake release	0 to 300	rpm ¹	rw	rw	-	
1100	1600	2	F02	brake set	0 to 300	rpm ¹	rw	rw	-	
1100	1600	3	F03	BA2 t-on	0, 32, to 5024	msec	-	-	rw	
1100	1600	3	F03	relay2 t-on	0, 32, to 5024		rw	rw	-	
1100	1600	4	F04	BA2 t-off	0, 32, to 5024	msec	-	-	rw	
1100	1600	4	F04	relay2 t-off	0, 32, to 5024		rw	rw	-	
1100	1600	5	F05	BA2 invert	0 to 1		-	-	rw	
1100	1600	5	F05	relay2 invert	0 to 1		rw	rw	-	
1100	1600	6	F06	t-brake release	0 to 5024	msec	rw	rw	rw	
1100	1600	7	F07	t-brake set	0 to 5024	msec	rw	rw	rw	
1100	1600	8	F08	brake	0 to 1		-	-	rw	
1100	1600	10	F10	relay 1-function	0 to 2		rw	rw	rw	
1100	1600	19	F19	quick stop end	0 to 1		rw	rw	rw	
1100	1600	20	F20	AE2-function	0 to 14		-	rw	rw	
1100	1600	21	F21	AE2-offset	-8192 to 8191	8192 = 100%	-	rw	rw	
1100	1600	22	F22	AE2-gain	-32768 to 32767	8192 = 100%	-	rw	rw	
1100	1600	23	F23	AE2-lowpass	0 to 10000	msec	-	rw	rw	
1100	1600	24	F24	AE2-offset2	-32768 to 32767	8192 = 100%	-	rw	rw	
1100	1600	25	F25	AE1-function	0 to 14		rw	rw	rw	
1100	1600	26	F26	AE1-offset	-32768 to 32767	8192 = 100%	rw	rw	rw	
1100	1600	27	F27	AE1-gain	-32768 to 32767	8192 = 100%	rw	rw	rw	
1100	1600	30	F30	BE-logic	0 to 1		rw	rw	rw	
1100	1600	31	F31	BE1-function	0 to 32		rw	rw	rw	
1100	1600	32	F32	BE2-function	0 to 32		rw	rw	rw	
1100	1600	33	F33	BE3-function	0 to 32		rw	rw	rw	
1100	1600	34	F34	BE4-function	0 to 32		rw	rw	rw	
1100	1600	35	F35	BE5-function	0 to 32		rw	rw	rw	
1100	1600	36	F36	BE-increments	30 to 4096	l/r	rw	rw	rw	
1100	1600	37	F37	fmax frequency-ref.value	30 to 512	0.1 kHz	rw	rw	-	

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU(s) Pset 1/2	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round- ing
						FAS	FDS	SDS	
1100	1600	38	F38	quick stop	0 to 2	rw	rw	rw	
1100	1600	40	F40	analog-output1-function	0 to 11	-	rw	rw	
1100	1600	41	F41	analog-output1-offset	-819 to 819	8192 = 100%	-	rw	rw
1100	1600	42	F42	analog-output1-gain	-32768 to 32767	8192 = 100%	-	rw	rw
1100	1600	43	F43	analog-output1-absolut	0 to 1	-	rw	rw	
1100	1600	45	F45	analog-output2-function	0 to 8	8192 = 100%	-	-	rw
1100	1600	46	F46	analog-output2-offset	-819 to 819	8192 = 100%	-	-	rw
1100	1600	47	F47	analog-output2-gain	-32768 to 32767	8192 = 100%	-	-	rw
1100	1600	49	F49	BE-gear ratio	0 to 32767	0.001	-	rw	rw
1100	1600	51	F51	BE1-invert	0 to 1	rw	rw	rw	
1100	1600	52	F52	BE2-invert	0 to 1	rw	rw	rw	
1100	1600	53	F53	BE3-invert	0 to 1	rw	rw	rw	
1100	1600	54	F54	BE4-invert	0 to 1	rw	rw	rw	
1100	1600	55	F55	BE5-invert	0 to 1	rw	rw	rw	
1100	1600	60	F60	BE6-function	0 to 32	-	rw	rw	
1100	1600	61	F61	BE7-function	0 to 32	-	rw	rw	
1100	1600	62	F62	BE8-function	0 to 32	-	rw	rw	
1100	1600	63	F63	BE9-function	0 to 32	-	rw	rw	
1100	1600	64	F64	BE10-function	0 to 32	-	rw	rw	
1100	1600	65	F65	BE11-function	0 to 32	-	rw	rw	
1100	1600	66	F66	BE12-function	0 to 32	-	rw	rw	
1100	1600	67	F67	BE13-function	0 to 32	-	rw	rw	
1100	1600	68	F68	BE14-function	0 to 32	-	rw	rw	
1100	1600	70	F70	BE6-invert	0 to 1	-	rw	rw	
1100	1600	71	F71	BE7-invert	0 to 1	-	rw	rw	
1100	1600	72	F72	BE8-invert	0 to 1	-	rw	rw	
1100	1600	73	F73	BE9-invert	0 to 1	-	rw	rw	
1100	1600	74	F74	BE10-invert	0 to 1	-	rw	rw	
1100	1600	75	F75	BE11-invert	0 to 1	-	rw	rw	
1100	1600	76	F76	BE12-invert	0 to 1	-	rw	rw	
1100	1600	77	F77	BE13-invert	0 to 1	-	rw	rw	
1100	1600	78	F78	BE14-invert	0 to 1	-	rw	rw	
1100	1600	80	F80	BA1-function	1 to 32	-	rw	rw	
1100	1600	80	F81	Relay2-function	0 to 32	rw	rw	-	
1100	1600	81	F81	BA2-function	0 to 32	-	-	rw	
1100	1600	82	F82	BA3-function	1 to 32	-	rw	rw	
1100	1600	83	F83	BA4-function	1 to 32	-	rw	rw	
1100	1600	84	F84	BA5-function	1 to 32	-	rw	rw	
1100	1600	85	F85	BA6-function	1 to 32	-	-	rw	
1100	1600	86	F86	BA7-function	1 to 32	-	-	rw	

PNU(s) Pset 1/2	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round- ing
						FAS	FDS	SDS	
1120	1620	0	G00	PID-controller	0 to 1	-	rw	rw	
1120	1620	1	G01	PID-controller Kp	0 to 1000	0.1	-	rw	rw
1120	1620	2	G02	PID-controller Ki	0 to 1000	0.01	-	rw	rw
1120	1620	3	G03	PID-controller Kd	0 to 1000	1msec	-	rw	rw
1120	1620	4	G04	PID-controller limit	-32768 to 32767	8192 = 100%	-	rw	rw
1120	1620	5	G05	PID-controller limit2	-32768 to 32767	8192 = 100%	-	rw	rw
1120	1620	6	G06	PID-controller Kp2	0 to 1000	0.01	-	rw	rw
1120	1620	10	G10	winding operation	0 to 2	-	rw	rw	
1120	1620	11	G11	diameter	0 to 2	-	rw	rw	
1120	1620	12	G12	min.winding diameter	10 to 3000	mm	-	rw	rw
1120	1620	13	G13	max.winding diameter	10 to 3000	mm	-	rw	rw
1120	1620	14	G14	begin.winding diameter	10 to 3000	mm	-	rw	rw
1120	1620	15	G15	overdrive ref.value	FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	-	rw	rw
1120	1620	16	G16	diam.calculator ramp	0 to 32767	0.01 mm/sec	-	rw	rw
1120	1620	17	G17	tension reduction	0 to 100	%	-	rw	rw

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU(s) Pset 1/2		Sub-index	Coor- dinate	Name	Value range	Scaling / measure unit	Access			Round- ing
							FAS	FDS	SDS	
1120	1620	19	G19	actual winding diameter	0 to 3000	mm	-	r	r	
1120	1620	20	G20	electronic gear	0 to 3		-	rw	rw	
1120	1620	21	G21	speed master	1 to 2147483647		-	rw	rw	
1120	1620	22	G22	speed slave	1 to 2147483647		-	rw	rw	
1120	1620	23	G23	Kp synchron	0 to 100	1 / sec	-	rw	rw	
1120	1620	24	G24	max.synchron difference	0 to 30000	°	-	rw	rw	
1120	1620	25	G25	synchron reset	0 to 3		-	rw	rw	
1120	1620	26	G26	n-correction-Max.	FDS: 0 to 12000 SDS: 0 to 6000	rpm ¹	-	rw	rw	
1120	1620	27	G27	synchronous encoder	FDS: 0 to 1 SDS: 0 to 2		-	rw	rw	
1120	1620	28	G28	n-Master	FDS: -12000 to 12000 SDS: -6000 to 6000	rpm ¹	-	r	r	
1120	1620	29	G29	synchron difference	2147483648 to -2147483647	°	-	r	r	-4
1120	1620	30	G30	speed feed forward	0 to 100	%	-	rw	rw	
1120	1620	31	G31	reference direction	0 to 1		-	rw	rw	
1120	1620	32	G32	reference speed fast	0 to 12000	rpm ¹	-	rw	rw	
1120	1620	33	G33	reference speed slow	0 to 12000	rpm ¹	-	rw	rw	
1120	1620	35	G35	ref.encoder signal 0	0 to 1		-	rw	rw	
1120	1620	38	G38	synchronous offset	-2147483648 to 2147483647	0.1 °	-	rw	rw	
1120	1620	40	G40	static friction torque	0 to 32767	0.01 Nm	-	rw	rw	
1120	1620	41	G41	dynamic friction torque	0 to 32767	0.01 Nm	-	rw	rw	
1120	1620	42	G42	T-dyn lowpass	0 to 10000	msec	-	rw	rw	

PNU(s) Pset 1/2		Sub-index	Coor- dinate	Name	Value range	Scaling / measure unit	Access			Round- ing
							FAS	FDS	SDS	
1140	1640	20	H20	X20-function	FDS: 0 to 5 SDS: 0 to 4		-	rw	rw	
1140	1640	21	H21	encodersim. increments	0 to 4		-	rw	rw	
1140	1640	22	H22	X20-increments	30 to 4096		-	rw	rw	
1140	1640	23	H23	X20-gear ratio	0 to 32767	0.001	-	rw	rw	
1140	1640	24	H24	X20-zeroPos.	0 to 3600	0.1°	-	rw	rw	
1140	1640	31	H31	resolver poles	2, 4, to 16		-	-	rw	
1140	1640	32	H32	commutation-offset	0 to 3600	0.1 ° elec.	-	-	rw	
1140	1640	40	H40	X41-function	0 to 3		-	-	rw	
1140	1640	41	H41	X41-increments	30 to 4096		-	-	rw	
1140	1640	42	H42	X41-gear ratio	0 to 32767	0.001	-	-	rw	
1140	1640	60	H60	SSI-invert	0 to 1		-	rw	rw	
1140	1640	61	H61	SSI-coding	0 to 1		-	rw	rw	
1140	1640	62	H62	SSI-data bits	24 to 25		-	rw	rw	

PNU	Sub-index		Coor- dinate	Name	Value range	Scaling / measure unit	Access			Round- ing
							FAS	FDS	SDS	
1160	0		I00	position range	0 to 1		rw	rw	rw	
1160	1		I01	circular length	0 to 2147483647	I05 * 10 ^ I06	rw	rw	rw	
1160	2		I02	posi.encoder	FDS: 0 to 2 SDS: 0 to 3		-	rw	rw	
1160	3		I03	direction optimization	0 to 1		rw	rw	rw	
1160	4		I04	move direction	0 to 2		rw	rw	rw	
1160	5		I05	measure unit selection	0 to 4		rw	rw	rw	
1160	6		I06	decimal digits	0 to 3		rw	rw	rw	
1160	7		I07	way/revolution numerator	1 to 2147483647	I05 * 10^{I06}	rw	rw	rw	
1160	8		I08	way/revolution denomin.	1 to 2147483647	I05 * 10^{I06}	rw	rw	rw	
1160	9		I09	measurement unit	xxxx		rw	rw	rw	
1160	10		I10	max.speed	0 to 2147483647	I05/sec * 10^{I06}	rw	rw	rw	
1160	11		I11	max.acceleration	0 to 2147483647	I05/sec² * 10^{I06}	rw	rw	rw	
1160	12		I12	tip speed	0 to 2147483647	I05/sec * 10^{I06}	rw	rw	rw	

¹ rpm: For FAS / FDS: Limit value is dependant to the number of poles.

Profibus-DP link

14. Parameter list

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1160	15	I15	accel-override	0 to 1		rW	rW	rW	
1160	16	I16	S-ramp	0 to 32767	msec	rW	rW	rW	
1160	16	I19	ENA-interrupting	0 to 1		rW	rW	rW	
1160	20	I20	Kv-factor	0 to 100		rW	rW	rW	
1160	21	I21	max.following error	0 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	22	I22	target window	0 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	23	I23	dead band pos. control.	0 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	25	I25	speed feed forward	0 to 8192	8192 = 100%	rW	rW	rW	
1160	30	I30	reference mode	0 to 4		rW	rW	rW	
1160	31	I31	reference direction	0 to 1		rW	rW	rW	
1160	32	I32	reference speed fast	0 to 2147483647	$105/\text{sec} * 10^{106}$	rW	rW	rW	
1160	33	I33	reference speed slow	0 to 2147483647	$105/\text{sec} * 10^{106}$	rW	rW	rW	
1160	34	I34	reference position	-2147483647 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	35	I35	ref.encoder signal 0	0 to 1		rW	rW	rW	
1160	36	I36	continuous reference	0 to 1		rW	rW	rW	
1160	37	I37	power-on reference	0 to 2		rW	rW	rW	
1160	38	I38	reference block	FAS/FDS: 0 to 8 SDS: 0 to 32		rW	rW	rW	
1160	40	I40	posi.-step memory	0 to 1		rW	rW	rW	
1160	50	I50	software-stop -	-2147483647 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	51	I51	software-stop +	-2147483647 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	60	I60	electronic cam 1 begin	-2147483647 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	61	I61	electronic cam 1 end	-2147483647 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	70	I70	position-offset	0 to 2147483647	$105 * 10^{106}$	rW	rW	rW	
1160	80	I80	actual position	-2147483647 to 2147483647	$105 * 10^{106}$	r	r	r	-2
1160	81	I81	target position	-2147483647 to 2147483647	$105 * 10^{106}$	r	r	r	-2
1160	82	I82	active process block	FAS/FDS: 0 to 8 SDS: 0 to 32		r	r	r	
1160	83	I83	selected process block	FAS/FDS: 0 to 8 SDS: 0 to 32		r	r	r	
1160	84	I84	following error	-2147483647 to 2147483647	$105 * 10^{106}$	r	r	r	-2
1160	85	I85	in position	0 to 1		r	r	r	
1160	86	I86	referenced	0 to 1		r	r	r	
1160	87	I87	electronic cam 1	0 to 1		r	r	r	
1160	88	I88	speed	-2147483647 to 2147483647	$105/\text{sec} * 10^{106}$	r	r	r	-2
1160	90	I90	switchmemory 1	0 to 1		r	r	r	
1160	91	I91	switchmemory 2	0 to 1		r	r	r	
1160	92	I92	switchmemory 3	0 to 1		r	r	r	

The **POSIDYN**® SDS 4000 servo inverter supports 32 process blocks. The frequency inverter series **POSIDRIVE**® FAS 4000 and **POSIDRIVE**® FDS 4000 supports eight process blocks.

All devices have the same parameters and the same access to these parameters for these first eight process blocks. (These parameters are accessed via PNU 1180 with subindex 10 to 88 for **J10** to **J88** and via PNU 1220 with subindex 10 to 80 for **L10** to **L80**.) Here you will notice that there is an easy-to-remember relationship between the menu coordinates on the device and the values for the subindex.

In addition, there is another type of addressing for all 32 process blocks of the SDS. The process block number is used as the subindex, and each element of a process block has one of the parameter numbers 10 to 20.

List of the **J..** parameters which are not assigned to any process block:

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1180	0	J00	posi.start	0 to 1 (set 1 for start)		rS	rS	rS	
1181	0	J00	result posi.start	0 to 21		r	r	r	
1180	1	J01	posi.step	0 to 1 (set 1 for start)		rS	rS	rS	
1181	0	J01	result posi step	0 to 21		r	r	r	
1180	2	J02	process block number	0 to 8		rW	rW	rW	
1180	4	J04	teach-in	0 to 1 (set 1 for start)		rS	rS	rS	
1181	4	J04	result teach-in	0 to 21		r	r	r	
1180	5	J05	start reference	0 to 1 (set 1 for start)		rS	rS	rS	
1181	5	J05	result start reference	0 to 21		r	r	r	

Profibus-DP link

14. Parameter list

List of the **J..** parameters for the first eight process blocks organized by FAS/FDS-compatible type of addressing:

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1180	10	J10	position	-2147483647 to 2147483647	I05 * 10 ¹⁰⁶	rw	rw	rw	
1180	11	J11	position mode	0 to 3		rw	rw	rw	
1180	12	J12	speed	0 to 2147483647	I05 / sec * 10 ¹⁰⁶	rw	rw	rw	
1180	13	J13	accel	0 to 2147483647	I05 / sec ² * 10 ¹⁰⁶	rw	rw	rw	
1180	14	J14	decel	0 to 2147483647	I05 / sec ² * 10 ¹⁰⁶	rw	rw	rw	
1180	15	J15	repeat number	0 to 254		rw	rw	rw	
1180	16	J16	next block	FAS/FDS: 0 to 8 SDS: 0 to 32		rw	rw	rw	
1180	17	J17	next start	0 to 4		rw	rw	rw	
1180	18	J18	delay	0 to 65535	msec	rw	rw	rw	
1180	20 ... 28	J20 ... J28	position ... delay	see process block 1		rw	rw	rw	
1180	30 ... 38	J30 ... J38	position ... delay	see process block 1		rw	rw	rw	
1180	40 ... 48	J40 ... J48	position ... delay	see process block 1		rw	rw	rw	
1180	50 ... 58	J50 ... J58	position ... delay	see process block 1		rw	rw	rw	
1180	60 ... 68	J60 ... J68	position ... delay	see process block 1		rw	rw	rw	
1180	70 ... 78	J70 ... J78	position ... delay	see process block 1		rw	rw	rw	
1180	80 ... 88	J80 ... J88	position ... delay	see process block 1		rw	rw	rw	

List of the parameters of all 32 process blocks organized by the new type of addressing (**only for SDS**):

PNU	Subindex = no. of the process block	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
10	1, 2,, 31, 32	Jxx0	position	-2147483647 to 2147483647	I05 * 10 ¹⁰⁶	-	-	rw
11	1, 2,, 31, 32	Jxx1	position mode	0 to 3		-	-	rw
12	1, 2,, 31, 32	Jxx2	speed	0 to 2147483647	I05 / sec * 10 ¹⁰⁶	-	-	rw
13	1, 2,, 31, 32	Jxx3	accel	0 to 2147483647	I05 / sec ² * 10 ¹⁰⁶	-	-	rw
14	1, 2,, 31, 32	Jxx4	decel	0 to 2147483647	I05 / sec ² * 10 ¹⁰⁶	-	-	rw
15	1, 2,, 31, 32	Jxx5	repeat number	0 to 254		-	-	rw
16	1, 2,, 31, 32	Jxx6	next block	0 to 32		-	-	rw
17	1, 2,, 31, 32	Jxx7	next start	0 to 4		-	-	rw
18	1, 2,, 31, 32	Jxx8	delay	0 to 65535	msec	-	-	rw
20	1, 2,, 31, 32	Lxx0	brake	0 to 1		-	-	rw
21	1, 2,, 31, 32	Lxx1	switch A	0 to 4		-	-	rw
22	1, 2,, 31, 32	Lxx2	switch B	0 to 4		-	-	rw

The parameters of the **K..** group are commentary texts which are only visible in the FDS-Tool. With FDS Tool, commentary texts can be entered, saved and printed to provide extra information on a configuration. Parameters **K00** to **K03** (PNU 1200 to 1203) have default values and can be overwritten if necessary. Together they represent the configuration information (name of the clerk, file name and date of the FDS file). The parameter **K00** (P-user) can be changed via fieldbus.

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1200	0	K00	P-user B0-3	" VOR"		rw	rw	rw	
1201	0	K00	P-user B4-7	"NAME"		rw	rw	rw	
1202	0	K00	P-user B8-11	"und"		rw	rw	rw	
1203	0	K00	P-user B12-15	"NAME"		rw	rw	rw	
1200	1	K01	P-Date B0-3	"24.0"		rw	rw	rw	
1201	1	K01	P-Date B4-7	"2.20"		rw	rw	rw	
1202	1	K01	P-Date B8-11	"00 "		rw	rw	rw	
1203	1	K01	P-Date B12-15	" "		rw	rw	rw	
1200	2	K02	P-filename B0-3	"TEST"		rw	rw	rw	
1201	2	K02	P- filename B4-7	"1234"		rw	rw	rw	
1202	2	K02	P- filename B8-11	".FDS"		rw	rw	rw	
1203	2	K02	P- filename B12-15	" "		rw	rw	rw	

Profibus-DP link

14. Parameter list

List of the L... parameters for the first eight process blocks organized by FDS-compatible type of addressing:

PNU	sub-index	coordinate	name	value range	scaling / measure unit	access			Round- ing
						FAS	FDS	SDS	
1220	10	L10	brake	0 to 1		rw	rw	rw	
1220	11	L11	switch A	0 to 4		rw	rw	rw	
1220	12	L12	switch B	0 to 4		rw	rw	rw	
1220	20	L20	brake	0 to 1		rw	rw	rw	
1220	21	L21	switch A	0 to 4		rw	rw	rw	
1220	22	L22	switch B	0 to 4		rw	rw	rw	
1220	30	L30	brake	0 to 1		rw	rw	rw	
1220	31	L31	switch A	0 to 4		rw	rw	rw	
1220	32	L32	switch B	0 to 4		rw	rw	rw	
1220	40	L40	brake	0 to 1		rw	rw	rw	
1220	41	L41	switch A	0 to 4		rw	rw	rw	
1220	42	L42	switch B	0 to 4		rw	rw	rw	
1220	50	L50	brake	0 to 1		rw	rw	rw	
1220	51	L51	switch A	0 to 4		rw	rw	rw	
1220	52	L52	switch B	0 to 4		rw	rw	rw	
1220	60	L60	brake	0 to 1		rw	rw	rw	
1220	61	L61	switch A	0 to 4		rw	rw	rw	
1220	62	L62	switch B	0 to 4		rw	rw	rw	
1220	70	L70	brake	0 to 1		rw	rw	rw	
1220	71	L71	switch A	0 to 4		rw	rw	rw	
1220	72	L72	switch B	0 to 4		rw	rw	rw	
1220	80	L80	brake	0 to 1		rw	rw	rw	
1220	81	L81	switch A	0 to 4		rw	rw	rw	
1220	82	L82	switch B	0 to 4		rw	rw	rw	

PNU	sub-index	coordinate	name	value range	scaling / measure unit	access			Round- ing
						FAS	FDS	SDS	
1240	50	M50	F1-jump to	0 to 0x1A63	1. byte 1=group A, ... 2. byte 00..99 numbers in group	rw	rw	rw	
1240	51	M51	F1-lower limit	-2147483647 to 2147483647	scaling	rw	rw	rw	
1240	52	M52	F1-upper limit	-2147483647 to 2147483647	see parameter	rw	rw	rw	
1240	60	M60	F2-jump to	0 to 0x1A63	s. M50	rw	rw	rw	
1240	61	M61	F2-lower limit	-2147483647 to 2147483647	scaling	rw	rw	rw	
1240	62	M62	F2-upper limit	-2147483647 to 2147483647	see parameter	rw	rw	rw	
1240	70	M70	F3-jump to	0 to 0x1A63	s. M50	rw	rw	rw	
1240	71	M71	F3-lower limit	-2147483647 to 2147483647	scaling	rw	rw	rw	
1240	72	M72	F3-upper limit	-2147483647 to 2147483647	see parameter	rw	rw	rw	
1240	80	M80	F4-jump to	0 to 0x1A63	s. M50	rw	rw	rw	
1240	81	M81	F4-lower limit	-2147483647 to 2147483647	scaling	rw	rw	rw	
1240	82	M82	F4-upper limit	-2147483647 to 2147483647	see parameter	rw	rw	rw	

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round- ing
						FAS	FDS	SDS	
1260	10	N10	s1-position	-2147483647 ... 2147483647	I05 * 10 ¹⁰⁶	rw	rw	rw	
1260	11	N11	s1-method	0 to 2		rw	rw	rw	
1260	12	N12	s1-memory1	0 to 3		rw	rw	rw	
1260	13	N13	s1-memory2	0 to 3		rw	rw	rw	
1260	14	N14	s1-memory3	0 to 3		rw	rw	rw	
1260	20	N20	s2-position	-2147483647 to 2147483647	I05 * 10 ¹⁰⁶	rw	rw	rw	
1260	21	N21	s2-method	0 to 2		rw	rw	rw	
1260	22	N22	s2-memory1	0 to 3		rw	rw	rw	
1260	23	N23	s2-memory2	0 to 3		rw	rw	rw	
1260	24	N24	s2-memory3	0 to 3		rw	rw	rw	
1260	30	N30	s3-position	-2147483647 to 2147483647	I05 * 10 ¹⁰⁶	rw	rw	rw	
1260	31	N31	s3-method	0 to 2		rw	rw	rw	
1260	32	N32	s3-memory1	0 to 3		rw	rw	rw	

Profibus-DP link

14. Parameter list

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1260	33	N33	s3-memory2	0 to 3		rw	rw	rw	
1260	34	N34	s3-memory3	0 to 3		rw	rw	rw	
1260	40	N40	s4-position	-2147483647 to 2147483647	105 * 10 ¹⁰⁶	rw	rw	rw	
1260	41	N41	s4-method	0 to 2		rw	rw	rw	
1260	42	N42	s4-memory1	0 to 3		rw	rw	rw	
1260	43	N43	s4-memory2	0 to 3		rw	rw	rw	
1260	44	N44	s4-memory3	0 to 3		rw	rw	rw	

The parameters of the **U..** group are also not visible in the menu of the inverter. They can only be specified via fieldbus and by FDS Tool:

Reactions of the inverter to events can be manipulated by the **U..** parameters.

0: *Off*; No reaction to the event

1: *Message*; The event is indicated in plain text (see Ux2 text) on Controlbox or on the display of the FDS.

2: *Warning*; When it occurs, the event is indicated as under "1:Message." After a tolerance time expires (Ux1), the inverter assumes malfunction status.

3: *Fault*; When it occurs, the event is indicated as under "1:Message." The inverter immediately assumes malfunction status.

PNU(s) Pset 1/2	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1400	-	0	U00	level low voltage	2 to 3	rw	rw	rw	
1400	-	1	U01	time low voltage	1 to 10	rw	rw	rw	
1400	-	2	U02	level low voltage device i2t	0 to 3	-	-	rw	
1400	-	3	U03	time low voltage device i2t	1 to 120	-	-	rw	
1400	1900	10	U10	level temp.limit mot.i2t	0 to 2	rw	rw	rw	
1400	1900	11	U11	time temp.limit mot.i2t	1 to 120	rw	rw	rw	
1400	1900	20	U20	level drive overload	0 to 3	rw	rw	rw	
1400	1900	21	U21	time drive overload	1 to 120	rw	rw	rw	
1400	1900	22	U22	text drive overload	xxxx	rw	rw	rw	
1400	1900	30	U30	level accelerat.overload	0 to 3	rw	rw	rw	
1400	1900	31	U31	time accelerat.overload	1 to 10	rw	rw	rw	
1400	1900	32	U32	text accelerat.overload	xxxx	rw	rw	rw	
1400	1900	40	U40	level break overload	0 to 3	rw	rw	rw	
1400	1900	41	U41	time break overload	1 to 10	rw	rw	rw	
1400	1900	42	U42	text break overload	xxxx	rw	rw	rw	
1400	1900	50	U50	level operating range	0 to 3	rw	rw	rw	
1400	1900	51	U51	time operating range	1 to 120	rw	rw	rw	
1400	1900	52	U52	text operating range	xxxx	rw	rw	rw	
1400	1900	60	U60	level following error	0 to 3	rw	rw	rw	
1400	1900	61	U61	time following error	0 to 32767	rw	rw	rw	
1400	1900	70	U70	level posi.refused	0 to 3	rw	rw	rw	

The indications for the number of faults are located in group **Z..** as with FDS Tool. They can be viewed in the menu of the inverter with **E42**.

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round-ing
						FAS	FDS	SDS	
1500	31	Z31	short circuit/to ground	0 to 65535		r	r	r	
1500	32	Z32	short circ./toGround int	0 to 65535		r	r	r	
1500	33	Z33	overcurrent	0 to 65535		r	r	r	
1500	34	Z34	hardware fault	0 to 65535		r	r	r	
1500	35	Z35	watchdog	0 to 65535		r	r	r	
1500	36	Z36	high voltage	0 to 65535		r	r	r	
1500	37	Z37	n-feedback	0 to 65535		r	r	r	
1500	38	Z38	temp.limit device sensor	0 to 65535		r	r	r	
1500	39	Z39	temp.limit device i2t	0 to 65535		r	r	r	
1500	40	Z40	invalid data	0 to 65535		r	r	r	
1500	41	Z41	temp.limit motor TMP	0 to 65535		r	r	r	
1500	42	Z42	temp.limit motor resist.	0 to 65535		r	r	r	
1500	43	Z43	line break ref.value	0 to 65535		r	r	r	
1500	44	Z44	extern fault	0 to 65535		r	r	r	
1500	45	Z45	temp.limit motor i2t	0 to 65535		r	r	r	
1500	46	Z46	low voltage	0 to 65535		r	r	r	
1500	47	Z47	drive overload	0 to 65535		r	r	r	

Profibus-DP link

14. Parameter list

PNU	Sub-index	Coordinate	Name	Value range	Scaling / measure unit	Access			Round- ing
						FAS	FDS	SDS	
1500	48	Z48	acceleration overload	0 to 65535		r	r	r	
1500	49	Z49	deceleration overload	0 to 65535		r	r	r	
1500	50	Z50	operating range	0 to 65535		r	r	r	
1500	51	Z51	posi.refused	0 to 65535		r	r	r	
1500	52	Z52	communication	0 to 65535		r	r	r	
1500	53	Z53	stop input	0 to 65535		r	r	r	
1500	54	Z54	following error	0 to 65535		r	r	r	
1500	55	Z55	option-board	0 to 65535		r	r	r	
1500	56	Z56	overspeed	0 to 65535		-	-	r	

[illegible]



STÖBER ANTRIEBSTECHNIK
GmbH + Co. KG

GERMANY
Kieselbronner Strasse 12 · 75177 Pforzheim
Postfach 910103 · 75091 Pforzheim
Fon +49 (0) 7231 582-0, Fax +49 (0) 7231 582-1000
Internet: <http://www.stoeber.de> / e-Mail: mail@stoeber.de

Überreicht durch: