Overview

This documentation applies to replacement parts that are approved for use with STOBER products and were purchased through the STOBER service.

This product may pose dangers that can be avoided by following the safety information below, as well as general technical rules and regulations. Replacement parts may only be replaced if the user has read and understood the safety information in this documentation, as well as the corresponding operating manual for the relevant STOBER product.

Qualified personnel

In order to be able to perform the tasks described in this documentation, the persons instructed to perform them must have the appropriate professional qualification and be able to assess the risks and residual hazards when handling the products. For this reason, all work on the products as well as their operation and disposal may be performed only by professionally qualified personnel.

Qualified personnel are persons who have acquired the authorization to perform these activities either through training to become a specialist and/or instruction by specialists.

Furthermore, valid regulations, legal requirements, applicable basic rules, this documentation and the safety notes included in it must be carefully read, understood and observed.

Working on the machine

Before all work on machines and systems, apply the 5 safety rules in accordance with DIN VDE 0105-100 (Operation of electrical installations – Part 100: General requirements) in the order listed:

- Disconnect (also ensure that the auxiliary circuits are disconnected).
- Ensure power cannot be switched on again.
- Ensure that everything is de-energized.
- Ground and short-circuit.
- Cover adjacent live parts.

Information

Note the discharge time of the DC link capacitors in the general technical data for the devices. You can only determine the absence of voltage after this time period.

Further information

For more information on removal, installation, and commissioning of your STOBER gearbox or motor, please refer to the respective operating manual. The current status of the documentation can be found in our download center at:
http://www.stoeber.de/en/downloads/.

11/2026 | ID 443554_en.00

STÖBER Antriebstechnik GmbH + Co. KG
Kieselbronner Str. 12 · 75177 Pforzheim · Germany · Tel. +49 7231 582-0 · mail@stoeber.de · www.stober.com